

# Bugatti Function List V18.0

Notes:	
√	Functions is fully supported and already existed in former software version.
※	Functions is fully supported and newly added in current software version.
Number	Index number of the special function , you can find the name from the special function table.
	Functions is not supported.

Index	Specil Function Name	Index	Specil Function Name
0001	Coding	0002	Basic Settings
0003	Adaptation	0004	Security Access
0005	Show advanced recognition		

Control unit	Ecu Info.	Read Codes	Erase Codes	Live data	Freeze Frame	Active Test	Special Function
03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005
01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005
02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005
04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005
05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005
06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005
07-Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005
08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005
09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005
0A-Alternative Fuel Engine	√	√	√	√	※	※	0001 0002 0003 0004 0005
0B-Auxiliary Air Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005
0C-Rear Axle Steering 2	√	√	√	√	※	※	0001 0002 0003 0004 0005
0D-Sliding Door Left	√	√	√	√	※	※	0001 0002 0003 0004 0005
0E-Media Player Position 1	√	√	√	√	※	※	0001 0002 0003 0004 0005
0F-Radio Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005
10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005
11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005
12-Clutch Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005
13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005
14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005
15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005
16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005
17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005
18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005
19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005
1A-Fuel Cell Engine	√	√	√	√	※	※	0001 0002 0003 0004 0005
1B-Active Steering	√	√	√	√	※	※	0001 0002 0003 0004 0005
1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005

1D-Driver Identification	√	√	√	√	※	※	0001 0002 0003 0004 0005
1E-Media Player Position 2	√	√	√	√	※	※	0001 0002 0003 0004 0005
1F-Radio Tuner - Satellite	√	√	√	√	※	※	0001 0002 0003 0004 0005
20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005
21-Battery Energy Control Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005
22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005
23-Brake Boost	√	√	√	√	※	※	0001 0002 0003 0004 0005
24-Anti Slip Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005
25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005
26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005
27-Display Control Unit Rear	√	√	√	√	※	※	0001 0002 0003 0004 0005
28-Climate Control Unit Rear	√	√	√	√	※	※	0001 0002 0003 0004 0005
29-Light Control Left	√	√	√	√	※	※	0001 0002 0003 0004 0005
2A-Control Unit Wireless Charging	√	√	√	√	※	※	0001 0002 0003 0004 0005
2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005
2C-Seat Allocation Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005
2D-Voice Amplifier	√	√	√	√	※	※	0001 0002 0003 0004 0005
2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005
2F-TV Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005
30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005
31-Engine Electronics Group	√	√	√	√	※	※	0001 0002 0003 0004 0005
32-Lock Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005
33-All OBD Systems	√	√	√	√	※	※	0001 0002 0003 0004 0005
34-Ride Control System	√	√	√	√	※	※	0001 0002 0003 0004 0005
35-Central Locking Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005
36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005
37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005
38-Roof Electronic Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005
39-Light Control Right	√	√	√	√	※	※	0001 0002 0003 0004 0005
3A-Special Vehicle Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005
3B-Sensor Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005
3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005
3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005
3E-Media Player Position 4	√	√	√	√	※	※	0001 0002 0003 0004 0005
3F-Dynamic Assembly Mounting	√	√	√	√	※	※	0001 0002 0003 0004 0005
40-Air Conditioning Compressor	√	√	√	√	※	※	0001 0002 0003 0004 0005
41-Diesel Pump Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005
42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005
43-Brake Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005
44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005
45-Interior Monitoring	√	√	√	√	※	※	0001 0002 0003 0004 0005
46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005
47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005
48-Seat Adjustment Rear Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005
49-Automatic Light Switch	√	√	√	√	※	※	0001 0002 0003 0004 0005

4A-Rear Light	√	√	√	√	※	※	0001 0002 0003 0004 0005
4B-Multifunction Module	√	√	√	√	※	※	0001 0002 0003 0004 0005
4C-Tire Pressure Monitoring 2	√	√	√	√	※	※	0001 0002 0003 0004 0005
4D-Data Transmission	√	√	√	√	※	※	0001 0002 0003 0004 0005
4E-Control Head Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005
4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005
50-Seat Adjustment 3rd Row	√	√	√	√	※	※	0001 0002 0003 0004 0005
51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005
52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005
53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005
54-Rear Spoiler	√	√	√	√	※	※	0001 0002 0003 0004 0005
55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005
56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005
57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005
58-Fuel Supply	√	√	√	√	※	※	0001 0002 0003 0004 0005
59-Towing Protection	√	√	√	√	※	※	0001 0002 0003 0004 0005
5A-Longitudinal Control	√	√	√	√	※	※	0001 0002 0003 0004 0005
5B-Seat Adjustment Rear Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005
5C-Lane Departure Warning System	√	√	√	√	※	※	0001 0002 0003 0004 0005
5D-Operation	√	√	√	√	※	※	0001 0002 0003 0004 0005
5E-Control Head Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005
5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005
60-Tachograph	√	√	√	√	※	※	0001 0002 0003 0004 0005
61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005
62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005
63-Entry Assistance Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005
64-Stabilizers	√	√	√	√	※	※	0001 0002 0003 0004 0005
65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005
66-Seat Adjustment Rear	√	√	√	√	※	※	0001 0002 0003 0004 0005
67-Voice Control	√	√	√	√	※	※	0001 0002 0003 0004 0005
68-Wiper Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005
69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005
6B-Aerodynamics Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005
6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005
6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005
6E-Display Control Roof	√	√	√	√	※	※	0001 0002 0003 0004 0005
6F-Central Module Comfort System 2	√	√	√	√	※	※	0001 0002 0003 0004 0005
71-Battery Charger	√	√	√	√	※	※	0001 0002 0003 0004 0005
72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005
73-Entry Assistance Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005
74-Chassis Control	√	√	√	√	※	※	0001 0002 0003 0004 0005
75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005
76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005
77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005
78-Sliding Door Right	√	√	√	√	※	※	0001 0002 0003 0004 0005

7B-Subbus Systems Interface	√	√	√	√	※	※	0001 0002 0003 0004 0005
7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005
7E-Dash Board Display Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005
7F-Information Control Unit 2	√	√	√	√	※	※	0001 0002 0003 0004 0005
81-Gear Shift Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005
82-Head Up Display	√	√	√	√	※	※	0001 0002 0003 0004 0005
83-Front Observation Module	√	√	√	√	※	※	0001 0002 0003 0004 0005
84-Night Vision	√	√	√	√	※	※	0001 0002 0003 0004 0005
85-On-Board Camera	√	√	√	√	※	※	0001 0002 0003 0004 0005
88-Multi Contour Seat Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005
89-Multi Contour Seat Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005
8A-Multi Contour Seat Rear Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005
8B-Adaptive Cruise Control 2	√	√	√	√	※	※	0001 0002 0003 0004 0005
8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005
8D-Multi Contour Seat Rear Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005
8E-Image Processing Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005
8F-Pretensioner Front Left	√	√	√	√	※	※	0001 0002 0003 0004 0005
90-Pretensioner Front Right	√	√	√	√	※	※	0001 0002 0003 0004 0005
A4-Armrest	√	√	√	√	※	※	0001 0002 0003 0004 0005
A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005
A6-Microphone Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005
A7-Infotainment Interface	√	√	√	√	※	※	0001 0002 0003 0004 0005
A8-External Communication Interface	√	√	√	√	※	※	0001 0002 0003 0004 0005
A9-Actuator For Structure-Borne Sound	√	√	√	√	※	※	0001 0002 0003 0004 0005
AA-Wheel Brake Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005
AB-Wheel Brake Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005
AC-Reductant Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005
AD-Sensors Brake Systems	√	√	√	√	※	※	0001 0002 0003 0004 0005
B7-Access Startsystem Interface	√	√	√	√	※	※	0001 0002 0003 0004 0005
B8-Electronic Roof Control 2	√	√	√	√	※	※	0001 0002 0003 0004 0005
B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005
BA-Assembly Mounting	√	√	√	√	※	※	0001 0002 0003 0004 0005
BB-Door Electronics Rear Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005
BC-Door Electronics Rear Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005
BD-High Voltage Battery Charge Management	√	√	√	√	※	※	0001 0002 0003 0004 0005
BE-Sliding Door Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005
BF-Sliding Door Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005
C0-Actuator For Exterior Noise	√	√	√	√	※	※	0001 0002 0003 0004 0005
C2-Transmission Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005
C3-Drive Motor Control Module 3	√	√	√	√	※	※	0001 0002 0003 0004 0005
C4-DC/DC Converter Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005
C5-Thermal Management	√	√	√	√	※	※	0001 0002 0003 0004 0005
C6-Battery Charger Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005
C7-Pedestrian Protection	√	√	√	√	※	※	0001 0002 0003 0004 0005
C8-Auxiliary Display Control Unit 2	√	√	√	√	※	※	0001 0002 0003 0004 0005

C9-Rear Mirror	√	√	√	√	※	※	0001 0002 0003 0004 0005
CA-Control Module For Sunroof	√	√	√	√	※	※	0001 0002 0003 0004 0005
CB-Rear Axle Steering	√	√	√	√	※	※	0001 0002 0003 0004 0005
CC-Starter / Generator Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005
CD-Laser Scanner	√	√	√	√	※	※	0001 0002 0003 0004 0005
CE-Drive Motor Control Module2	√	√	√	√	※	※	0001 0002 0003 0004 0005
CF-Control Unit Lane Change Assistant 2	√	√	√	√	※	※	0001 0002 0003 0004 0005
D0-Front Axle Lift System	√	√	√	√	※	※	0001 0002 0003 0004 0005
D1-Center Display	√	√	√	√	※	※	0001 0002 0003 0004 0005
D4-Roll Control System 1	√	√	√	√	※	※	0001 0002 0003 0004 0005
D5-Roll Control System 2	√	√	√	√	※	※	0001 0002 0003 0004 0005
D6-Light Control Left 2	√	√	√	√	※	※	0001 0002 0003 0004 0005
D7-Light Control Right 2	√	√	√	√	※	※	0001 0002 0003 0004 0005
D8-Matrix Headlamp Powermodule Left	√	√	√	√	※	※	0001 0002 0003 0004 0005
D9-Matrix Headlamp Powermodule Right	√	√	√	√	※	※	0001 0002 0003 0004 0005
DB-Front Corner Radar 1	√	√	√	√	※	※	0001 0002 0003 0004 0005
DC-Front Corner Radar 2	√	√	√	√	※	※	0001 0002 0003 0004 0005
DD-Control Module 2 For Sunroof	√	√	√	√	※	※	0001 0002 0003 0004 0005
DE-Charger 1 Mobile Devices	√	√	√	√	※	※	0001 0002 0003 0004 0005
DF-Charger 2 Mobile Devices	√	√	√	√	※	※	0001 0002 0003 0004 0005