

Notes:

√	Functions is fully supported and already existed in former software version.
*	Functions is fully supported and newly added in current software version.
	Functions is not supported.

Brand	Model	Year Model	System	Ecu Info.	Read Codes	Erase Codes	Data List	Active Test	Utility
SCION	FR-S	Up to 2017	ABS/VSC/TRAC	√	√	√	√	√	√
SCION	FR-S	Up to 2017	Accessory Gateway	√	√	√	√	√	
SCION	FR-S	Up to 2017	Air Conditioner	√	√	√	√	√	√
SCION	FR-S	Up to 2017	Combination Meter	√	√	√	√	√	
SCION	FR-S	Up to 2017	Cruise Control	√	√	√	√		
SCION	FR-S	Up to 2017	D-Door Motor	√	√	√	√	√	
SCION	FR-S	Up to 2017	EMPS	√	√	√	√	√	√
SCION	FR-S	Up to 2017	Engine and ECT	√	√	√	√	√	√
SCION	FR-S	Up to 2017	Four Wheel Drive	√	√	√	√	√	√
SCION	FR-S	Up to 2017	Immobiliser	√	√	√	√	√	
SCION	FR-S	Up to 2017	Main Body	√	√	√	√	√	√
SCION	FR-S	Up to 2017	Occupant Detection	√	√	√	√	√	√
SCION	FR-S	Up to 2017	SRS Airbag	√	√	√	√	√	√
SCION	FR-S	Up to 2017	Sliding Roof	√	√	√	√	√	
SCION	FR-S	Up to 2017	Theft Deterrent	√	√	√	√	√	
SCION	FR-S	Up to 2017	Auto Leveling Module	√	√	√	√	√	
SCION	FR-S	Up to 2017	Connectivity Master Unit	√	√	√	√	√	
SCION	FR-S	Up to 2017	ECT	√	√	√	√	√	
SCION	FR-S	Up to 2017	EV	√	√	√	√	√	
SCION	FR-S	Up to 2017	EV Battery	√	√	√	√	√	
SCION	FR-S	Up to 2017	Electric Supply Unit	√	√	√	√	√	
SCION	FR-S	Up to 2017	Engine	√	√	√	√	√	
SCION	FR-S	Up to 2017	Instrument Cluster	√	√	√	√	√	
SCION	FR-S	Up to 2017	Master Switch	√	√	√	√		
SCION	FR-S	Up to 2017	Navigation System	√	√	√	√		
SCION	FR-S	Up to 2017	P-Door Motor	√	√	√	√	√	
SCION	FR-S	Up to 2017	PM1 Gateway	√	√	√	√		
SCION	FR-S	Up to 2017	Plug-in Control	√	√	√	√	√	
SCION	FR-S	Up to 2017	Power Source Control	√	√	√	√	√	
SCION	FR-S	Up to 2017	Powertrain Control Module	√	√	√	√	√	
SCION	FR-S	Up to 2017	Remote Engine Starter	√	√	√	√	√	
SCION	FR-S	Up to 2017	Restraint Control Module	√	√	√	√	√	
SCION	FR-S	Up to 2017	Sliding Roof	√	√	√	√	√	
SCION	FR-S	Up to 2017	Smart City Brake Support	√	√	√	√	√	
SCION	FR-S	Up to 2017	Smart Key	√	√	√	√	√	
SCION	FR-S	Up to 2017	Smart Start Unit	√	√	√	√	√	
SCION	FR-S	Up to 2017	Starting Control	√	√	√	√	√	
SCION	FR-S	Up to 2017	Telematics	√	√	√	√		
SCION	FR-S	Up to 2017	Transmission Control Module	√	√	√	√	√	
SCION	FR-S	Up to 2017	Tire Pressure Monitor	√	√	√	√	√	√
SCION	iA	Up to 2017	ABS/VSC/TRAC	√	√	√	√	√	√
SCION	iA	Up to 2017	Accessory Gateway	√	√	√	√	√	
SCION	iA	Up to 2017	Air Conditioner	√	√	√	√	√	√
SCION	iA	Up to 2017	Combination Meter	√	√	√	√	√	
SCION	iA	Up to 2017	Cruise Control	√	√	√	√		
SCION	iA	Up to 2017	D-Door Motor	√	√	√	√	√	
SCION	iA	Up to 2017	EMPS	√	√	√	√	√	√
SCION	iA	Up to 2017	Engine and ECT	√	√	√	√	√	√
SCION	iA	Up to 2017	Four Wheel Drive	√	√	√	√	√	√
SCION	iA	Up to 2017	Immobiliser	√	√	√	√	√	
SCION	iA	Up to 2017	Main Body	√	√	√	√	√	√
SCION	iA	Up to 2017	Occupant Detection	√	√	√	√	√	√
SCION	iA	Up to 2017	SRS Airbag	√	√	√	√	√	√

SCION	iA	Up to 2017	Sliding Roof	√	√	√	√	√	
SCION	iA	Up to 2017	Theft Deterrent	√	√	√	√	√	
SCION	iA	Up to 2017	Auto Leveling Module	√	√	√	√	√	
SCION	iA	Up to 2017	Connectivity Master Unit	√	√	√	√	√	
SCION	iA	Up to 2017	ECT	√	√	√	√	√	
SCION	iA	Up to 2017	EV	√	√	√	√	√	
SCION	iA	Up to 2017	EV Battery	√	√	√	√	√	
SCION	iA	Up to 2017	Electric Supply Unit	√	√	√	√	√	
SCION	iA	Up to 2017	Engine	√	√	√	√	√	
SCION	iA	Up to 2017	Instrument Cluster	√	√	√	√	√	
SCION	iA	Up to 2017	Master Switch	√	√	√	√		
SCION	iA	Up to 2017	Navigation System	√	√	√	√		
SCION	iA	Up to 2017	P-Door Motor	√	√	√	√	√	
SCION	iA	Up to 2017	PM1 Gateway	√	√	√	√		
SCION	iA	Up to 2017	Plug-in Control	√	√	√	√	√	
SCION	iA	Up to 2017	Power Source Control	√	√	√	√	√	
SCION	iA	Up to 2017	Powertrain Control Module	√	√	√	√	√	
SCION	iA	Up to 2017	Remote Engine Starter	√	√	√	√	√	
SCION	iA	Up to 2017	Restraint Control Module	√	√	√	√	√	
SCION	iA	Up to 2017	Sliding Roof	√	√	√	√	√	
SCION	iA	Up to 2017	Smart City Brake Support	√	√	√	√	√	
SCION	iA	Up to 2017	Smart Key	√	√	√	√	√	
SCION	iA	Up to 2017	Smart Start Unit	√	√	√	√	√	
SCION	iA	Up to 2017	Starting Control	√	√	√	√	√	
SCION	iA	Up to 2017	Telematics	√	√	√	√		
SCION	iA	Up to 2017	Transmission Control Module	√	√	√	√	√	
SCION	iA	Up to 2017	Tire Pressure Monitor	√	√	√	√	√	√
SCION	iM	Up to 2017	ABS/VSC/TRAC	√	√	√	√	√	√
SCION	iM	Up to 2017	Accessory Gateway	√	√	√	√	√	
SCION	iM	Up to 2017	Air Conditioner	√	√	√	√	√	√
SCION	iM	Up to 2017	Combination Meter	√	√	√	√	√	
SCION	iM	Up to 2017	Cruise Control	√	√	√	√		
SCION	iM	Up to 2017	D-Door Motor	√	√	√	√	√	
SCION	iM	Up to 2017	EMPS	√	√	√	√	√	√
SCION	iM	Up to 2017	Engine and ECT	√	√	√	√	√	√
SCION	iM	Up to 2017	Four Wheel Drive	√	√	√	√	√	√
SCION	iM	Up to 2017	Immobiliser	√	√	√	√	√	
SCION	iM	Up to 2017	Main Body	√	√	√	√	√	√
SCION	iM	Up to 2017	Occupant Detection	√	√	√	√	√	√
SCION	iM	Up to 2017	SRS Airbag	√	√	√	√	√	√
SCION	iM	Up to 2017	Sliding Roof	√	√	√	√	√	
SCION	iM	Up to 2017	Theft Deterrent	√	√	√	√	√	
SCION	iM	Up to 2017	Auto Leveling Module	√	√	√	√	√	
SCION	iM	Up to 2017	Connectivity Master Unit	√	√	√	√	√	
SCION	iM	Up to 2017	ECT	√	√	√	√	√	
SCION	iM	Up to 2017	EV	√	√	√	√	√	
SCION	iM	Up to 2017	EV Battery	√	√	√	√	√	
SCION	iM	Up to 2017	Electric Supply Unit	√	√	√	√	√	
SCION	iM	Up to 2017	Engine	√	√	√	√	√	
SCION	iM	Up to 2017	Instrument Cluster	√	√	√	√	√	
SCION	iM	Up to 2017	Master Switch	√	√	√	√		
SCION	iM	Up to 2017	Navigation System	√	√	√	√		
SCION	iM	Up to 2017	P-Door Motor	√	√	√	√	√	
SCION	iM	Up to 2017	PM1 Gateway	√	√	√	√		
SCION	iM	Up to 2017	Plug-in Control	√	√	√	√	√	
SCION	iM	Up to 2017	Power Source Control	√	√	√	√	√	
SCION	iM	Up to 2017	Powertrain Control Module	√	√	√	√	√	
SCION	iM	Up to 2017	Remote Engine Starter	√	√	√	√	√	
SCION	iM	Up to 2017	Restraint Control Module	√	√	√	√	√	
SCION	iM	Up to 2017	Sliding Roof	√	√	√	√	√	
SCION	iM	Up to 2017	Smart City Brake Support	√	√	√	√	√	
SCION	iM	Up to 2017	Smart Key	√	√	√	√	√	
SCION	iM	Up to 2017	Smart Start Unit	√	√	√	√	√	
SCION	iM	Up to 2017	Starting Control	√	√	√	√	√	
SCION	iM	Up to 2017	Telematics	√	√	√	√		

SCION	iM	Up to 2017	Transmission Control Module	√	√	√	√	√	
SCION	iM	Up to 2017	Tire Pressure Monitor	√	√	√	√	√	√
SCION	iQ	Up to 2017	ABS/VSC/TRAC	√	√	√	√	√	√
SCION	iQ	Up to 2017	Accessory Gateway	√	√	√	√	√	
SCION	iQ	Up to 2017	Air Conditioner	√	√	√	√	√	√
SCION	iQ	Up to 2017	Combination Meter	√	√	√	√	√	
SCION	iQ	Up to 2017	Cruise Control	√	√	√	√		
SCION	iQ	Up to 2017	D-Door Motor	√	√	√	√	√	
SCION	iQ	Up to 2017	EMPS	√	√	√	√	√	√
SCION	iQ	Up to 2017	Engine and ECT	√	√	√	√	√	√
SCION	iQ	Up to 2017	Four Wheel Drive	√	√	√	√	√	√
SCION	iQ	Up to 2017	Immobiliser	√	√	√	√	√	
SCION	iQ	Up to 2017	Main Body	√	√	√	√	√	√
SCION	iQ	Up to 2017	Occupant Detection	√	√	√	√	√	√
SCION	iQ	Up to 2017	SRS Airbag	√	√	√	√	√	√
SCION	iQ	Up to 2017	Sliding Roof	√	√	√	√	√	
SCION	iQ	Up to 2017	Theft Deterrent	√	√	√	√	√	
SCION	iQ	Up to 2017	Auto Leveling Module	√	√	√	√	√	
SCION	iQ	Up to 2017	Connectivity Master Unit	√	√	√	√	√	
SCION	iQ	Up to 2017	ECT	√	√	√	√	√	
SCION	iQ	Up to 2017	EV	√	√	√	√	√	
SCION	iQ	Up to 2017	EV Battery	√	√	√	√	√	
SCION	iQ	Up to 2017	Electric Supply Unit	√	√	√	√	√	
SCION	iQ	Up to 2017	Engine	√	√	√	√	√	
SCION	iQ	Up to 2017	Instrument Cluster	√	√	√	√	√	
SCION	iQ	Up to 2017	Master Switch	√	√	√	√		
SCION	iQ	Up to 2017	Navigation System	√	√	√	√		
SCION	iQ	Up to 2017	P-Door Motor	√	√	√	√	√	
SCION	iQ	Up to 2017	PM1 Gateway	√	√	√	√		
SCION	iQ	Up to 2017	Plug-in Control	√	√	√	√	√	
SCION	iQ	Up to 2017	Power Source Control	√	√	√	√	√	
SCION	iQ	Up to 2017	Powertrain Control Module	√	√	√	√	√	
SCION	iQ	Up to 2017	Remote Engine Starter	√	√	√	√	√	
SCION	iQ	Up to 2017	Restraint Control Module	√	√	√	√	√	
SCION	iQ	Up to 2017	Sliding Roof	√	√	√	√	√	
SCION	iQ	Up to 2017	Smart City Brake Support	√	√	√	√	√	
SCION	iQ	Up to 2017	Smart Key	√	√	√	√	√	
SCION	iQ	Up to 2017	Smart Start Unit	√	√	√	√	√	
SCION	iQ	Up to 2017	Starting Control	√	√	√	√	√	
SCION	iQ	Up to 2017	Telematics	√	√	√	√		
SCION	iQ	Up to 2017	Transmission Control Module	√	√	√	√	√	
SCION	iQ	Up to 2017	Tire Pressure Monitor	√	√	√	√	√	√
SCION	iQ EV	Up to 2017	ABS/VSC/TRAC	√	√	√	√	√	√
SCION	iQ EV	Up to 2017	Accessory Gateway	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Air Conditioner	√	√	√	√	√	√
SCION	iQ EV	Up to 2017	Combination Meter	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Cruise Control	√	√	√	√		
SCION	iQ EV	Up to 2017	D-Door Motor	√	√	√	√	√	
SCION	iQ EV	Up to 2017	EMPS	√	√	√	√	√	√
SCION	iQ EV	Up to 2017	Engine and ECT	√	√	√	√	√	√
SCION	iQ EV	Up to 2017	Four Wheel Drive	√	√	√	√	√	√
SCION	iQ EV	Up to 2017	Immobiliser	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Main Body	√	√	√	√	√	√
SCION	iQ EV	Up to 2017	Occupant Detection	√	√	√	√	√	√
SCION	iQ EV	Up to 2017	SRS Airbag	√	√	√	√	√	√
SCION	iQ EV	Up to 2017	Sliding Roof	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Theft Deterrent	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Auto Leveling Module	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Connectivity Master Unit	√	√	√	√	√	
SCION	iQ EV	Up to 2017	ECT	√	√	√	√	√	
SCION	iQ EV	Up to 2017	EV	√	√	√	√	√	
SCION	iQ EV	Up to 2017	EV Battery	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Electric Supply Unit	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Engine	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Instrument Cluster	√	√	√	√	√	

SCION	iQ EV	Up to 2017	Master Switch	√	√	√	√		
SCION	iQ EV	Up to 2017	Navigation System	√	√	√	√		
SCION	iQ EV	Up to 2017	P-Door Motor	√	√	√	√	√	
SCION	iQ EV	Up to 2017	PM1 Gateway	√	√	√	√		
SCION	iQ EV	Up to 2017	Plug-in Control	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Power Source Control	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Powertrain Control Module	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Remote Engine Starter	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Restraint Control Module	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Sliding Roof	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Smart City Brake Support	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Smart Key	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Smart Start Unit	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Starting Control	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Telematics	√	√	√	√		
SCION	iQ EV	Up to 2017	Transmission Control Module	√	√	√	√	√	
SCION	iQ EV	Up to 2017	Tire Pressure Monitor	√	√	√	√	√	√
SCION	tC	Up to 2017	ABS/VSC/TRAC	√	√	√	√	√	√
SCION	tC	Up to 2017	Accessory Gateway	√	√	√	√	√	
SCION	tC	Up to 2017	Air Conditioner	√	√	√	√	√	√
SCION	tC	Up to 2017	Combination Meter	√	√	√	√	√	
SCION	tC	Up to 2017	Cruise Control	√	√	√	√		
SCION	tC	Up to 2017	D-Door Motor	√	√	√	√	√	
SCION	tC	Up to 2017	EMPS	√	√	√	√	√	√
SCION	tC	Up to 2017	Engine and ECT	√	√	√	√	√	√
SCION	tC	Up to 2017	Four Wheel Drive	√	√	√	√	√	√
SCION	tC	Up to 2017	Immobiliser	√	√	√	√	√	
SCION	tC	Up to 2017	Main Body	√	√	√	√	√	√
SCION	tC	Up to 2017	Occupant Detection	√	√	√	√	√	√
SCION	tC	Up to 2017	SRS Airbag	√	√	√	√	√	√
SCION	tC	Up to 2017	Sliding Roof	√	√	√	√	√	
SCION	tC	Up to 2017	Theft Deterrent	√	√	√	√	√	
SCION	tC	Up to 2017	Auto Leveling Module	√	√	√	√	√	
SCION	tC	Up to 2017	Connectivity Master Unit	√	√	√	√	√	
SCION	tC	Up to 2017	ECT	√	√	√	√	√	
SCION	tC	Up to 2017	EV	√	√	√	√	√	
SCION	tC	Up to 2017	EV Battery	√	√	√	√	√	
SCION	tC	Up to 2017	Electric Supply Unit	√	√	√	√	√	
SCION	tC	Up to 2017	Engine	√	√	√	√	√	
SCION	tC	Up to 2017	Instrument Cluster	√	√	√	√	√	
SCION	tC	Up to 2017	Master Switch	√	√	√	√		
SCION	tC	Up to 2017	Navigation System	√	√	√	√		
SCION	tC	Up to 2017	P-Door Motor	√	√	√	√	√	
SCION	tC	Up to 2017	PM1 Gateway	√	√	√	√		
SCION	tC	Up to 2017	Plug-in Control	√	√	√	√	√	
SCION	tC	Up to 2017	Power Source Control	√	√	√	√	√	
SCION	tC	Up to 2017	Powertrain Control Module	√	√	√	√	√	
SCION	tC	Up to 2017	Remote Engine Starter	√	√	√	√	√	
SCION	tC	Up to 2017	Restraint Control Module	√	√	√	√	√	
SCION	tC	Up to 2017	Sliding Roof	√	√	√	√	√	
SCION	tC	Up to 2017	Smart City Brake Support	√	√	√	√	√	
SCION	tC	Up to 2017	Smart Key	√	√	√	√	√	
SCION	tC	Up to 2017	Smart Start Unit	√	√	√	√	√	
SCION	tC	Up to 2017	Starting Control	√	√	√	√	√	
SCION	tC	Up to 2017	Telematics	√	√	√	√		
SCION	tC	Up to 2017	Transmission Control Module	√	√	√	√	√	
SCION	tC	Up to 2017	Tire Pressure Monitor	√	√	√	√	√	√
SCION	XA	Up to 2017	ABS/VSC/TRAC	√	√	√	√	√	√
SCION	XA	Up to 2017	Accessory Gateway	√	√	√	√	√	
SCION	XA	Up to 2017	Air Conditioner	√	√	√	√	√	√
SCION	XA	Up to 2017	Combination Meter	√	√	√	√	√	
SCION	XA	Up to 2017	Cruise Control	√	√	√	√		
SCION	XA	Up to 2017	D-Door Motor	√	√	√	√	√	
SCION	XA	Up to 2017	EMPS	√	√	√	√	√	√
SCION	XA	Up to 2017	Engine and ECT	√	√	√	√	√	√

SCION	XA	Up to 2017	Four Wheel Drive	√	√	√	√	√	√
SCION	XA	Up to 2017	Immobiliser	√	√	√	√	√	
SCION	XA	Up to 2017	Main Body	√	√	√	√	√	√
SCION	XA	Up to 2017	Occupant Detection	√	√	√	√	√	√
SCION	XA	Up to 2017	SRS Airbag	√	√	√	√	√	√
SCION	XA	Up to 2017	Sliding Roof	√	√	√	√	√	
SCION	XA	Up to 2017	Theft Deterrent	√	√	√	√	√	
SCION	XA	Up to 2017	Auto Leveling Module	√	√	√	√	√	
SCION	XA	Up to 2017	Connectivity Master Unit	√	√	√	√	√	
SCION	XA	Up to 2017	ECT	√	√	√	√	√	
SCION	XA	Up to 2017	EV	√	√	√	√	√	
SCION	XA	Up to 2017	EV Battery	√	√	√	√	√	
SCION	XA	Up to 2017	Electric Supply Unit	√	√	√	√	√	
SCION	XA	Up to 2017	Engine	√	√	√	√	√	
SCION	XA	Up to 2017	Instrument Cluster	√	√	√	√	√	
SCION	XA	Up to 2017	Master Switch	√	√	√	√		
SCION	XA	Up to 2017	Navigation System	√	√	√	√		
SCION	XA	Up to 2017	P-Door Motor	√	√	√	√	√	
SCION	XA	Up to 2017	PM1 Gateway	√	√	√	√		
SCION	XA	Up to 2017	Plug-in Control	√	√	√	√	√	
SCION	XA	Up to 2017	Power Source Control	√	√	√	√	√	
SCION	XA	Up to 2017	Powertrain Control Module	√	√	√	√	√	
SCION	XA	Up to 2017	Remote Engine Starter	√	√	√	√	√	
SCION	XA	Up to 2017	Restraint Control Module	√	√	√	√	√	
SCION	XA	Up to 2017	Sliding Roof	√	√	√	√	√	
SCION	XA	Up to 2017	Smart City Brake Support	√	√	√	√	√	
SCION	XA	Up to 2017	Smart Key	√	√	√	√	√	
SCION	XA	Up to 2017	Smart Start Unit	√	√	√	√	√	
SCION	XA	Up to 2017	Starting Control	√	√	√	√	√	
SCION	XA	Up to 2017	Telematics	√	√	√	√		
SCION	XA	Up to 2017	Transmission Control Module	√	√	√	√	√	
SCION	XA	Up to 2017	Tire Pressure Monitor	√	√	√	√	√	√
SCION	XB	Up to 2017	ABS/VSC/TRAC	√	√	√	√	√	√
SCION	XB	Up to 2017	Accessory Gateway	√	√	√	√	√	
SCION	XB	Up to 2017	Air Conditioner	√	√	√	√	√	√
SCION	XB	Up to 2017	Combination Meter	√	√	√	√	√	
SCION	XB	Up to 2017	Cruise Control	√	√	√	√		
SCION	XB	Up to 2017	D-Door Motor	√	√	√	√	√	
SCION	XB	Up to 2017	EMPS	√	√	√	√	√	√
SCION	XB	Up to 2017	Engine and ECT	√	√	√	√	√	√
SCION	XB	Up to 2017	Four Wheel Drive	√	√	√	√	√	√
SCION	XB	Up to 2017	Immobiliser	√	√	√	√	√	
SCION	XB	Up to 2017	Main Body	√	√	√	√	√	√
SCION	XB	Up to 2017	Occupant Detection	√	√	√	√	√	√
SCION	XB	Up to 2017	SRS Airbag	√	√	√	√	√	√
SCION	XB	Up to 2017	Sliding Roof	√	√	√	√	√	
SCION	XB	Up to 2017	Theft Deterrent	√	√	√	√	√	
SCION	XB	Up to 2017	Auto Leveling Module	√	√	√	√	√	
SCION	XB	Up to 2017	Connectivity Master Unit	√	√	√	√	√	
SCION	XB	Up to 2017	ECT	√	√	√	√	√	
SCION	XB	Up to 2017	EV	√	√	√	√	√	
SCION	XB	Up to 2017	EV Battery	√	√	√	√	√	
SCION	XB	Up to 2017	Electric Supply Unit	√	√	√	√	√	
SCION	XB	Up to 2017	Engine	√	√	√	√	√	
SCION	XB	Up to 2017	Instrument Cluster	√	√	√	√	√	
SCION	XB	Up to 2017	Master Switch	√	√	√	√		
SCION	XB	Up to 2017	Navigation System	√	√	√	√		
SCION	XB	Up to 2017	P-Door Motor	√	√	√	√	√	
SCION	XB	Up to 2017	PM1 Gateway	√	√	√	√		
SCION	XB	Up to 2017	Plug-in Control	√	√	√	√	√	
SCION	XB	Up to 2017	Power Source Control	√	√	√	√	√	
SCION	XB	Up to 2017	Powertrain Control Module	√	√	√	√	√	
SCION	XB	Up to 2017	Remote Engine Starter	√	√	√	√	√	
SCION	XB	Up to 2017	Restraint Control Module	√	√	√	√	√	
SCION	XB	Up to 2017	Sliding Roof	√	√	√	√	√	

SCION	XB	Up to 2017	Smart City Brake Support	√	√	√	√	√	
SCION	XB	Up to 2017	Smart Key	√	√	√	√	√	
SCION	XB	Up to 2017	Smart Start Unit	√	√	√	√	√	
SCION	XB	Up to 2017	Starting Control	√	√	√	√	√	
SCION	XB	Up to 2017	Telematics	√	√	√	√		
SCION	XB	Up to 2017	Transmission Control Module	√	√	√	√	√	
SCION	XB	Up to 2017	Tire Pressure Monitor	√	√	√	√	√	√
SCION	XB	Up to 2017	ABS/VSC/TRAC	√	√	√	√	√	√
SCION	XB	Up to 2017	Accessory Gateway	√	√	√	√	√	
SCION	XB	Up to 2017	Air Conditioner	√	√	√	√	√	√
SCION	XB	Up to 2017	Combination Meter	√	√	√	√	√	
SCION	XB	Up to 2017	Cruise Control	√	√	√	√		
SCION	XB	Up to 2017	D-Door Motor	√	√	√	√	√	
SCION	XB	Up to 2017	EMPS	√	√	√	√	√	√
SCION	XB	Up to 2017	Engine and ECT	√	√	√	√	√	√
SCION	XB	Up to 2017	Four Wheel Drive	√	√	√	√	√	√
SCION	XB	Up to 2017	Immobiliser	√	√	√	√	√	
SCION	XB	Up to 2017	Main Body	√	√	√	√	√	√
SCION	XB	Up to 2017	Occupant Detection	√	√	√	√	√	√
SCION	XB	Up to 2017	SRS Airbag	√	√	√	√	√	√
SCION	XB	Up to 2017	Sliding Roof	√	√	√	√	√	
SCION	XB	Up to 2017	Theft Deterrent	√	√	√	√	√	
SCION	XB	Up to 2017	Auto Leveling Module	√	√	√	√	√	
SCION	XB	Up to 2017	Connectivity Master Unit	√	√	√	√	√	
SCION	XB	Up to 2017	ECT	√	√	√	√	√	
SCION	XB	Up to 2017	EV	√	√	√	√	√	
SCION	XB	Up to 2017	EV Battery	√	√	√	√	√	
SCION	XB	Up to 2017	Electric Supply Unit	√	√	√	√	√	
SCION	XB	Up to 2017	Engine	√	√	√	√	√	
SCION	XB	Up to 2017	Instrument Cluster	√	√	√	√	√	
SCION	XB	Up to 2017	Master Switch	√	√	√	√		
SCION	XB	Up to 2017	Navigation System	√	√	√	√		
SCION	XB	Up to 2017	P-Door Motor	√	√	√	√	√	
SCION	XB	Up to 2017	PM1 Gateway	√	√	√	√		
SCION	XB	Up to 2017	Plug-in Control	√	√	√	√	√	
SCION	XB	Up to 2017	Power Source Control	√	√	√	√	√	
SCION	XB	Up to 2017	Powertrain Control Module	√	√	√	√	√	
SCION	XB	Up to 2017	Remote Engine Starter	√	√	√	√	√	
SCION	XB	Up to 2017	Restraint Control Module	√	√	√	√	√	
SCION	XB	Up to 2017	Sliding Roof	√	√	√	√	√	
SCION	XB	Up to 2017	Smart City Brake Support	√	√	√	√	√	
SCION	XB	Up to 2017	Smart Key	√	√	√	√	√	
SCION	XB	Up to 2017	Smart Start Unit	√	√	√	√	√	
SCION	XB	Up to 2017	Starting Control	√	√	√	√	√	
SCION	XB	Up to 2017	Telematics	√	√	√	√		
SCION	XB	Up to 2017	Transmission Control Module	√	√	√	√	√	
SCION	XB	Up to 2017	Tire Pressure Monitor	√	√	√	√	√	√

System	Utilitys
ABS/VSC/TRC	2nd Sys. Air Bleeding
ABS/VSC/TRC	Air Bleeding
ABS/VSC/TRC	Check Mode
ABS/VSC/TRC	ECB Utility
ABS/VSC/TRC	ES Calibration
ABS/VSC/TRC	Inspection Mode
ABS/VSC/TRC	Reset Memory
ABS/VSC/TRC	Test Mode
ABS/VSC/TRC	VSC Sensor Neutral Memorization
ABS/VSC/TRC	VSC/TR(A)C/4WD Control Prevention Mode
ABS/VSC/TRC	Vehicle Information Synchronization
Air Conditioner	Blower Motor Brush Wear Amount Initialization
Air Conditioner	Rear Cooling Unit Check
Air Conditioner	Refrigerant Gas Volume Check
Air Conditioner	Servomotor Initialization
Engine and ECT	A/F Sensor Compensation Reset

Engine and ECT	A/T Code Registration
Engine and ECT	A/T Code Reset
Engine and ECT	All Readiness
Engine and ECT	CVT Oil Pressure Calibration
Engine and ECT	Catalyst Record Clear
Engine and ECT	Catalyst Record Read
Engine and ECT	Catalyst Record Transferring
Engine and ECT	Check Mode
Engine and ECT	Crank Time Compensation Reset
Engine and ECT	DPF Deterioration Record Clear
Engine and ECT	Deceleration Sensor Zero Point Calibration
Engine and ECT	Electric Throttle Learning
Engine and ECT	Engine History Utility
Engine and ECT	Engine Oil Pressure Control Check
Engine and ECT	Injector Compensation
Engine and ECT	Learning Value Reset
Engine and ECT	Learning Values Confirmation
Engine and ECT	Learning Values Save
Engine and ECT	Learning Values Write
Engine and ECT	Pilot Quantity Learning
Engine and ECT	Pilot Quantity Learning Values Clear
Engine and ECT	Pilot Quantity Learning Values Reset
Engine and ECT	Pilot Quantity Learning(Detail)
Engine and ECT	Pressure Discharge Valve Check
Engine and ECT	Reset Memory
Engine and ECT	Supply Pump Initialization
Engine and ECT	VIN
Engine and ECT	Vehicle Mileage Write
Engine and ECT	i-ART Learning Value Reset
Four Wheel Drive	4WD Control Prevention Mode
Four Wheel Drive	Reset Memory
Four Wheel Drive	VSC/TR(A)C/4WD Control Prevention Mode
Main Body	Wireless Door Lock Diagnosis Mode
Occupant Detection	Sensitivity Check
Occupant Detection	Zero Point Calibration
SRS Airbag	Check Mode
Tire Pressure Monitor	ID Registration

Vehicle Customize Setting covered

Customize Setting
Air Conditioner
Compass Calibration
Display
Door Lock
Illuminated Entry
Light Control
Option Setup
Power Window
Retractable Hardtop
Seat
Security
Sensor
Slide Roof
Smart Key / Access
TVSS
Tilt & Telesco
Unit conversion
Warning
Wiper
Wireless Door Lock
Others