

Note:	
√	Functions marked with √ is fully supported and already existed in former software version.
Number	Index number of the special function , you can find the name from the special function table.

Area	Model	Year	Engine	System	ECU Info.	Read Code	Clear Code	Live Data	Active Test	Special Func
Europe/General	AVELLA(FV)	2000	G 1.3 SOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	AVELLA(FV)	2000	G 1.5 SOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	AVELLA(FV)	1999	G 1.3 SOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	AVELLA(FV)	1999	G 1.5 SOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	AVELLA(FV)	1998	G 1.3 SOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	AVELLA(FV)	1998	G 1.5 SOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	AVELLA(FV)	1997	G 1.3 SOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	AVELLA(FV)	1997	G 1.5 SOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	AVELLA(FV)	1996	G 1.3 SOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	AVELLA(FV)	1996	G 1.5 SOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	AVELLA(FV)	1995	G 1.3 SOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	AVELLA(FV)	1994	G 1.3 SOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	BESTA(TP)	2003	D 2.5 TCI	ENGINE [Engine Control]		√	√	√	√	
Europe/General	BESTA(TP)	2002	D 2.5 TCI	ENGINE [Engine Control]		√	√	√	√	
Europe/General	BESTA(TP)	2002	D 2.5 TCI	AT [Automatic Transaxle]		√	√	√		
Europe/General	BESTA(TP)	2001	D 2.5 TCI	ENGINE [Engine Control]		√	√	√	√	
Europe/General	BESTA(TP)	2001	D 2.5 TCI	AT [Automatic Transaxle]		√	√	√		
Europe/General	BESTA(TP)	2000	D 2.5 TCI	ENGINE [Engine Control]		√	√	√	√	
Europe/General	BESTA(TP)	2000	D 2.5 TCI	AT [Automatic Transaxle]		√	√	√		
Europe/General	BESTA(TP)	1999	D 2.5 TCI	ENGINE [Engine Control]		√	√	√	√	
Europe/General	BESTA(TP)	1999	D 2.5 TCI	AT [Automatic Transaxle]		√	√	√		
Europe/General	BESTA(TP)	1998	D 2.5 TCI	ENGINE [Engine Control]		√	√	√	√	
Europe/General	BESTA(TP)	1998	D 2.5 TCI	AT [Automatic Transaxle]		√	√	√		
Europe/General	BESTA(TP)	1997	D 2.5 TCI	ENGINE [Engine Control]		√	√	√	√	
Europe/General	BESTA(TP)	1997	D 2.5 TCI	AT [Automatic Transaxle]		√	√	√		
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	ENGINE [Unleaded All]		√	√			0011, 0043, 0094, 0126
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	ENGINE [Leaded All]		√	√			0011, 0043, 0094, 0126
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	SPAS [Smart Parking Assist System]	√	√	√	√	√	

Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	AVN [AVN 3.0]		√				
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	AVN [AUDIO 3.0 C]		√				
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	SCM [Steering Column Module]	√	√	√	√	√	0114
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	HSM [Haptic Seat Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CADENZA(VG)	2016	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	ENGINE [Unleaded All]		√	√			0011, 0043, 0094, 0126
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	ENGINE [Leaded All]		√	√			0011, 0043, 0094, 0126
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	AVN [AVN 3.0]		√				
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	AVN [AUDIO 3.0 C]		√				
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	SCM [Steering Column Module]	√	√	√	√	√	0114
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	HSM [Haptic Seat Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CADENZA(VG)	2015	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	ENGINE [Unleaded All]		√	√			0011, 0043, 0094, 0126
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	ENGINE [Leaded All]		√	√			0011, 0043, 0094, 0126

Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	AVN [AVN 3.0]		√				
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	AVN [AUDIO 3.0 C]		√				
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	SCM [Steering Column Module]	√	√	√	√	√	0114
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	HSM [Haptic Seat Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CADENZA(VG)	2014	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	ENGINE [Unleaded All]		√	√			0011, 0043, 0094, 0126
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	ENGINE [Leaded All]		√	√			0011, 0043, 0094, 0126
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	SVMS [Surround View Monito System]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	IPM [Instrument Panel Module]	√	√	√	√	√	

Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	SCM [Steering Column Module]	√	√	√	√	√	0114
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	HSM [Haptic Seat Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CADENZA(VG)	2013	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	ENGINE [Unleaded All]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	EPB [Electric Parking Brake]	√	√	√	√	√	0013
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	SCM [Steering Column Module]	√	√	√	√	√	0114
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2012	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CADENZA(VG)	2011	G 3.5 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	CADENZA(VG)	2011	G 3.5 DOHC	ENGINE [Unleaded All]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CADENZA(VG)	2011	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CADENZA(VG)	2011	G 3.5 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0008
Europe/General	CADENZA(VG)	2011	G 3.5 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CADENZA(VG)	2011	G 3.5 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CADENZA(VG)	2011	G 3.5 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2011	G 3.5 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2011	G 3.5 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CADENZA(VG)	2011	G 3.5 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	CADENZA(VG)	2011	G 3.5 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	CADENZA(VG)	2011	G 3.5 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	CADENZA(VG)	2011	G 3.5 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2011	G 3.5 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2011	G 3.5 DOHC	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CADENZA(VG)	2011	G 3.5 DOHC	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2011	G 3.5 DOHC	SCM [Steering Column Module]	√	√	√	√	√	0114
Europe/General	CADENZA(VG)	2011	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CADENZA(VG)	2010	G 3.5 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126

Europe/General	CADENZA(VG)	2010	G 3.5 DOHC	ENGINE [Unleaded All]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CADENZA(VG)	2010	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CADENZA(VG)	2010	G 3.5 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0008
Europe/General	CADENZA(VG)	2010	G 3.5 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CADENZA(VG)	2010	G 3.5 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CADENZA(VG)	2010	G 3.5 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2010	G 3.5 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2010	G 3.5 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CADENZA(VG)	2010	G 3.5 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	CADENZA(VG)	2010	G 3.5 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	CADENZA(VG)	2010	G 3.5 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	CADENZA(VG)	2010	G 3.5 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2010	G 3.5 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2010	G 3.5 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2010	G 3.5 DOHC	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CADENZA(VG)	2010	G 3.5 DOHC	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CADENZA(VG)	2010	G 3.5 DOHC	SCM [Steering Column Module]	√	√	√	√	√	0114
Europe/General	CADENZA(VG)	2010	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0126
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	ABSESP [ABS / ESP]	√	√	√	√	√	0010, 0013, 0051
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	AEB [Assist Emergency Braking System]	√	√	√	√		
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	TPMS [Tire Pressure Monitoring]	√	√	√			
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	PGS [Parking Guide System]	√	√	√	√		
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	SVMS [Surround View Monitor System]	√	√	√	√	√	0006
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	BSD [Blind Spot Detection]	√	√	√	√		
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045,0102
			LAMBDA II							
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	AMP [Amplifier]						0003
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	SCM [Steering Column Module]	√	√	√	√	√	0114
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	HUD [Head Up Display]	√	√	√	√		
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	PTM [Power Trunk Module]	√	√	√	√		
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	ADM [Assist Door Module]	√	√	√	√	√	

Europe/General	CADENZA(YG)	2017	G 3.3 GDI LAMBDA II	IGPM [Intergrated Gateway & Power Control Module]	√	√	√	√	√	0041
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	ECALL [e - Call]	√	√	√			
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	ENGINE [Engine Control]	√	√	√	√		0011, 0043, 0094, 0126
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	ABSESP [ABS / ESP]	√	√	√	√	√	0010, 0013, 0051
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	AEB [Assist Emergency Braking System]	√	√	√	√		
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	TPMS [Tire Pressure Monitoring]	√	√	√			
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	PGS [Parking Guide System]	√	√	√	√		
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	SVMS [Surround View Monitor System]	√	√	√	√	√	0006
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	BSD [Blind Spot Detection]	√	√	√	√		
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CADENZA(YG)	2017	G 3.3 GDI LAMBDA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	AMP [Amplifier]						0003
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	SCM [Steering Column Module]	√	√	√	√	√	0114
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	HUD [Head Up Display]	√	√	√	√		
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	PTM [Power Trunk Module]	√	√	√	√		
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	CADENZA(YG)	2017	G 3.3 GDI LAMBDA II	IGPM [Intergrated Gateway & Power Control Module]	√	√	√	√	√	0041
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	ECALL [e - Call]	√	√	√			
Europe/General	CADENZA(YG)	2017	G 3.3 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(FJ)	2007	D 2.0 TCI	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CARENS(FJ)	2007	D 2.0 TCI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(FJ)	2007	D 2.0 TCI	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARENS(FJ)	2007	D 2.0 TCI	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CARENS(FJ)	2007	G 1.6 DOHC	ENGINE [Unleaded IMMO (-)]		√	√	√		
Europe/General	CARENS(FJ)	2007	G 1.6 DOHC	ENGINE [Unleaded IMMO (+)]		√	√	√		
Europe/General	CARENS(FJ)	2007	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARENS(FJ)	2007	G 1.6 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARENS(FJ)	2007	G 1.6 DOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CARENS(FJ)	2007	G 1.8 DOHC	ENGINE [Unleaded EURO - 4]		√	√	√		
Europe/General	CARENS(FJ)	2007	G 1.8 DOHC	ENGINE [Unleaded IMMO (+)]		√	√	√		
Europe/General	CARENS(FJ)	2007	G 1.8 DOHC	ENGINE [Unleaded IMMO (-)]		√	√	√		

Europe/General	CARENS(FJ)	2007	G 1.8 DOHC	ENGINE [Leaded All]		√	√	√		
Europe/General	CARENS(FJ)	2007	G 1.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARENS(FJ)	2007	G 1.8 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARENS(FJ)	2007	G 1.8 DOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CARENS(FJ)	2007	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0098
Europe/General	CARENS(FJ)	2007	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0062, 0011, 0098
Europe/General	CARENS(FJ)	2007	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	CARENS(FJ)	2007	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARENS(FJ)	2007	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARENS(FJ)	2007	G 2.0 DOHC	IMMO [Immobilizer]				√		
Europe/General	CARENS(FJ)	2006	D 2.0 TCI	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CARENS(FJ)	2006	D 2.0 TCI	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARENS(FJ)	2006	D 2.0 TCI	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CARENS(FJ)	2006	G 1.6 DOHC	ENGINE [Unleaded IMMO (-)]		√	√	√		
Europe/General	CARENS(FJ)	2006	G 1.6 DOHC	ENGINE [Unleaded IMMO (+)]		√	√	√		
Europe/General	CARENS(FJ)	2006	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARENS(FJ)	2006	G 1.6 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARENS(FJ)	2006	G 1.6 DOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CARENS(FJ)	2006	G 1.8 DOHC	ENGINE [Unleaded EURO - 4]		√	√	√		
Europe/General	CARENS(FJ)	2006	G 1.8 DOHC	ENGINE [Unleaded IMMO (+)]		√	√	√		
Europe/General	CARENS(FJ)	2006	G 1.8 DOHC	ENGINE [Unleaded IMMO (-)]		√	√	√		
Europe/General	CARENS(FJ)	2006	G 1.8 DOHC	ENGINE [Leaded All]		√	√	√		
Europe/General	CARENS(FJ)	2006	G 1.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARENS(FJ)	2006	G 1.8 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARENS(FJ)	2006	G 1.8 DOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CARENS(FJ)	2006	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0098
Europe/General	CARENS(FJ)	2006	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0062, 0062, 0011, 0011, 0098
Europe/General	CARENS(FJ)	2006	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	CARENS(FJ)	2006	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARENS(FJ)	2006	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARENS(FJ)	2006	G 2.0 DOHC	IMMO [Immobilizer]				√		
Europe/General	CARENS(FJ)	2005	D 2.0 TCI	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CARENS(FJ)	2005	D 2.0 TCI	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARENS(FJ)	2005	D 2.0 TCI	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARENS(FJ)	2005	D 2.0 TCI	IMMO [Immobilizer]				√		
Europe/General	CARENS(FJ)	2005	G 1.6 DOHC	ENGINE [Unleaded IMMO (-)]		√	√	√		
Europe/General	CARENS(FJ)	2005	G 1.6 DOHC	ENGINE [Unleaded IMMO (+)]		√	√	√		
Europe/General	CARENS(FJ)	2005	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARENS(FJ)	2005	G 1.6 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARENS(FJ)	2005	G 1.6 DOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CARENS(FJ)	2005	G 1.8 DOHC	ENGINE [Unleaded EURO - 4]		√	√	√		
Europe/General	CARENS(FJ)	2005	G 1.8 DOHC	ENGINE [Unleaded IMMO (+)]		√	√	√		
Europe/General	CARENS(FJ)	2005	G 1.8 DOHC	ENGINE [Unleaded IMMO (-)]		√	√	√		
Europe/General	CARENS(FJ)	2005	G 1.8 DOHC	ENGINE [Leaded All]		√	√	√		
Europe/General	CARENS(FJ)	2005	G 1.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	

Europe/General	CARENS(FJ)	2005	G 1.8 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARENS(FJ)	2005	G 1.8 DOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CARENS(FJ)	2005	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0098
Europe/General	CARENS(FJ)	2005	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0062, 0011, 0098
Europe/General	CARENS(FJ)	2005	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	CARENS(FJ)	2005	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARENS(FJ)	2005	G 2.0 DOHC	IMMO [Immobilizer]				√		
Europe/General	CARENS(FJ)	2004	D 2.0 TCI	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CARENS(FJ)	2004	D 2.0 TCI	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARENS(FJ)	2004	D 2.0 TCI	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARENS(FJ)	2004	D 2.0 TCI	IMMO [Immobilizer]				√		
Europe/General	CARENS(FJ)	2004	G 1.6 DOHC	ENGINE [Unleaded IMMO (-)]		√	√	√		
Europe/General	CARENS(FJ)	2004	G 1.6 DOHC	ENGINE [Unleaded IMMO (+)]		√	√	√		
Europe/General	CARENS(FJ)	2004	G 1.6 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	CARENS(FJ)	2004	G 1.6 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARENS(FJ)	2004	G 1.6 DOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CARENS(FJ)	2004	G 1.8 DOHC	ENGINE [Unleaded EURO - 4]		√	√	√		
Europe/General	CARENS(FJ)	2004	G 1.8 DOHC	ENGINE [Unleaded IMMO (+)]		√	√	√		
Europe/General	CARENS(FJ)	2004	G 1.8 DOHC	ENGINE [Unleaded IMMO (-)]		√	√	√		
Europe/General	CARENS(FJ)	2004	G 1.8 DOHC	ENGINE [Leaded All]		√	√	√		
Europe/General	CARENS(FJ)	2004	G 1.8 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	CARENS(FJ)	2004	G 1.8 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARENS(FJ)	2004	G 1.8 DOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CARENS(FJ)	2003	D 2.0 TCI	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CARENS(FJ)	2003	D 2.0 TCI	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARENS(FJ)	2003	D 2.0 TCI	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARENS(FJ)	2003	D 2.0 TCI	IMMO [Immobilizer]				√		
Europe/General	CARENS(FJ)	2003	G 1.8 DOHC	ENGINE [Unleaded EURO - 4]		√	√	√		
Europe/General	CARENS(FJ)	2003	G 1.8 DOHC	ENGINE [Unleaded IMMO (+)]		√	√	√		
Europe/General	CARENS(FJ)	2003	G 1.8 DOHC	ENGINE [Unleaded IMMO (-)]		√	√	√		
Europe/General	CARENS(FJ)	2003	G 1.8 DOHC	ENGINE [Leaded All]		√	√	√		
Europe/General	CARENS(FJ)	2003	G 1.8 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	CARENS(FJ)	2003	G 1.8 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARENS(FJ)	2003	G 1.8 DOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CARENS(FJ)	2002	G 1.8 DOHC	ENGINE [Engine Control - MT]	√	√	√	√		
Europe/General	CARENS(FJ)	2002	G 1.8 DOHC	ENGINE [Engine Control - AT]	√	√	√	√		
Europe/General	CARENS(FJ)	2002	G 1.8 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	CARENS(FJ)	2001	G 1.8 DOHC	ENGINE [Engine Control - MT]	√	√	√	√		
Europe/General	CARENS(FJ)	2001	G 1.8 DOHC	ENGINE [Engine Control - AT]	√	√	√	√		
Europe/General	CARENS(FJ)	2001	G 1.8 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	CARENS(FJ)	2000	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	CARENS(FJ)	2000	G 1.8 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	CARENS(UN)	2013	D 1.6 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CARENS(UN)	2013	D 1.6 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2013	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	CARENS(UN)	2013	D 1.6 TCI-U2	IMMO [Immobilizer]				√		0075, 0072, 0112, 0075, 0092, 0083, 0119
Europe/General	CARENS(UN)	2013	D 1.6 TCI-U2	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2013	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2013	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CARENS(UN)	2013	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2013	D 2.0 TCI-D	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2013	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2013	D 2.0 TCI-D	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2013	D 2.0 TCI-D	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2013	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2013	D 2.0 TCI-D	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2013	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	CARENS(UN)	2013	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0094, 0098, 0126
Europe/General	CARENS(UN)	2013	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0094, 0098, 0126
Europe/General	CARENS(UN)	2013	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2013	G 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2013	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2013	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2013	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2013	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2013	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2013	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0098, 0126
Europe/General	CARENS(UN)	2013	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0098, 0126
Europe/General	CARENS(UN)	2013	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0098, 0126
Europe/General	CARENS(UN)	2013	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2013	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2013	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2013	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2013	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2013	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2013	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2012	D 1.6 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CARENS(UN)	2012	D 1.6 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2012	D 1.6 TCI-U2	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2012	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2012	D 1.6 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2012	D 1.6 TCI-U2	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2012	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CARENS(UN)	2012	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2012	D 2.0 TCI-D	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2012	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2012	D 2.0 TCI-D	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2012	D 2.0 TCI-D	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2012	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	

Europe/General	CARENS(UN)	2012	D 2.0 TCI-D	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2012	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	CARENS(UN)	2012	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0094, 0098, 0126
Europe/General	CARENS(UN)	2012	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0094, 0098, 0126
Europe/General	CARENS(UN)	2012	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2012	G 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2012	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2012	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2012	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2012	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2012	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2012	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0098, 0126
Europe/General	CARENS(UN)	2012	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0098, 0126
Europe/General	CARENS(UN)	2012	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0098, 0126
Europe/General	CARENS(UN)	2012	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2012	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2012	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2012	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2012	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2012	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2012	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2011	D 1.6 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CARENS(UN)	2011	D 1.6 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2011	D 1.6 TCI-U2	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2011	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2011	D 1.6 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2011	D 1.6 TCI-U2	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2011	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2011	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CARENS(UN)	2011	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2011	D 2.0 TCI-D	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2011	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2011	D 2.0 TCI-D	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2011	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2011	D 2.0 TCI-D	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2011	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	CARENS(UN)	2011	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0094, 0098, 0126
Europe/General	CARENS(UN)	2011	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0094, 0098, 0126
Europe/General	CARENS(UN)	2011	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2011	G 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2011	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2011	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2011	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2011	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2011	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022

Europe/General	CARENS(UN)	2011	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0098, 0126
Europe/General	CARENS(UN)	2011	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0098, 0126
Europe/General	CARENS(UN)	2011	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0098, 0126
Europe/General	CARENS(UN)	2011	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2011	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2011	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2011	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2011	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2011	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2011	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2010	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CARENS(UN)	2010	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2010	D 2.0 TCI-D	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2010	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2010	D 2.0 TCI-D	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2010	D 2.0 TCI-D	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2010	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2010	D 2.0 TCI-D	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2010	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	CARENS(UN)	2010	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0094, 0098, 0126
Europe/General	CARENS(UN)	2010	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0094, 0098, 0126
Europe/General	CARENS(UN)	2010	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2010	G 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2010	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2010	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2010	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2010	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2010	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0098, 0126
Europe/General	CARENS(UN)	2010	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0098, 0126
Europe/General	CARENS(UN)	2010	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0098, 0126
Europe/General	CARENS(UN)	2010	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2010	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2010	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2010	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2010	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2010	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2010	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2009	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CARENS(UN)	2009	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2009	D 2.0 TCI-D	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	CARENS(UN)	2009	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2009	D 2.0 TCI-D	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2009	D 2.0 TCI-D	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2009	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2009	D 2.0 TCI-D	CODE [Transmitter Code Saving]				√		0022

Europe/General	CARENS(UN)	2009	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	CARENS(UN)	2009	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0094, 0098, 0126
Europe/General	CARENS(UN)	2009	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0094, 0098, 0126
Europe/General	CARENS(UN)	2009	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2009	G 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	CARENS(UN)	2009	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2009	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2009	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2009	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2009	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2009	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0098, 0126
Europe/General	CARENS(UN)	2009	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0098, 0126
Europe/General	CARENS(UN)	2009	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0098, 0126
Europe/General	CARENS(UN)	2009	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2009	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	CARENS(UN)	2009	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2009	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2009	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2009	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2009	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2008	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2008	D 2.0 TCI-D	ABSESP [ABS / ESP (MGH - 40)]	√	√	√	√	√	
Europe/General	CARENS(UN)	2008	D 2.0 TCI-D	ABSESP [ABS / ESP (MGH - 25)]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2008	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2008	D 2.0 TCI-D	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2008	D 2.0 TCI-D	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2008	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2008	D 2.0 TCI-D	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2008	G 2.0 DOHC	ENGINE [Leaded]	√	√	√	√	√	0011, 0062, 0094, 0098, 0126
Europe/General	CARENS(UN)	2008	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0098, 0126
Europe/General	CARENS(UN)	2008	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0098, 0126
Europe/General	CARENS(UN)	2008	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2008	G 2.0 DOHC	ABSESP [ABS / ESP (MGH - 40)]	√	√	√	√	√	
Europe/General	CARENS(UN)	2008	G 2.0 DOHC	ABSESP [ABS / ESP (MGH - 25)]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2008	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2008	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2008	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2008	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2008	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2008	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062
Europe/General	CARENS(UN)	2008	G 2.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	CARENS(UN)	2008	G 2.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	CARENS(UN)	2008	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2008	G 2.4 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2008	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090

Europe/General	CARENS(UN)	2008	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2008	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2008	G 2.4 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2008	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2007	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CARENS(UN)	2007	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2007	D 2.0 TCI-D	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2007	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2007	D 2.0 TCI-D	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2007	D 2.0 TCI-D	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2007	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2007	D 2.0 TCI-D	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2007	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0098, 0126
Europe/General	CARENS(UN)	2007	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0098, 0126
Europe/General	CARENS(UN)	2007	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2007	G 2.0 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2007	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2007	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2007	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2007	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2007	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS(UN)	2007	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062
Europe/General	CARENS(UN)	2007	G 2.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	CARENS(UN)	2007	G 2.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	CARENS(UN)	2007	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS(UN)	2007	G 2.4 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	CARENS(UN)	2007	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARENS(UN)	2007	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS(UN)	2007	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARENS(UN)	2007	G 2.4 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CARENS(UN)	2007	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	AT [Double Clutch Transmission]	√	√	√	√		0018, 0021
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			

Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	BSD - R [Blind Spot Detection - Right]	√	√	√	√	√	0012
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	BSD - L [Blind Spot Detection - Left]	√	√	√	√	√	0012
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	0110, 0122, 0125
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2017	D 1.7 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	LDWS [Lane Departure Warning System]	√	√	√	√		0070

Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	BSD - R [Blind Spot Detection - Right]	√	√	√	√	√	0012
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	BSD - L [Blind Spot Detection - Left]	√	√	√	√	√	0012
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	AMP [Amplifier]						0003
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2017	G 1.6 GDI-GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	BSD - R [Blind Spot Detection - Right]	√	√	√	√	√	0012
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	BSD - L [Blind Spot Detection - Left]	√	√	√	√	√	0012
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092

Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	AMP [Amplifier]						0003
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	BCM [Body Control Module]	√	√	√	√	√	0110, 0122, 0125
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 GDI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	ENGINE [Unleaded All]	√	√	√	√		0126, 0011, 0094, 0098
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	ENGINE [Leaded All]	√	√	√	√		0126, 0062, 0011, 0094, 0098
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	BSD - R [Blind Spot Detection - Right]	√	√	√	√	√	0012
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	BSD - L [Blind Spot Detection - Left]	√	√	√	√	√	0012
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	AMP [Amplifier]						0003
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	BCM [Body Control Module]	√	√	√	√	√	0110, 0122, 0125
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	CLU [Cluster Module]	√	√	√	√	√	

Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2017	G 2.0 MPI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS/RONDO(RP)	2016	D 1.7 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	CARENS/RONDO(RP)	2016	D 1.7 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS/RONDO(RP)	2016	D 1.7 TCI-U2	AT [Double Clutch Transmission]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2016	D 1.7 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CARENS/RONDO(RP)	2016	D 1.7 TCI-U2	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	CARENS/RONDO(RP)	2016	D 1.7 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2016	D 1.7 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2016	D 1.7 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2016	D 1.7 TCI-U2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2016	D 1.7 TCI-U2	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	CARENS/RONDO(RP)	2016	D 1.7 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2016	D 1.7 TCI-U2	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	CARENS/RONDO(RP)	2016	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARENS/RONDO(RP)	2016	D 1.7 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARENS/RONDO(RP)	2016	D 1.7 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARENS/RONDO(RP)	2016	D 1.7 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2016	D 1.7 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	0110, 0122, 0125
Europe/General	CARENS/RONDO(RP)	2016	D 1.7 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS/RONDO(RP)	2016	G 1.6 GDI-GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CARENS/RONDO(RP)	2016	G 1.6 GDI-GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS/RONDO(RP)	2016	G 1.6 GDI-GAMMA	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CARENS/RONDO(RP)	2016	G 1.6 GDI-GAMMA	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	CARENS/RONDO(RP)	2016	G 1.6 GDI-GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2016	G 1.6 GDI-GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			

Europe/General	CARENS/RONDO(RP)	2016	G 1.6 GDI-GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2016	G 1.6 GDI-GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2016	G 1.6 GDI-GAMMA	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	CARENS/RONDO(RP)	2016	G 1.6 GDI-GAMMA	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2016	G 1.6 GDI-GAMMA	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	CARENS/RONDO(RP)	2016	G 1.6 GDI-GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARENS/RONDO(RP)	2016	G 1.6 GDI-GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARENS/RONDO(RP)	2016	G 1.6 GDI-GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARENS/RONDO(RP)	2016	G 1.6 GDI-GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2016	G 1.6 GDI-GAMMA	BCM [Body Control Module]	√	√	√	√	√	0110, 0122, 0125
Europe/General	CARENS/RONDO(RP)	2016	G 1.6 GDI-GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2016	G 1.6 GDI-GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 GDI-NU	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 GDI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 GDI-NU	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 GDI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 GDI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 GDI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 GDI-NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 GDI-NU	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 GDI-NU	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 GDI-NU	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 GDI-NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 GDI-NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 GDI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 GDI-NU	CLU [Cluster Module]	√	√	√	√	√	

Europe/General	CARENS/RONDO(RP)	2016	G 2.0 GDI-NU	BCM [Body Control Module]	√	√	√	√	√	0110, 0122, 0125
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 GDI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 GDI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 MPI-NU	ENGINE [Unleaded All]	√	√	√	√		0126, 0011, 0094, 0098
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 MPI-NU	ENGINE [Leaded All]	√	√	√	√		0126, 0062, 0011, 0094, 0098
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 MPI-NU	AT [A6MF1]	√	√	√	√	√	0099
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 MPI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 MPI-NU	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 MPI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 MPI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 MPI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 MPI-NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 MPI-NU	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 MPI-NU	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 MPI-NU	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 MPI-NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 MPI-NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 MPI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 MPI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 MPI-NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2016	G 2.0 MPI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS/RONDO(RP)	2015	D 1.7 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	CARENS/RONDO(RP)	2015	D 1.7 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS/RONDO(RP)	2015	D 1.7 TCI-U2	AT [Double Clutch Transmission]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2015	D 1.7 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CARENS/RONDO(RP)	2015	D 1.7 TCI-U2	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049

Europe/General	CARENS/RONDO(RP)	2015	D 1.7 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2015	D 1.7 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2015	D 1.7 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2015	D 1.7 TCI-U2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2015	D 1.7 TCI-U2	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	CARENS/RONDO(RP)	2015	D 1.7 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2015	D 1.7 TCI-U2	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	CARENS/RONDO(RP)	2015	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARENS/RONDO(RP)	2015	D 1.7 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARENS/RONDO(RP)	2015	D 1.7 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARENS/RONDO(RP)	2015	D 1.7 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2015	D 1.7 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2015	D 1.7 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	0110, 0122, 0125
Europe/General	CARENS/RONDO(RP)	2015	D 1.7 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS/RONDO(RP)	2015	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CARENS/RONDO(RP)	2015	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS/RONDO(RP)	2015	G 1.6 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CARENS/RONDO(RP)	2015	G 1.6 GDI	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	CARENS/RONDO(RP)	2015	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2015	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2015	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2015	G 1.6 GDI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2015	G 1.6 GDI	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	CARENS/RONDO(RP)	2015	G 1.6 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2015	G 1.6 GDI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	CARENS/RONDO(RP)	2015	G 1.6 GDI	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARENS/RONDO(RP)	2015	G 1.6 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARENS/RONDO(RP)	2015	G 1.6 GDI	CLU [Cluster Module]	√	√	√	√	√	

Europe/General	CARENS/RONDO(RP)	2015	G 1.6 GDI	BCM [Body Control Module]	√	√	√	√	√	0110, 0122, 0125
Europe/General	CARENS/RONDO(RP)	2015	G 1.6 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2015	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 GDI	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 GDI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 GDI	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 GDI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 GDI	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 GDI	BCM [Body Control Module]	√	√	√	√	√	0110, 0122, 0125
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 MPI	ENGINE [Unleaded All]	√	√	√	√		0126, 0011, 0094, 0098
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 MPI	ENGINE [Leaded All]	√	√	√	√		0126, 0062, 0011, 0094, 0098
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 MPI	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049

Europe/General	CARENS/RONDO(RP)	2015	G 2.0 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 MPI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 MPI	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 MPI	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 MPI	BCM [Body Control Module]	√	√	√	√	√	0110, 0122, 0125
Europe/General	CARENS/RONDO(RP)	2015	G 2.0 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS/RONDO(RP)	2014	D 1.7 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2014	D 1.7 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS/RONDO(RP)	2014	D 1.7 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CARENS/RONDO(RP)	2014	D 1.7 TCI-U2	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	CARENS/RONDO(RP)	2014	D 1.7 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2014	D 1.7 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2014	D 1.7 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2014	D 1.7 TCI-U2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2014	D 1.7 TCI-U2	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	CARENS/RONDO(RP)	2014	D 1.7 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2014	D 1.7 TCI-U2	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	CARENS/RONDO(RP)	2014	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARENS/RONDO(RP)	2014	D 1.7 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARENS/RONDO(RP)	2014	D 1.7 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102

Europe/General	CARENS/RONDO(RP)	2014	D 1.7 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2014	D 1.7 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	0110, 0122, 0125
Europe/General	CARENS/RONDO(RP)	2014	D 1.7 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2014	D 1.7 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS/RONDO(RP)	2014	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CARENS/RONDO(RP)	2014	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS/RONDO(RP)	2014	G 1.6 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CARENS/RONDO(RP)	2014	G 1.6 GDI	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	CARENS/RONDO(RP)	2014	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2014	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2014	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2014	G 1.6 GDI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2014	G 1.6 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2014	G 1.6 GDI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	CARENS/RONDO(RP)	2014	G 1.6 GDI	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARENS/RONDO(RP)	2014	G 1.6 GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARENS/RONDO(RP)	2014	G 1.6 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARENS/RONDO(RP)	2014	G 1.6 GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2014	G 1.6 GDI	BCM [Body Control Module]	√	√	√	√	√	0110, 0122, 0125
Europe/General	CARENS/RONDO(RP)	2014	G 1.6 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2014	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 GDI	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			

Europe/General	CARENS/RONDO(RP)	2014	G 2.0 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 GDI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 GDI	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 GDI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 GDI	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 GDI	BCM [Body Control Module]	√	√	√	√	√	0110, 0122, 0125
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 MPI	ENGINE [Unleaded All]	√	√	√	√		0126, 0011, 0094, 0098
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 MPI	ENGINE [Leaded All]	√	√	√	√		0126, 0062, 0011, 0094, 0098
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 MPI	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 MPI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 MPI	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 MPI	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 MPI	SJB [Smart Junction Block]	√	√	√	√	√	

Europe/General	CARENS/RONDO(RP)	2014	G 2.0 MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 MPI	BCM [Body Control Module]	√	√	√	√	√	0110, 0122, 0125
Europe/General	CARENS/RONDO(RP)	2014	G 2.0 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(GQ)	2006	D 2.9 TCI-J3	ENGINE [Engine (C / Rail)]	√	√	√	√	√	0028, 0047, 0067
Europe/General	CARNIVAL/SEDONA(GQ)	2006	D 2.9 TCI-J3	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(GQ)	2006	D 2.9 TCI-J3	ABS [ABS (C / Rail)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(GQ)	2006	D 2.9 TCI-J3	ABS [ABS (EURO - 3)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(GQ)	2006	D 2.9 TCI-J3	AIRBAG [Airbag Control]		√	√			
Europe/General	CARNIVAL/SEDONA(GQ)	2006	D 2.9 TCI-J3	IMMO [IMMO (C / Rail)]				√		0075, 0083, 0092, 0119
Europe/General	CARNIVAL/SEDONA(GQ)	2006	G 2.5 DOHC	ENGINE [General KV6]		√	√	√	√	0062
Europe/General	CARNIVAL/SEDONA(GQ)	2006	G 2.5 DOHC	ENGINE [EURO - 3]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(GQ)	2006	G 2.5 DOHC	ENGINE [Gasoline KV6]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(GQ)	2006	G 2.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(GQ)	2006	G 2.5 DOHC	ABS [ABS (EURO - 3)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(GQ)	2006	G 2.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(GQ)	2006	G 2.5 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	CARNIVAL/SEDONA(GQ)	2006	G 2.5 DOHC	IMMO [Bosch Smartra]				√		0075, 0083, 0092, 0119
Europe/General	CARNIVAL/SEDONA(GQ)	2006	G 3.5 DOHC	ENGINE [Engine (China)]	√	√	√	√	√	0063
Europe/General	CARNIVAL/SEDONA(GQ)	2006	G 3.5 DOHC	ENGINE [Engine (M / East)]	√	√	√	√	√	0063
Europe/General	CARNIVAL/SEDONA(GQ)	2006	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(GQ)	2006	G 3.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(GQ)	2006	G 3.5 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	CARNIVAL/SEDONA(GQ)	2006	G 3.5 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	CARNIVAL/SEDONA(GQ)	2005	D 2.9 TCI-J3	ENGINE [Engine (C / Rail)]	√	√	√	√	√	0028, 0047, 0067

Europe/General	CARNIVAL/SEDONA(G Q)	2005	D 2.9 TCI-J3	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2005	D 2.9 TCI-J3	ABS [ABS (C / Rail)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2005	D 2.9 TCI-J3	AIRBAG [Airbag Control]		√	√			
Europe/General	CARNIVAL/SEDONA(G Q)	2005	D 2.9 TCI-J3	IMMO [IMMO (C / Rail)]				√		0075, 0083, 0092, 0119
Europe/General	CARNIVAL/SEDONA(G Q)	2005	G 2.5 DOHC	ENGINE [General]		√	√	√	√	0062
Europe/General	CARNIVAL/SEDONA(G Q)	2005	G 2.5 DOHC	ENGINE [EURO - 3]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(G Q)	2005	G 2.5 DOHC	ENGINE [Gasoline]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2005	G 2.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2005	G 2.5 DOHC	ABS [ABS (EURO - 3)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2005	G 2.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2005	G 2.5 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	CARNIVAL/SEDONA(G Q)	2005	G 2.5 DOHC	IMMO [Bosch Smatra]				√		0075, 0083, 0092, 0119
Europe/General	CARNIVAL/SEDONA(G Q)	2005	G 3.5 DOHC	ENGINE [Engine (China)]	√	√	√	√	√	0063
Europe/General	CARNIVAL/SEDONA(G Q)	2005	G 3.5 DOHC	ENGINE [Engine (M / East)]	√	√	√	√	√	0063
Europe/General	CARNIVAL/SEDONA(G Q)	2005	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2005	G 3.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2005	G 3.5 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	CARNIVAL/SEDONA(G Q)	2005	G 3.5 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	CARNIVAL/SEDONA(G Q)	2004	D 2.9 TCI-J3	ENGINE [Engine (C / Rail)]	√	√	√	√	√	0028, 0047, 0067
Europe/General	CARNIVAL/SEDONA(G Q)	2004	D 2.9 TCI-J3	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2004	D 2.9 TCI-J3	ABS [ABS (C / Rail)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2004	D 2.9 TCI-J3	ABS [ABS (EURO - 3)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2004	D 2.9 TCI-J3	AIRBAG [Airbag Control]		√	√			
Europe/General	CARNIVAL/SEDONA(G Q)	2004	D 2.9 TCI-J3	IMMO [IMMO (C / Rail)]				√		0075, 0083, 0092, 0119

Europe/General	CARNIVAL/SEDONA(G Q)	2004	G 2.5 DOHC	ENGINE [General]		√	√	√	√	0062
Europe/General	CARNIVAL/SEDONA(G Q)	2004	G 2.5 DOHC	ENGINE [EURO - 3]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(G Q)	2004	G 2.5 DOHC	ENGINE [Gasoline]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2004	G 2.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2004	G 2.5 DOHC	ABS [ABS (EURO - 3)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2004	G 2.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2004	G 2.5 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	CARNIVAL/SEDONA(G Q)	2004	G 2.5 DOHC	IMMO [Bosch Smartra]				√		0075, 0083, 0092, 0119
Europe/General	CARNIVAL/SEDONA(G Q)	2004	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0063
Europe/General	CARNIVAL/SEDONA(G Q)	2004	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2004	G 3.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2004	G 3.5 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	CARNIVAL/SEDONA(G Q)	2004	G 3.5 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	CARNIVAL/SEDONA(G Q)	2003	D 2.9 TCI-J3	ENGINE [Engine (C / Rail)]	√	√	√	√	√	0028, 0047, 0067
Europe/General	CARNIVAL/SEDONA(G Q)	2003	D 2.9 TCI-J3	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2003	D 2.9 TCI-J3	ABS [ABS (C / Rail)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2003	D 2.9 TCI-J3	ABS [ABS (EURO - 3)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2003	D 2.9 TCI-J3	IMMO [IMMO (C / Rail)]				√		0075, 0083, 0092, 0119
Europe/General	CARNIVAL/SEDONA(G Q)	2003	G 2.4 DOHC	ENGINE [Engine Control]		√	√	√	√	0062
Europe/General	CARNIVAL/SEDONA(G Q)	2003	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2003	G 2.4 DOHC	ABS [ABS (EURO - 3)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2003	G 2.4 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2003	G 2.4 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	CARNIVAL/SEDONA(G Q)	2003	G 2.4 DOHC	IMMO [Bosch Smartra]				√		0075, 0083, 0092, 0119

Europe/General	CARNIVAL/SEDONA(G Q)	2003	G 2.5 DOHC	ENGINE [General]		√	√	√	√	0062
Europe/General	CARNIVAL/SEDONA(G Q)	2003	G 2.5 DOHC	ENGINE [EURO - 3]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(G Q)	2003	G 2.5 DOHC	ENGINE [Gasoline]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2003	G 2.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2003	G 2.5 DOHC	ABS [ABS (EURO - 3)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2003	G 2.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2003	G 2.5 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	CARNIVAL/SEDONA(G Q)	2003	G 2.5 DOHC	IMMO [Bosch Smartra]				√		0075, 0083, 0092, 0119
Europe/General	CARNIVAL/SEDONA(G Q)	2003	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0063
Europe/General	CARNIVAL/SEDONA(G Q)	2003	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2003	G 3.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2003	G 3.5 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	CARNIVAL/SEDONA(G Q)	2003	G 3.5 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	CARNIVAL/SEDONA(G Q)	2002	D 2.9 TCI-J3	ENGINE [Engine (C / Rail)]	√	√	√	√	√	0028, 0047, 0067
Europe/General	CARNIVAL/SEDONA(G Q)	2002	D 2.9 TCI-J3	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2002	D 2.9 TCI-J3	ABS [ABS (C / Rail)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2002	D 2.9 TCI-J3	ABS [ABS (EURO - 3)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2002	D 2.9 TCI-J3	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2002	D 2.9 TCI-J3	AIRBAG [Airbag Control]		√	√			
Europe/General	CARNIVAL/SEDONA(G Q)	2002	D 2.9 TCI-J3	IMMO [IMMO (C / Rail)]				√		0075, 0083, 0092, 0119
Europe/General	CARNIVAL/SEDONA(G Q)	2002	G 2.4 DOHC	ENGINE [Engine Control]		√	√	√	√	0062
Europe/General	CARNIVAL/SEDONA(G Q)	2002	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2002	G 2.4 DOHC	ABS [ABS (C / Rail)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2002	G 2.4 DOHC	ABS [ABS (EURO - 3)]		√	√	√	√	0051

Europe/General	CARNIVAL/SEDONA(G Q)	2002	G 2.4 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2002	G 2.4 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	CARNIVAL/SEDONA(G Q)	2002	G 2.4 DOHC	IMMO [IMMO (Bosch)]				√		0075, 0083, 0092, 0119
Europe/General	CARNIVAL/SEDONA(G Q)	2002	G 2.5 DOHC	ENGINE [General]		√	√	√	√	0062
Europe/General	CARNIVAL/SEDONA(G Q)	2002	G 2.5 DOHC	ENGINE [EURO - 3]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(G Q)	2002	G 2.5 DOHC	ENGINE [Europe]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2002	G 2.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2002	G 2.5 DOHC	ABS [ABS (C / Rail)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2002	G 2.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2002	G 2.5 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	CARNIVAL/SEDONA(G Q)	2002	G 2.5 DOHC	IMMO [IMMO (Bosch)]				√		0075, 0083, 0092, 0119
Europe/General	CARNIVAL/SEDONA(G Q)	2001	D 2.9 TCI-J3	AT [A / T (Europe)]		√	√	√		
Europe/General	CARNIVAL/SEDONA(G Q)	2001	D 2.9 TCI-J3	AT [A / T (General)]		√	√	√		
Europe/General	CARNIVAL/SEDONA(G Q)	2001	D 2.9 TCI-J3	ABS [ABS (General)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2001	D 2.9 TCI-J3	ABS [ABS (Europe)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2001	D 2.9 TCI-J3	AIRBAG [Airbag (General)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(G Q)	2001	D 2.9 TCI-J3	AIRBAG [Airbag (Europe)]		√	√	√		
Europe/General	CARNIVAL/SEDONA(G Q)	2001	G 2.5 DOHC	ENGINE [Engine (General)]		√	√	√	√	0062
Europe/General	CARNIVAL/SEDONA(G Q)	2001	G 2.5 DOHC	ENGINE [Engine (Europe)]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2001	G 2.5 DOHC	AT [A / T (Europe)]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2001	G 2.5 DOHC	AT [A / T (General)]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2001	G 2.5 DOHC	ABS [ABS (General)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2001	G 2.5 DOHC	ABS [ABS (Europe)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2001	G 2.5 DOHC	AIRBAG [Airbag (General)]	√	√	√			

Europe/General	CARNIVAL/SEDONA(G Q)	2001	G 2.5 DOHC	AIRBAG [Airbag (Europe)]		√	√	√		
Europe/General	CARNIVAL/SEDONA(G Q)	2000	D 2.9 TCI-J3	AT [A / T (Europe)]		√	√	√		
Europe/General	CARNIVAL/SEDONA(G Q)	2000	D 2.9 TCI-J3	AT [A / T (General)]		√	√	√		
Europe/General	CARNIVAL/SEDONA(G Q)	2000	D 2.9 TCI-J3	ABS [ABS (General)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2000	D 2.9 TCI-J3	ABS [ABS (Europe)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2000	D 2.9 TCI-J3	AIRBAG [Airbag (General)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(G Q)	2000	D 2.9 TCI-J3	AIRBAG [Airbag (Europe)]		√	√	√		
Europe/General	CARNIVAL/SEDONA(G Q)	2000	G 2.5 DOHC	ENGINE [Engine (General)]		√	√	√	√	0062
Europe/General	CARNIVAL/SEDONA(G Q)	2000	G 2.5 DOHC	ENGINE [Engine (Europe)]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2000	G 2.5 DOHC	AT [A / T (Europe)]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2000	G 2.5 DOHC	AT [A / T (General)]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	2000	G 2.5 DOHC	ABS [ABS (General)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2000	G 2.5 DOHC	ABS [ABS (Europe)]		√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(G Q)	2000	G 2.5 DOHC	AIRBAG [Airbag (General)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(G Q)	2000	G 2.5 DOHC	AIRBAG [Airbag (Europe)]		√	√	√		
Europe/General	CARNIVAL/SEDONA(G Q)	1999	D 2.9 TCI-J3	AT [A / T (Europe)]		√	√	√		
Europe/General	CARNIVAL/SEDONA(G Q)	1999	D 2.9 TCI-J3	AT [A / T (General)]		√	√	√		
Europe/General	CARNIVAL/SEDONA(G Q)	1999	G 2.5 DOHC	ENGINE [Engine (General)]		√	√	√	√	0062
Europe/General	CARNIVAL/SEDONA(G Q)	1999	G 2.5 DOHC	ENGINE [Engine (Europe)]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	1999	G 2.5 DOHC	AT [A / T (Europe)]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	1999	G 2.5 DOHC	AT [A / T (General)]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	1998	D 2.9 TCI-J3	AT [A / T (Europe)]		√	√	√		
Europe/General	CARNIVAL/SEDONA(G Q)	1998	D 2.9 TCI-J3	AT [A / T (General)]		√	√	√		
Europe/General	CARNIVAL/SEDONA(G Q)	1998	G 2.5 DOHC	ENGINE [Engine (Europe)]		√	√	√	√	

Europe/General	CARNIVAL/SEDONA(G Q)	1998	G 2.5 DOHC	AT [A / T (Europe)]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(G Q)	1998	G 2.5 DOHC	AT [A / T (General)]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.2 TCI-R	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	0048
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.2 TCI-R	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	0048
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.2 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.2 TCI-R	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.2 TCI-R	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.2 TCI-R	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.2 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.2 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.2 TCI-R	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.2 TCI-R	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.2 TCI-R	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.2 TCI-R	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.2 TCI-R	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.2 TCI-R	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.2 TCI-R	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.2 TCI-R	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.2 TCI-R	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.2 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.9 VGT	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.9 VGT	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.9 VGT	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.9 VGT	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051

Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 VGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 VGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 VGT	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 VGT	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 VGT	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 VGT	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 VGT	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 VGT	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 VGT	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 VGT	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 VGT	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 VGT	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 VGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 VGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 WGT	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 WGT	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 WGT	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 WGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 WGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 WGT	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 WGT	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 WGT	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 WGT	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	D 2.9 WGT	ADM [Assist Door Module]		√	√	√	√	

Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.9 WGT	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.9 WGT	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.9 WGT	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.9 WGT	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.9 WGT	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.9 WGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2014	D 2.9 WGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(V Q)	2014	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(V Q)	2014	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(V Q)	2014	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094
Europe/General	CARNIVAL/SEDONA(V Q)	2014	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(V Q)	2014	G 2.7 DOHC	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2014	G 2.7 DOHC	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2014	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(V Q)	2014	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2014	G 2.7 DOHC	IMMO [Immobilizer]				√		0075, 0072, 0112, 0075, 0092, 0083, 0119
Europe/General	CARNIVAL/SEDONA(V Q)	2014	G 2.7 DOHC	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2014	G 2.7 DOHC	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2014	G 2.7 DOHC	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2014	G 2.7 DOHC	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2014	G 2.7 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2014	G 2.7 DOHC	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2014	G 2.7 DOHC	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2014	G 2.7 DOHC	PSD - R [Power Sliding Door - Right]	√	√	√	√		

Europe/General	CARNIVAL/SEDONA(VQ)	2014	G 2.7 DOHC	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2014	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2014	G 3.5 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2014	G 3.5 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2014	G 3.5 DOHC	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2014	G 3.5 DOHC	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2014	G 3.5 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2014	G 3.5 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	G 3.5 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(VQ)	2014	G 3.5 DOHC	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	G 3.5 DOHC	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	G 3.5 DOHC	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	G 3.5 DOHC	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	G 3.5 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	G 3.5 DOHC	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2014	G 3.5 DOHC	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2014	G 3.5 DOHC	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2014	G 3.5 DOHC	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2014	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.2 TCI-R	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	0048
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.2 TCI-R	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	0048
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.2 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.2 TCI-R	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.2 TCI-R	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051

Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.2 TCI-R	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.2 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.2 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.2 TCI-R	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.2 TCI-R	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.2 TCI-R	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.2 TCI-R	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.2 TCI-R	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.2 TCI-R	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.2 TCI-R	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.2 TCI-R	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.2 TCI-R	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.2 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 VGT	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 VGT	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 VGT	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 VGT	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 VGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 VGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 VGT	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 VGT	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 VGT	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 VGT	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 VGT	IMS [Integrated Memory System]		√	√	√	√	

Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 VGT	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 VGT	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 VGT	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 VGT	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 VGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 VGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 WGT	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 WGT	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 WGT	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 WGT	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 WGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 WGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 WGT	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 WGT	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 WGT	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 WGT	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 WGT	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 WGT	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 WGT	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 WGT	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 WGT	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 WGT	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 WGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	D 2.9 WGT	CODE [Transmitter Code Saving]				√		0022

Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 2.7 DOHC	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 2.7 DOHC	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 2.7 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 2.7 DOHC	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 2.7 DOHC	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 2.7 DOHC	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 2.7 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 2.7 DOHC	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 2.7 DOHC	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 2.7 DOHC	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 2.7 DOHC	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 3.5 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 3.5 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 3.5 DOHC	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 3.5 DOHC	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 3.5 DOHC	AIRBAG [Airbag Control]	√	√	√			0090

Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 3.5 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 3.5 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 3.5 DOHC	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 3.5 DOHC	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 3.5 DOHC	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 3.5 DOHC	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 3.5 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 3.5 DOHC	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 3.5 DOHC	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 3.5 DOHC	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 3.5 DOHC	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2013	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.2 TCI-R	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	0048
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.2 TCI-R	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	0048
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.2 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.2 TCI-R	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.2 TCI-R	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.2 TCI-R	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.2 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.2 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.2 TCI-R	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.2 TCI-R	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.2 TCI-R	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.2 TCI-R	ADM [Assist Door Module]		√	√	√	√	

Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.2 TCI-R	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.2 TCI-R	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.2 TCI-R	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.2 TCI-R	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.2 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.9 VGT	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.9 VGT	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.9 VGT	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.9 VGT	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.9 VGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.9 VGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.9 VGT	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.9 VGT	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.9 VGT	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.9 VGT	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.9 VGT	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.9 VGT	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.9 VGT	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.9 VGT	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.9 VGT	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.9 VGT	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.9 VGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.9 VGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2012	D 2.9 WGT	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067

Europe/General	CARNIVAL/SEDONA(V Q)	2012	D 2.9 WGT	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2012	D 2.9 WGT	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2012	D 2.9 WGT	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2012	D 2.9 WGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(V Q)	2012	D 2.9 WGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2012	D 2.9 WGT	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CARNIVAL/SEDONA(V Q)	2012	D 2.9 WGT	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2012	D 2.9 WGT	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2012	D 2.9 WGT	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2012	D 2.9 WGT	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2012	D 2.9 WGT	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2012	D 2.9 WGT	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2012	D 2.9 WGT	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2012	D 2.9 WGT	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2012	D 2.9 WGT	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2012	D 2.9 WGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2012	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(V Q)	2012	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(V Q)	2012	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094
Europe/General	CARNIVAL/SEDONA(V Q)	2012	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(V Q)	2012	G 2.7 DOHC	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2012	G 2.7 DOHC	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2012	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(V Q)	2012	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 2.7 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 2.7 DOHC	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 2.7 DOHC	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 2.7 DOHC	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 2.7 DOHC	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 2.7 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 2.7 DOHC	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 2.7 DOHC	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 2.7 DOHC	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 2.7 DOHC	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 3.5 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 3.5 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 3.5 DOHC	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 3.5 DOHC	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 3.5 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 3.5 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 3.5 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 3.5 DOHC	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 3.5 DOHC	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 3.5 DOHC	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 3.5 DOHC	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 3.5 DOHC	IMS [Integrated Memory System]		√	√	√	√	

Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 3.5 DOHC	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 3.5 DOHC	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 3.5 DOHC	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 3.5 DOHC	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2012	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.2 TCI-R	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	0048
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.2 TCI-R	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	0048
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.2 TCI-R	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.2 TCI-R	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.2 TCI-R	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.2 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.2 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.2 TCI-R	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.2 TCI-R	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.2 TCI-R	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.2 TCI-R	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.2 TCI-R	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.2 TCI-R	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.2 TCI-R	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.2 TCI-R	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.2 TCI-R	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.2 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 VGT	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 VGT	AT [Automatic Transaxle]	√	√	√	√	√	0099

Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 VGT	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 VGT	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 VGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 VGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 VGT	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 VGT	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 VGT	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 VGT	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 VGT	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 VGT	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 VGT	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 VGT	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 VGT	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 VGT	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 VGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 VGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 WGT	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 WGT	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 WGT	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 WGT	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 WGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 WGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 WGT	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 WGT	FAM [Front Area Module]		√	√	√	√	

Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 WGT	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 WGT	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 WGT	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 WGT	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 WGT	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 WGT	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 WGT	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 WGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	D 2.9 WGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 2.7 DOHC	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 2.7 DOHC	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 2.7 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 2.7 DOHC	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 2.7 DOHC	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 2.7 DOHC	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 2.7 DOHC	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 2.7 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 2.7 DOHC	IPM [Instrument Panel Module]		√	√	√	√	

Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 2.7 DOHC	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 2.7 DOHC	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 2.7 DOHC	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 3.5 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 3.5 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 3.5 DOHC	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 3.5 DOHC	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 3.5 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 3.5 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 3.5 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 3.5 DOHC	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 3.5 DOHC	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 3.5 DOHC	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 3.5 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 3.5 DOHC	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 3.5 DOHC	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 3.5 DOHC	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 3.5 DOHC	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2011	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2010	D 2.2 TCI-R	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	0048
Europe/General	CARNIVAL/SEDONA(VQ)	2010	D 2.2 TCI-R	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	0048
Europe/General	CARNIVAL/SEDONA(VQ)	2010	D 2.2 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099

Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.2 TCI-R	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.2 TCI-R	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.2 TCI-R	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.2 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.2 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.2 TCI-R	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.2 TCI-R	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.2 TCI-R	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.2 TCI-R	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.2 TCI-R	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.2 TCI-R	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.2 TCI-R	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.2 TCI-R	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.2 TCI-R	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.2 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 VGT	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 VGT	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 VGT	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 VGT	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 VGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 VGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 VGT	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 VGT	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 VGT	FAM [Front Area Module]		√	√	√	√	

Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 VGT	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 VGT	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 VGT	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 VGT	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 VGT	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 VGT	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 VGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 VGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 WGT	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 WGT	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 WGT	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 WGT	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 WGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 WGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 WGT	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 WGT	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 WGT	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 WGT	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 WGT	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 WGT	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 WGT	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 WGT	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 WGT	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 WGT	PTG [Power Tail Gate]	√	√	√	√		

Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 WGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	D 2.9 WGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 2.7 DOHC	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 2.7 DOHC	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 2.7 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 2.7 DOHC	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 2.7 DOHC	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 2.7 DOHC	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 2.7 DOHC	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 2.7 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 2.7 DOHC	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 2.7 DOHC	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 2.7 DOHC	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 3.8 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094
Europe/General	CARNIVAL/SEDONA(V Q)	2010	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099

Europe/General	CARNIVAL/SEDONA(VQ)	2010	G 3.8 DOHC	ABSESP [ABS (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2010	G 3.8 DOHC	ABSESP [ESP (MEB - 2)]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2010	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2010	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2010	G 3.8 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(VQ)	2010	G 3.8 DOHC	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2010	G 3.8 DOHC	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2010	G 3.8 DOHC	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2010	G 3.8 DOHC	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2010	G 3.8 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2010	G 3.8 DOHC	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2010	G 3.8 DOHC	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2010	G 3.8 DOHC	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2010	G 3.8 DOHC	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2010	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2009	D 2.9 VGT	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	CARNIVAL/SEDONA(VQ)	2009	D 2.9 VGT	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(VQ)	2009	D 2.9 VGT	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2009	D 2.9 VGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2009	D 2.9 VGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2009	D 2.9 VGT	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(VQ)	2009	D 2.9 VGT	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2009	D 2.9 VGT	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2009	D 2.9 VGT	RAM [Rear Area Module]		√	√	√	√	

Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 VGT	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 VGT	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 VGT	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 VGT	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 VGT	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 VGT	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 VGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 VGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 WGT	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 WGT	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 WGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 WGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 WGT	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 WGT	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 WGT	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 WGT	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 WGT	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 WGT	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 WGT	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 WGT	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 WGT	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 WGT	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 WGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	D 2.9 WGT	CODE [Transmitter Code Saving]				√		0022

Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 2.7 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 2.7 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 2.7 DOHC	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 2.7 DOHC	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 2.7 DOHC	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 2.7 DOHC	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 2.7 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 2.7 DOHC	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 2.7 DOHC	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 2.7 DOHC	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 2.7 DOHC	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 3.8 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 3.8 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2009	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			0090

Europe/General	CARNIVAL/SEDONA(VQ)	2009	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2009	G 3.8 DOHC	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2009	G 3.8 DOHC	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2009	G 3.8 DOHC	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2009	G 3.8 DOHC	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2009	G 3.8 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2009	G 3.8 DOHC	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2009	G 3.8 DOHC	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2009	G 3.8 DOHC	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2009	G 3.8 DOHC	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2009	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 VGT	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 VGT	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 VGT	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 VGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 VGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 VGT	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 VGT	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 VGT	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 VGT	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 VGT	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 VGT	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 VGT	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 VGT	PSD - L [Power Sliding Door - Left]	√	√	√	√		

Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 VGT	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 VGT	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 VGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 VGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 WGT	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 WGT	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 WGT	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 WGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 WGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 WGT	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 WGT	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 WGT	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 WGT	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 WGT	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 WGT	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 WGT	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 WGT	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 WGT	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 WGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	D 2.9 WGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099

Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 2.7 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 2.7 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 2.7 DOHC	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 2.7 DOHC	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 2.7 DOHC	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 2.7 DOHC	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 2.7 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 2.7 DOHC	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 2.7 DOHC	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 2.7 DOHC	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 2.7 DOHC	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 3.8 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 3.8 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 3.8 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 3.8 DOHC	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 3.8 DOHC	RAM [Rear Area Module]		√	√	√	√	

Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 3.8 DOHC	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 3.8 DOHC	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 3.8 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 3.8 DOHC	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 3.8 DOHC	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 3.8 DOHC	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2008	G 3.8 DOHC	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 VGT	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 VGT	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 VGT	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 VGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 VGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 VGT	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 VGT	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 VGT	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 VGT	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 VGT	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 VGT	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 VGT	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 VGT	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 VGT	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 VGT	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 VGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 VGT	CODE [Transmitter Code Saving]				√		0022

Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 WGT	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 WGT	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 WGT	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 WGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 WGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 WGT	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 WGT	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 WGT	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 WGT	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 WGT	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 WGT	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 WGT	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 WGT	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 WGT	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 WGT	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 WGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	D 2.9 WGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 2.7 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 2.7 DOHC	IMMO [Immobilizer]				√		

Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 2.7 DOHC	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 2.7 DOHC	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 2.7 DOHC	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 2.7 DOHC	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 2.7 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 2.7 DOHC	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 2.7 DOHC	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 2.7 DOHC	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 2.7 DOHC	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 3.8 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 3.8 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 3.8 DOHC	IMMO [Immobilizer]				√		
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 3.8 DOHC	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 3.8 DOHC	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 3.8 DOHC	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 3.8 DOHC	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 3.8 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 3.8 DOHC	IPM [Instrument Panel Module]		√	√	√	√	

Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 3.8 DOHC	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 3.8 DOHC	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 3.8 DOHC	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2007	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 VGT	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 VGT	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 VGT	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 VGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 VGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 VGT	IMMO [Immobilizer]				√		
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 VGT	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 VGT	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 VGT	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 VGT	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 VGT	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 VGT	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 VGT	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 VGT	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 VGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 VGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 WGT	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 WGT	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 WGT	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2006	D 2.9 WGT	AIRBAG [Airbag Control]	√	√	√			0090

Europe/General	CARNIVAL/SEDONA(V Q)	2006	D 2.9 WGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2006	D 2.9 WGT	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CARNIVAL/SEDONA(V Q)	2006	D 2.9 WGT	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2006	D 2.9 WGT	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2006	D 2.9 WGT	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2006	D 2.9 WGT	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2006	D 2.9 WGT	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2006	D 2.9 WGT	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2006	D 2.9 WGT	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2006	D 2.9 WGT	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2006	D 2.9 WGT	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(V Q)	2006	D 2.9 WGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2006	D 2.9 WGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(V Q)	2006	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2006	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2006	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2006	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2006	G 2.7 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(V Q)	2006	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(V Q)	2006	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2006	G 2.7 DOHC	IMMO [Immobilizer]				√		
Europe/General	CARNIVAL/SEDONA(V Q)	2006	G 2.7 DOHC	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2006	G 2.7 DOHC	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(V Q)	2006	G 2.7 DOHC	DDM [Driver Door Module]		√	√	√	√	

Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 2.7 DOHC	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 2.7 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 2.7 DOHC	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 2.7 DOHC	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 2.7 DOHC	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 3.8 DOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 3.8 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 3.8 DOHC	IMMO [Immobilizer]				√		
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 3.8 DOHC	FAM [Front Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 3.8 DOHC	RAM [Rear Area Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 3.8 DOHC	DDM [Driver Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 3.8 DOHC	ADM [Assist Door Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 3.8 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 3.8 DOHC	IPM [Instrument Panel Module]		√	√	√	√	
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 3.8 DOHC	PSD - L [Power Sliding Door - Left]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 3.8 DOHC	PSD - R [Power Sliding Door - Right]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 3.8 DOHC	PTG [Power Tail Gate]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(VQ)	2006	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022

Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	ENGINE [Engine Control]	√	√	√	√		0029, 0126, 0029, 0060, 0126, 0094, 0048
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	AEB [Autonomous Emergency Braking System]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	AIRCON [Dual Auto Temperature Control (DATC)]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	BSD - R [Blind Spot Detection - R]	√	√	√	√	√	0012
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	BSD - L [Blind Spot Detection - L]	√	√	√	√	√	0012
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	AHS [Active Hood System]	√	√	√		√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	AMP [Amplifier]						0003
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	PSD [Power Sliding Door]	√	√	√	√		

Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	ECALL [e - Call]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2017	D 2.2 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	ENGINE [Engine Control]		√	√			0011, 0043, 0094, 0126
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	AEB [Autonomous Emergency Braking System]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	AIRCON [Dual Auto Temperature Control (DATC)]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	BSD - R [Blind Spot Detection - R]	√	√	√	√	√	0012
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	BSD - L [Blind Spot Detection - L]	√	√	√	√	√	0012
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	AHS [Active Hood System]	√	√	√		√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	AMP [Amplifier]						0003
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	CLU [Cluster Module]	√	√	√	√	√	

Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	PSD [Power Sliding Door]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	ECALL [e - Call]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 GDI LAMBDA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	ENGINE [Engine Control]		√	√			0011, 0043, 0094, 0126
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	AEB [Autonomous Emergency Braking System]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	BSD - R [Blind Spot Detection - R]	√	√	√	√	√	0012
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	BSD - L [Blind Spot Detection - L]	√	√	√	√	√	0012
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	AHS [Active Hood System]	√	√	√		√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	AMP [Amplifier]						0003
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	ADM [Assist Door Module]	√	√	√	√	√	

Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	PSD [Power Sliding Door]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	CARNIVAL/SEDONA(Y P)	2017	G 3.3 MPI LAMBDA II	ECALL [e - Call]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	ENGINE [Engine Control]	√	√	√	√		0029, 0126, 0029, 0060, 0126, 0094, 0048
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	AIRCON [Dual Auto Temperature Control (DATC)]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	BSD - R [Blind Spot Detection - R]	√	√	√	√	√	0012
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	LDWS [Lane Departure Warning System]	√	√	√	√		0104
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	BSD - L [Blind Spot Detection - L]	√	√	√	√	√	0012
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	AHS [Active Hood System]	√	√	√		√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102

Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	AMP [Amplifier]						0003
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	PSD [Power Sliding Door]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	CARNIVAL/SEDONA(Y P)	2016	D 2.2 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	ENGINE [Engine Control]		√	√			0011, 0043, 0094, 0126
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	AIRCON [Dual Auto Temperature Control (DATC)]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	BSD - R [Blind Spot Detection - R]	√	√	√	√	√	0012
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	LDWS [Lane Departure Warning System]	√	√	√	√		0104
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	BSD - L [Blind Spot Detection - L]	√	√	√	√	√	0012
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	AHS [Active Hood System]	√	√	√		√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092

Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	AMP [Amplifier]						0003
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	PSD [Power Sliding Door]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 GDI LAMBDA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	ENGINE [Engine Control]		√	√			0011, 0043, 0094, 0126
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	AIRCON [Dual Auto Temperature Control (DATC)]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	BSD - R [Blind Spot Detection - R]	√	√	√	√	√	0012
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	LDWS [Lane Departure Warning System]	√	√	√	√		0104
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	BSD - L [Blind Spot Detection - L]	√	√	√	√	√	0012
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	AHS [Active Hood System]	√	√	√		√	

Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	AMP [Amplifier]						0003
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	PSD [Power Sliding Door]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	CARNIVAL/SEDONA(Y P)	2016	G 3.3 MPI LAMBDA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	ENGINE [Engine Control]	√	√	√	√		0029, 0126, 0029, 0060, 0126, 0094, 0048
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	AIRCON [Dual Auto Temperature Control (DATC)]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	BSD - R [Blind Spot Detection - R]	√	√	√	√	√	0012
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	LDWS [Lane Departure Warning System]	√	√	√	√		0104
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	BSD - L [Blind Spot Detection - L]	√	√	√	√	√	0012
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055

Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	AHS [Active Hood System]	√	√	√		√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	AMP [Amplifier]						0003
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	PSD [Power Sliding Door]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	CARNIVAL/SEDONA(Y P)	2015	D 2.2 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	ENGINE [Engine Control]		√	√			0011, 0043, 0094, 0126
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	AIRCON [Dual Auto Temperature Control (DATC)]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	BSD - R [Blind Spot Detection - R]	√	√	√	√	√	0012
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	LDWS [Lane Departure Warning System]	√	√	√	√		0104
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	BSD - L [Blind Spot Detection - L]	√	√	√	√	√	0012

Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	AHS [Active Hood System]	√	√	√		√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	AMP [Amplifier]						0003
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	PSD [Power Sliding Door]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 GDI LAMBDA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	ENGINE [Engine Control]		√	√			0011, 0043, 0094, 0126
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	AIRCON [Dual Auto Temperature Control (DATC)]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	BSD - R [Blind Spot Detection - R]	√	√	√	√	√	0012
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	LDWS [Lane Departure Warning System]	√	√	√	√		0104

Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	BSD - L [Blind Spot Detection - L]	√	√	√	√	√	0012
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	AMP [Amplifier]						0003
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	PSD [Power Sliding Door]	√	√	√	√		
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	CARNIVAL/SEDONA(Y P)	2015	G 3.3 MPI LAMBDA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2013	D 1.6 TCI-U2	ENGINE [ISG (+) / CPF (-)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2013	D 1.6 TCI-U2	ENGINE [ISG (+) / CPF (+)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2013	D 1.6 TCI-U2	ENGINE [ISG (-) / CPF (+)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2013	D 1.6 TCI-U2	ENGINE [ISG (-) / CPF (-)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2013	D 1.6 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2013	D 1.6 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2013	D 1.6 TCI-U2	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2013	D 1.6 TCI-U2	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2013	D 1.6 TCI-U2	AIRCON [Air Conditioner (Single)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2013	D 1.6 TCI-U2	EPS [Electronic Power Steering]	√	√	√	√		0004
Europe/General	Cee'd(ED)	2013	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2013	D 1.6 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2013	D 1.6 TCI-U2	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2013	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2013	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2013	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2013	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2013	D 2.0 TCI-D	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2013	D 2.0 TCI-D	AIRCON [Air Conditioner (Single)]	√	√	√	√	√	

Europe/General	Cee'd(ED)	2013	D 2.0 TCI-D	EPS [Electronic Power Steering]	√	√	√	√		0004
Europe/General	Cee'd(ED)	2013	D 2.0 TCI-D	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2013	D 2.0 TCI-D	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2013	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2013	D 2.0 TCI-D	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2013	G 1.4 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(ED)	2013	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2013	G 1.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2013	G 1.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2013	G 1.4 DOHC	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2013	G 1.4 DOHC	AIRCON [Air Conditioner (Single)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2013	G 1.4 DOHC	EPS [Electronic Power Steering]	√	√	√	√		0004
Europe/General	Cee'd(ED)	2013	G 1.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2013	G 1.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2013	G 1.4 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2013	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2013	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(ED)	2013	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2013	G 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2013	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2013	G 1.6 DOHC	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2013	G 1.6 DOHC	AIRCON [Air Conditioner (Single)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2013	G 1.6 DOHC	EPS [Electronic Power Steering]	√	√	√	√		0004
Europe/General	Cee'd(ED)	2013	G 1.6 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2013	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2013	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2013	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2013	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0098
Europe/General	Cee'd(ED)	2013	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2013	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2013	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2013	G 2.0 DOHC	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2013	G 2.0 DOHC	AIRCON [Air Conditioner (Single)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2013	G 2.0 DOHC	EPS [Electronic Power Steering]	√	√	√	√		0004
Europe/General	Cee'd(ED)	2013	G 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2013	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2013	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2012	D 1.6 TCI-U2	ENGINE [ISG (+) / CPF (-)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2012	D 1.6 TCI-U2	ENGINE [ISG (+) / CPF (+)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2012	D 1.6 TCI-U2	ENGINE [ISG (-) / CPF (+)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2012	D 1.6 TCI-U2	ENGINE [ISG (-) / CPF (-)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2012	D 1.6 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2012	D 1.6 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2012	D 1.6 TCI-U2	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2012	D 1.6 TCI-U2	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	

Europe/General	Cee'd(ED)	2012	D 1.6 TCI-U2	AIRCON [Air Conditioner (Single)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2012	D 1.6 TCI-U2	EPS [Electronic Power Steering]	√	√	√	√		0004
Europe/General	Cee'd(ED)	2012	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2012	D 1.6 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2012	D 1.6 TCI-U2	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2012	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2012	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2012	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2012	D 2.0 TCI-D	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2012	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2012	D 2.0 TCI-D	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2012	D 2.0 TCI-D	AIRCON [Air Conditioner (Single)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2012	D 2.0 TCI-D	EPS [Electronic Power Steering]	√	√	√	√		0004
Europe/General	Cee'd(ED)	2012	D 2.0 TCI-D	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2012	D 2.0 TCI-D	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2012	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2012	D 2.0 TCI-D	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2012	G 1.4 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(ED)	2012	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2012	G 1.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2012	G 1.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2012	G 1.4 DOHC	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2012	G 1.4 DOHC	AIRCON [Air Conditioner (Single)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2012	G 1.4 DOHC	EPS [Electronic Power Steering]	√	√	√	√		0004
Europe/General	Cee'd(ED)	2012	G 1.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2012	G 1.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2012	G 1.4 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2012	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2012	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(ED)	2012	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2012	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2012	G 1.6 DOHC	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2012	G 1.6 DOHC	AIRCON [Air Conditioner (Single)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2012	G 1.6 DOHC	EPS [Electronic Power Steering]	√	√	√	√		0004
Europe/General	Cee'd(ED)	2012	G 1.6 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2012	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2012	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2012	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2012	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0098
Europe/General	Cee'd(ED)	2012	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2012	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2012	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2012	G 2.0 DOHC	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2012	G 2.0 DOHC	AIRCON [Air Conditioner (Single)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2012	G 2.0 DOHC	EPS [Electronic Power Steering]	√	√	√	√		0004

Europe/General	Cee'd(ED)	2012	G 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2012	G 2.0 DOHC	IMMO [Immobilizer]				√	√	0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2012	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2012	G 2.0 DOHC	CODE [Transmitter Code Saving]				√	√	0022
Europe/General	Cee'd(ED)	2011	D 1.6 TCI-U2	ENGINE [ISG (+) / CPF (-)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2011	D 1.6 TCI-U2	ENGINE [ISG (+) / CPF (+)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2011	D 1.6 TCI-U2	ENGINE [ISG (-) / CPF (+)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2011	D 1.6 TCI-U2	ENGINE [ISG (-) / CPF (-)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2011	D 1.6 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2011	D 1.6 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2011	D 1.6 TCI-U2	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2011	D 1.6 TCI-U2	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2011	D 1.6 TCI-U2	AIRCON [Air Conditioner (Single)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2011	D 1.6 TCI-U2	EPS [Electronic Power Steering]	√	√	√	√		0004
Europe/General	Cee'd(ED)	2011	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2011	D 1.6 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2011	D 1.6 TCI-U2	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2011	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2011	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2011	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2011	D 2.0 TCI-D	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2011	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2011	D 2.0 TCI-D	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2011	D 2.0 TCI-D	AIRCON [Air Conditioner (Single)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2011	D 2.0 TCI-D	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2011	D 2.0 TCI-D	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2011	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2011	D 2.0 TCI-D	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2011	G 1.4 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(ED)	2011	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2011	G 1.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2011	G 1.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2011	G 1.4 DOHC	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2011	G 1.4 DOHC	AIRCON [Air Conditioner (Single)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2011	G 1.4 DOHC	EPS [Electronic Power Steering]	√	√	√	√		0004
Europe/General	Cee'd(ED)	2011	G 1.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2011	G 1.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2011	G 1.4 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2011	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2011	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(ED)	2011	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2011	G 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2011	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2011	G 1.6 DOHC	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2011	G 1.6 DOHC	AIRCON [Air Conditioner (Single)]	√	√	√	√	√	

Europe/General	Cee'd(ED)	2011	G 1.6 DOHC	EPS [Electronic Power Steering]	√	√	√	√		0004
Europe/General	Cee'd(ED)	2011	G 1.6 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2011	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2011	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2011	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2011	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0098
Europe/General	Cee'd(ED)	2011	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2011	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2011	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2011	G 2.0 DOHC	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2011	G 2.0 DOHC	AIRCON [Air Conditioner (Single)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2011	G 2.0 DOHC	EPS [Electronic Power Steering]	√	√	√	√		0004
Europe/General	Cee'd(ED)	2011	G 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2011	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2011	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2011	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2010	D 1.6 TCI-U2	ENGINE [ISG (+) / CPF (-)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2010	D 1.6 TCI-U2	ENGINE [ISG (+) / CPF (+)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2010	D 1.6 TCI-U2	ENGINE [ISG (-) / CPF (-)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2010	D 1.6 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2010	D 1.6 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2010	D 1.6 TCI-U2	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2010	D 1.6 TCI-U2	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2010	D 1.6 TCI-U2	AIRCON [Air Conditioner (Single)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2010	D 1.6 TCI-U2	EPS [Electronic Power Steering]	√	√	√	√		0004
Europe/General	Cee'd(ED)	2010	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2010	D 1.6 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2010	D 1.6 TCI-U2	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2010	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2010	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2010	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2010	D 2.0 TCI-D	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2010	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2010	D 2.0 TCI-D	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2010	D 2.0 TCI-D	AIRCON [Air Conditioner (Single)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2010	D 2.0 TCI-D	EPS [Electronic Power Steering]	√	√	√	√		0004
Europe/General	Cee'd(ED)	2010	D 2.0 TCI-D	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2010	D 2.0 TCI-D	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2010	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2010	D 2.0 TCI-D	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2010	G 1.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0033, 0061, 0126, 0094, 0098
Europe/General	Cee'd(ED)	2010	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2010	G 1.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2010	G 1.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090

Europe/General	Cee'd(ED)	2010	G 1.4 DOHC	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2010	G 1.4 DOHC	AIRCON [Air Conditioner (Single)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2010	G 1.4 DOHC	EPS [Electronic Power Steering]	√	√	√	√		0004
Europe/General	Cee'd(ED)	2010	G 1.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2010	G 1.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2010	G 1.4 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2010	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2010	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0033, 0061, 0033, 0126, 0094, 0098
Europe/General	Cee'd(ED)	2010	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2010	G 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2010	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2010	G 1.6 DOHC	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2010	G 1.6 DOHC	EPS [Electronic Power Steering]	√	√	√	√		0004
Europe/General	Cee'd(ED)	2010	G 1.6 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2010	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2010	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2010	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2010	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0098
Europe/General	Cee'd(ED)	2010	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2010	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2010	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2010	G 2.0 DOHC	AIRCON [Air Conditioner (Dual)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2010	G 2.0 DOHC	AIRCON [Air Conditioner (Single)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2010	G 2.0 DOHC	EPS [Electronic Power Steering]	√	√	√	√		0004
Europe/General	Cee'd(ED)	2010	G 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2010	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2010	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2010	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U	EPS [Electronic Power Steering]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U2	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U2	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U2	AIRBAG [Airbag Control]	√	√	√			0090

Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U2	EPS [Electronic Power Steering]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U2	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2009	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2009	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2009	D 2.0 TCI-D	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2009	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2009	D 2.0 TCI-D	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2009	D 2.0 TCI-D	EPS [Electronic Power Steering]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2009	D 2.0 TCI-D	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2009	D 2.0 TCI-D	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2009	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2009	D 2.0 TCI-D	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2009	G 1.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0061, 0033, 0126, 0094, 0094, 0098
Europe/General	Cee'd(ED)	2009	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2009	G 1.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2009	G 1.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2009	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2009	G 1.4 DOHC	EPS [Electronic Power Steering]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2009	G 1.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2009	G 1.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2009	G 1.4 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2009	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2009	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0061, 0033, 0126, 0094, 0094, 0098
Europe/General	Cee'd(ED)	2009	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2009	G 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2009	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2009	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2009	G 1.6 DOHC	EPS [Electronic Power Steering]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2009	G 1.6 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2009	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2009	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2009	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2009	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0098
Europe/General	Cee'd(ED)	2009	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2009	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2009	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2009	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2009	G 2.0 DOHC	EPS [Electronic Power Steering]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2009	G 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2009	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112

Europe/General	Cee'd(ED)	2009	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2009	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2008	D 1.6 TCI-U	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2008	D 1.6 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2008	D 1.6 TCI-U	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2008	D 1.6 TCI-U	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2008	D 1.6 TCI-U	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2008	D 1.6 TCI-U	EPS [Electronic Power Steering]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2008	D 1.6 TCI-U	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2008	D 1.6 TCI-U	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2008	D 1.6 TCI-U	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2008	D 1.6 TCI-U	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2008	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2008	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2008	D 2.0 TCI-D	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2008	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2008	D 2.0 TCI-D	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2008	D 2.0 TCI-D	EPS [Electronic Power Steering]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2008	D 2.0 TCI-D	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2008	D 2.0 TCI-D	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2008	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2008	D 2.0 TCI-D	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2008	G 1.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0094, 0098, 0126
Europe/General	Cee'd(ED)	2008	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2008	G 1.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2008	G 1.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2008	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2008	G 1.4 DOHC	EPS [Electronic Power Steering]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2008	G 1.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2008	G 1.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2008	G 1.4 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2008	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2008	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0094, 0098, 0126
Europe/General	Cee'd(ED)	2008	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2008	G 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2008	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2008	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2008	G 1.6 DOHC	EPS [Electronic Power Steering]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2008	G 1.6 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2008	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2008	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2008	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0098
Europe/General	Cee'd(ED)	2008	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2008	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2008	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090

Europe/General	Cee'd(ED)	2008	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2008	G 2.0 DOHC	EPS [Electronic Power Steering]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2008	G 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(ED)	2008	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2008	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2008	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2007	D 1.6 TCI-U	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2007	D 1.6 TCI-U	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2007	D 1.6 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2007	D 1.6 TCI-U	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2007	D 1.6 TCI-U	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2007	D 1.6 TCI-U	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2007	D 1.6 TCI-U	EPS [MDPS]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2007	D 1.6 TCI-U	TPMS [TPMS]	√	√	√		√	
Europe/General	Cee'd(ED)	2007	D 1.6 TCI-U	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2007	D 1.6 TCI-U	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2007	D 1.6 TCI-U	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2007	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2007	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2007	D 2.0 TCI-D	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2007	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2007	D 2.0 TCI-D	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2007	D 2.0 TCI-D	EPS [MDPS]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2007	D 2.0 TCI-D	TPMS [TPMS]	√	√	√		√	
Europe/General	Cee'd(ED)	2007	D 2.0 TCI-D	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2007	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2007	D 2.0 TCI-D	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2007	G 1.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0094, 0098, 0126
Europe/General	Cee'd(ED)	2007	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2007	G 1.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2007	G 1.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2007	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2007	G 1.4 DOHC	EPS [MDPS]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2007	G 1.4 DOHC	TPMS [TPMS]	√	√	√		√	
Europe/General	Cee'd(ED)	2007	G 1.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2007	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2007	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0094, 0098, 0126
Europe/General	Cee'd(ED)	2007	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2007	G 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2007	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2007	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2007	G 1.6 DOHC	EPS [MDPS]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2007	G 1.6 DOHC	TPMS [TPMS]	√	√	√		√	
Europe/General	Cee'd(ED)	2007	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2007	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	

Europe/General	Cee'd(ED)	2007	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2007	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0098
Europe/General	Cee'd(ED)	2007	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2007	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2007	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2007	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2007	G 2.0 DOHC	EPS [MDPS]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2007	G 2.0 DOHC	TPMS [TPMS]	√	√	√		√	
Europe/General	Cee'd(ED)	2007	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2007	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2007	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2006	D 1.6 TCI-U	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2006	D 1.6 TCI-U	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2006	D 1.6 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2006	D 1.6 TCI-U	ESP [ESP]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2006	D 1.6 TCI-U	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2006	D 1.6 TCI-U	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2006	D 1.6 TCI-U	EPS [MDPS]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2006	D 1.6 TCI-U	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2006	D 1.6 TCI-U	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2006	D 1.6 TCI-U	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2006	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2006	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2006	D 2.0 TCI-D	ESP [ESP]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2006	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2006	D 2.0 TCI-D	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2006	D 2.0 TCI-D	EPS [MDPS]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2006	D 2.0 TCI-D	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2006	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2006	G 1.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0094, 0098, 0126
Europe/General	Cee'd(ED)	2006	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2006	G 1.4 DOHC	ESP [ESP]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2006	G 1.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2006	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2006	G 1.4 DOHC	EPS [MDPS]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2006	G 1.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2006	G 1.4 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2006	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2006	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0094, 0098, 0126
Europe/General	Cee'd(ED)	2006	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2006	G 1.6 DOHC	ESP [ESP]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2006	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2006	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2006	G 1.6 DOHC	EPS [MDPS]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2006	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112

Europe/General	Cee'd(ED)	2006	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2006	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(ED)	2006	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0098
Europe/General	Cee'd(ED)	2006	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(ED)	2006	G 2.0 DOHC	ESP [ESP]	√	√	√	√	√	0051
Europe/General	Cee'd(ED)	2006	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Cee'd(ED)	2006	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(ED)	2006	G 2.0 DOHC	EPS [MDPS]	√	√	√	√		0004, 0032
Europe/General	Cee'd(ED)	2006	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Cee'd(ED)	2006	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Cee'd(ED)	2006	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2016	D 1.4 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	Cee'd(JD)	2016	D 1.4 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2016	D 1.4 TCI-U2	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2016	D 1.4 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2016	D 1.4 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2016	D 1.4 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	D 1.4 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2016	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2016	D 1.4 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	Cee'd(JD)	2016	D 1.4 TCI-U2	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	D 1.4 TCI-U2	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	Cee'd(JD)	2016	D 1.4 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2016	D 1.4 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2016	D 1.4 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	D 1.4 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	D 1.4 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	D 1.4 TCI-U2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2016	D 1.4 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	AT [Double Clutch Transmission (7th)]	√	√	√	√		
Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102

Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2016	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2016	G 1.0 T-GDI KAPPA	ENGINE [Engine Control]	√	√	√	√		0011, 0061, 0094, 0126
Europe/General	Cee'd(JD)	2016	G 1.0 T-GDI KAPPA	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2016	G 1.0 T-GDI KAPPA	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2016	G 1.0 T-GDI KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2016	G 1.0 T-GDI KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.0 T-GDI KAPPA	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2016	G 1.0 T-GDI KAPPA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2016	G 1.0 T-GDI KAPPA	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	Cee'd(JD)	2016	G 1.0 T-GDI KAPPA	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.0 T-GDI KAPPA	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	Cee'd(JD)	2016	G 1.0 T-GDI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2016	G 1.0 T-GDI KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2016	G 1.0 T-GDI KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2016	G 1.0 T-GDI KAPPA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.0 T-GDI KAPPA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.0 T-GDI KAPPA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.0 T-GDI KAPPA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2016	G 1.0 T-GDI KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2016	G 1.4 MPI KAPPA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(JD)	2016	G 1.4 MPI KAPPA	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2016	G 1.4 MPI KAPPA	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2016	G 1.4 MPI KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			

Europe/General	Cee'd(JD)	2016	G 1.4 MPI KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2016	G 1.4 MPI KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.4 MPI KAPPA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2016	G 1.4 MPI KAPPA	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	Cee'd(JD)	2016	G 1.4 MPI KAPPA	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.4 MPI KAPPA	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	Cee'd(JD)	2016	G 1.4 MPI KAPPA	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2016	G 1.4 MPI KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2016	G 1.4 MPI KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2016	G 1.4 MPI KAPPA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.4 MPI KAPPA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.4 MPI KAPPA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.4 MPI KAPPA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2016	G 1.4 MPI KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2016	G 1.6 GDI GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(JD)	2016	G 1.6 GDI GAMMA	AT [Double Clutch Transmission (6th)]	√	√	√	√	√	0024
Europe/General	Cee'd(JD)	2016	G 1.6 GDI GAMMA	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2016	G 1.6 GDI GAMMA	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2016	G 1.6 GDI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2016	G 1.6 GDI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2016	G 1.6 GDI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.6 GDI GAMMA	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2016	G 1.6 GDI GAMMA	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	Cee'd(JD)	2016	G 1.6 GDI GAMMA	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.6 GDI GAMMA	MFC [Multi Function Camera]	√	√	√	√		

Europe/General	Cee'd(JD)	2016	G 1.6 GDI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2016	G 1.6 GDI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2016	G 1.6 GDI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2016	G 1.6 GDI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.6 GDI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.6 GDI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.6 GDI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2016	G 1.6 GDI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2016	G 1.6 MPI GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(JD)	2016	G 1.6 MPI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(JD)	2016	G 1.6 MPI GAMMA	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2016	G 1.6 MPI GAMMA	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2016	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2016	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2016	G 1.6 MPI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.6 MPI GAMMA	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2016	G 1.6 MPI GAMMA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2016	G 1.6 MPI GAMMA	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.6 MPI GAMMA	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	Cee'd(JD)	2016	G 1.6 MPI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2016	G 1.6 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2016	G 1.6 MPI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2016	G 1.6 MPI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.6 MPI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.6 MPI GAMMA	BCM [Body Control Module]	√	√	√	√	√	

Europe/General	Cee'd(JD)	2016	G 1.6 MPI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2016	G 1.6 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2016	G 1.6 T-GDI GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(JD)	2016	G 1.6 T-GDI GAMMA	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2016	G 1.6 T-GDI GAMMA	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2016	G 1.6 T-GDI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2016	G 1.6 T-GDI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2016	G 1.6 T-GDI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.6 T-GDI GAMMA	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2016	G 1.6 T-GDI GAMMA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2016	G 1.6 T-GDI GAMMA	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	Cee'd(JD)	2016	G 1.6 T-GDI GAMMA	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.6 T-GDI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2016	G 1.6 T-GDI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2016	G 1.6 T-GDI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2016	G 1.6 T-GDI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.6 T-GDI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.6 T-GDI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2016	G 1.6 T-GDI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2016	G 1.6 T-GDI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2015	D 1.4 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	Cee'd(JD)	2015	D 1.4 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2015	D 1.4 TCI-U2	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2015	D 1.4 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2015	D 1.4 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2015	D 1.4 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	D 1.4 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2015	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2015	D 1.4 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	

Europe/General	Cee'd(JD)	2015	D 1.4 TCI-U2	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	Cee'd(JD)	2015	D 1.4 TCI-U2	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2015	D 1.4 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2015	D 1.4 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2015	D 1.4 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	D 1.4 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	D 1.4 TCI-U2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2015	D 1.4 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	D 1.4 TCI-U2	SERVICE [Service Reminder]	√					
Europe/General	Cee'd(JD)	2015	D 1.4 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2015	D 1.6 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	D 1.6 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(JD)	2015	D 1.6 TCI-U2	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2015	D 1.6 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2015	D 1.6 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2015	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	D 1.6 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2015	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2015	D 1.6 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	D 1.6 TCI-U2	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	Cee'd(JD)	2015	D 1.6 TCI-U2	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2015	D 1.6 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2015	D 1.6 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2015	D 1.6 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	D 1.6 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	D 1.6 TCI-U2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2015	D 1.6 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	D 1.6 TCI-U2	SERVICE [Service Reminder]	√					
Europe/General	Cee'd(JD)	2015	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2015	G 1.4 MPI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(JD)	2015	G 1.4 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2015	G 1.4 MPI	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2015	G 1.4 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2015	G 1.4 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2015	G 1.4 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.4 MPI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2015	G 1.4 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2015	G 1.4 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.4 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	Cee'd(JD)	2015	G 1.4 MPI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2015	G 1.4 MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2015	G 1.4 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2015	G 1.4 MPI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.4 MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.4 MPI	PSM [Power Seat Module]	√	√	√	√	√	0106

Europe/General	Cee'd(JD)	2015	G 1.4 MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.4 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	AT [Double Clutch Transmission]	√	√	√	√	√	0024
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	SERVICE [Service Reminder]	√					
Europe/General	Cee'd(JD)	2015	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2015	G 1.6 MPI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(JD)	2015	G 1.6 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(JD)	2015	G 1.6 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2015	G 1.6 MPI	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2015	G 1.6 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2015	G 1.6 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2015	G 1.6 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.6 MPI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2015	G 1.6 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2015	G 1.6 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.6 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	Cee'd(JD)	2015	G 1.6 MPI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2015	G 1.6 MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2015	G 1.6 MPI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.6 MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.6 MPI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2015	G 1.6 MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.6 MPI	SERVICE [Service Reminder]	√					
Europe/General	Cee'd(JD)	2015	G 1.6 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2015	G 1.6 T-GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(JD)	2015	G 1.6 T-GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2015	G 1.6 T-GDI	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2015	G 1.6 T-GDI	AIRBAG [Airbag (Event #1)]	√	√	√			

Europe/General	Cee'd(JD)	2015	G 1.6 T-GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2015	G 1.6 T-GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.6 T-GDI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2015	G 1.6 T-GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2015	G 1.6 T-GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.6 T-GDI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	Cee'd(JD)	2015	G 1.6 T-GDI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2015	G 1.6 T-GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2015	G 1.6 T-GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2015	G 1.6 T-GDI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.6 T-GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.6 T-GDI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2015	G 1.6 T-GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2015	G 1.6 T-GDI	SERVICE [Service Reminder]	√					
Europe/General	Cee'd(JD)	2015	G 1.6 T-GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2014	D 1.4 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	Cee'd(JD)	2014	D 1.4 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2014	D 1.4 TCI-U2	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2014	D 1.4 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2014	D 1.4 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2014	D 1.4 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	D 1.4 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2014	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2014	D 1.4 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	D 1.4 TCI-U2	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	Cee'd(JD)	2014	D 1.4 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2014	D 1.4 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2014	D 1.4 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	D 1.4 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	D 1.4 TCI-U2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2014	D 1.4 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	D 1.4 TCI-U2	SERVICE [Service Reminder]	√					
Europe/General	Cee'd(JD)	2014	D 1.4 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015

Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	SERVICE [Service Reminder]	√					
Europe/General	Cee'd(JD)	2014	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2014	G 1.4 MPI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(JD)	2014	G 1.4 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2014	G 1.4 MPI	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2014	G 1.4 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2014	G 1.4 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2014	G 1.4 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	G 1.4 MPI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2014	G 1.4 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2014	G 1.4 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	Cee'd(JD)	2014	G 1.4 MPI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2014	G 1.4 MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2014	G 1.4 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2014	G 1.4 MPI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	G 1.4 MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	G 1.4 MPI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2014	G 1.4 MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	G 1.4 MPI	SERVICE [Service Reminder]	√					
Europe/General	Cee'd(JD)	2014	G 1.4 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2014	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(JD)	2014	G 1.6 GDI	AT [Double Clutch Transmission]	√	√	√	√	√	0024
Europe/General	Cee'd(JD)	2014	G 1.6 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2014	G 1.6 GDI	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2014	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2014	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2014	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	G 1.6 GDI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2014	G 1.6 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2014	G 1.6 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	G 1.6 GDI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	Cee'd(JD)	2014	G 1.6 GDI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2014	G 1.6 GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2014	G 1.6 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2014	G 1.6 GDI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	G 1.6 GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	G 1.6 GDI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2014	G 1.6 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	G 1.6 GDI	SERVICE [Service Reminder]	√					

Europe/General	Cee'd(JD)	2014	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2014	G 1.6 MPI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(JD)	2014	G 1.6 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(JD)	2014	G 1.6 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2014	G 1.6 MPI	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2014	G 1.6 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2014	G 1.6 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	G 1.6 MPI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2014	G 1.6 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2014	G 1.6 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	G 1.6 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	Cee'd(JD)	2014	G 1.6 MPI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2014	G 1.6 MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2014	G 1.6 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2014	G 1.6 MPI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	G 1.6 MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	G 1.6 MPI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2014	G 1.6 MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	G 1.6 MPI	SERVICE [Service Reminder]	√					
Europe/General	Cee'd(JD)	2014	G 1.6 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2014	G 1.6 T-GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(JD)	2014	G 1.6 T-GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2014	G 1.6 T-GDI	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2014	G 1.6 T-GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2014	G 1.6 T-GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2014	G 1.6 T-GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	G 1.6 T-GDI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2014	G 1.6 T-GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2014	G 1.6 T-GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	G 1.6 T-GDI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	Cee'd(JD)	2014	G 1.6 T-GDI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2014	G 1.6 T-GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2014	G 1.6 T-GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2014	G 1.6 T-GDI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	G 1.6 T-GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	G 1.6 T-GDI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2014	G 1.6 T-GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2014	G 1.6 T-GDI	SERVICE [Service Reminder]	√					
Europe/General	Cee'd(JD)	2014	G 1.6 T-GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2013	D 1.4 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2013	D 1.4 TCI-U2	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2013	D 1.4 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2013	D 1.4 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2013	D 1.4 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	D 1.4 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√		

Europe/General	Cee'd(JD)	2013	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	D 1.4 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	D 1.4 TCI-U2	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	Cee'd(JD)	2013	D 1.4 TCI-U2	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2013	D 1.4 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2013	D 1.4 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2013	D 1.4 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	D 1.4 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	D 1.4 TCI-U2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2013	D 1.4 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	D 1.4 TCI-U2	SERVICE [Service Reminder]	√					
Europe/General	Cee'd(JD)	2013	D 1.4 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2013	D 1.6 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	D 1.6 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(JD)	2013	D 1.6 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2013	D 1.6 TCI-U2	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2013	D 1.6 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2013	D 1.6 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2013	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	D 1.6 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2013	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2013	D 1.6 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	D 1.6 TCI-U2	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	Cee'd(JD)	2013	D 1.6 TCI-U2	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2013	D 1.6 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2013	D 1.6 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2013	D 1.6 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	D 1.6 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	D 1.6 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	D 1.6 TCI-U2	SERVICE [Service Reminder]	√					
Europe/General	Cee'd(JD)	2013	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2013	G 1.4 MPI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(JD)	2013	G 1.4 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2013	G 1.4 MPI	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2013	G 1.4 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2013	G 1.4 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2013	G 1.4 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	G 1.4 MPI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2013	G 1.4 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2013	G 1.4 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	G 1.4 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	Cee'd(JD)	2013	G 1.4 MPI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2013	G 1.4 MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2013	G 1.4 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2013	G 1.4 MPI	BCM [Body Control Module]	√	√	√	√	√	

Europe/General	Cee'd(JD)	2013	G 1.4 MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	G 1.4 MPI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2013	G 1.4 MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	G 1.4 MPI	SERVICE [Service Reminder]	√					
Europe/General	Cee'd(JD)	2013	G 1.4 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2013	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(JD)	2013	G 1.6 GDI	AT [Double Clutch Transmission]	√	√	√	√	√	0024
Europe/General	Cee'd(JD)	2013	G 1.6 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2013	G 1.6 GDI	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2013	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2013	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2013	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	G 1.6 GDI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2013	G 1.6 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2013	G 1.6 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	G 1.6 GDI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	Cee'd(JD)	2013	G 1.6 GDI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2013	G 1.6 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2013	G 1.6 GDI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	G 1.6 GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	G 1.6 GDI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2013	G 1.6 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	G 1.6 GDI	SERVICE [Service Reminder]	√					
Europe/General	Cee'd(JD)	2013	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	SERVICE [Service Reminder]	√					
Europe/General	Cee'd(JD)	2013	G 1.6 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	Cee'd(JD)	2013	G 1.6 T-GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126

Europe/General	Cee'd(JD)	2013	G 1.6 T-GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Cee'd(JD)	2013	G 1.6 T-GDI	EPB [Electric Parking Brake]	√	√	√	√	√	0013, 0031, 0049
Europe/General	Cee'd(JD)	2013	G 1.6 T-GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Cee'd(JD)	2013	G 1.6 T-GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Cee'd(JD)	2013	G 1.6 T-GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	G 1.6 T-GDI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	Cee'd(JD)	2013	G 1.6 T-GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	Cee'd(JD)	2013	G 1.6 T-GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	G 1.6 T-GDI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Cee'd(JD)	2013	G 1.6 T-GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Cee'd(JD)	2013	G 1.6 T-GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Cee'd(JD)	2013	G 1.6 T-GDI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	G 1.6 T-GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	G 1.6 T-GDI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Cee'd(JD)	2013	G 1.6 T-GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	Cee'd(JD)	2013	G 1.6 T-GDI	SERVICE [Service Reminder]	√					
Europe/General	Cee'd(JD)	2013	G 1.6 T-GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO(LD)	2009	D 1.6 TCI-U	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CERATO(LD)	2009	D 1.6 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO(LD)	2009	D 1.6 TCI-U	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2009	D 1.6 TCI-U	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CERATO(LD)	2009	D 1.6 TCI-U	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO(LD)	2009	D 1.6 TCI-U	IMMO [Immobilizer]				√		0075, 0072, 0112, 0075, 0092, 0083, 0119
Europe/General	CERATO(LD)	2009	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	CERATO(LD)	2009	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0094, 0098, 0126
Europe/General	CERATO(LD)	2009	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0094, 0098, 0126
Europe/General	CERATO(LD)	2009	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO(LD)	2009	G 1.6 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2009	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CERATO(LD)	2009	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO(LD)	2009	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CERATO(LD)	2009	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0098
Europe/General	CERATO(LD)	2009	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0098
Europe/General	CERATO(LD)	2009	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0098
Europe/General	CERATO(LD)	2009	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO(LD)	2009	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2009	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CERATO(LD)	2009	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO(LD)	2009	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CERATO(LD)	2008	D 1.6 TCI-U	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CERATO(LD)	2008	D 1.6 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO(LD)	2008	D 1.6 TCI-U	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2008	D 1.6 TCI-U	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CERATO(LD)	2008	D 1.6 TCI-U	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	CERATO(LD)	2008	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	CERATO(LD)	2008	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0094, 0098, 0126
Europe/General	CERATO(LD)	2008	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0094, 0098, 0126
Europe/General	CERATO(LD)	2008	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO(LD)	2008	G 1.6 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2008	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CERATO(LD)	2008	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO(LD)	2008	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CERATO(LD)	2008	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0098
Europe/General	CERATO(LD)	2008	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0098
Europe/General	CERATO(LD)	2008	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0098
Europe/General	CERATO(LD)	2008	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO(LD)	2008	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2008	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CERATO(LD)	2008	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO(LD)	2008	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CERATO(LD)	2007	D 1.6 TCI-U	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CERATO(LD)	2007	D 1.6 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO(LD)	2007	D 1.6 TCI-U	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2007	D 1.6 TCI-U	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CERATO(LD)	2007	D 1.6 TCI-U	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO(LD)	2007	D 1.6 TCI-U	IMMO [Immobilizer]				√		0075, 0072, 0112, 0075, 0092, 0083, 0119
Europe/General	CERATO(LD)	2007	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	CERATO(LD)	2007	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0094, 0098, 0126
Europe/General	CERATO(LD)	2007	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0094, 0098, 0126
Europe/General	CERATO(LD)	2007	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO(LD)	2007	G 1.6 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2007	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CERATO(LD)	2007	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO(LD)	2007	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CERATO(LD)	2007	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0098
Europe/General	CERATO(LD)	2007	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0098
Europe/General	CERATO(LD)	2007	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0098
Europe/General	CERATO(LD)	2007	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO(LD)	2007	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2007	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	CERATO(LD)	2007	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO(LD)	2007	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CERATO(LD)	2006	D 1.5 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CERATO(LD)	2006	D 1.5 TCI-U	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2006	D 1.5 TCI-U	AIRBAG [Airbag Control]	√	√	√			
Europe/General	CERATO(LD)	2006	D 1.5 TCI-U	IMMO [Immobilizer]				√		
Europe/General	CERATO(LD)	2006	D 1.6 TCI-U	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CERATO(LD)	2006	D 1.6 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	

Europe/General	CERATO(LD)	2006	D 1.6 TCI-U	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2006	D 1.6 TCI-U	AIRBAG [Airbag Control]	√	√	√			
Europe/General	CERATO(LD)	2006	D 1.6 TCI-U	IMMO [Immobilizer]				√		
Europe/General	CERATO(LD)	2006	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CERATO(LD)	2006	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CERATO(LD)	2006	D 2.0 TCI-D	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2006	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			
Europe/General	CERATO(LD)	2006	D 2.0 TCI-D	IMMO [Immobilizer]				√		
Europe/General	CERATO(LD)	2006	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	CERATO(LD)	2006	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062
Europe/General	CERATO(LD)	2006	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	CERATO(LD)	2006	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CERATO(LD)	2006	G 1.6 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2006	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	CERATO(LD)	2006	G 1.6 DOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	CERATO(LD)	2006	G 2.0 DOHC	ENGINE [Leaded All (- CVVT)]	√	√	√	√	√	0011, 0062, 0098
Europe/General	CERATO(LD)	2006	G 2.0 DOHC	ENGINE [Leaded All (+CVVT)]	√	√	√	√	√	0011, 0062, 0098
Europe/General	CERATO(LD)	2006	G 2.0 DOHC	ENGINE [Unleaded GEN (- CVVT)]	√	√	√	√	√	0011, 0098
Europe/General	CERATO(LD)	2006	G 2.0 DOHC	ENGINE [Unleaded GEN (+CVVT)]	√	√	√	√	√	0011, 0098
Europe/General	CERATO(LD)	2006	G 2.0 DOHC	ENGINE [Unleaded EOBD (- CVVT)]	√	√	√	√	√	0011, 0098
Europe/General	CERATO(LD)	2006	G 2.0 DOHC	ENGINE [Unleaded EOBD (+CVVT)]	√	√	√	√	√	0011, 0098
Europe/General	CERATO(LD)	2006	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CERATO(LD)	2006	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2006	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	CERATO(LD)	2006	G 2.0 DOHC	IMMO [Immobilizer]				√		
Europe/General	CERATO(LD)	2005	D 1.5 TCI-U	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CERATO(LD)	2005	D 1.5 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CERATO(LD)	2005	D 1.5 TCI-U	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2005	D 1.5 TCI-U	AIRBAG [Airbag Control]	√	√	√			
Europe/General	CERATO(LD)	2005	D 1.5 TCI-U	IMMO [Immobilizer]				√		
Europe/General	CERATO(LD)	2005	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CERATO(LD)	2005	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CERATO(LD)	2005	D 2.0 TCI-D	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2005	D 2.0 TCI-D	IMMO [Immobilizer]				√		
Europe/General	CERATO(LD)	2005	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	CERATO(LD)	2005	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062
Europe/General	CERATO(LD)	2005	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	CERATO(LD)	2005	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CERATO(LD)	2005	G 1.6 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2005	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	CERATO(LD)	2005	G 1.6 DOHC	IMMO [Immobilizer]				√		
Europe/General	CERATO(LD)	2005	G 2.0 DOHC	ENGINE [Leaded All (- CVVT)]	√	√	√	√	√	0011, 0062, 0098
Europe/General	CERATO(LD)	2005	G 2.0 DOHC	ENGINE [Leaded All (+CVVT)]	√	√	√	√	√	0011, 0062, 0098
Europe/General	CERATO(LD)	2005	G 2.0 DOHC	ENGINE [Unleaded GEN (- CVVT)]	√	√	√	√	√	0011, 0098
Europe/General	CERATO(LD)	2005	G 2.0 DOHC	ENGINE [Unleaded GEN (+CVVT)]	√	√	√	√	√	0011, 0098

Europe/General	CERATO(LD)	2005	G 2.0 DOHC	ENGINE [Unleaded EOBD (- CVVT)]	√	√	√	√	√	0011, 0098
Europe/General	CERATO(LD)	2005	G 2.0 DOHC	ENGINE [Unleaded EOBD (+CVVT)]	√	√	√	√	√	0011, 0098
Europe/General	CERATO(LD)	2005	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CERATO(LD)	2005	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2005	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	CERATO(LD)	2005	G 2.0 DOHC	IMMO [Immobilizer]				√		
Europe/General	CERATO(LD)	2004	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	CERATO(LD)	2004	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CERATO(LD)	2004	D 2.0 TCI-D	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2004	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			
Europe/General	CERATO(LD)	2004	D 2.0 TCI-D	IMMO [Immobilizer]				√		
Europe/General	CERATO(LD)	2004	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	CERATO(LD)	2004	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062
Europe/General	CERATO(LD)	2004	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	CERATO(LD)	2004	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CERATO(LD)	2004	G 1.6 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2004	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	CERATO(LD)	2004	G 1.6 DOHC	IMMO [Immobilizer]				√		
Europe/General	CERATO(LD)	2004	G 2.0 DOHC	ENGINE [Leaded All (- CVVT)]	√	√	√	√	√	0011, 0062, 0098
Europe/General	CERATO(LD)	2004	G 2.0 DOHC	ENGINE [Leaded All (+CVVT)]	√	√	√	√	√	0011, 0062, 0098
Europe/General	CERATO(LD)	2004	G 2.0 DOHC	ENGINE [Unleaded GEN (- CVVT)]	√	√	√	√	√	0011, 0098
Europe/General	CERATO(LD)	2004	G 2.0 DOHC	ENGINE [Unleaded GEN (+CVVT)]	√	√	√	√	√	0011, 0098
Europe/General	CERATO(LD)	2004	G 2.0 DOHC	ENGINE [Unleaded EOBD (- CVVT)]	√	√	√	√	√	0011, 0098
Europe/General	CERATO(LD)	2004	G 2.0 DOHC	ENGINE [Unleaded EOBD (+CVVT)]	√	√	√	√	√	0011, 0098
Europe/General	CERATO(LD)	2004	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CERATO(LD)	2004	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2004	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	CERATO(LD)	2003	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	CERATO(LD)	2003	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062
Europe/General	CERATO(LD)	2003	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	CERATO(LD)	2003	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	CERATO(LD)	2003	G 1.6 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CERATO(LD)	2003	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	CERATO(LD)	2003	G 1.6 DOHC	IMMO [Immobilizer]				√		
Europe/General	CERATO/FORTE(TD)	2013	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(TD)	2013	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(TD)	2013	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(TD)	2013	G 1.6 DOHC	AT [Automatic Transaxle (4 - Speed)]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(TD)	2013	G 1.6 DOHC	AT [Automatic Transaxle (6 - Speed)]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2013	G 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051

Europe/General	CERATO/FORTE(TD)	2013	G 1.6 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(TD)	2013	G 1.6 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(TD)	2013	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2013	G 1.6 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(TD)	2013	G 1.6 DOHC	EPS [Power Steering (KOUPI)]	√	√	√	√		
Europe/General	CERATO/FORTE(TD)	2013	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CERATO/FORTE(TD)	2013	G 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	CERATO/FORTE(TD)	2013	G 1.6 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	CERATO/FORTE(TD)	2013	G 1.6 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	CERATO/FORTE(TD)	2013	G 1.6 DOHC	BCM [Body Control Module (5DR)]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2013	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2013	G 1.6 DOHC	BCM [Body Control Module (KOUPI)]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2013	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(TD)	2013	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0043, 0011, 0126, 0094, 0098
Europe/General	CERATO/FORTE(TD)	2013	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0043, 0011, 0126, 0094, 0098
Europe/General	CERATO/FORTE(TD)	2013	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0043, 0011, 0126, 0094, 0098
Europe/General	CERATO/FORTE(TD)	2013	G 2.0 DOHC	AT [Automatic Transaxle (6 - Speed)]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2013	G 2.0 DOHC	AT [Automatic Transaxle (4 - Speed)]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(TD)	2013	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(TD)	2013	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(TD)	2013	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(TD)	2013	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2013	G 2.0 DOHC	EPS [Power Steering (KOUPI)]	√	√	√	√		
Europe/General	CERATO/FORTE(TD)	2013	G 2.0 DOHC	EPS [Power Steering]	√	√	√	√		

Europe/General	CERATO/FORTE(TD)	2013	G 2.0 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	CERATO/FORTE(TD)	2013	G 2.0 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	CERATO/FORTE(TD)	2013	G 2.0 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	CERATO/FORTE(TD)	2013	G 2.0 DOHC	BCM [Body Control Module (5DR)]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2013	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2013	G 2.0 DOHC	BCM [Body Control Module (KOUP)]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2013	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(TD)	2012	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(TD)	2012	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(TD)	2012	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(TD)	2012	G 1.6 DOHC	AT [Automatic Transaxle (4 - Speed)]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(TD)	2012	G 1.6 DOHC	AT [Automatic Transaxle (6 - Speed)]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2012	G 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(TD)	2012	G 1.6 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(TD)	2012	G 1.6 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(TD)	2012	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2012	G 1.6 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(TD)	2012	G 1.6 DOHC	EPS [Power Steering (KOUP)]	√	√	√	√		
Europe/General	CERATO/FORTE(TD)	2012	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CERATO/FORTE(TD)	2012	G 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	CERATO/FORTE(TD)	2012	G 1.6 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	CERATO/FORTE(TD)	2012	G 1.6 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	CERATO/FORTE(TD)	2012	G 1.6 DOHC	BCM [Body Control Module (5DR)]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2012	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	

Europe/General	CERATO/FORTE(TD)	2012	G 1.6 DOHC	BCM [Body Control Module (KROUP)]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2012	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(TD)	2012	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0094, 0098
Europe/General	CERATO/FORTE(TD)	2012	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0094, 0098
Europe/General	CERATO/FORTE(TD)	2012	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0094, 0098
Europe/General	CERATO/FORTE(TD)	2012	G 2.0 DOHC	AT [Automatic Transaxle (6 - Speed)]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2012	G 2.0 DOHC	AT [Automatic Transaxle (4 - Speed)]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(TD)	2012	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(TD)	2012	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(TD)	2012	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(TD)	2012	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2012	G 2.0 DOHC	EPS [Power Steering (KROUP)]	√	√	√	√		
Europe/General	CERATO/FORTE(TD)	2012	G 2.0 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(TD)	2012	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CERATO/FORTE(TD)	2012	G 2.0 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	CERATO/FORTE(TD)	2012	G 2.0 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	CERATO/FORTE(TD)	2012	G 2.0 DOHC	BCM [Body Control Module (5DR)]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2012	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2012	G 2.0 DOHC	BCM [Body Control Module (KROUP)]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2012	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(TD)	2011	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(TD)	2011	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(TD)	2011	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(TD)	2011	G 1.6 DOHC	AT [Automatic Transaxle (4 - Speed)]	√	√	√	√	√	0099

Europe/General	CERATO/FORTE(TD)	2011	G 1.6 DOHC	AT [Automatic Transaxle (6 - Speed)]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2011	G 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(TD)	2011	G 1.6 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(TD)	2011	G 1.6 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(TD)	2011	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2011	G 1.6 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(TD)	2011	G 1.6 DOHC	EPS [Power Steering (KROUP)]	√	√	√	√		
Europe/General	CERATO/FORTE(TD)	2011	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CERATO/FORTE(TD)	2011	G 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	CERATO/FORTE(TD)	2011	G 1.6 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	CERATO/FORTE(TD)	2011	G 1.6 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	CERATO/FORTE(TD)	2011	G 1.6 DOHC	BCM [Body Control Module (5DR)]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2011	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2011	G 1.6 DOHC	BCM [Body Control Module (KROUP)]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2011	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(TD)	2011	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2011	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2011	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2011	G 2.0 DOHC	AT [Automatic Transaxle (6 - Speed)]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2011	G 2.0 DOHC	AT [Automatic Transaxle (4 - Speed)]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(TD)	2011	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(TD)	2011	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(TD)	2011	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(TD)	2011	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	CERATO/FORTE(TD)	2011	G 2.0 DOHC	EPS [Power Steering (KROUP)]	√	√	√	√		
Europe/General	CERATO/FORTE(TD)	2011	G 2.0 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(TD)	2011	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CERATO/FORTE(TD)	2011	G 2.0 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	CERATO/FORTE(TD)	2011	G 2.0 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	CERATO/FORTE(TD)	2011	G 2.0 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	CERATO/FORTE(TD)	2011	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2011	G 2.0 DOHC	BCM [Body Control Module (KROUP)]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2011	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(TD)	2010	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0094, 0098, 0126
Europe/General	CERATO/FORTE(TD)	2010	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0094, 0098, 0126
Europe/General	CERATO/FORTE(TD)	2010	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	CERATO/FORTE(TD)	2010	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(TD)	2010	G 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(TD)	2010	G 1.6 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(TD)	2010	G 1.6 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(TD)	2010	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2010	G 1.6 DOHC	EPS [Power Steering (KROUP)]	√	√	√	√		
Europe/General	CERATO/FORTE(TD)	2010	G 1.6 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(TD)	2010	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CERATO/FORTE(TD)	2010	G 1.6 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	CERATO/FORTE(TD)	2010	G 1.6 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	CERATO/FORTE(TD)	2010	G 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	CERATO/FORTE(TD)	2010	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	

Europe/General	CERATO/FORTE(TD)	2010	G 1.6 DOHC	BCM [Body Control Module (Koup)]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2010	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(TD)	2010	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2010	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2010	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2010	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(TD)	2010	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(TD)	2010	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(TD)	2010	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(TD)	2010	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2010	G 2.0 DOHC	EPS [Power Steering (Koup)]	√	√	√	√		
Europe/General	CERATO/FORTE(TD)	2010	G 2.0 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(TD)	2010	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CERATO/FORTE(TD)	2010	G 2.0 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	CERATO/FORTE(TD)	2010	G 2.0 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	CERATO/FORTE(TD)	2010	G 2.0 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	CERATO/FORTE(TD)	2010	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2010	G 2.0 DOHC	BCM [Body Control Module (Koup)]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2010	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(TD)	2009	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	CERATO/FORTE(TD)	2009	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0094, 0098, 0126
Europe/General	CERATO/FORTE(TD)	2009	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(TD)	2009	G 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2009	G 1.6 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			

Europe/General	CERATO/FORTE(TD)	2009	G 1.6 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(TD)	2009	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2009	G 1.6 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(TD)	2009	G 1.6 DOHC	IMMO [IMMO (Bosch)]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CERATO/FORTE(TD)	2009	G 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	CERATO/FORTE(TD)	2009	G 1.6 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	CERATO/FORTE(TD)	2009	G 1.6 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	CERATO/FORTE(TD)	2009	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2009	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(TD)	2009	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2009	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2009	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2009	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(TD)	2009	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2009	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(TD)	2009	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(TD)	2009	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(TD)	2009	G 2.0 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(TD)	2009	G 2.0 DOHC	IMMO [IMMO (Bosch)]				√		0072, 0075, 0083, 0092, 0112
Europe/General	CERATO/FORTE(TD)	2009	G 2.0 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	CERATO/FORTE(TD)	2009	G 2.0 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	CERATO/FORTE(TD)	2009	G 2.0 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	CERATO/FORTE(TD)	2009	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	CERATO/FORTE(TD)	2009	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022

Europe/General	CERATO/FORTE(YD)	2017	D 1.6 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2017	D 1.6 TCI-U2	AT [Double Clutch Transmission (7thDCT)]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2017	D 1.6 TCI-U2	ABSESC [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2017	D 1.6 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2017	D 1.6 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2017	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2017	D 1.6 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2017	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2017	D 1.6 TCI-U2	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2017	D 1.6 TCI-U2	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2017	D 1.6 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2017	D 1.6 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2017	D 1.6 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2017	D 1.6 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2017	D 1.6 TCI-U2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2017	D 1.6 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2017	D 1.6 TCI-U2	ECALL [e - Call]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2017	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 MPI GAMMA	ENGINE [Leaded]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 MPI GAMMA	ENGINE [Unleaded]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 MPI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 MPI	ABSESC [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 MPI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	CERATO/FORTE(YD)	2017	G 1.6 MPI GAMMA	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 MPI GAMMA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 MPI GAMMA	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 MPI GAMMA	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 MPI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 MPI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 MPI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 MPI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 MPI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 MPI GAMMA	ECALL [e - Call]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 T-GDI GAMMA	ENGINE [Leaded]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 T-GDI GAMMA	ENGINE [Unleaded]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 T-GDI GAMMA	AT [Double Clutch Transmission (7thDCT)]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 T-GDI	ABSESC [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 T-GDI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 T-GDI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 T-GDI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 T-GDI GAMMA	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 T-GDI GAMMA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 T-GDI GAMMA	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 T-GDI GAMMA	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 T-GDI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 T-GDI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092

Europe/General	CERATO/FORTE(YD)	2017	G 1.6 T-GDI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 T-GDI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 T-GDI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 T-GDI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 T-GDI GAMMA	ECALL [e - Call]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2017	G 1.6 T-GDI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2017	G 2.0 MPI NU	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2017	G 2.0 MPI NU	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	CERATO/FORTE(YD)	2017	G 2.0 MPI NU	ABSESC [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2017	G 2.0 MPI NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2017	G 2.0 MPI NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2017	G 2.0 MPI NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2017	G 2.0 MPI NU	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2017	G 2.0 MPI NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2017	G 2.0 MPI NU	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2017	G 2.0 MPI NU	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2017	G 2.0 MPI NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2017	G 2.0 MPI NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2017	G 2.0 MPI NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2017	G 2.0 MPI NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2017	G 2.0 MPI NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2017	G 2.0 MPI NU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2017	G 2.0 MPI NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2017	G 2.0 MPI NU	ECALL [e - Call]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2017	G 2.0 MPI NU	CODE [Transmitter Code Saving]				√		0022

Europe/General	CERATO/FORTE(YD)	2016	D 1.6 TCI-U2(YD PE)	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2016	D 1.6 TCI-U2(YD PE)	AT [Double Clutch Transmission (7thDCT)]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	D 1.6 TCI-U2(YD PE)	ABSESC [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2016	D 1.6 TCI-U2(YD PE)	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	D 1.6 TCI-U2(YD PE)	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	D 1.6 TCI-U2(YD PE)	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	D 1.6 TCI-U2(YD PE)	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2016	D 1.6 TCI-U2(YD PE)	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	D 1.6 TCI-U2(YD PE)	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	D 1.6 TCI-U2(YD PE)	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2016	D 1.6 TCI-U2(YD PE)	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2016	D 1.6 TCI-U2(YD PE)	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2016	D 1.6 TCI-U2(YD PE)	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	D 1.6 TCI-U2(YD PE)	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	D 1.6 TCI-U2(YD PE)	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2016	D 1.6 TCI-U2(YD PE)	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	D 1.6 TCI-U2(YD PE)	ECALL [e - Call]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	D 1.6 TCI-U2(YD PE)	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2016	F 1.6 MPI GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2016	F 1.6 MPI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2016	F 1.6 MPI GAMMA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2016	F 1.6 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	F 1.6 MPI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	F 1.6 MPI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	F 1.6 MPI GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		

Europe/General	CERATO/FORTE(YD)	2016	F 1.6 MPI GAMMA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2016	F 1.6 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2016	F 1.6 MPI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2016	F 1.6 MPI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	F 1.6 MPI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	F 1.6 MPI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2016	F 1.6 MPI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	F 1.6 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 GDI GAMMA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 GDI GAMMA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 GDI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 GDI GAMMA	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 GDI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 GDI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 GDI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 GDI GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 GDI GAMMA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 GDI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 GDI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 GDI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 GDI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 GDI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 GDI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 GDI GAMMA	CODE [Transmitter Code Saving]				√		0022

Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	ENGINE [Unleaded]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	ENGINE [Leaded]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI	ABSESC [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	ECALL [e - Call]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	ENGINE [Unleaded]	√	√	√	√		0033, 0061, 0094, 0126

Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	ENGINE [Leaded]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	ABSESC [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0102, 0045, 0036
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	ECALL [e - Call]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 MPI GAMMA(YD PE)	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099

Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	AT [Double Clutch Transmission (7thDCT)]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	ABSESC [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0102, 0045, 0036
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	ECALL [e - Call]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	AT [Double Clutch Transmission (7thDCT)]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	ABSESC [Electronic Stability Program]	√	√	√	√	√	0051

Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0102, 0045, 0036
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	ECALL [e - Call]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 1.6 T-GDI GAMMA(YD PE)	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2016	G 1.8 MPI NU	ENGINE [Unleaded All]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 1.8 MPI NU	ENGINE [Leaded All]	√	√	√	√		0011, 0062, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 1.8 MPI NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2016	G 1.8 MPI NU	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2016	G 1.8 MPI NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 1.8 MPI NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 1.8 MPI NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.8 MPI NU	EPS [Motor Driven Power Steering]	√	√	√	√		

Europe/General	CERATO/FORTE(YD)	2016	G 1.8 MPI NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.8 MPI NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2016	G 1.8 MPI NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2016	G 1.8 MPI NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2016	G 1.8 MPI NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.8 MPI NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.8 MPI NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 1.8 MPI NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 GDI NU	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 GDI NU	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 GDI NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 GDI NU	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 GDI NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 GDI NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 GDI NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 GDI NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 GDI NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 GDI NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 GDI NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 GDI NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 GDI NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 GDI NU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 GDI NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 GDI NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 GDI NU	CODE [Transmitter Code Saving]				√		0022

Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	ENGINE [Leaded All]	√	√	√	√		0011, 0062, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	ENGINE [Unleaded All]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	ABSESC [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0102, 0045, 0036
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	ECALL [e - Call]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	ENGINE [Leaded All]	√	√	√	√		0011, 0062, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	ENGINE [Unleaded All]	√	√	√	√		0011, 0094, 0098, 0126

Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	ABSESC [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	ECALL [e - Call]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2016	G 2.0 MPI NU(YD PE)	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2015	F 1.6 MPI GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2015	F 1.6 MPI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2015	F 1.6 MPI GAMMA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2015	F 1.6 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2015	F 1.6 MPI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2015	F 1.6 MPI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	CERATO/FORTE(YD)	2015	F 1.6 MPI GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2015	F 1.6 MPI GAMMA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2015	F 1.6 MPI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2015	F 1.6 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2015	F 1.6 MPI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2015	F 1.6 MPI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	F 1.6 MPI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	F 1.6 MPI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2015	F 1.6 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 GDI GAMMA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 GDI GAMMA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 GDI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 GDI GAMMA	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 GDI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 GDI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 GDI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 GDI GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 GDI GAMMA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 GDI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 GDI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 GDI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 GDI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 GDI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 GDI GAMMA	CLU [Cluster Module]	√	√	√	√	√	

Europe/General	CERATO/FORTE(YD)	2015	G 1.6 GDI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 GDI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 MPI GAMMA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 MPI GAMMA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 MPI GAMMA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 MPI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 MPI GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 MPI GAMMA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 MPI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 MPI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 MPI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 MPI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 MPI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 MPI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 T-GDI GAMMA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 T-GDI GAMMA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 T-GDI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 T-GDI GAMMA	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 T-GDI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 T-GDI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			

Europe/General	CERATO/FORTE(YD)	2015	G 1.6 T-GDI GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 T-GDI GAMMA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 T-GDI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 T-GDI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 T-GDI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 T-GDI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 T-GDI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 T-GDI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 T-GDI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 1.6 T-GDI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2015	G 1.8 MPI NU	ENGINE [Unleaded]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2015	G 1.8 MPI NU	ENGINE [Leaded]	√	√	√	√		0011, 0062, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2015	G 1.8 MPI NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2015	G 1.8 MPI NU	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2015	G 1.8 MPI NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2015	G 1.8 MPI NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2015	G 1.8 MPI NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 1.8 MPI NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2015	G 1.8 MPI NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2015	G 1.8 MPI NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2015	G 1.8 MPI NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2015	G 1.8 MPI NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2015	G 1.8 MPI NU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2015	G 1.8 MPI NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 1.8 MPI NU	BCM [Body Control Module]	√	√	√	√	√	

Europe/General	CERATO/FORTE(YD)	2015	G 1.8 MPI NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 1.8 MPI NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 GDI NU	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 GDI NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 GDI NU	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 GDI NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 GDI NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 GDI NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 GDI NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 GDI NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 GDI NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 GDI NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 GDI NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 GDI NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 GDI NU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 GDI NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 GDI NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 GDI NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 MPI NU	ENGINE [Unleaded All]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 MPI NU	ENGINE [Leaded All]	√	√	√	√		0011, 0062, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 MPI NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 MPI NU	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 MPI NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 MPI NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 MPI NU	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	CERATO/FORTE(YD)	2015	G 2.0 MPI NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 MPI NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 MPI NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 MPI NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 MPI NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 MPI NU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 MPI NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 MPI NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 MPI NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2015	G 2.0 MPI NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2014	F 1.6 MPI GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2014	F 1.6 MPI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2014	F 1.6 MPI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2014	F 1.6 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2014	F 1.6 MPI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	F 1.6 MPI GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2014	F 1.6 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2014	F 1.6 MPI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2014	F 1.6 MPI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	F 1.6 MPI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2014	F 1.6 MPI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	F 1.6 MPI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	F 1.6 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 GDI GAMMA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 GDI GAMMA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126

Europe/General	CERATO/FORTE(YD)	2014	G 1.6 GDI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 GDI GAMMA	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 GDI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 GDI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 GDI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 GDI GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 GDI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 GDI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 GDI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 GDI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 GDI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 GDI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 GDI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 MPI GAMMA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 MPI GAMMA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 MPI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 MPI GAMMA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 MPI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 MPI GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 MPI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 MPI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102

Europe/General	CERATO/FORTE(YD)	2014	G 1.6 MPI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 MPI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 MPI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 T-GDI GAMMA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 T-GDI GAMMA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 T-GDI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 T-GDI GAMMA	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 T-GDI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 T-GDI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 T-GDI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 T-GDI GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 T-GDI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 T-GDI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 T-GDI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 T-GDI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 T-GDI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 T-GDI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 T-GDI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 1.6 T-GDI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2014	G 1.8 MPI NU	ENGINE [Leaded All]	√	√	√	√		0011, 0062, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2014	G 1.8 MPI NU	ENGINE [Unleaded All]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2014	G 1.8 MPI NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2014	G 1.8 MPI NU	ABSESP [ABS / ESP]	√	√	√	√	√	0051

Europe/General	CERATO/FORTE(YD)	2014	G 1.8 MPI NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2014	G 1.8 MPI NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2014	G 1.8 MPI NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2014	G 1.8 MPI NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2014	G 1.8 MPI NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2014	G 1.8 MPI NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 1.8 MPI NU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2014	G 1.8 MPI NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 1.8 MPI NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 1.8 MPI NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 GDI NU	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 GDI NU	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 GDI NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 GDI NU	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 GDI NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 GDI NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 GDI NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 GDI NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 GDI NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 GDI NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 GDI NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 GDI NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 GDI NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 GDI NU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 GDI NU	SJB [Smart Junction Block]	√	√	√	√	√	

Europe/General	CERATO/FORTE(YD)	2014	G 2.0 GDI NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 MPI NU	ENGINE [Leaded All]	√	√	√	√		0011, 0062, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 MPI NU	ENGINE [Unleaded All]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 MPI NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 MPI NU	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 MPI NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 MPI NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 MPI NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 MPI NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 MPI NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 MPI NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 MPI NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 MPI NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 MPI NU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 MPI NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2014	G 2.0 MPI NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2013	F 1.6 MPI GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2013	F 1.6 MPI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2013	F 1.6 MPI GAMMA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2013	F 1.6 MPI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2013	F 1.6 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2013	F 1.6 MPI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	F 1.6 MPI GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2013	F 1.6 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2013	F 1.6 MPI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102

Europe/General	CERATO/FORTE(YD)	2013	F 1.6 MPI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	F 1.6 MPI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2013	F 1.6 MPI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	F 1.6 MPI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	F 1.6 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2013	G 1.6 MPI GAMMA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2013	G 1.6 MPI GAMMA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2013	G 1.6 MPI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2013	G 1.6 MPI GAMMA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2013	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2013	G 1.6 MPI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	G 1.6 MPI GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2013	G 1.6 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2013	G 1.6 MPI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2013	G 1.6 MPI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	G 1.6 MPI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2013	G 1.6 MPI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	G 1.6 MPI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	G 1.6 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2013	G 1.8 MPI NU	ENGINE [Leaded All]	√	√	√	√		0011, 0062, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2013	G 1.8 MPI NU	ENGINE [Unleaded All]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2013	G 1.8 MPI NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2013	G 1.8 MPI NU	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2013	G 1.8 MPI NU	AIRBAG [Airbag (Event #2)]	√	√	√			

Europe/General	CERATO/FORTE(YD)	2013	G 1.8 MPI NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2013	G 1.8 MPI NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	G 1.8 MPI NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2013	G 1.8 MPI NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2013	G 1.8 MPI NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2013	G 1.8 MPI NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	G 1.8 MPI NU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2013	G 1.8 MPI NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	G 1.8 MPI NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	G 1.8 MPI NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 GDI NU	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 GDI NU	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 GDI NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 GDI NU	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 GDI NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 GDI NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 GDI NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 GDI NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 GDI NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 GDI NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 GDI NU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 GDI NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 GDI NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 GDI NU	CODE [Transmitter Code Saving]				√		0022

Europe/General	CERATO/FORTE(YD)	2013	G 2.0 MPI NU	ENGINE [Leaded All]	√	√	√	√		0011, 0062, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 MPI NU	ENGINE [Unleaded All]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 MPI NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 MPI NU	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 MPI NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 MPI NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 MPI NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 MPI NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 MPI NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 MPI NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 MPI NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 MPI NU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 MPI NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 MPI NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YD)	2013	G 2.0 MPI NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YDm)	2017	F 1.6 MPI GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YDm)	2017	F 1.6 MPI GAMMA	AT [Automatic Transaxle]	√	√	√	√		0005, 0099
Europe/General	CERATO/FORTE(YDm)	2017	F 1.6 MPI GAMMA	ABSESC [ABS / ESC]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YDm)	2017	F 1.6 MPI GAMMA	AEB [Autonomous Emergency Braking System]	√	√	√	√		
Europe/General	CERATO/FORTE(YDm)	2017	F 1.6 MPI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YDm)	2017	F 1.6 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YDm)	2017	F 1.6 MPI GAMMA	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YDm)	2017	F 1.6 MPI GAMMA	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	CERATO/FORTE(YDm)	2017	F 1.6 MPI GAMMA	TPMS [Tire Pressure Monitoring]	√	√	√		√	

Europe/General	CERATO/FORTE(YDm)	2017	F 1.6 MPI GAMMA	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CERATO/FORTE(YDm)	2017	F 1.6 MPI GAMMA	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YDm)	2017	F 1.6 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YDm)	2017	F 1.6 MPI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0045, 0102
Europe/General	CERATO/FORTE(YDm)	2017	F 1.6 MPI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YDm)	2017	F 1.6 MPI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YDm)	2017	F 1.6 MPI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YDm)	2017	F 1.6 MPI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YDm)	2017	F 1.6 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YDm)	2017	G 1.6 MPI GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	CERATO/FORTE(YDm)	2017	G 1.6 MPI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	CERATO/FORTE(YDm)	2017	G 1.6 MPI GAMMA	ABSESC [ABS / ESC]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YDm)	2017	G 1.6 MPI GAMMA	AEB [Autonomous Emergency Braking System]	√	√	√	√		
Europe/General	CERATO/FORTE(YDm)	2017	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YDm)	2017	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YDm)	2017	G 1.6 MPI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YDm)	2017	G 1.6 MPI GAMMA	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YDm)	2017	G 1.6 MPI GAMMA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YDm)	2017	G 1.6 MPI GAMMA	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CERATO/FORTE(YDm)	2017	G 1.6 MPI GAMMA	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YDm)	2017	G 1.6 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YDm)	2017	G 1.6 MPI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0045, 0102
Europe/General	CERATO/FORTE(YDm)	2017	G 1.6 MPI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YDm)	2017	G 1.6 MPI GAMMA	CLU [Cluster Module]	√	√	√	√	√	

Europe/General	CERATO/FORTE(YDm)	2017	G 1.6 MPI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YDm)	2017	G 1.6 MPI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YDm)	2017	G 1.6 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	CERATO/FORTE(YDm)	2017	G 2.0 MPI NU	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0126
Europe/General	CERATO/FORTE(YDm)	2017	G 2.0 MPI NU	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	CERATO/FORTE(YDm)	2017	G 2.0 MPI NU	ABSESC [ABS / ESC]	√	√	√	√	√	0051
Europe/General	CERATO/FORTE(YDm)	2017	G 2.0 MPI NU	AEB [Autonomous Emergency Braking System]	√	√	√	√		
Europe/General	CERATO/FORTE(YDm)	2017	G 2.0 MPI NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	CERATO/FORTE(YDm)	2017	G 2.0 MPI NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	CERATO/FORTE(YDm)	2017	G 2.0 MPI NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YDm)	2017	G 2.0 MPI NU	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	CERATO/FORTE(YDm)	2017	G 2.0 MPI NU	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	CERATO/FORTE(YDm)	2017	G 2.0 MPI NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	CERATO/FORTE(YDm)	2017	G 2.0 MPI NU	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	CERATO/FORTE(YDm)	2017	G 2.0 MPI NU	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YDm)	2017	G 2.0 MPI NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	CERATO/FORTE(YDm)	2017	G 2.0 MPI NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0045, 0102
Europe/General	CERATO/FORTE(YDm)	2017	G 2.0 MPI NU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	CERATO/FORTE(YDm)	2017	G 2.0 MPI NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YDm)	2017	G 2.0 MPI NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YDm)	2017	G 2.0 MPI NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	CERATO/FORTE(YDm)	2017	G 2.0 MPI NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	CLARUS(FE)	2000	G 1.8 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	CLARUS(FE)	2000	G 1.8 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CLARUS(FE)	2000	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	CLARUS(FE)	2000	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	CLARUS(FE)	2000	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051

Europe/General	CLARUS(FE)	1999	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	CLARUS(FE)	1999	G 1.8 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	CLARUS(FE)	1999	G 1.8 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CLARUS(FE)	1999	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	CLARUS(FE)	1999	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	CLARUS(FE)	1999	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CLARUS(FE)	1998	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	CLARUS(FE)	1998	G 1.8 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	CLARUS(FE)	1998	G 1.8 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CLARUS(FE)	1998	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	CLARUS(FE)	1998	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	CLARUS(FE)	1998	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	CLARUS(FE)	1997	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	CLARUS(FE)	1997	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	CLARUS(FE)	1996	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	CLARUS(FE)	1996	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	CLARUS(FE)	1995	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	ENTERPRISE(DB)	2002	G 3.0 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	ENTERPRISE(DB)	2002	G 3.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	ENTERPRISE(DB)	2001	G 3.0 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	ENTERPRISE(DB)	2001	G 3.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	ENTERPRISE(DB)	2000	G 2.5 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	ENTERPRISE(DB)	2000	G 2.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	ENTERPRISE(DB)	2000	G 3.0 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	ENTERPRISE(DB)	2000	G 3.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	ENTERPRISE(DB)	2000	G 3.6 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	ENTERPRISE(DB)	2000	G 3.6 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	ENTERPRISE(DB)	1999	G 2.5 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	ENTERPRISE(DB)	1999	G 2.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	ENTERPRISE(DB)	1999	G 3.0 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	ENTERPRISE(DB)	1999	G 3.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	ENTERPRISE(DB)	1999	G 3.6 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	ENTERPRISE(DB)	1999	G 3.6 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	ENTERPRISE(DB)	1998	G 3.6 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	ENTERPRISE(DB)	1997	G 3.0 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	ENTERPRISE(DB)	1997	G 3.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	ENTERPRISE(DB)	1997	G 3.6 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	ENTERPRISE(DB)	1997	G 3.6 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	
Europe/General	JOICE(NO)	2002	G 2.0 DOHC	ENGINE [Unleaded EURO - 3]	√	√	√	√	√	
Europe/General	JOICE(NO)	2002	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	JOICE(NO)	2002	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	JOICE(NO)	2002	G 2.0 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080
Europe/General	JOICE(NO)	2002	G 2.0 DOHC	IMMO [Immobilizer (EURO - 3)]		√	√	√		0064, 0079, 0080, 0083
Europe/General	JOICE(NO)	2001	G 2.0 DOHC	ENGINE [Unleaded EURO - 3]	√	√	√	√	√	
Europe/General	JOICE(NO)	2001	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051

Europe/General	JOICE(NO)	2001	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	JOICE(NO)	2001	G 2.0 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080
Europe/General	JOICE(NO)	2001	G 2.0 DOHC	IMMO [Immobilizer (EURO - 3)]		√	√	√		0064, 0079, 0080, 0083
Europe/General	JOICE(NO)	2000	G 2.0 DOHC	ENGINE [Unleaded EURO - 3]	√	√	√	√	√	
Europe/General	JOICE(NO)	2000	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	JOICE(NO)	2000	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	JOICE(NO)	2000	G 2.0 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080
Europe/General	JOICE(NO)	2000	G 2.0 DOHC	IMMO [Immobilizer (EURO - 3)]		√	√	√		0064, 0079, 0080, 0083
Europe/General	JOICE(NO)	1999	G 2.0 DOHC	ENGINE [Unleaded EURO - 3]	√	√	√	√	√	
Europe/General	JOICE(NO)	1999	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	JOICE(NO)	1999	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	JOICE(NO)	1999	G 2.0 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080
Europe/General	JOICE(NO)	1999	G 2.0 DOHC	IMMO [Immobilizer (EURO - 3)]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K3000S(PU)	2015	D 2.5 TCI-4D56	ENGINE [Engine Control]		√	√	√	√	
Europe/General	K2500/K2700/K3000/K3000S(PU)	2015	D 2.5 TCI-4D56	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K3000S(PU)	2015	D 2.5 TCI-4D56	ABSVC [Anti - Lock Brake]	√	√	√	√	√	0051, 0078
Europe/General	K2500/K2700/K3000/K3000S(PU)	2015	D 2.5 TCI-4D56	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K3000S(PU)	2015	D 2.5 TCI-A2	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	K2500/K2700/K3000/K3000S(PU)	2015	D 2.5 TCI-A2	AT [Automatic Transaxle]	√	√	√	√	√	0099, 0116
Europe/General	K2500/K2700/K3000/K3000S(PU)	2015	D 2.5 TCI-A2	ABSVC [Anti - Lock Brake]	√	√	√	√	√	0051, 0078
Europe/General	K2500/K2700/K3000/K3000S(PU)	2015	D 2.5 TCI-A2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	K2500/K2700/K3000/K3000S(PU)	2015	D 2.5 TCI-A2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	K2500/K2700/K3000/K3000S(PU)	2015	D 2.7 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K3000S(PU)	2015	D 2.7 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	

Europe/General	K2500/K2700/K3000/K300 0S(PU)	2015	D 2.7 IDI-J	ABSVC [Anti - Lock Brake]	√	√	√	√	√	0051, 0078
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2015	D 2.7 IDI-J	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2015	D 2.9 C/R-J	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2015	D 2.9 C/R-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2015	D 2.9 C/R-J	ABSVC [Anti - Lock Brake]	√	√	√	√	√	0051, 0078
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2015	D 2.9 C/R-J	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2015	D 3.0 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2015	D 3.0 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2015	D 3.0 IDI-J	ABSVC [Anti - Lock Brake]	√	√	√	√	√	0051, 0078
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2015	D 3.0 IDI-J	IMMO [Immobilizer]		√	√	√		0079, 0064, 0075, 0092, 0083, 0080, 0119
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 2.5 TCI-4D56	ENGINE [Engine Control]		√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 2.5 TCI-4D56	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 2.5 TCI-4D56	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 2.5 TCI-4D56	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 2.5 TCI-A2	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 2.5 TCI-A2	AT [Automatic Transaxle]	√	√	√	√	√	0099, 0116

Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 2.5 TCI-A2	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 2.5 TCI-A2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 2.5 TCI-A2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 2.7 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 2.7 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 2.7 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 2.7 IDI-J	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 2.9 C/R-J	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 2.9 C/R-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 2.9 C/R-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 2.9 C/R-J	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 3.0 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 3.0 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 3.0 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2014	D 3.0 IDI-J	IMMO [Immobilizer]		√	√	√		0079, 0064, 0075, 0092, 0083, 0080, 0119
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 2.5 TCI-4D56	ENGINE [Engine Control]		√	√	√	√	

Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 2.5 TCI-4D56	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 2.5 TCI-4D56	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 2.5 TCI-4D56	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 2.5 TCI-A2	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 2.5 TCI-A2	AT [Automatic Transaxle]	√	√	√	√	√	0099, 0116
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 2.5 TCI-A2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 2.5 TCI-A2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 2.5 TCI-A2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 2.7 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 2.7 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 2.7 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 2.7 IDI-J	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 2.9 C/R-J	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 2.9 C/R-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 2.9 C/R-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 2.9 C/R-J	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119

Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 3.0 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 3.0 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 3.0 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2013	D 3.0 IDI-J	IMMO [Immobilizer]		√	√	√		0079, 0064, 0075, 0092, 0083, 0080, 0119
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 2.5 TCI-4D56	ENGINE [Engine Control]		√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 2.5 TCI-4D56	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 2.5 TCI-4D56	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 2.5 TCI-4D56	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 2.5 TCI-A2	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 2.5 TCI-A2	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 2.5 TCI-A2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 2.5 TCI-A2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 2.5 TCI-A2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 2.7 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 2.7 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 2.7 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051

Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 2.7 IDI-J	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 2.9 C/R-J	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 2.9 C/R-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 2.9 C/R-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 2.9 C/R-J	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 3.0 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 3.0 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 3.0 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2012	D 3.0 IDI-J	IMMO [Immobilizer]		√	√	√		0079, 0064, 0075, 0092, 0083, 0080, 0119
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2011	D 2.5 TCI-4D56	ENGINE [Engine Control]		√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2011	D 2.5 TCI-4D56	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2011	D 2.5 TCI-4D56	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2011	D 2.5 TCI-4D56	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2011	D 2.7 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2011	D 2.7 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2011	D 2.7 IDI-J	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083

Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2011	D 2.9 C/R-J	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2011	D 2.9 C/R-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2011	D 2.9 C/R-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2011	D 2.9 C/R-J	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2011	D 3.0 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2011	D 3.0 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2011	D 3.0 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2011	D 3.0 IDI-J	IMMO [Immobilizer]		√	√	√		0079, 0064, 0075, 0092, 0083, 0080, 0119
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2010	D 2.5 TCI-4D56	ENGINE [Engine Control]		√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2010	D 2.5 TCI-4D56	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2010	D 2.5 TCI-4D56	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2010	D 2.5 TCI-4D56	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2010	D 2.7 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2010	D 2.7 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2010	D 2.7 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2010	D 2.7 IDI-J	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083

Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2010	D 2.9 C/R-J	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2010	D 2.9 C/R-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2010	D 2.9 C/R-J	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2010	D 3.0 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2010	D 3.0 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2010	D 3.0 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2010	D 3.0 IDI-J	IMMO [Immobilizer]		√	√	√		0079, 0064, 0075, 0092, 0083, 0080, 0119
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2009	D 2.5 TCI-4D56	ENGINE [Engine Control]		√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2009	D 2.5 TCI-4D56	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2009	D 2.5 TCI-4D56	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2009	D 2.5 TCI-4D56	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2009	D 2.7 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2009	D 2.7 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2009	D 2.7 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2009	D 2.7 IDI-J	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 00 0S(PU)	2009	D 2.9 C/R-J	ENGINE [Engine Control]	√	√	√	√	√	0047

Europe/General	K2500/K2700/K3000/K300 0S(PU)	2009	D 2.9 C/R-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2009	D 2.9 C/R-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2009	D 2.9 C/R-J	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2009	D 3.0 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2009	D 3.0 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2009	D 3.0 IDI-J	IMMO [Immobilizer]		√	√	√		0079, 0064, 0075, 0092, 0083, 0080, 0119
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2008	D 2.5 TCI-4D56	ENGINE [Engine Control]		√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2008	D 2.5 TCI-4D56	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2008	D 2.5 TCI-4D56	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2008	D 2.5 TCI-4D56	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2008	D 2.7 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2008	D 2.7 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2008	D 2.7 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2008	D 2.7 IDI-J	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2008	D 2.9 C/R-J	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067, 0047
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2008	D 2.9 C/R-J	AT [Automatic Transaxle]	√	√	√	√	√	

Europe/General	K2500/K2700/K3000/K300 0S(PU)	2008	D 2.9 C/R-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2008	D 2.9 C/R-J	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2008	D 3.0 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2008	D 3.0 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2008	D 3.0 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2008	D 3.0 IDI-J	IMMO [Immobilizer]		√	√	√		0079, 0064, 0075, 0092, 0083, 0080, 0119
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2007	D 2.5 TCI-4D56	ENGINE [Engine Control]		√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2007	D 2.5 TCI-4D56	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2007	D 2.5 TCI-4D56	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2007	D 2.7 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2007	D 2.7 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2007	D 2.7 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2007	D 2.7 IDI-J	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2007	D 2.9 C/R-J	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067, 0047
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2007	D 2.9 C/R-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2007	D 2.9 C/R-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051

Europe/General	K2500/K2700/K3000/K300 0S(PU)	2007	D 2.9 C/R-J	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2007	D 3.0 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2007	D 3.0 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2007	D 3.0 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2007	D 3.0 IDI-J	IMMO [Immobilizer]		√	√	√		0079, 0064, 0075, 0092, 0083, 0080, 0119
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2006	D 2.5 TCI-4D56	ENGINE [Engine Control]		√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2006	D 2.5 TCI-4D56	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2006	D 2.5 TCI-4D56	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2006	D 2.5 TCI-4D56	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2006	D 2.7 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2006	D 2.7 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2006	D 2.7 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2006	D 2.7 IDI-J	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2006	D 2.9 C/R-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2006	D 2.9 C/R-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2006	D 2.9 C/R-J	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119

Europe/General	K2500/K2700/K3000/K300 0S(PU)	2006	D 3.0 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2006	D 3.0 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2006	D 3.0 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2006	D 3.0 IDI-J	IMMO [Immobilizer]		√	√	√		0079, 0064, 0075, 0092, 0083, 0080, 0119
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2005	D 2.5 TCI-4D56	ENGINE [Engine Control]		√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2005	D 2.5 TCI-4D56	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2005	D 2.5 TCI-4D56	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2005	D 2.5 TCI-4D56	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2005	D 2.7 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2005	D 2.7 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2005	D 2.7 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2005	D 2.7 IDI-J	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2005	D 3.0 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2005	D 3.0 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2005	D 3.0 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2005	D 3.0 IDI-J	IMMO [Immobilizer]		√	√	√		0079, 0064, 0075, 0092, 0083, 0080, 0119

Europe/General	K2500/K2700/K3000/K300 0S(PU)	2004	D 2.5 TCI-4D56	ENGINE [Engine Control]		√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2004	D 2.5 TCI-4D56	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2004	D 2.5 TCI-4D56	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2004	D 2.7 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2004	D 2.7 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2004	D 2.7 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2004	D 2.7 IDI-J	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2004	D 3.0 IDI-J	ENGINE [Engine Control]	√	√	√	√	√	0028, 0047, 0067
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2004	D 3.0 IDI-J	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2004	D 3.0 IDI-J	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	K2500/K2700/K3000/K300 0S(PU)	2004	D 3.0 IDI-J	IMMO [Immobilizer]		√	√	√		0079, 0064, 0075, 0092, 0083, 0080, 0119
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	ENGINE [Engine Control]	√	√	√	√	√	0126, 0029, 0094, 0048
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	4WD [4WD Control]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	ECS [Electronic Control Suspension]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058

Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	PGS [Parking Guide System]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	AVM [Surround View Monitor System]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	IMMO [Immobilizer]		√	√	√		0075, 0072, 0112, 0072, 0075, 0083, 0092
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	SCM [Steering Column Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	SCR [Selective Catalytic Reduction]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	D 3.0 TCI-S2	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	ESC [Electronic Stability Control]	√	√	√	√	√	0051

Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	4WD [4WD Control]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	ECS [Electronic Control Suspension]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	PGS [Parking Guide System]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	AVM [Surround View Monitor System]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	IMMO [Immobilizer]		√	√	√		0075, 0072, 0112, 0092, 0083
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	AMP [Amplifier]						0003
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	SCM [Steering Column Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	CLU [Cluster Module]	√	√	√	√	√	

Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	SCR [Selective Catalytic Reduction]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2017	G 3.8 MPI LAMBDA	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	D 3.0 TCI-S2	CODE [Transmitter Code Saving]				√		0022

Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	ECS [ECS (Mando)]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	IPM [Instrument Panel Module (Unleaded)]	√	√	√	√	√	

Europe/General	MOHAVE/BORREGO(H M)	2016	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0094, 0098, 0126
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0014, 0099
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	ECS [NON - ECS]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2016	G 4.6 DOHC	CODE [Transmitter Code Saving]				√		0022

Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	ECS [NON - ECS]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	D 3.0 TCI-S2	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126

Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	ECS [ECS (Mando)]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	IPM [Instrument Panel Module (Unleaded)]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	IPM [Instrument Panel Module (Leaded)]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022

Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0094, 0098, 0126
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0014, 0099
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	ECS [NON - ECS]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2015	G 4.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	AT [Automatic Transaxle]	√	√	√	√		0099

Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	ECS [NON - ECS]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	D 3.0 TCI-S2	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	

Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	ECS [ECS (Mando)]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	IPM [Instrument Panel Module (Unleaded)]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	IPM [Instrument Panel Module (Leaded)]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0094, 0098, 0126
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0014, 0099

Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	ECS [NON - ECS]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2014	G 4.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	AIRBAG [Airbag Control]	√	√	√			

Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	ECS [NON - ECS]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	D 3.0 TCI-S2	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051

Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	ECS [ECS (Mando)]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	IPM [Instrument Panel Module (Unleaded)]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	IPM [Instrument Panel Module (Leaded)]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0094, 0098, 0126
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0014, 0099
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	AIRBAG [Airbag Control]	√	√	√			

Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	ECS [NON - ECS]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2013	G 4.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	4WD [4WD (EST)]	√	√	√	√		

Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	ECS [NON - ECS]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	D 3.0 TCI-S2	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	ECS [ECS (Mando)]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	IPM [Instrument Panel Module (Unleaded)]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	IPM [Instrument Panel Module (Leaded)]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0094, 0098, 0126
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0014, 0099
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	4WD [4WD (TOD)]	√	√	√	√	√	0120

Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	ECS [NON - ECS]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2012	G 4.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	AT [Automatic Transaxle]	√	√	√	√	√	0014, 0099
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	EPS [Electronic Power Steering]	√	√	√	√		

Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	ECS [ECS (Mando)]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	IMMO [Immobilizer]				√		0075, 0072, 0112, 0075, 0092, 0083, 0119
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	D 3.0 TCI-S	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	4WD [4WD (TOD)]	√	√	√	√	√	0120

Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	ECS [ECS (Mando)]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	IPM [Instrument Panel Module (Unleaded)]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	IPM [Instrument Panel Module (Leaded)]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0094, 0098, 0126
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0014, 0099
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	EPS [Electronic Power Steering]	√	√	√	√		

Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	ECS [NON - ECS]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2011	G 4.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	AT [Automatic Transaxle]	√	√	√	√	√	0014, 0099
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	AHLS [AHLS]	√	√	√	√		0074, 0107

Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	IMMO [Immobilizer]				√		0075, 0112, 0072, 0075, 0083, 0092, 0119
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	D 3.0 TCI-S	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	ECS [ECS (Mando)]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058

Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	IPM [Instrument Panel Module (Unleaded)]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0094, 0098, 0126
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0014, 0099
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	ECS [NON - ECS]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	AHLS [AHLS]	√	√	√	√		0074, 0107

Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2010	G 4.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	AT [Automatic Transaxle]	√	√	√	√	√	0014, 0099
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	ECS [ECS (Mando)]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	IMMO [Immobilizer]				√		0075, 0112, 0072, 0075, 0083, 0092, 0119

Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	D 3.0 TCI-S	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	ECS [ECS (Mando)]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112

Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	IPM [Instrument Panel Module (Unleaded)]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	IPM [Instrument Panel Module (Leaded)]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0094, 0098, 0126
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0014, 0099
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	4WD [4WD (TOD)]	√	√	√	√	√	0120
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	4WD [4WD (EST)]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	ECS [NON - ECS]	√	√	√	√	√	0002, 0054, 0056, 0057, 0058
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	AHLS [AHLS]	√	√	√	√		0074, 0107
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102

Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	FAM [Front Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	IMS [Integrated Memory System]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	SCM [Steering Column Module]		√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	OPTION [User Option]				√		
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	RAM [Rear Area Module]	√	√	√	√	√	
Europe/General	MOHAVE/BORREGO(H M)	2009	G 4.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0126
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	AT [Double Clutch Transmission (6DCT)]	√	√	√	√		
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	ABSESC [Electronic Stability Control (+AHB)]	√	√	√	√	√	0046, 0059
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	AEB [Autonomous Emergency Braking System]	√	√	√	√		
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	BMS [HEV Battery System]	√	√	√	√	√	0103
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	HCULDC [HEV Control System (+LDC)]	√	√	√	√	√	0038, 0039, 0040, 0066, 0069, 0097, 0113
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	MCU [HEV Motor Control System]	√	√	√	√		0037, 0053, 0082
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012

Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	AAF [Active Air Flap]	√	√	√	√	√	
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	AMP [Amplifier]						0003
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	IBU - BCM [Intergrated Body Control Unit - BCM]	√	√	√	√	√	
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	IBU - TPMS [Intergrated Body Control Unit - TPMS]	√	√	√			
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	IGPM [Intergrated Gateway & Power Control Module]	√	√	√	√	√	0041
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	ECALL [e - Call]	√	√	√			
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	VESS [Virtual Engine Sound System]	√	√	√		√	
Europe/General	Niro(DE HEV)	2017	G 1.6 GDI KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPIRUS(GH)	2010	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	OPIRUS(GH)	2010	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	OPIRUS(GH)	2010	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094
Europe/General	OPIRUS(GH)	2010	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPIRUS(GH)	2010	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	OPIRUS(GH)	2010	G 2.7 DOHC	AIRCON [Air Conditioner]		√	√	√	√	
Europe/General	OPIRUS(GH)	2010	G 2.7 DOHC	EPS [Electronic Power Steering]		√	√	√		
Europe/General	OPIRUS(GH)	2010	G 2.7 DOHC	ECS [Electronic Control Suspension]		√	√	√	√	
Europe/General	OPIRUS(GH)	2010	G 2.7 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	OPIRUS(GH)	2010	G 2.7 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPIRUS(GH)	2010	G 2.7 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	OPIRUS(GH)	2010	G 2.7 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	OPIRUS(GH)	2010	G 2.7 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	OPIRUS(GH)	2010	G 2.7 DOHC	PWM [Power Window Main]		√	√		√	
Europe/General	OPIRUS(GH)	2010	G 2.7 DOHC	PWA [Power Window Assist]		√	√		√	
Europe/General	OPIRUS(GH)	2010	G 2.7 DOHC	PSM [Power Seat Module]		√	√	√	√	

Europe/General	OPIRUS(GH)	2010	G 2.7 DOHC	TILT [Tilt & Telescope]		√	√	√	√	
Europe/General	OPIRUS(GH)	2010	G 2.7 DOHC	BCM [Body Control Module]	√	√	√		√	
Europe/General	OPIRUS(GH)	2010	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0096
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	ESP [Electronic Stability Program]		√	√	√	√	
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	AIRCON [Air Conditioner]		√	√	√	√	
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	EPS [Electronic Power Steering]		√	√	√		
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	ECS [Electronic Control Suspension]		√	√	√	√	
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	PWM [Power Window Main]		√	√		√	
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	PWA [Power Window Assist]		√	√		√	
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	PSM [Power Seat Module]		√	√	√	√	
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	TILT [Tilt & Telescope]		√	√	√	√	
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	BCM [Body Control Module]	√	√	√		√	
Europe/General	OPIRUS(GH)	2010	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0096
Europe/General	OPIRUS(GH)	2009	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	OPIRUS(GH)	2009	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	OPIRUS(GH)	2009	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094
Europe/General	OPIRUS(GH)	2009	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPIRUS(GH)	2009	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	OPIRUS(GH)	2009	G 2.7 DOHC	AIRCON [Air Conditioner]		√	√	√	√	
Europe/General	OPIRUS(GH)	2009	G 2.7 DOHC	EPS [Electronic Power Steering]		√	√	√		
Europe/General	OPIRUS(GH)	2009	G 2.7 DOHC	ECS [Electronic Control Suspension]		√	√	√	√	
Europe/General	OPIRUS(GH)	2009	G 2.7 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	OPIRUS(GH)	2009	G 2.7 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPIRUS(GH)	2009	G 2.7 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	OPIRUS(GH)	2009	G 2.7 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	OPIRUS(GH)	2009	G 2.7 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	OPIRUS(GH)	2009	G 2.7 DOHC	PWM [Power Window Main]		√	√		√	
Europe/General	OPIRUS(GH)	2009	G 2.7 DOHC	PWA [Power Window Assist]		√	√		√	
Europe/General	OPIRUS(GH)	2009	G 2.7 DOHC	PSM [Power Seat Module]		√	√	√	√	
Europe/General	OPIRUS(GH)	2009	G 2.7 DOHC	TILT [Tilt & Telescope]		√	√	√	√	
Europe/General	OPIRUS(GH)	2009	G 2.7 DOHC	BCM [Body Control Module]	√	√	√		√	
Europe/General	OPIRUS(GH)	2009	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0096
Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094

Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	ESP [Electronic Stability Program]		√	√	√	√	
Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	AIRCON [Air Conditioner]		√	√	√	√	
Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	EPS [Electronic Power Steering]		√	√	√		
Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	ECS [Electronic Control Suspension]		√	√	√	√	
Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	PWM [Power Window Main]		√	√		√	
Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	PWA [Power Window Assist]		√	√		√	
Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	PSM [Power Seat Module]		√	√	√	√	
Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	TILT [Tilt & Telescope]		√	√	√	√	
Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	BCM [Body Control Module]	√	√	√		√	
Europe/General	OPIRUS(GH)	2009	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0096
Europe/General	OPIRUS(GH)	2008	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	OPIRUS(GH)	2008	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	OPIRUS(GH)	2008	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094
Europe/General	OPIRUS(GH)	2008	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPIRUS(GH)	2008	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	OPIRUS(GH)	2008	G 2.7 DOHC	AIRCON [Air Conditioner]		√	√	√	√	
Europe/General	OPIRUS(GH)	2008	G 2.7 DOHC	EPS [Electronic Power Steering]		√	√	√		
Europe/General	OPIRUS(GH)	2008	G 2.7 DOHC	ECS [Electronic Control Suspension]		√	√	√	√	
Europe/General	OPIRUS(GH)	2008	G 2.7 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	OPIRUS(GH)	2008	G 2.7 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPIRUS(GH)	2008	G 2.7 DOHC	IFU [Interface Unit]	√	√	√		√	0027
Europe/General	OPIRUS(GH)	2008	G 2.7 DOHC	SMK [Smart Key Unit]		√	√	√	√	0108
Europe/General	OPIRUS(GH)	2008	G 2.7 DOHC	SMKCODE [Smart Key Code Saving]				√		0111
Europe/General	OPIRUS(GH)	2008	G 2.7 DOHC	PWM [Power Window Main]		√	√		√	
Europe/General	OPIRUS(GH)	2008	G 2.7 DOHC	PWA [Power Window Assist]		√	√		√	
Europe/General	OPIRUS(GH)	2008	G 2.7 DOHC	PSM [Power Seat Module]		√	√	√	√	
Europe/General	OPIRUS(GH)	2008	G 2.7 DOHC	TILT [Tilt & Telescope]		√	√	√	√	
Europe/General	OPIRUS(GH)	2008	G 2.7 DOHC	BCM [Body Control Module]	√	√	√		√	
Europe/General	OPIRUS(GH)	2008	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0096
Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094
Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	ESP [Electronic Stability Program]		√	√	√	√	
Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	AIRCON [Air Conditioner]		√	√	√	√	
Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	EPS [Electronic Power Steering]		√	√	√		
Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	ECS [Electronic Control Suspension]		√	√	√	√	

Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	IFU [Interface Unit]	√	√	√		√	0027
Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	SMK [Smart Key Unit]		√	√	√	√	0108
Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	SMKCODE [Smart Key Code Saving]				√		0111
Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	PWM [Power Window Main]		√	√		√	
Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	PWA [Power Window Assist]		√	√		√	
Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	PSM [Power Seat Module]		√	√	√	√	
Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	TILT [Tilt & Telescope]		√	√	√	√	
Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	BCM [Body Control Module]	√	√	√		√	
Europe/General	OPIRUS(GH)	2008	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0096
Europe/General	OPIRUS(GH)	2007	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	OPIRUS(GH)	2007	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	OPIRUS(GH)	2007	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094
Europe/General	OPIRUS(GH)	2007	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPIRUS(GH)	2007	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	OPIRUS(GH)	2007	G 2.7 DOHC	AIRCON [Air Conditioner]		√	√	√	√	
Europe/General	OPIRUS(GH)	2007	G 2.7 DOHC	EPS [Electronic Power Steering]		√	√	√		
Europe/General	OPIRUS(GH)	2007	G 2.7 DOHC	ECS [Electronic Control Suspension]		√	√	√	√	
Europe/General	OPIRUS(GH)	2007	G 2.7 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	OPIRUS(GH)	2007	G 2.7 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPIRUS(GH)	2007	G 2.7 DOHC	IFU [Interface Unit]	√	√	√		√	0027
Europe/General	OPIRUS(GH)	2007	G 2.7 DOHC	SMK [Smart Key Unit]		√	√	√	√	0108
Europe/General	OPIRUS(GH)	2007	G 2.7 DOHC	SMKCODE [Smart Key Code Saving]				√		0111
Europe/General	OPIRUS(GH)	2007	G 2.7 DOHC	PWM [Power Window Main]		√	√		√	
Europe/General	OPIRUS(GH)	2007	G 2.7 DOHC	PWA [Power Window Assist]		√	√		√	
Europe/General	OPIRUS(GH)	2007	G 2.7 DOHC	PSM [Power Seat Module]		√	√	√	√	
Europe/General	OPIRUS(GH)	2007	G 2.7 DOHC	TILT [Tilt & Telescope]		√	√	√	√	
Europe/General	OPIRUS(GH)	2007	G 2.7 DOHC	BCM [Body Control Module]	√	√	√		√	
Europe/General	OPIRUS(GH)	2007	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0096
Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	ENGINE [Leaded]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094
Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	ESP [Electronic Stability Program]		√	√	√	√	
Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	AIRCON [Air Conditioner]		√	√	√	√	
Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	EPS [Electronic Power Steering]		√	√	√		
Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	ECS [Electronic Control Suspension]		√	√	√	√	
Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	IFU [Interface Unit]	√	√	√		√	0027
Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	SMK [Smart Key Unit]		√	√	√	√	0108
Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	SMKCODE [Smart Key Code Saving]				√		0111
Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	PWM [Power Window Main]		√	√		√	

Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	PWA [Power Window Assist]		√	√		√	
Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	PSM [Power Seat Module]		√	√	√	√	
Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	TILT [Tilt & Telescope]		√	√	√	√	
Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	BCM [Body Control Module]	√	√	√		√	
Europe/General	OPIRUS(GH)	2007	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0096
Europe/General	OPIRUS(GH)	2006	G 3.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	OPIRUS(GH)	2006	G 3.0 DOHC	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	OPIRUS(GH)	2006	G 3.0 DOHC	ESP [Electronic Stability Program]		√	√	√	√	
Europe/General	OPIRUS(GH)	2006	G 3.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	OPIRUS(GH)	2006	G 3.0 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	OPIRUS(GH)	2006	G 3.0 DOHC	ECS [Electronic Control Suspension]		√	√	√	√	
Europe/General	OPIRUS(GH)	2006	G 3.0 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	OPIRUS(GH)	2006	G 3.0 DOHC	IMMO [Immobilizer]				√		0076, 0119
Europe/General	OPIRUS(GH)	2006	G 3.0 DOHC	SMK [Smart Key Unit]		√	√	√	√	
Europe/General	OPIRUS(GH)	2006	G 3.0 DOHC	SMKCODE [Smart Key Code Saving]				√		0111
Europe/General	OPIRUS(GH)	2006	G 3.0 DOHC	PSM [Power Seat Module]		√	√	√	√	
Europe/General	OPIRUS(GH)	2006	G 3.0 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPIRUS(GH)	2006	G 3.0 DOHC	PWA [Power Window Assist]		√	√		√	
Europe/General	OPIRUS(GH)	2006	G 3.0 DOHC	TILT [Tilt & Telescope]		√	√	√	√	
Europe/General	OPIRUS(GH)	2006	G 3.0 DOHC	PWM [Power Window Main]		√	√		√	
Europe/General	OPIRUS(GH)	2006	G 3.0 DOHC	CODE [Transmitter Code Saving]				√		0096
Europe/General	OPIRUS(GH)	2006	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	OPIRUS(GH)	2006	G 3.5 DOHC	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	OPIRUS(GH)	2006	G 3.5 DOHC	ESP [Electronic Stability Program]		√	√	√	√	
Europe/General	OPIRUS(GH)	2006	G 3.5 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	OPIRUS(GH)	2006	G 3.5 DOHC	AIRCON [Air Conditioner]		√	√	√	√	
Europe/General	OPIRUS(GH)	2006	G 3.5 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	OPIRUS(GH)	2006	G 3.5 DOHC	ECS [Electronic Control Suspension]		√	√	√	√	
Europe/General	OPIRUS(GH)	2006	G 3.5 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	OPIRUS(GH)	2006	G 3.5 DOHC	IMMO [Immobilizer]				√		0076, 0119
Europe/General	OPIRUS(GH)	2006	G 3.5 DOHC	SMK [Smart Key Unit]		√	√	√	√	
Europe/General	OPIRUS(GH)	2006	G 3.5 DOHC	SMKCODE [Smart Key Code Saving]				√		0111
Europe/General	OPIRUS(GH)	2006	G 3.5 DOHC	PSM [Power Seat Module]		√	√	√	√	
Europe/General	OPIRUS(GH)	2006	G 3.5 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPIRUS(GH)	2006	G 3.5 DOHC	PWA [Power Window Assist]		√	√		√	
Europe/General	OPIRUS(GH)	2006	G 3.5 DOHC	TILT [Tilt & Telescope]		√	√	√	√	
Europe/General	OPIRUS(GH)	2006	G 3.5 DOHC	PWM [Power Window Main]		√	√		√	
Europe/General	OPIRUS(GH)	2006	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0096
Europe/General	OPIRUS(GH)	2005	G 3.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	OPIRUS(GH)	2005	G 3.0 DOHC	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	OPIRUS(GH)	2005	G 3.0 DOHC	ESP [Electronic Stability Program]		√	√	√	√	
Europe/General	OPIRUS(GH)	2005	G 3.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	OPIRUS(GH)	2005	G 3.0 DOHC	AIRCON [Air Conditioner]		√	√	√	√	
Europe/General	OPIRUS(GH)	2005	G 3.0 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	OPIRUS(GH)	2005	G 3.0 DOHC	ECS [Electronic Control Suspension]		√	√	√	√	

Europe/General	OPIRUS(GH)	2005	G 3.0 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	OPIRUS(GH)	2005	G 3.0 DOHC	IMMO [Immobilizer]				√		0076, 0119
Europe/General	OPIRUS(GH)	2005	G 3.0 DOHC	SMK [Smart Key Unit]		√	√	√	√	
Europe/General	OPIRUS(GH)	2005	G 3.0 DOHC	PSM [Power Seat Module]		√	√	√	√	
Europe/General	OPIRUS(GH)	2005	G 3.0 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPIRUS(GH)	2005	G 3.0 DOHC	PWA [Power Window Assist]		√	√		√	
Europe/General	OPIRUS(GH)	2005	G 3.0 DOHC	TILT [Tilt & Telescope]		√	√	√	√	
Europe/General	OPIRUS(GH)	2005	G 3.0 DOHC	PWM [Power Window Main]		√	√		√	
Europe/General	OPIRUS(GH)	2005	G 3.0 DOHC	CODE [Transmitter Code Saving]				√		0096
Europe/General	OPIRUS(GH)	2005	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	OPIRUS(GH)	2005	G 3.5 DOHC	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	OPIRUS(GH)	2005	G 3.5 DOHC	ESP [Electronic Stability Program]		√	√	√	√	
Europe/General	OPIRUS(GH)	2005	G 3.5 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	OPIRUS(GH)	2005	G 3.5 DOHC	AIRCON [Air Conditioner]		√	√	√	√	
Europe/General	OPIRUS(GH)	2005	G 3.5 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	OPIRUS(GH)	2005	G 3.5 DOHC	ECS [Electronic Control Suspension]		√	√	√	√	
Europe/General	OPIRUS(GH)	2005	G 3.5 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	OPIRUS(GH)	2005	G 3.5 DOHC	IMMO [Immobilizer]				√		0076, 0119
Europe/General	OPIRUS(GH)	2005	G 3.5 DOHC	SMK [Smart Key Unit]		√	√	√	√	
Europe/General	OPIRUS(GH)	2005	G 3.5 DOHC	SMKCODE [Smart Key Code Saving]				√		0111
Europe/General	OPIRUS(GH)	2005	G 3.5 DOHC	PSM [Power Seat Module]		√	√	√	√	
Europe/General	OPIRUS(GH)	2005	G 3.5 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPIRUS(GH)	2005	G 3.5 DOHC	PWA [Power Window Assist]		√	√		√	
Europe/General	OPIRUS(GH)	2005	G 3.5 DOHC	TILT [Tilt & Telescope]		√	√	√	√	
Europe/General	OPIRUS(GH)	2005	G 3.5 DOHC	PWM [Power Window Main]		√	√		√	
Europe/General	OPIRUS(GH)	2005	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0096
Europe/General	OPIRUS(GH)	2004	G 3.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	OPIRUS(GH)	2004	G 3.0 DOHC	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	OPIRUS(GH)	2004	G 3.0 DOHC	ESP [Electronic Stability Program]		√	√	√	√	
Europe/General	OPIRUS(GH)	2004	G 3.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	OPIRUS(GH)	2004	G 3.0 DOHC	AIRCON [Air Conditioner]		√	√	√	√	
Europe/General	OPIRUS(GH)	2004	G 3.0 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	OPIRUS(GH)	2004	G 3.0 DOHC	ECS [Electronic Control Suspension]		√	√	√	√	
Europe/General	OPIRUS(GH)	2004	G 3.0 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	OPIRUS(GH)	2004	G 3.0 DOHC	IMMO [Immobilizer]				√		0076, 0119
Europe/General	OPIRUS(GH)	2004	G 3.0 DOHC	SMK [Smart Key Unit]		√	√	√	√	
Europe/General	OPIRUS(GH)	2004	G 3.0 DOHC	SMKCODE [Smart Key Code Saving]				√		0111
Europe/General	OPIRUS(GH)	2004	G 3.0 DOHC	PSM [Power Seat Module]		√	√	√	√	
Europe/General	OPIRUS(GH)	2004	G 3.0 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPIRUS(GH)	2004	G 3.0 DOHC	PWA [Power Window Assist]		√	√		√	
Europe/General	OPIRUS(GH)	2004	G 3.0 DOHC	TILT [Tilt & Telescope]		√	√	√	√	
Europe/General	OPIRUS(GH)	2004	G 3.0 DOHC	PWM [Power Window Main]		√	√		√	
Europe/General	OPIRUS(GH)	2004	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	OPIRUS(GH)	2004	G 3.5 DOHC	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	OPIRUS(GH)	2004	G 3.5 DOHC	ESP [Electronic Stability Program]		√	√	√	√	

Europe/General	OPIRUS(GH)	2004	G 3.5 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	OPIRUS(GH)	2004	G 3.5 DOHC	AIRCON [Air Conditioner]		√	√	√	√	
Europe/General	OPIRUS(GH)	2004	G 3.5 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	OPIRUS(GH)	2004	G 3.5 DOHC	ECS [Electronic Control Suspension]		√	√	√	√	
Europe/General	OPIRUS(GH)	2004	G 3.5 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	OPIRUS(GH)	2004	G 3.5 DOHC	IMMO [Immobilizer]				√		0076, 0119
Europe/General	OPIRUS(GH)	2004	G 3.5 DOHC	SMK [Smart Key Unit]		√	√	√	√	
Europe/General	OPIRUS(GH)	2004	G 3.5 DOHC	SMKCODE [Smart Key Code Saving]				√		0111
Europe/General	OPIRUS(GH)	2004	G 3.5 DOHC	PSM [Power Seat Module]		√	√	√	√	
Europe/General	OPIRUS(GH)	2004	G 3.5 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPIRUS(GH)	2004	G 3.5 DOHC	PWA [Power Window Assist]		√	√		√	
Europe/General	OPIRUS(GH)	2004	G 3.5 DOHC	TILT [Tilt & Telescope]		√	√	√	√	
Europe/General	OPIRUS(GH)	2004	G 3.5 DOHC	PWM [Power Window Main]		√	√		√	
Europe/General	OPIRUS(GH)	2004	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0096
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI HEV	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0126
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI HEV	AT [Automatic Transaxle]	√	√	√	√		0030, 0099
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI HEV	AEB [Autonomous Emergency Braking System]	√	√	√	√		
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI HEV	ABS [Electronic Stability Program]	√	√	√	√	√	0046, 0059
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI HEV	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI HEV	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI HEV	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI HEV	AIRCON [Dual auto (HCC)]	√	√	√	√	√	
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI HEV	BMS [HEV Battery System]	√	√	√	√	√	0103
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI HEV	HCULDC [HCU / Low DC - DC Converter]	√	√	√	√	√	0026, 0039, 0040, 0069
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI HEV	MCU [HEV Motor Control System]	√	√	√	√		0037, 0082
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI HEV	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI HEV	SVMS [Surround View Monitor System]	√	√	√	√	√	0006
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI HEV	PGS [Parking Guide System]	√	√	√	√		
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI HEV	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI HEV	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI HEV	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012

Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI	AAF [Active Air Flap]	√	√	√	√	√	
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI	SMKCODE [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI	AMP [Amplifier]						0003
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI	CGW [Central Gateway]	√	√	√			0041
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI	ECALL [e - Call]	√	√	√			
Europe/General	OPTIMA HEV(JF HEV)	2016	G 2.0 NU GDI	VESS [Virtual Engine Sound System]	√	√	√		√	
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	ESP [Electronic Stability Program]	√	√	√	√	√	0046, 0059, 0078
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	EPB [Electronic Parking Brake]	√	√	√	√	√	0084, 0085
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	BMS [HEV Battery System]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	HCU [HEV Control System]	√	√	√	√		0026, 0039, 0040, 0069
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	MCU [HEV Motor Control System]	√	√	√	√	√	0037, 0082
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	LDC [Low DC / DC Converter]	√	√	√	√		

Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	EPS [Power Steering]	√	√	√	√		
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	LKAS [Lane Keeping Assist System]	√	√	√	√		
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	AAF [Active Air Flap]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2015	G 2.0 HEV	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	ENGINE [Engine Control]	√	√	√	√		0126, 0011, 0011, 0126, 0094, 0098
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	AT [Automatic Transaxle]	√	√	√	√	√	0030, 0099
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	AHB [Active Hydraulic Booster]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	BMS [HEV Battery System]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	HCU [HEV Control System]	√	√	√	√		0026, 0039, 0040, 0069
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	MCU [HEV Motor Control System]	√	√	√	√	√	0037, 0082
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	LDC [Low DC / DC Converter]	√	√	√	√		
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	EPS [Power Steering]	√	√	√	√		
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	

Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	AAF [Active Air Flap]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	SMK [Smart Key Unit]	√	√	√	√	√	0035, 0036, 0045, 0102
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2014	G 2.0 HEV	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	ENGINE [Engine Control]	√	√	√	√		0126, 0011, 0094, 0098
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	AT [Automatic Transaxle]	√	√	√	√	√	0030, 0099
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	AHB [Active Hydraulic Booster]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	BMS [HEV Battery System]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	HCU [HEV Control System]	√	√	√	√		0026, 0039, 0040, 0069
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	MCU [HEV Motor Control System]	√	√	√	√	√	0037, 0082
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	LDC [Low DC / DC Converter]	√	√	√	√		
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	EPS [Power Steering]	√	√	√	√		
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	AAF [Active Air Flap]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	SMK [Smart Key Unit]	√	√	√	√	√	0035, 0036, 0045, 0102
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	BCM [Body Control Module]	√	√	√	√	√	

Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA HEV(TF HEV)	2013	G 2.0 HEV	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0126
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	AT [Automatic Transaxle]	√	√	√	√		0030, 0099
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	ABSESC [Electronic Stability Program]	√	√	√	√	√	0046, 0059
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	AEB [Autonomous Emergency Braking (SCC / AEB)]	√	√	√	√		
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	BMS [HEV Battery System]	√	√	√	√	√	0103
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	HCULDC [HCU / Low DC - DC Converter]	√	√	√	√	√	0026, 0039, 0040, 0069
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	MCU [HEV Motor Control System]	√	√	√	√		0037, 0082
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	OBC [On Board Charger]	√	√	√	√		
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	TPMS [Tire Pressure Monitoring]	√	√	√			
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	SVMS [Surround View Monitor System]	√	√	√	√	√	0006
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	PGS [Parking Guide System]	√	√	√	√		
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	LDWS [Lane Departure Warning System (MFC)]	√	√	√	√		
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015

Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	AAF [Active Air Flap]	√	√	√	√	√	
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	AMP [Amplifier]						0003
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	CGW [Central Gateway]	√	√	√			0041
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	ECALL [e - Call]	√	√	√			
Europe/General	OPTIMA PHEV(JF PHEV)	2017	G 2.0 GDI NU(PHEV)	VESS [Virtual Engine Sound System]	√	√	√		√	
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0126
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	AT [Automatic Transaxle]	√	√	√	√		0030, 0099
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	ABSESC [ABS / ESC]	√	√	√	√	√	0046, 0059
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	AEB [Autonomous Emergency Braking (SCC / AEB)]	√	√	√	√		
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	BMS [HEV Battery System]	√	√	√	√	√	0103
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	HCULDC [HCU / Low DC - DC Converter]	√	√	√	√	√	0026, 0039, 0040, 0069
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	MCU [HEV Motor Control System]	√	√	√	√		0037, 0082

Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	OBC [On Board Charger]	√	√	√	√		
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	TPMS [Tire Pressure Monitoring]	√	√	√			
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	SVMS [Surround View Monitor System]	√	√	√	√	√	0006
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	PGS [Parking Guide System]	√	√	√	√		
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	LDWS [Lane Departure Warning System (MFC)]	√	√	√	√		
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	AAF [Active Air Flap]	√	√	√	√	√	
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	AMP [Amplifier]						0003
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	CGW [Central Gateway]	√	√	√			0041
Europe/General	OPTIMA PHEV(JF PHEV)	2016	G 2.0 GDI NU(PHEV)	VESS [Virtual Engine Sound System]	√	√	√		√	
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	AT [Double Clutch Transmission (7th)]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	AEB [Autonomous Emergency Braking]	√	√	√	√		

Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	PGS [Parking Guide System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling System (WGN)]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling System (Sedan)]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	PTG [Power Tailgate (WGN Only)]	√	√	√	√		0093
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	ECALL [e - Call]	√	√	√			
Europe/General	OPTIMA(JF)	2017	D 1.7 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	AT [Automatic Transaxle]	√	√	√	√		0005, 0099
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	PGS [Parking Guide System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	SPAS [Smart Parking Assist System]	√	√	√	√		

Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	AHLS [Auto Headlamp Leveling System (WGN)]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	AHLS [Auto Headlamp Leveling System (Sedan)]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	ECALL [e - Call]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.0 CVVL- NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	PGS [Parking Guide System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	ADM [Assist Door Module]	√	√	√	√	√	

Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	ECALL [e - Call]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.0 MPI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	PGS [Parking Guide System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	AHLS [Auto Headlamp Leveling System (WGN)]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	AHLS [Auto Headlamp Leveling System (Sedan)]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	ADM [Assist Door Module]	√	√	√	√	√	

Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	PTG [Power Tailgate ((WGN Only)]	√	√	√	√		0093
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	ECALL [e - Call]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	VESS [Electronic Sound Generator]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.0 T-GDI THETA2	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0100, 0126
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	PGS [Parking Guide System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	SPAS [Smart Parking Assist System]	√	√	√	√		

Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.4 GDI THETA2	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	EPS [Motor Driven Power Steering]	√	√	√	√		

Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	PGS [Parking Guide System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	ECALL [e - Call]	√	√	√			
Europe/General	OPTIMA(JF)	2017	G 2.4 MPI THETA2	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	AT [Double Clutch Transmission (7th)]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			

Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	PGS [Parking Guide System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	ECALL [e - Call]	√	√	√			
Europe/General	OPTIMA(JF)	2016	D 1.7 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	PGS [Parking Guide System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102

Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	ECALL [e - Call]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.0 CVVL- NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	PGS [Parking Guide System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	ECALL [e - Call]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.0 MPI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0100, 0126
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	AEB [Autonomous Emergency Braking]	√	√	√	√		

Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	PGS [Parking Guide System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	WPC [Wireless Power Charger]	√	√	√	√	√	

Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	ECALL [e - Call]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.0 T-GDI THETA2	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0100, 0126
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	PGS [Parking Guide System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102

Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	ECALL [e - Call]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.4 GDI THETA2	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	PGS [Parking Guide System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012

Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	ECALL [e - Call]	√	√	√			
Europe/General	OPTIMA(JF)	2016	G 2.4 MPI THETA2	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	AT [Automatic Transaxle]	√	√	√	√		
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	EPB [Parking Brake]	√	√	√	√	√	0017
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	ODS [Occupant Detection Sensor]	√	√	√	√		
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	PGS [Parking Guide System]	√	√	√	√		
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	BSD - L [Blind Spot Detection - L]	√	√	√	√	√	0012
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	BSD - R [Blind Spot Detection - R]	√	√	√	√	√	0012
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0045, 0102
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	AMP [Amplifier]						0003
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	DDM [Driver Door Module]	√	√	√	√	√	

Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 1.6 T-GDI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0100, 0126
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	EPB [Parking Brake]	√	√	√	√	√	0017
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	ODS [Occupant Detection Sensor]	√	√	√	√		
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	PGS [Parking Guide System]	√	√	√	√		
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	SVMS [Surround View Monitor System]	√	√	√	√	√	

Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	BSD - L [Blind Spot Detection - L]	√	√	√	√	√	0012
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	BSD - R [Blind Spot Detection - R]	√	√	√	√	√	0012
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0045, 0102
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	AMP [Amplifier]						0003
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.0 T-GDI THETA2	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0100, 0126

Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	EPB [Parking Brake]	√	√	√	√	√	0017
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	ODS [Occupant Detection Sensor]	√	√	√	√		
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	PGS [Parking Guide System]	√	√	√	√		
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	BSD - L [Blind Spot Detection - L]	√	√	√	√	√	0012
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	BSD - R [Blind Spot Detection - R]	√	√	√	√	√	0012
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	

Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0045, 0102
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	AMP [Amplifier]						0003
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(JFA) - For Mexico only	2016	G 2.4 GDI THETA2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	EPB [Electric Parking Brake]	√	√	√	√	√	0084, 0085
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	LKAS [Lane Keeping Assist System]	√	√	√	√		
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	AVN [Audio Video Navigation (4.0)]	√	√	√			
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	AVN [Audio Video Navigation (3.0)]		√				
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	PSM [Power Seat Module]	√	√	√	√	√	0106

Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	D 1.7 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	EPB [Electric Parking Brake]	√	√	√	√	√	0084, 0085
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	LKAS [Lane Keeping Assist System]	√	√	√	√		
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	AVN [Audio Video Navigation (3.0)]		√				
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.0 Nu MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI	EPB [Electric Parking Brake]	√	√	√	√	√	0084, 0085
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI	BSD [Blind Spot Detection]	√	√	√	√	√	

Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI THETA2	LKAS [Lane Keeping Assist System]	√	√	√	√		
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI THETA2	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI THETA2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI THETA2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI THETA2	AVN [Audio Video Navigation (4.0)]	√	√	√			
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI THETA2	AVN [Audio Video Navigation (3.0)]		√				
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI THETA2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI THETA2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI THETA2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.0 T-GDI THETA2	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	EPB [Electric Parking Brake]	√	√	√	√	√	0084, 0085
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	LKAS [Lane Keeping Assist System]	√	√	√	√		
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112

Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	AVN [Audio Video Navigation (4.0)]	√	√	√			
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.4 GDI THETA2	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	EPB [Electric Parking Brake]	√	√	√	√	√	0084, 0085
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	LKAS [Lane Keeping Assist System]	√	√	√	√		
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	AVN [Audio Video Navigation (3.0)]		√				
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	PSM [Power Seat Module]	√	√	√	√	√	0106

Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2015	G 2.4 MPI THETA2	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	EPB [Electric Parking Brake]	√	√	√	√	√	0084, 0085
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	LKAS [Lane Keeping Assist System]	√	√	√	√		
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	AVN [Audio Video Navigation (4.0)]	√	√	√			
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	AVN [Audio Video Navigation (3.0)]		√				
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	D 1.7 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	EPB [Electric Parking Brake]	√	√	√	√	√	0084, 0085
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	LKAS [Lane Keeping Assist System]	√	√	√	√		
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	AVN [Audio Video Navigation (4.0)]	√	√	√			
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	AVN [Audio Video Navigation (3.0)]		√				

Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.0 Nu MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	EPB [Electric Parking Brake]	√	√	√	√	√	0084, 0085
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	AVN [Audio Video Navigation (4.0)]	√	√	√			
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	AVN [Audio Video Navigation (3.0)]		√				
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.0 T-GDI THETA2	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126

Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	EPB [Electric Parking Brake]	√	√	√	√	√	0084, 0085
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	LKAS [Lane Keeping Assist System]	√	√	√	√		
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	AVN [Audio Video Navigation (4.0)]	√	√	√			
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	AVN [Audio Video Navigation (3.0)]		√				
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.4 GDI THETA2	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	EPB [Electric Parking Brake]	√	√	√	√	√	0084, 0085

Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	LKAS [Lane Keeping Assist System]	√	√	√	√		
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	AVN [Audio Video Navigation (4.0)]	√	√	√			
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	AVN [Audio Video Navigation (3.0)]		√				
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2014	G 2.4 MPI THETA2	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2013	D 1.7 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	D 1.7 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2013	D 1.7 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2013	D 1.7 TCI-U2	EPB [Electric Parking Brake]	√	√	√	√	√	0084, 0085
Europe/General	OPTIMA(TF)	2013	D 1.7 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2013	D 1.7 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2013	D 1.7 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	D 1.7 TCI-U2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2013	D 1.7 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2013	D 1.7 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	D 1.7 TCI-U2	LKAS [Lane Keeping Assist System]	√	√	√	√		
Europe/General	OPTIMA(TF)	2013	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling (GEN)]	√	√	√	√	√	

Europe/General	OPTIMA(TF)	2013	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling (EURO)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	D 1.7 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2013	D 1.7 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	D 1.7 TCI-U2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(TF)	2013	D 1.7 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	D 1.7 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	D 1.7 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0011, 0126, 0094, 0098
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0011, 0126, 0094, 0098
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0011, 0126, 0094, 0098
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	EPB [Electric Parking Brake]	√	√	√	√	√	0084, 0085
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	LKAS [Lane Keeping Assist System]	√	√	√	√		
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	AHLS [Auto Headlamp Leveling (EURO)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	AHLS [Auto Headlamp Leveling (GEN)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	ENGINE [Engine Control (Nu MPI - CVVL)]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	ENGINE [Engine Control (Nu MPI)]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	EPB [Electric Parking Brake]	√	√	√	√	√	0084, 0085
Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	SPAS [Smart Parking Assist System]	√	√	√	√	√	

Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	LKAS [Lane Keeping Assist System]	√	√	√	√		
Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	AHLS [Auto Headlamp Leveling (EURO)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	AHLS [Auto Headlamp Leveling (GEN)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.0 MPI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0094, 0098
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0094, 0098
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0094, 0098
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	EPB [EPB]	√	√	√	√	√	0084, 0085
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	LKAS [Lane Keeping Assist System]	√	√	√	√		
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	AHLS [Auto Headlamp Leveling (EURO)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	AHLS [Auto Headlamp Leveling (GEN)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	ENGINE [Engine Control]	√	√	√	√	√	0126, 0011, 0011, 0126, 0094, 0098
Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	EPB [EPB]	√	√	√	√	√	0084, 0085
Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	

Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	LKAS [Lane Keeping Assist System]	√	√	√	√		
Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	AHLS [Auto Headlamp Leveling (GEN)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	AHLS [Auto Headlamp Leveling (EURO)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2013	G 2.4 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2012	D 1.7 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	D 1.7 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2012	D 1.7 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2012	D 1.7 TCI-U2	EPB [Electric Parking Brake]	√	√	√	√	√	0084, 0085
Europe/General	OPTIMA(TF)	2012	D 1.7 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2012	D 1.7 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2012	D 1.7 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	D 1.7 TCI-U2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2012	D 1.7 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2012	D 1.7 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	D 1.7 TCI-U2	LKAS [Lane Keeping Assist System]	√	√	√	√		
Europe/General	OPTIMA(TF)	2012	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling (GEN)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	D 1.7 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2012	D 1.7 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2012	D 1.7 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	D 1.7 TCI-U2	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(TF)	2012	D 1.7 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	D 1.7 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	D 1.7 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0094, 0098
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0094, 0098
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0094, 0098
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	EPB [EPB]	√	√	√	√	√	0084, 0085
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	LKAS [Lane Keeping Assist System]	√	√	√	√		

Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	AHLS [Auto Headlamp Leveling (EURO)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	AHLS [Auto Headlamp Leveling (GEN)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0094, 0098
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0094, 0098
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0094, 0098
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	EPB [EPB]	√	√	√	√	√	0084, 0085
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	LKAS [Lane Keeping Assist System]	√	√	√	√		
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	AHLS [Auto Headlamp Leveling (EURO)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	AHLS [Auto Headlamp Leveling (GEN)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	ENGINE [Engine Control]	√	√	√	√	√	0126, 0011, 0094, 0098
Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	EPB [EPB]	√	√	√	√	√	0084, 0085
Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	LKAS [Lane Keeping Assist System]	√	√	√	√		

Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	AHLS [Auto Headlamp Leveling (GEN)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	AHLS [Auto Headlamp Leveling (EURO)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2012	G 2.4 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2011	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2011	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2011	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2011	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2011	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.0 DOHC	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2011	G 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2011	G 2.0 DOHC	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.0 DOHC	AHLS [Auto Headlamp Leveling (GEN)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.0 DOHC	AHLS [Auto Headlamp Leveling (EURO)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2011	G 2.0 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2011	G 2.0 DOHC	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.0 DOHC	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(TF)	2011	G 2.0 DOHC	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.0 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2011	G 2.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2011	G 2.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2011	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2011	G 2.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2011	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.4 DOHC	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2011	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2011	G 2.4 DOHC	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.4 DOHC	AHLS [Auto Headlamp Leveling (GEN)]	√	√	√	√	√	

Europe/General	OPTIMA(TF)	2011	G 2.4 DOHC	AHLS [Auto Headlamp Leveling (EURO)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2011	G 2.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2011	G 2.4 DOHC	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(TF)	2011	G 2.4 DOHC	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.4 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	OPTIMA(TF)	2011	G 2.4 GDI	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.4 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	OPTIMA(TF)	2011	G 2.4 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	OPTIMA(TF)	2011	G 2.4 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	OPTIMA(TF)	2011	G 2.4 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	OPTIMA(TF)	2011	G 2.4 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.4 GDI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	OPTIMA(TF)	2011	G 2.4 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	OPTIMA(TF)	2011	G 2.4 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.4 GDI	AHLS [Auto Headlamp Leveling (EURO)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.4 GDI	AHLS [Auto Headlamp Leveling (GEN)]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.4 GDI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	OPTIMA(TF)	2011	G 2.4 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0035, 0036, 0045, 0102
Europe/General	OPTIMA(TF)	2011	G 2.4 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.4 GDI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	OPTIMA(TF)	2011	G 2.4 GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.4 GDI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	OPTIMA(TF)	2011	G 2.4 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	Optima/Magentis(MG)	2010	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2010	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Optima/Magentis(MG)	2010	D 2.0 TCI-D	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Optima/Magentis(MG)	2010	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Optima/Magentis(MG)	2010	D 2.0 TCI-D	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2010	D 2.0 TCI-D	ECS [Electronic Control Suspension]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2010	D 2.0 TCI-D	IMMO [Immobilizer]				√		0075, 0072, 0112, 0075, 0092, 0083, 0119
Europe/General	Optima/Magentis(MG)	2010	D 2.0 TCI-D	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	Optima/Magentis(MG)	2010	D 2.0 TCI-D	SMKCODE [Smart Key Code Saving]				√		

Europe/General	Optima/Magentis(MG)	2010	D 2.0 TCI-D	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	Optima/Magentis(MG)	2010	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	
Europe/General	Optima/Magentis(MG)	2010	D 2.0 TCI-D	CODE [Transmitter Code Saving]				√		0022
Europe/General	Optima/Magentis(MG)	2010	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0094, 0098
Europe/General	Optima/Magentis(MG)	2010	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0011, 0126, 0094, 0098
Europe/General	Optima/Magentis(MG)	2010	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Optima/Magentis(MG)	2010	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Optima/Magentis(MG)	2010	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Optima/Magentis(MG)	2010	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2010	G 2.0 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2010	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Optima/Magentis(MG)	2010	G 2.0 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	Optima/Magentis(MG)	2010	G 2.0 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	Optima/Magentis(MG)	2010	G 2.0 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	Optima/Magentis(MG)	2010	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Optima/Magentis(MG)	2010	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Optima/Magentis(MG)	2010	G 2.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0011, 0126, 0094, 0098
Europe/General	Optima/Magentis(MG)	2010	G 2.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0011, 0126, 0094, 0098
Europe/General	Optima/Magentis(MG)	2010	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0011, 0011, 0126, 0094, 0098
Europe/General	Optima/Magentis(MG)	2010	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Optima/Magentis(MG)	2010	G 2.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Optima/Magentis(MG)	2010	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Optima/Magentis(MG)	2010	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2010	G 2.4 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	

Europe/General	Optima/Magentis(MG)	2010	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Optima/Magentis(MG)	2010	G 2.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	Optima/Magentis(MG)	2010	G 2.4 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	Optima/Magentis(MG)	2010	G 2.4 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	Optima/Magentis(MG)	2010	G 2.4 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Optima/Magentis(MG)	2010	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Optima/Magentis(MG)	2010	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062
Europe/General	Optima/Magentis(MG)	2010	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011
Europe/General	Optima/Magentis(MG)	2010	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011
Europe/General	Optima/Magentis(MG)	2010	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Optima/Magentis(MG)	2010	G 2.7 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	Optima/Magentis(MG)	2010	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Optima/Magentis(MG)	2010	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2010	G 2.7 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2010	G 2.7 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Optima/Magentis(MG)	2010	G 2.7 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	Optima/Magentis(MG)	2010	G 2.7 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	Optima/Magentis(MG)	2010	G 2.7 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	Optima/Magentis(MG)	2010	G 2.7 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Optima/Magentis(MG)	2009	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2009	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Optima/Magentis(MG)	2009	D 2.0 TCI-D	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2009	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Optima/Magentis(MG)	2009	D 2.0 TCI-D	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	Optima/Magentis(MG)	2009	D 2.0 TCI-D	ECS [Electronic Control Suspension]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2009	D 2.0 TCI-D	IMMO [Immobilizer]				√		0075, 0072, 0112, 0075, 0092, 0083, 0119
Europe/General	Optima/Magentis(MG)	2009	D 2.0 TCI-D	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	Optima/Magentis(MG)	2009	D 2.0 TCI-D	SMKCODE [Smart Key Code Saving]				√		
Europe/General	Optima/Magentis(MG)	2009	D 2.0 TCI-D	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	Optima/Magentis(MG)	2009	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	
Europe/General	Optima/Magentis(MG)	2009	D 2.0 TCI-D	CODE [Transmitter Code Saving]				√		0022
Europe/General	Optima/Magentis(MG)	2009	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0094, 0098
Europe/General	Optima/Magentis(MG)	2009	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0094, 0098
Europe/General	Optima/Magentis(MG)	2009	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0094, 0098
Europe/General	Optima/Magentis(MG)	2009	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Optima/Magentis(MG)	2009	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2009	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Optima/Magentis(MG)	2009	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2009	G 2.0 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2009	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Optima/Magentis(MG)	2009	G 2.0 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	Optima/Magentis(MG)	2009	G 2.0 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	Optima/Magentis(MG)	2009	G 2.0 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	Optima/Magentis(MG)	2009	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Optima/Magentis(MG)	2009	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Optima/Magentis(MG)	2009	G 2.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0094, 0098
Europe/General	Optima/Magentis(MG)	2009	G 2.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0094, 0098
Europe/General	Optima/Magentis(MG)	2009	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0094, 0098

Europe/General	Optima/Magentis(MG)	2009	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Optima/Magentis(MG)	2009	G 2.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2009	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Optima/Magentis(MG)	2009	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2009	G 2.4 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2009	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Optima/Magentis(MG)	2009	G 2.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	Optima/Magentis(MG)	2009	G 2.4 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	Optima/Magentis(MG)	2009	G 2.4 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	Optima/Magentis(MG)	2009	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Optima/Magentis(MG)	2009	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062
Europe/General	Optima/Magentis(MG)	2009	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011
Europe/General	Optima/Magentis(MG)	2009	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011
Europe/General	Optima/Magentis(MG)	2009	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Optima/Magentis(MG)	2009	G 2.7 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2009	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Optima/Magentis(MG)	2009	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2009	G 2.7 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2009	G 2.7 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Optima/Magentis(MG)	2009	G 2.7 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	Optima/Magentis(MG)	2009	G 2.7 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	Optima/Magentis(MG)	2009	G 2.7 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	Optima/Magentis(MG)	2009	G 2.7 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Optima/Magentis(MG)	2009	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022

Europe/General	Optima/Magentis(MG)	2008	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2008	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Optima/Magentis(MG)	2008	D 2.0 TCI-D	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	Optima/Magentis(MG)	2008	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Optima/Magentis(MG)	2008	D 2.0 TCI-D	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2008	D 2.0 TCI-D	ECS [Electronic Control Suspension]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2008	D 2.0 TCI-D	IMMO [Immobilizer]				√		0075, 0072, 0112, 0075, 0092, 0083, 0119
Europe/General	Optima/Magentis(MG)	2008	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	
Europe/General	Optima/Magentis(MG)	2008	D 2.0 TCI-D	CODE [Transmitter Code Saving]				√		0022
Europe/General	Optima/Magentis(MG)	2008	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0062, 0011, 0094, 0118, 0098
Europe/General	Optima/Magentis(MG)	2008	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0118, 0011, 0094, 0098
Europe/General	Optima/Magentis(MG)	2008	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0118, 0011, 0094, 0098
Europe/General	Optima/Magentis(MG)	2008	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Optima/Magentis(MG)	2008	G 2.0 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	Optima/Magentis(MG)	2008	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Optima/Magentis(MG)	2008	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2008	G 2.0 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2008	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Optima/Magentis(MG)	2008	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Optima/Magentis(MG)	2008	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Optima/Magentis(MG)	2008	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2008	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Optima/Magentis(MG)	2008	G 2.4 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	Optima/Magentis(MG)	2008	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	Optima/Magentis(MG)	2008	G 2.4 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2008	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Optima/Magentis(MG)	2008	G 2.4 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Optima/Magentis(MG)	2008	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Optima/Magentis(MG)	2008	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0062, 0011
Europe/General	Optima/Magentis(MG)	2008	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011
Europe/General	Optima/Magentis(MG)	2008	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011
Europe/General	Optima/Magentis(MG)	2008	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Optima/Magentis(MG)	2008	G 2.7 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	Optima/Magentis(MG)	2008	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Optima/Magentis(MG)	2008	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2008	G 2.7 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2008	G 2.7 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Optima/Magentis(MG)	2008	G 2.7 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Optima/Magentis(MG)	2008	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Optima/Magentis(MG)	2007	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2007	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Optima/Magentis(MG)	2007	D 2.0 TCI-D	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	Optima/Magentis(MG)	2007	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Optima/Magentis(MG)	2007	D 2.0 TCI-D	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2007	D 2.0 TCI-D	ECS [Electronic Control Suspension]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2007	D 2.0 TCI-D	IMMO [Immobilizer]				√		0075, 0072, 0112, 0075, 0092, 0083, 0119
Europe/General	Optima/Magentis(MG)	2007	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	
Europe/General	Optima/Magentis(MG)	2007	D 2.0 TCI-D	CODE [Transmitter Code Saving]				√		0022

Europe/General	Optima/Magentis(MG)	2007	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0098, 0126
Europe/General	Optima/Magentis(MG)	2007	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0098, 0126
Europe/General	Optima/Magentis(MG)	2007	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0098, 0126
Europe/General	Optima/Magentis(MG)	2007	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Optima/Magentis(MG)	2007	G 2.0 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	Optima/Magentis(MG)	2007	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Optima/Magentis(MG)	2007	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2007	G 2.0 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2007	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Optima/Magentis(MG)	2007	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Optima/Magentis(MG)	2007	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Optima/Magentis(MG)	2007	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2007	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Optima/Magentis(MG)	2007	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Optima/Magentis(MG)	2007	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2007	G 2.4 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2007	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Optima/Magentis(MG)	2007	G 2.4 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Optima/Magentis(MG)	2007	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Optima/Magentis(MG)	2007	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062
Europe/General	Optima/Magentis(MG)	2007	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011
Europe/General	Optima/Magentis(MG)	2007	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011
Europe/General	Optima/Magentis(MG)	2007	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Optima/Magentis(MG)	2007	G 2.7 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051

Europe/General	Optima/Magentis(MG)	2007	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Optima/Magentis(MG)	2007	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2007	G 2.7 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2007	G 2.7 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Optima/Magentis(MG)	2007	G 2.7 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Optima/Magentis(MG)	2007	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Optima/Magentis(MG)	2006	D 2.0 TCI-D	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2006	D 2.0 TCI-D	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Optima/Magentis(MG)	2006	D 2.0 TCI-D	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	Optima/Magentis(MG)	2006	D 2.0 TCI-D	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Optima/Magentis(MG)	2006	D 2.0 TCI-D	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2006	D 2.0 TCI-D	ECS [Electronic Control Suspension]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2006	D 2.0 TCI-D	IMMO [Immobilizer]				√		0075, 0072, 0112, 0075, 0092, 0083, 0119
Europe/General	Optima/Magentis(MG)	2006	D 2.0 TCI-D	BCM [Body Control Module]	√			√	√	
Europe/General	Optima/Magentis(MG)	2006	D 2.0 TCI-D	CODE [Transmitter Code Saving]				√		0022
Europe/General	Optima/Magentis(MG)	2006	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0098, 0126
Europe/General	Optima/Magentis(MG)	2006	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0098, 0126
Europe/General	Optima/Magentis(MG)	2006	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0098, 0126
Europe/General	Optima/Magentis(MG)	2006	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Optima/Magentis(MG)	2006	G 2.0 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	Optima/Magentis(MG)	2006	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Optima/Magentis(MG)	2006	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2006	G 2.0 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2006	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112

Europe/General	Optima/Magentis(MG)	2006	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Optima/Magentis(MG)	2006	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Optima/Magentis(MG)	2006	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2006	G 2.4 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	Optima/Magentis(MG)	2006	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Optima/Magentis(MG)	2006	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2006	G 2.4 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2006	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Optima/Magentis(MG)	2006	G 2.4 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Optima/Magentis(MG)	2006	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Optima/Magentis(MG)	2006	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062
Europe/General	Optima/Magentis(MG)	2006	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011
Europe/General	Optima/Magentis(MG)	2006	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011
Europe/General	Optima/Magentis(MG)	2006	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	Optima/Magentis(MG)	2006	G 2.7 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	Optima/Magentis(MG)	2006	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	Optima/Magentis(MG)	2006	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2006	G 2.7 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
Europe/General	Optima/Magentis(MG)	2006	G 2.7 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	Optima/Magentis(MG)	2006	G 2.7 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	Optima/Magentis(MG)	2006	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	Optima/Magentis(MS)	2006	G 2.0 DOHC	ENGINE [M / T (Leaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2006	G 2.0 DOHC	ENGINE [M / T (Unleaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2006	G 2.0 DOHC	ENGINE [A / T (Leaded)]	√	√	√	√	√	

Europe/General	Optima/Magentis(MS)	2006	G 2.0 DOHC	ENGINE [A / T (Unleaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2006	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2006	G 2.0 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0001, 0051
Europe/General	Optima/Magentis(MS)	2006	G 2.0 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2006	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	Optima/Magentis(MS)	2006	G 2.0 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2006	G 2.5 DOHC	ENGINE [Unleaded EOBD (ZrO2)]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2006	G 2.5 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0098
Europe/General	Optima/Magentis(MS)	2006	G 2.5 DOHC	ENGINE [Unleaded EOBD (TiO2)]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2006	G 2.5 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2006	G 2.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2006	G 2.5 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0001, 0051
Europe/General	Optima/Magentis(MS)	2006	G 2.5 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2006	G 2.5 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	Optima/Magentis(MS)	2006	G 2.5 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2006	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2006	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2006	G 2.7 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0001, 0051
Europe/General	Optima/Magentis(MS)	2006	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	Optima/Magentis(MS)	2006	G 2.7 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2005	G 2.0 DOHC	ENGINE [M / T (Leaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2005	G 2.0 DOHC	ENGINE [M / T (Unleaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2005	G 2.0 DOHC	ENGINE [A / T (Leaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2005	G 2.0 DOHC	ENGINE [A / T (Unleaded)]	√	√	√	√	√	

Europe/General	Optima/Magentis(MS)	2005	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2005	G 2.0 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0001, 0051
Europe/General	Optima/Magentis(MS)	2005	G 2.0 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2005	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	Optima/Magentis(MS)	2005	G 2.0 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2005	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2005	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2005	G 2.4 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0001, 0051
Europe/General	Optima/Magentis(MS)	2005	G 2.4 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2005	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	Optima/Magentis(MS)	2005	G 2.4 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2005	G 2.5 DOHC	ENGINE [Unleaded EOBD (ZrO2)]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2005	G 2.5 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0098
Europe/General	Optima/Magentis(MS)	2005	G 2.5 DOHC	ENGINE [Unleaded EOBD (TiO2)]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2005	G 2.5 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2005	G 2.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2005	G 2.5 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0001, 0051
Europe/General	Optima/Magentis(MS)	2005	G 2.5 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2005	G 2.5 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	Optima/Magentis(MS)	2005	G 2.5 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2005	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2005	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2005	G 2.7 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0001, 0051
Europe/General	Optima/Magentis(MS)	2005	G 2.7 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051

Europe/General	Optima/Magentis(MS)	2005	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	Optima/Magentis(MS)	2005	G 2.7 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2004	G 2.0 DOHC	ENGINE [M / T (Leaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2004	G 2.0 DOHC	ENGINE [M / T (Unleaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2004	G 2.0 DOHC	ENGINE [A / T (Leaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2004	G 2.0 DOHC	ENGINE [A / T (Unleaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2004	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2004	G 2.0 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0001, 0051
Europe/General	Optima/Magentis(MS)	2004	G 2.0 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2004	G 2.0 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2004	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2004	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2004	G 2.4 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0001, 0051
Europe/General	Optima/Magentis(MS)	2004	G 2.4 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2004	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	Optima/Magentis(MS)	2004	G 2.4 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2004	G 2.5 DOHC	ENGINE [Unleaded EOBD (ZrO2)]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2004	G 2.5 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0098
Europe/General	Optima/Magentis(MS)	2004	G 2.5 DOHC	ENGINE [Unleaded EOBD (TiO2)]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2004	G 2.5 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2004	G 2.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2004	G 2.5 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0001, 0051
Europe/General	Optima/Magentis(MS)	2004	G 2.5 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2004	G 2.5 DOHC	AIRBAG [Airbag Control]	√	√	√			

Europe/General	Optima/Magentis(MS)	2004	G 2.5 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2004	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2004	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2004	G 2.7 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0001, 0051
Europe/General	Optima/Magentis(MS)	2004	G 2.7 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2004	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	Optima/Magentis(MS)	2004	G 2.7 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2003	G 2.0 DOHC	ENGINE [M / T (Leaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2003	G 2.0 DOHC	ENGINE [M / T (Unleaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2003	G 2.0 DOHC	ENGINE [A / T (Leaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2003	G 2.0 DOHC	ENGINE [A / T (Unleaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2003	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2003	G 2.0 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0001, 0051
Europe/General	Optima/Magentis(MS)	2003	G 2.0 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2003	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	Optima/Magentis(MS)	2003	G 2.0 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2003	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2003	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2003	G 2.4 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0001, 0051
Europe/General	Optima/Magentis(MS)	2003	G 2.4 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2003	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	Optima/Magentis(MS)	2003	G 2.4 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2003	G 2.5 DOHC	ENGINE [Unleaded EOBD (ZrO2)]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2003	G 2.5 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0098

Europe/General	Optima/Magentis(MS)	2003	G 2.5 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2003	G 2.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2003	G 2.5 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0001, 0051
Europe/General	Optima/Magentis(MS)	2003	G 2.5 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2003	G 2.5 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	Optima/Magentis(MS)	2003	G 2.5 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2003	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2003	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2003	G 2.7 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0001, 0051
Europe/General	Optima/Magentis(MS)	2003	G 2.7 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2003	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	Optima/Magentis(MS)	2003	G 2.7 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2002	G 2.0 DOHC	ENGINE [M / T (Leaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2002	G 2.0 DOHC	ENGINE [M / T (Unlesded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2002	G 2.0 DOHC	ENGINE [A / T (Leaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2002	G 2.0 DOHC	ENGINE [A / T (Unleaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2002	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2002	G 2.0 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0001, 0051
Europe/General	Optima/Magentis(MS)	2002	G 2.0 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2002	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	Optima/Magentis(MS)	2002	G 2.0 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2002	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2002	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2002	G 2.4 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0001, 0051

Europe/General	Optima/Magentis(MS)	2002	G 2.4 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2002	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	Optima/Magentis(MS)	2002	G 2.4 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2002	G 2.5 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0098
Europe/General	Optima/Magentis(MS)	2002	G 2.5 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2002	G 2.5 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2002	G 2.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2002	G 2.5 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0001, 0051
Europe/General	Optima/Magentis(MS)	2002	G 2.5 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2002	G 2.5 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	Optima/Magentis(MS)	2002	G 2.5 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2002	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2002	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2002	G 2.7 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0001, 0051
Europe/General	Optima/Magentis(MS)	2002	G 2.7 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2002	G 2.7 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2001	G 2.0 DOHC	ENGINE [M / T (Leaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2001	G 2.0 DOHC	ENGINE [M / T (Unleaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2001	G 2.0 DOHC	ENGINE [A / T (Leaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2001	G 2.0 DOHC	ENGINE [A / T (Unleaded)]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2001	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2001	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2001	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	Optima/Magentis(MS)	2001	G 2.0 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083

Europe/General	Optima/Magentis(MS)	2001	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2001	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2001	G 2.4 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2001	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	Optima/Magentis(MS)	2001	G 2.4 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	Optima/Magentis(MS)	2001	G 2.5 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0098
Europe/General	Optima/Magentis(MS)	2001	G 2.5 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2001	G 2.5 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0098
Europe/General	Optima/Magentis(MS)	2001	G 2.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	Optima/Magentis(MS)	2001	G 2.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	Optima/Magentis(MS)	2001	G 2.5 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	Optima/Magentis(MS)	2001	G 2.5 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	PICANTO(SA)	2011	D 1.1 TCI-U	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2011	D 1.1 TCI-U	ABSESP [ABS / ESP (MGH - 40)]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2011	D 1.1 TCI-U	ABSESP [ABS / ESP (MGH - 60)]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2011	D 1.1 TCI-U	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2011	D 1.1 TCI-U	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2011	D 1.1 TCI-U	EPS [MDPS]	√	√	√	√		
Europe/General	PICANTO(SA)	2011	D 1.1 TCI-U	IMMO [IMMO (Bosch)]				√		0072, 0075, 0083, 0092, 0112
Europe/General	PICANTO(SA)	2011	G 1.0 SOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0094, 0098
Europe/General	PICANTO(SA)	2011	G 1.0 SOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0094, 0098, 0126
Europe/General	PICANTO(SA)	2011	G 1.0 SOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	PICANTO(SA)	2011	G 1.0 SOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(SA)	2011	G 1.0 SOHC	ABSESP [ABS / ESP (MGH - 40)]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2011	G 1.0 SOHC	ABSESP [ABS / ESP (MGH - 60)]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2011	G 1.0 SOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2011	G 1.0 SOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2011	G 1.0 SOHC	EPS [MDPS]	√	√	√	√		
Europe/General	PICANTO(SA)	2011	G 1.0 SOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	PICANTO(SA)	2011	G 1.1 SOHC	ENGINE [Laeded All]	√	√	√	√	√	0126, 0062, 0094, 0098
Europe/General	PICANTO(SA)	2011	G 1.1 SOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	PICANTO(SA)	2011	G 1.1 SOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(SA)	2011	G 1.1 SOHC	ABSESP [ABS / ESP (MGH - 40)]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2011	G 1.1 SOHC	ABSESP [ABS / ESP (MGH - 60)]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2011	G 1.1 SOHC	AIRBAG [Airbag Control]	√	√	√			

Europe/General	PICANTO(SA)	2011	G 1.1 SOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2011	G 1.1 SOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	PICANTO(SA)	2011	G 1.1 SOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	PICANTO(SA)	2010	D 1.1 TCI-U	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2010	D 1.1 TCI-U	ABSESP [ABS / ESP (MGH - 40)]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2010	D 1.1 TCI-U	ABSESP [ABS / ESP (MGH - 60) (2009.12.7~)]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2010	D 1.1 TCI-U	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2010	D 1.1 TCI-U	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2010	D 1.1 TCI-U	EPS [MDPS]	√	√	√	√		
Europe/General	PICANTO(SA)	2010	D 1.1 TCI-U	IMMO [IMMO (Bosch)]				√		0072, 0075, 0083, 0092, 0112
Europe/General	PICANTO(SA)	2010	G 1.0 SOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0094, 0098
Europe/General	PICANTO(SA)	2010	G 1.0 SOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0094, 0098, 0126
Europe/General	PICANTO(SA)	2010	G 1.0 SOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	PICANTO(SA)	2010	G 1.0 SOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(SA)	2010	G 1.0 SOHC	ABSESP [ABS / ESP (~2009.12.6)]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2010	G 1.0 SOHC	ABSESP [ABS / ESP (2009.12.7~)]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2010	G 1.0 SOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2010	G 1.0 SOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2010	G 1.0 SOHC	EPS [MDPS]	√	√	√	√		
Europe/General	PICANTO(SA)	2010	G 1.0 SOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	PICANTO(SA)	2010	G 1.1 SOHC	ENGINE [Laeded All]	√	√	√	√	√	0126, 0062, 0094, 0098
Europe/General	PICANTO(SA)	2010	G 1.1 SOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0094, 0098, 0126
Europe/General	PICANTO(SA)	2010	G 1.1 SOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	PICANTO(SA)	2010	G 1.1 SOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(SA)	2010	G 1.1 SOHC	ABSESP [ABS / ESP (~2009.12.6)]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2010	G 1.1 SOHC	ABSESP [ABS / ESP (2009.12.7~)]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2010	G 1.1 SOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2010	G 1.1 SOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2010	G 1.1 SOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	PICANTO(SA)	2010	G 1.1 SOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	PICANTO(SA)	2009	D 1.1 TCI-U	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2009	D 1.1 TCI-U	ABSESP [ABS / ESP]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2009	D 1.1 TCI-U	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2009	D 1.1 TCI-U	EPS [MDPS]	√	√	√	√		
Europe/General	PICANTO(SA)	2009	D 1.1 TCI-U	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	PICANTO(SA)	2009	G 1.0 SOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0094, 0098
Europe/General	PICANTO(SA)	2009	G 1.0 SOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0094, 0098, 0126
Europe/General	PICANTO(SA)	2009	G 1.0 SOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	PICANTO(SA)	2009	G 1.0 SOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(SA)	2009	G 1.0 SOHC	ABSESP [ABS / ESP]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2009	G 1.0 SOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2009	G 1.0 SOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2009	G 1.0 SOHC	EPS [MDPS]	√	√	√	√		
Europe/General	PICANTO(SA)	2009	G 1.0 SOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112

Europe/General	PICANTO(SA)	2009	G 1.1 SOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0094, 0098
Europe/General	PICANTO(SA)	2009	G 1.1 SOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0094, 0098, 0126
Europe/General	PICANTO(SA)	2009	G 1.1 SOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	PICANTO(SA)	2009	G 1.1 SOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(SA)	2009	G 1.1 SOHC	ABSESP [ABS / ESP]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2009	G 1.1 SOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2009	G 1.1 SOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2009	G 1.1 SOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	PICANTO(SA)	2009	G 1.1 SOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	PICANTO(SA)	2008	D 1.1 TCI-U	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2008	D 1.1 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(SA)	2008	D 1.1 TCI-U	ABSESP [ABS / ESP (MGH - 40)]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2008	D 1.1 TCI-U	ABSESP [ABS / ESP (MGH - 25)]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2008	D 1.1 TCI-U	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2008	D 1.1 TCI-U	AIRCON [Full auto (HCC)]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2008	D 1.1 TCI-U	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	PICANTO(SA)	2008	D 1.1 TCI-U	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	PICANTO(SA)	2008	G 1.0 SOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0094, 0098
Europe/General	PICANTO(SA)	2008	G 1.0 SOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0094, 0098, 0126
Europe/General	PICANTO(SA)	2008	G 1.0 SOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	PICANTO(SA)	2008	G 1.0 SOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(SA)	2008	G 1.0 SOHC	ABSESP [ABS / ESP (MGH - 40)]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2008	G 1.0 SOHC	ABSESP [ABS / ESP (MGH - 25)]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2008	G 1.0 SOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2008	G 1.0 SOHC	AIRCON [Full auto (HCC)]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2008	G 1.0 SOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	PICANTO(SA)	2008	G 1.0 SOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	PICANTO(SA)	2008	G 1.1 SOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0094, 0098
Europe/General	PICANTO(SA)	2008	G 1.1 SOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	PICANTO(SA)	2008	G 1.1 SOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(SA)	2008	G 1.1 SOHC	ABSESP [ABS / ESP (MGH - 40)]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2008	G 1.1 SOHC	ABSESP [ABS / ESP (MGH - 25)]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2008	G 1.1 SOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2008	G 1.1 SOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2008	G 1.1 SOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	PICANTO(SA)	2008	G 1.1 SOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	PICANTO(SA)	2007	D 1.1 TCI-U	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2007	D 1.1 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(SA)	2007	D 1.1 TCI-U	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2007	D 1.1 TCI-U	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2007	D 1.1 TCI-U	EPS [Electronic Power Steering]	√	√	√	√		0032
Europe/General	PICANTO(SA)	2007	D 1.1 TCI-U	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	PICANTO(SA)	2007	G 1.0 SOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2007	G 1.0 SOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2007	G 1.0 SOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	

Europe/General	PICANTO(SA)	2007	G 1.0 SOHC	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	PICANTO(SA)	2007	G 1.0 SOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2007	G 1.0 SOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2007	G 1.0 SOHC	EPS [Motor driven Power Steering]	√	√	√	√		0032
Europe/General	PICANTO(SA)	2007	G 1.0 SOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	PICANTO(SA)	2007	G 1.1 SOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2007	G 1.1 SOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2007	G 1.1 SOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2007	G 1.1 SOHC	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	PICANTO(SA)	2007	G 1.1 SOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2007	G 1.1 SOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2007	G 1.1 SOHC	EPS [Electronic Power Steering]	√	√	√	√		0032
Europe/General	PICANTO(SA)	2007	G 1.1 SOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	PICANTO(SA)	2006	D 1.1 TCI-U	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2006	D 1.1 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(SA)	2006	D 1.1 TCI-U	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2006	D 1.1 TCI-U	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2006	D 1.1 TCI-U	EPS [Electronic Power Steering]	√	√	√	√		0032
Europe/General	PICANTO(SA)	2006	D 1.1 TCI-U	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	PICANTO(SA)	2006	G 1.0 SOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2006	G 1.0 SOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2006	G 1.0 SOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2006	G 1.0 SOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2006	G 1.0 SOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2006	G 1.0 SOHC	EPS [Electronic Power Steering]	√	√	√	√		0032
Europe/General	PICANTO(SA)	2006	G 1.0 SOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	PICANTO(SA)	2006	G 1.1 SOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2006	G 1.1 SOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2006	G 1.1 SOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2006	G 1.1 SOHC	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	PICANTO(SA)	2006	G 1.1 SOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2006	G 1.1 SOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2006	G 1.1 SOHC	EPS [Electronic Power Steering]	√	√	√	√		0032
Europe/General	PICANTO(SA)	2006	G 1.1 SOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	PICANTO(SA)	2005	G 1.0 SOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2005	G 1.0 SOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2005	G 1.0 SOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2005	G 1.0 SOHC	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	PICANTO(SA)	2005	G 1.0 SOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2005	G 1.0 SOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2005	G 1.0 SOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	PICANTO(SA)	2005	G 1.1 SOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2005	G 1.1 SOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2005	G 1.1 SOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2005	G 1.1 SOHC	AT [Automatic Transaxle]		√	√	√	√	

Europe/General	PICANTO(SA)	2005	G 1.1 SOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2005	G 1.1 SOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2005	G 1.1 SOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	PICANTO(SA)	2004	G 1.0 SOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2004	G 1.0 SOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2004	G 1.0 SOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2004	G 1.0 SOHC	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	PICANTO(SA)	2004	G 1.0 SOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2004	G 1.0 SOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2004	G 1.0 SOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	PICANTO(SA)	2004	G 1.1 SOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2004	G 1.1 SOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2004	G 1.1 SOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2004	G 1.1 SOHC	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	PICANTO(SA)	2004	G 1.1 SOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2004	G 1.1 SOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2003	G 1.1 SOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2003	G 1.1 SOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2003	G 1.1 SOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	PICANTO(SA)	2003	G 1.1 SOHC	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	PICANTO(SA)	2003	G 1.1 SOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	PICANTO(SA)	2003	G 1.1 SOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	PICANTO(SA)	2003	G 1.1 SOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	PICANTO(TA)	2017	F 1.0 DOHC KAPPA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2017	F 1.0 DOHC KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2017	F 1.0 DOHC KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2017	F 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2017	F 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2017	F 1.0 DOHC KAPPA	AIRCON [Air Conditioner (TA PE)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2017	F 1.0 DOHC KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2017	F 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2017	F 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (TA PE)]	√	√	√	√		
Europe/General	PICANTO(TA)	2017	F 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2017	F 1.0 DOHC KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2017	F 1.0 DOHC KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102

Europe/General	PICANTO(TA)	2017	F 1.0 DOHC KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2017	F 1.0 DOHC KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2017	F 1.0 DOHC KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2017	G 1.0 MPI KAPPA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2017	G 1.0 MPI KAPPA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	PICANTO(TA)	2017	G 1.0 MPI KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2017	G 1.0 MPI KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2017	G 1.0 MPI KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2017	G 1.0 MPI KAPPA	AIRCON [Air Conditioner (TA PE)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2017	G 1.0 MPI KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2017	G 1.0 MPI KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2017	G 1.0 MPI KAPPA	EPS [Motor Driven Power Steering (TA PE)]	√	√	√	√		
Europe/General	PICANTO(TA)	2017	G 1.0 MPI KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2017	G 1.0 MPI KAPPA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	PICANTO(TA)	2017	G 1.0 MPI KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2017	G 1.0 MPI KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2017	G 1.0 MPI KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2017	G 1.0 MPI KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2017	G 1.0 MPI KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2017	G 1.2 MPI KAPPA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2017	G 1.2 MPI KAPPA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	PICANTO(TA)	2017	G 1.2 MPI KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2017	G 1.2 MPI KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2017	G 1.2 MPI KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			

Europe/General	PICANTO(TA)	2017	G 1.2 MPI KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2017	G 1.2 MPI KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2017	G 1.2 MPI KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2017	G 1.2 MPI KAPPA	EPS [Motor Driven Power Steering (TA PE)]	√	√	√	√		
Europe/General	PICANTO(TA)	2017	G 1.2 MPI KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2017	G 1.2 MPI KAPPA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	PICANTO(TA)	2017	G 1.2 MPI KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2017	G 1.2 MPI KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2017	G 1.2 MPI KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2017	G 1.2 MPI KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2017	G 1.2 MPI KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2017	L 1.0 LPGi KAPPA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2017	L 1.0 LPGi KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2017	L 1.0 LPGi KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2017	L 1.0 LPGi KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2017	L 1.0 LPGi KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2017	L 1.0 LPGi KAPPA	AIRCON [Air Conditioner (TA PE)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2017	L 1.0 LPGi KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2017	L 1.0 LPGi KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2017	L 1.0 LPGi KAPPA	EPS [Motor Driven Power Steering (TA PE)]	√	√	√	√		
Europe/General	PICANTO(TA)	2017	L 1.0 LPGi KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2017	L 1.0 LPGi KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2017	L 1.0 LPGi KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2017	L 1.0 LPGi KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	

Europe/General	PICANTO(TA)	2017	L 1.0 LPGi KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2017	L 1.0 LPGi KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2016	F 1.0 DOHC KAPPA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2016	F 1.0 DOHC KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2016	F 1.0 DOHC KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2016	F 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2016	F 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2016	F 1.0 DOHC KAPPA	AIRCON [Air Conditioner (TA PE)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2016	F 1.0 DOHC KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2016	F 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2016	F 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (TA PE)]	√	√	√	√		
Europe/General	PICANTO(TA)	2016	F 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2016	F 1.0 DOHC KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2016	F 1.0 DOHC KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2016	F 1.0 DOHC KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2016	F 1.0 DOHC KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2016	F 1.0 DOHC KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2016	G 1.0 MPI KAPPA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	PICANTO(TA)	2016	G 1.0 MPI KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2016	G 1.0 MPI KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2016	G 1.0 MPI KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2016	G 1.0 MPI KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2016	G 1.0 MPI KAPPA	AIRCON [Air Conditioner (TA PE)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2016	G 1.0 MPI KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	PICANTO(TA)	2016	G 1.0 MPI KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2016	G 1.0 MPI KAPPA	EPS [Motor Driven Power Steering (TA PE)]	√	√	√	√		
Europe/General	PICANTO(TA)	2016	G 1.0 MPI KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2016	G 1.0 MPI KAPPA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	PICANTO(TA)	2016	G 1.0 MPI KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2016	G 1.0 MPI KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2016	G 1.0 MPI KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2016	G 1.0 MPI KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2016	G 1.0 MPI KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2016	G 1.2 MPI KAPPA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2016	G 1.2 MPI KAPPA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	PICANTO(TA)	2016	G 1.2 MPI KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2016	G 1.2 MPI KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2016	G 1.2 MPI KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2016	G 1.2 MPI KAPPA	AIRCON [Air Conditioner (TA PE)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2016	G 1.2 MPI KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2016	G 1.2 MPI KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2016	G 1.2 MPI KAPPA	EPS [Motor Driven Power Steering (TA PE)]	√	√	√	√		
Europe/General	PICANTO(TA)	2016	G 1.2 MPI KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2016	G 1.2 MPI KAPPA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	PICANTO(TA)	2016	G 1.2 MPI KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2016	G 1.2 MPI KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2016	G 1.2 MPI KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2016	G 1.2 MPI KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	

Europe/General	PICANTO(TA)	2016	G 1.2 MPI KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2016	L 1.0 LPGi KAPPA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2016	L 1.0 LPGi KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2016	L 1.0 LPGi KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2016	L 1.0 LPGi KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2016	L 1.0 LPGi KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2016	L 1.0 LPGi KAPPA	AIRCON [Air Conditioner (TA PE)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2016	L 1.0 LPGi KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2016	L 1.0 LPGi KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2016	L 1.0 LPGi KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2016	L 1.0 LPGi KAPPA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	PICANTO(TA)	2016	L 1.0 LPGi KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2016	L 1.0 LPGi KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2016	L 1.0 LPGi KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2016	L 1.0 LPGi KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2016	L 1.0 LPGi KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2015	F 1.0 DOHC KAPPA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2015	F 1.0 DOHC KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2015	F 1.0 DOHC KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2015	F 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2015	F 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2015	F 1.0 DOHC KAPPA	AIRCON [Air Conditioner (TA PE)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2015	F 1.0 DOHC KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2015	F 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		

Europe/General	PICANTO(TA)	2015	F 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (TA PE)]	√	√	√	√		
Europe/General	PICANTO(TA)	2015	F 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2015	F 1.0 DOHC KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2015	F 1.0 DOHC KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2015	F 1.0 DOHC KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2015	F 1.0 DOHC KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2015	G 1.0 MPI KAPPA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2015	G 1.0 MPI KAPPA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	PICANTO(TA)	2015	G 1.0 MPI KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2015	G 1.0 MPI KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2015	G 1.0 MPI KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2015	G 1.0 MPI KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2015	G 1.0 MPI KAPPA	AIRCON [Air Conditioner (TA PE)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2015	G 1.0 MPI KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2015	G 1.0 MPI KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2015	G 1.0 MPI KAPPA	EPS [Motor Driven Power Steering (TA PE)]	√	√	√	√		
Europe/General	PICANTO(TA)	2015	G 1.0 MPI KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2015	G 1.0 MPI KAPPA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	PICANTO(TA)	2015	G 1.0 MPI KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2015	G 1.0 MPI KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2015	G 1.0 MPI KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2015	G 1.0 MPI KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2015	G 1.0 MPI KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2015	G 1.2 MPI KAPPA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126

Europe/General	PICANTO(TA)	2015	G 1.2 MPI KAPPA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	PICANTO(TA)	2015	G 1.2 MPI KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2015	G 1.2 MPI KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2015	G 1.2 MPI KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2015	G 1.2 MPI KAPPA	AIRCON [Air Conditioner (TA PE)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2015	G 1.2 MPI KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2015	G 1.2 MPI KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2015	G 1.2 MPI KAPPA	EPS [Motor Driven Power Steering (TA PE)]	√	√	√	√		
Europe/General	PICANTO(TA)	2015	G 1.2 MPI KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2015	G 1.2 MPI KAPPA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	PICANTO(TA)	2015	G 1.2 MPI KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2015	G 1.2 MPI KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2015	G 1.2 MPI KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2015	G 1.2 MPI KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2015	G 1.2 MPI KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2015	L 1.0 LPGi KAPPA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2015	L 1.0 LPGi KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2015	L 1.0 LPGi KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2015	L 1.0 LPGi KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2015	L 1.0 LPGi KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2015	L 1.0 LPGi KAPPA	AIRCON [Air Conditioner (TA PE)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2015	L 1.0 LPGi KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2015	L 1.0 LPGi KAPPA	EPS [Motor Driven Power Steering (TA PE)]	√	√	√	√		
Europe/General	PICANTO(TA)	2015	L 1.0 LPGi KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		

Europe/General	PICANTO(TA)	2015	L 1.0 LPGi KAPPA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	PICANTO(TA)	2015	L 1.0 LPGi KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2015	L 1.0 LPGi KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2015	L 1.0 LPGi KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2015	L 1.0 LPGi KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2015	L 1.0 LPGi KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2014	B 1.0 DOHC KAPPA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2014	B 1.0 DOHC KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2014	B 1.0 DOHC KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2014	B 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2014	B 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2014	B 1.0 DOHC KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2014	B 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2014	B 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2014	B 1.0 DOHC KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2014	B 1.0 DOHC KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2014	B 1.0 DOHC KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2014	B 1.0 DOHC KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2014	F 1.0 DOHC KAPPA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2014	F 1.0 DOHC KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2014	F 1.0 DOHC KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2014	F 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2014	F 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2014	F 1.0 DOHC KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	PICANTO(TA)	2014	F 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2014	F 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2014	F 1.0 DOHC KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2014	F 1.0 DOHC KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2014	F 1.0 DOHC KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2014	F 1.0 DOHC KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2014	F 1.0 DOHC KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2014	G 1.0 MPI KAPPA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	PICANTO(TA)	2014	G 1.0 MPI KAPPA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2014	G 1.0 MPI KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2014	G 1.0 MPI KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2014	G 1.0 MPI KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2014	G 1.0 MPI KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2014	G 1.0 MPI KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2014	G 1.0 MPI KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2014	G 1.0 MPI KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2014	G 1.0 MPI KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2014	G 1.0 MPI KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2014	G 1.0 MPI KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2014	G 1.0 MPI KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2014	G 1.2 MPI KAPPA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	PICANTO(TA)	2014	G 1.2 MPI KAPPA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2014	G 1.2 MPI KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2014	G 1.2 MPI KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051

Europe/General	PICANTO(TA)	2014	G 1.2 MPI KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2014	G 1.2 MPI KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2014	G 1.2 MPI KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2014	G 1.2 MPI KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2014	G 1.2 MPI KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2014	G 1.2 MPI KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2014	G 1.2 MPI KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2014	G 1.2 MPI KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2014	G 1.2 MPI KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2014	L 1.0 LPGi KAPPA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2014	L 1.0 LPGi KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2014	L 1.0 LPGi KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2014	L 1.0 LPGi KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2014	L 1.0 LPGi KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2014	L 1.0 LPGi KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2014	L 1.0 LPGi KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2014	L 1.0 LPGi KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2014	L 1.0 LPGi KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2014	L 1.0 LPGi KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2014	L 1.0 LPGi KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2014	L 1.0 LPGi KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2014	L 1.0 LPGi KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2013	B 1.0 DOHC KAPPA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2013	B 1.0 DOHC KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099

Europe/General	PICANTO(TA)	2013	B 1.0 DOHC KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2013	B 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2013	B 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2013	B 1.0 DOHC KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2013	B 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2013	B 1.0 DOHC KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2013	B 1.0 DOHC KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2013	B 1.0 DOHC KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2013	B 1.0 DOHC KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2013	B 1.0 DOHC KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2013	F 1.0 DOHC KAPPA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2013	F 1.0 DOHC KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2013	F 1.0 DOHC KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2013	F 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2013	F 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2013	F 1.0 DOHC KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2013	F 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2013	F 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2013	F 1.0 DOHC KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2013	F 1.0 DOHC KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2013	F 1.0 DOHC KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2013	F 1.0 DOHC KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2013	F 1.0 DOHC KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2013	G 1.0 DOHC KAPPA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126

Europe/General	PICANTO(TA)	2013	G 1.0 DOHC KAPPA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2013	G 1.0 DOHC KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2013	G 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2013	G 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2013	G 1.0 DOHC KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2013	G 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2013	G 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2013	G 1.0 DOHC KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2013	G 1.0 DOHC KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2013	G 1.0 DOHC KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2013	G 1.0 DOHC KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2013	G 1.0 DOHC KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2013	G 1.2 MPI KAPPA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	PICANTO(TA)	2013	G 1.2 MPI KAPPA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2013	G 1.2 MPI KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2013	G 1.2 MPI KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2013	G 1.2 MPI KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2013	G 1.2 MPI KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2013	G 1.2 MPI KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2013	G 1.2 MPI KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2013	G 1.2 MPI KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2013	G 1.2 MPI KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2013	G 1.2 MPI KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2013	G 1.2 MPI KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	

Europe/General	PICANTO(TA)	2013	G 1.2 MPI KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2013	L 1.0 LPGi KAPPA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2013	L 1.0 LPGi KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2013	L 1.0 LPGi KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2013	L 1.0 LPGi KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2013	L 1.0 LPGi KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2013	L 1.0 LPGi KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2013	L 1.0 LPGi KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2013	L 1.0 LPGi KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2013	L 1.0 LPGi KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2013	L 1.0 LPGi KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2013	L 1.0 LPGi KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2013	L 1.0 LPGi KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2013	L 1.0 LPGi KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2012	B 1.0 DOHC KAPPA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2012	B 1.0 DOHC KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2012	B 1.0 DOHC KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2012	B 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2012	B 1.0 DOHC KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2012	B 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2012	B 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2012	B 1.0 DOHC KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2012	B 1.0 DOHC KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2012	B 1.0 DOHC KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	

Europe/General	PICANTO(TA)	2012	B 1.0 DOHC KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2012	B 1.0 DOHC KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2012	F 1.0 DOHC KAPPA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2012	F 1.0 DOHC KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2012	F 1.0 DOHC KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2012	F 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2012	F 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2012	F 1.0 DOHC KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2012	F 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2012	F 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2012	F 1.0 DOHC KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2012	F 1.0 DOHC KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2012	F 1.0 DOHC KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2012	F 1.0 DOHC KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2012	G 1.0 DOHC KAPPA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	PICANTO(TA)	2012	G 1.0 DOHC KAPPA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2012	G 1.0 DOHC KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2012	G 1.0 DOHC KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2012	G 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2012	G 1.0 DOHC KAPPA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	PICANTO(TA)	2012	G 1.0 DOHC KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2012	G 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2012	G 1.0 DOHC KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2012	G 1.0 DOHC KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092

Europe/General	PICANTO(TA)	2012	G 1.0 DOHC KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2012	G 1.0 DOHC KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2012	G 1.0 DOHC KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2012	G 1.0 DOHC KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PICANTO(TA)	2012	G 1.2 MPI KAPPA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	PICANTO(TA)	2012	G 1.2 MPI KAPPA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	PICANTO(TA)	2012	G 1.2 MPI KAPPA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	PICANTO(TA)	2012	G 1.2 MPI KAPPA	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	PICANTO(TA)	2012	G 1.2 MPI KAPPA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	PICANTO(TA)	2012	G 1.2 MPI KAPPA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2012	G 1.2 MPI KAPPA	EPS [Motor Driven Power Steering (EURO)]	√	√	√	√		
Europe/General	PICANTO(TA)	2012	G 1.2 MPI KAPPA	EPS [Motor Driven Power Steering (GEN)]	√	√	√	√		
Europe/General	PICANTO(TA)	2012	G 1.2 MPI KAPPA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	PICANTO(TA)	2012	G 1.2 MPI KAPPA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	PICANTO(TA)	2012	G 1.2 MPI KAPPA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2012	G 1.2 MPI KAPPA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	PICANTO(TA)	2012	G 1.2 MPI KAPPA	CODE [Transmitter Code Saving]				√		0022
Europe/General	PREGIO(FP)	2006	D 2.5 TCI	ENGINE [Engine Control]		√	√	√	√	
Europe/General	PREGIO(FP)	2006	D 2.5 TCI	IMMO [Immobilizer]		√	√	√		0079, 0064, 0075, 0092, 0083, 0080, 0119
Europe/General	PREGIO(FP)	2006	D 2.7 J2	ENGINE [Engine Control]		√	√	√	√	
Europe/General	PREGIO(FP)	2006	D 2.7 J2	IMMO [Immobilizer]		√	√	√		0079, 0064, 0075, 0092, 0083, 0080, 0119
Europe/General	PREGIO(FP)	2005	D 2.5 TCI	ENGINE [Engine Control]		√	√	√	√	
Europe/General	PREGIO(FP)	2005	D 2.7 J2	ENGINE [Engine Control]		√	√	√	√	
Europe/General	PREGIO(FP)	2004	D 2.5 TCI	ENGINE [Engine Control]		√	√	√	√	
Europe/General	PREGIO(FP)	2004	D 2.7 J2	ENGINE [Engine Control]		√	√	√	√	
Europe/General	PREGIO(FP)	2003	D 2.5 TCI	ENGINE [Engine Control]		√	√	√	√	
Europe/General	PREGIO(FP)	2003	D 2.7 J2	ENGINE [Engine Control]		√	√	√	√	
Europe/General	PREGIO(FP)	2002	D 2.5 TCI	ENGINE [Engine Control]		√	√	√	√	
Europe/General	PREGIO(FP)	2002	D 2.7 J2	ENGINE [Engine Control]		√	√	√	√	

Europe/General	PREGIO(FP)	2001	D 2.7 J2	ENGINE [Engine Control]		√	√	√	√	
Europe/General	PREGIO(FP)	2000	D 2.7 J2	ENGINE [Engine Control]		√	√	√	√	
Europe/General	PREGIO(FP)	1999	D 2.7 J2	ENGINE [Engine Control]		√	√	√	√	
Europe/General	PREGIO(FP)	1998	D 2.7 J2	ENGINE [Engine Control]		√	√	√	√	
Europe/General	PREGIO(FP)	1997	D 2.7 J2	ENGINE [Engine Control]		√	√	√	√	
Europe/General	PRIDE(PRD)	2004	G 1.3 SOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	PRIDE(PRD)	2003	G 1.3 SOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	PRIDE(PRD)	2002	G 1.3 SOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	ENGINE [Engine Control]	√	√	√	√		0011, 0043, 0094, 0126
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	EPB [Electric Parking Brake]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	EPS [Electronic Hydraulic Power Steering System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	TPMS [Tire Pressure Monitoring]	√	√	√			
Europe/General	Quoris(KH)	2017	G 3.8 GDI	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	ESHIFTER [E - Shifter]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	PSB - L [Pre - safe Seat Belt - Left]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	PSB - R [Pre - safe Seat Belt - Right]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	AVN [Audio Video Navigation (Standard)]	√	√	√			

Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	AVN [Audio Video Navigation (Premium)]	√	√	√	√		0101
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	APSM [Assist Power Seat Module]	√	√	√	√	√	0106
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	SCM [Steering Column Module]	√	√	√	√	√	0114
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	FSJB [Front Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	RSJB [Rear Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 GDI	SVMS [Surround View Monitor System]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	PTM [Power Trunk Module]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	MFSW [Multi Function Switch]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	HUD [Head Up Display]	√	√	√			
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 GDI LAMBDA II	I - BOX [I - BOX]	√	√	√			
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	ENGINE [Engine Control]	√	√	√	√		0011, 0043, 0094, 0126
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	EPB [Electric Parking Brake]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	TPMS [Tire Pressure Monitoring]	√	√	√			
Europe/General	Quoris(KH)	2017	G 3.8 MPI	SVMS [Surround View Monitor System]	√	√	√	√	√	

Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	ESHIFTER [E - Shifter]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	PSB - L [Pre - safe Seat Belt - Left]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	PSB - R [Pre - safe Seat Belt - Right]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	AVN [Audio Video Navigation (Standard)]	√	√	√			
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	AVN [Audio Video Navigation (Premium)]	√	√	√	√		0101
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	APSM [Assist Power Seat Module]	√	√	√	√	√	0106
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	SCM [Steering Column Module]	√	√	√	√	√	0114
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	FSJB [Front Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	RSJB [Rear Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	PTM [Power Trunk Module]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	MFSW [Multi Function Switch]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	HUD [Head Up Display]	√	√	√			
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 3.8 MPI LAMBDA II	I - BOX [I - BOX]	√	√	√			
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	EPB [Electric Parking Brake]	√	√	√	√	√	

Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	EPS [Electronic Hydraulic Power Steering System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	TPMS [Tire Pressure Monitoring]	√	√	√			
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	ESHIFTER [E - Shifter]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	PSB - L [Pre - safe Seat Belt - Left]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	PSB - R [Pre - safe Seat Belt - Right]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	AVN [Audio Video Navigation (Prmium)]	√	√	√	√		0101
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	APSM [Assist Power Seat Module]	√	√	√	√	√	0106
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	SCM [Steering Column Module]	√	√	√	√	√	0114
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	FSJB [Front Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	RSJB [Rear Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	SVMS [Surround View Monitor System]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	PTM [Power Trunk Module]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	MFSW [Multi Function Switch]	√	√	√	√		
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	HUD [Head Up Display]	√	√	√			
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2017	G 5.0 GDI TAU	I - BOX [I - BOX]	√	√	√			
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	ENGINE [Engine Control]	√	√	√	√		0011, 0043, 0094, 0126
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	EPB [Electric Parking Brake]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	AIRBAG [Airbag (Event #2)]	√	√	√			

Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	EPS [Electronic Hydraulic Power Steering System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	TPMS [Tire Pressure Monitoring]	√	√	√			
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	ESHIFTER [E - Shifter]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	PSB - L [Pre - safe Seat Belt - Left]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	PSB - R [Pre - safe Seat Belt - Right]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	AVN [Audio Video Navigation (Standard)]	√	√	√			
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	AVN [Audio Video Navigation (Premium)]	√	√	√	√		0101
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	APSM [Assist Power Seat Module]	√	√	√	√	√	0106
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	SCM [Steering Column Module]	√	√	√	√	√	0114
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	FSJB [Front Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	RSJB [Rear Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 GDI	SVMS [Surround View Monitor System]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	PTM [Power Trunk Module]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	PSM [Power Seat Module]	√	√	√	√	√	0106

Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	HUD [Head Up Display]	√	√	√			
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 GDI LAMBDA II	I - BOX [I - BOX]	√	√	√			
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	ENGINE [Engine Control]	√	√	√	√		0011, 0043, 0094, 0126
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	EPB [Electric Parking Brake]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	EPS [Electronic Hydraulic Power Steering System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	TPMS [Tire Pressure Monitoring]	√	√	√			
Europe/General	Quoris(KH)	2016	G 3.8 MPI	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	ESHIFTER [E - Shifter]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	PSB - L [Pre - safe Seat Belt - Left]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	PSB - R [Pre - safe Seat Belt - Right]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	AVN [Audio Video Navigation (Standard)]	√	√	√			
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	AVN [Audio Video Navigation (Premium)]	√	√	√	√		0101
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	CLU [Cluster Module]	√	√	√	√	√	

Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	APSM [Assist Power Seat Module]	√	√	√	√	√	0106
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	SCM [Steering Column Module]	√	√	√	√	√	0114
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	FSJB [Front Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	RSJB [Rear Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 MPI	SVMS [Surround View Monitor System]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	PTM [Power Trunk Module]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	MFSW [Multi Function Switch]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	HUD [Head Up Display]	√	√	√			
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 3.8 MPI LAMBDA II	I - BOX [I - BOX]	√	√	√			
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	EPB [Electric Parking Brake]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	EPS [Electronic Hydraulic Power Steering System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	TPMS [Tire Pressure Monitoring]	√	√	√			
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	ESHIFTER [E - Shifter]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	PSB - L [Pre - safe Seat Belt - Left]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	PSB - R [Pre - safe Seat Belt - Right]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	AVN [Audio Video Navigation (Standard)]	√	√	√			

Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	AVN [Audio Video Navigation (Prmium)]	√	√	√	√		0101
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	APSM [Assist Power Seat Module]	√	√	√	√	√	0106
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	SCM [Steering Column Module]	√	√	√	√	√	0114
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	FSJB [Front Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	RSJB [Rear Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	SVMS [Surround View Monitor System]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	PTM [Power Trunk Module]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	MFSW [Multi Function Switch]	√	√	√	√		
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	HUD [Head Up Display]	√	√	√			
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2016	G 5.0 GDI TAU	I - BOX [I - BOX]	√	√	√			
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	EPB [Electric Parking Brake]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	EPS [Electronic Hydraulic Power Steering System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	TPMS [Tire Pressure Monitoring]	√	√	√			
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	LDWS [Lane Departure Warning System]	√	√	√	√		0070, 0071
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	AAF [Active Air Flap]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	ESHIFTER [E - Shifter]	√	√	√	√	√	

Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	PSB - L [Pre - safe Seat Belt - Left]	√	√	√	√		
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	PSB - R [Pre - safe Seat Belt - Right]	√	√	√	√		
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	APSM [Assist Power Seat Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	RSJB [Rear Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	FSJB [Front Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	PTM [Power Trunk Module]	√	√	√	√		
Europe/General	Quoris(KH)	2015	G 3.8 GDI	SVMS [Surround View Monitor System]	√	√	√	√		
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	MFSW [Multi Function Switch]	√	√	√	√		
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	HUD [Head Up Display]	√	√	√			
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 GDI LAMBDA II	DIS [Multimedia]	√	√		√		
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	ENGINE [Engine Control]	√	√	√	√		0011, 0043, 0094, 0126
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	EPB [Electric Parking Brake]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	EPS [Electronic Hydraulic Power Steering System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	SCC [Smart Cruise Control]	√	√	√	√		

Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	TPMS [Tire Pressure Monitoring]	√	√	√			
Europe/General	Quoris(KH)	2015	G 3.8 MPI	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	LDWS [Lane Departure Warning System]	√	√	√	√		0070, 0071
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	AAF [Active Air Flap]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	ESHIFTER [E - Shifter]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	PSB - L [Pre - safe Seat Belt - Left]	√	√	√	√		
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	PSB - R [Pre - safe Seat Belt - Right]	√	√	√	√		
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	SCM [Steering Column Module]	√	√	√	√	√	0114
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	APSM [Assist Power Seat Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	RSJB [Rear Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	FSJB [Front Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	PTM [Power Trunk Module]	√	√	√	√		
Europe/General	Quoris(KH)	2015	G 3.8 MPI	SVMS [Surround View Monitor System]	√	√	√	√		
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	MFSW [Multi Function Switch]	√	√	√	√		
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	HUD [Head Up Display]	√	√	√			
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 3.8 MPI LAMBDA II	DIS [Multimedia]	√	√		√		
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	EPB [Electric Parking Brake]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078

Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	EPS [Electronic Hydraulic Power Steering System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	TPMS [Tire Pressure Monitoring]	√	√	√			
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	LDWS [Lane Departure Warning System]	√	√	√	√		0070, 0071
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	AAF [Active Air Flap]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	ESHIFTER [E - Shifter]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	PSB - L [Pre - safe Seat Belt - Left]	√	√	√	√		
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	PSB - R [Pre - safe Seat Belt - Right]	√	√	√	√		
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	SCM [Steering Column Module]	√	√	√	√	√	0114
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	APSM [Assist Power Seat Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	RSJB [Rear Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	FSJB [Front Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	PTM [Power Trunk Module]	√	√	√	√		
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	MFSW [Multi Function Switch]	√	√	√	√		
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	HUD [Head Up Display]	√	√	√			
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2015	G 5.0 GDI TAU	DIS [Multimedia]	√	√		√		
Europe/General	Quoris(KH)	2014	G 3.8 MPI	ENGINE [Engine Control]	√	√	√	√		0011, 0043, 0094, 0126
Europe/General	Quoris(KH)	2014	G 3.8 MPI	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	Quoris(KH)	2014	G 3.8 MPI	EPB [Electric Parking Brake]	√	√	√	√	√	
Europe/General	Quoris(KH)	2014	G 3.8 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	Quoris(KH)	2014	G 3.8 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Quoris(KH)	2014	G 3.8 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Quoris(KH)	2014	G 3.8 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Quoris(KH)	2014	G 3.8 MPI	EPS [Electronic Hydraulic Power Steering System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2014	G 3.8 MPI	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	Quoris(KH)	2014	G 3.8 MPI	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	Quoris(KH)	2014	G 3.8 MPI	TPMS [Tire Pressure Monitoring]	√	√	√			
Europe/General	Quoris(KH)	2014	G 3.8 MPI	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2014	G 3.8 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070, 0071
Europe/General	Quoris(KH)	2014	G 3.8 MPI	BSD [Blind Spot Detection]	√	√	√	√	√	

Europe/General	Quoris(KH)	2014	G 3.8 MPI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	Quoris(KH)	2014	G 3.8 MPI	AAF [Active Air Flap]	√	√	√	√	√	
Europe/General	Quoris(KH)	2014	G 3.8 MPI	ESHIFTER [E - Shifter]	√	√	√	√	√	
Europe/General	Quoris(KH)	2014	G 3.8 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Quoris(KH)	2014	G 3.8 MPI	PSB - L [Pre - safe Seat Belt - Left]	√	√	√	√		
Europe/General	Quoris(KH)	2014	G 3.8 MPI	PSB - R [Pre - safe Seat Belt - Right]	√	√	√	√		
Europe/General	Quoris(KH)	2014	G 3.8 MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2014	G 3.8 MPI	SCM [Steering Column Module]	√	√	√	√	√	0114
Europe/General	Quoris(KH)	2014	G 3.8 MPI	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2014	G 3.8 MPI	APSM [Assist Power Seat Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2014	G 3.8 MPI	RSJB [Rear Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2014	G 3.8 MPI	FSJB [Front Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2014	G 3.8 MPI	PTM [Power Trunk Module]	√	√	√	√		
Europe/General	Quoris(KH)	2014	G 3.8 MPI	SVMS [Surround View Monitor System]	√	√	√	√		
Europe/General	Quoris(KH)	2014	G 3.8 MPI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Quoris(KH)	2014	G 3.8 MPI	MFSW [Multi Function Switch]	√	√	√	√		
Europe/General	Quoris(KH)	2014	G 3.8 MPI	HUD [Head Up Display]	√	√	√			
Europe/General	Quoris(KH)	2014	G 3.8 MPI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2014	G 3.8 MPI	DIS [Multimedia]	√	√		√		
Europe/General	Quoris(KH)	2013	G 3.8 MPI	ENGINE [Engine Control]	√	√	√	√		0011, 0043, 0094, 0126
Europe/General	Quoris(KH)	2013	G 3.8 MPI	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	Quoris(KH)	2013	G 3.8 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	Quoris(KH)	2013	G 3.8 MPI	EPB [Electric Parking Brake]	√	√	√	√	√	
Europe/General	Quoris(KH)	2013	G 3.8 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	Quoris(KH)	2013	G 3.8 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	Quoris(KH)	2013	G 3.8 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	Quoris(KH)	2013	G 3.8 MPI	EPS [Electronic Hydraulic Power Steering System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2013	G 3.8 MPI	ECS [Electronic Control Suspension]	√	√	√	√		
Europe/General	Quoris(KH)	2013	G 3.8 MPI	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	Quoris(KH)	2013	G 3.8 MPI	TPMS [Tire Pressure Monitoring]	√	√	√			
Europe/General	Quoris(KH)	2013	G 3.8 MPI	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2013	G 3.8 MPI	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	Quoris(KH)	2013	G 3.8 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070, 0071
Europe/General	Quoris(KH)	2013	G 3.8 MPI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	
Europe/General	Quoris(KH)	2013	G 3.8 MPI	AAF [Active Air Flap]	√	√	√	√	√	
Europe/General	Quoris(KH)	2013	G 3.8 MPI	ESHIFTER [E - Shifter]	√	√	√	√	√	
Europe/General	Quoris(KH)	2013	G 3.8 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	Quoris(KH)	2013	G 3.8 MPI	PSB - L [Pre - safe Seat Belt - Left]	√	√	√	√		
Europe/General	Quoris(KH)	2013	G 3.8 MPI	PSB - R [Pre - safe Seat Belt - Right]	√	√	√	√		
Europe/General	Quoris(KH)	2013	G 3.8 MPI	RSJB [Rear Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2013	G 3.8 MPI	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2013	G 3.8 MPI	APSM [Assist Power Seat Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2013	G 3.8 MPI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2013	G 3.8 MPI	SCM [Steering Column Module]	√	√	√	√	√	0114

Europe/General	Quoris(KH)	2013	G 3.8 MPI	FSJB [Front Smart Junction Block]	√	√	√	√	√	
Europe/General	Quoris(KH)	2013	G 3.8 MPI	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2013	G 3.8 MPI	HUD [Head Up Display]	√	√	√			
Europe/General	Quoris(KH)	2013	G 3.8 MPI	PTM [Power Trunk Module]	√	√	√	√		
Europe/General	Quoris(KH)	2013	G 3.8 MPI	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	Quoris(KH)	2013	G 3.8 MPI	MFSW [Multi Function Switch]	√	√	√	√		
Europe/General	Quoris(KH)	2013	G 3.8 MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	Quoris(KH)	2013	G 3.8 MPI	DIS [Multimedia]	√	√		√		
Europe/General	RETONA(JL)	2001	D 2.0 TCI	AT [Automatic Transaxle]		√	√	√		
Europe/General	RETONA(JL)	2001	D 2.0 TCI	AIRBAG [Airbag Control]		√	√			
Europe/General	RETONA(JL)	2001	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	RETONA(JL)	2001	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	RETONA(JL)	2001	G 2.0 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	RETONA(JL)	2000	D 2.0 TCI	AT [Automatic Transaxle]		√	√	√		
Europe/General	RETONA(JL)	2000	D 2.0 TCI	AIRBAG [Airbag Control]		√	√			
Europe/General	RETONA(JL)	2000	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	RETONA(JL)	2000	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	RETONA(JL)	2000	G 2.0 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	RETONA(JL)	1999	D 2.0 TCI	AT [Automatic Transaxle]		√	√	√		
Europe/General	RETONA(JL)	1999	D 2.0 TCI	AIRBAG [Airbag Control]		√	√			
Europe/General	RETONA(JL)	1999	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	RETONA(JL)	1999	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	RETONA(JL)	1999	G 2.0 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	RETONA(JL)	1998	D 2.0 TCI	AT [Automatic Transaxle]		√	√	√		
Europe/General	RETONA(JL)	1998	D 2.0 TCI	AIRBAG [Airbag Control]		√	√			
Europe/General	RIO(BC)	2013	G 1.5 DOHC	ENGINE [Unleaded (RHD) - MAP]		√	√	√		
Europe/General	RIO(BC)	2013	G 1.5 DOHC	ENGINE [Unleaded (RHD) - MAF]		√	√	√		
Europe/General	RIO(BC)	2013	G 1.5 DOHC	ENGINE [Unleaded - MAF]		√	√	√		
Europe/General	RIO(BC)	2013	G 1.5 DOHC	ENGINE [Leaded All]		√	√	√		
Europe/General	RIO(BC)	2013	G 1.5 DOHC	ENGINE [Unleaded - W / IMMO]		√	√	√		
Europe/General	RIO(BC)	2013	G 1.5 DOHC	ENGINE [Unleaded - MAP]		√	√	√		
Europe/General	RIO(BC)	2013	G 1.5 DOHC	AT [Automatic Transaxle (RHD)]		√	√	√		
Europe/General	RIO(BC)	2013	G 1.5 DOHC	AT [Automatic Transaxle (LHD)]		√	√	√		
Europe/General	RIO(BC)	2013	G 1.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	RIO(BC)	2013	G 1.5 DOHC	AIRBAG [Airbag Control (RHD)]		√	√	√		
Europe/General	RIO(BC)	2013	G 1.5 DOHC	AIRBAG [Airbag Control (LHD)]		√	√	√		
Europe/General	RIO(BC)	2012	G 1.5 DOHC	ENGINE [Unleaded (RHD) - MAP]		√	√	√		
Europe/General	RIO(BC)	2012	G 1.5 DOHC	ENGINE [Unleaded (RHD) - MAF]		√	√	√		
Europe/General	RIO(BC)	2012	G 1.5 DOHC	ENGINE [Unleaded - MAF]		√	√	√		
Europe/General	RIO(BC)	2012	G 1.5 DOHC	ENGINE [Leaded All]		√	√	√		
Europe/General	RIO(BC)	2012	G 1.5 DOHC	ENGINE [Unleaded - W / IMMO]		√	√	√		
Europe/General	RIO(BC)	2012	G 1.5 DOHC	ENGINE [Unleaded - MAP]		√	√	√		
Europe/General	RIO(BC)	2012	G 1.5 DOHC	AT [Automatic Transaxle (RHD)]		√	√	√		
Europe/General	RIO(BC)	2012	G 1.5 DOHC	AT [Automatic Transaxle (LHD)]		√	√	√		
Europe/General	RIO(BC)	2012	G 1.5 DOHC	AIRBAG [Airbag Control (RHD)]		√	√	√		

Europe/General	RIO(BC)	2005	G 1.5 DOHC	ENGINE [Leaded All]		√	√	√		
Europe/General	RIO(BC)	2005	G 1.5 DOHC	ENGINE [Unleaded - W / IMMO]		√	√	√		
Europe/General	RIO(BC)	2005	G 1.5 DOHC	ENGINE [Unleaded - MAP]		√	√	√		
Europe/General	RIO(BC)	2005	G 1.5 DOHC	AT [Automatic Transaxle (RHD)]		√	√	√		
Europe/General	RIO(BC)	2005	G 1.5 DOHC	AT [Automatic Transaxle (LHD)]		√	√	√		
Europe/General	RIO(BC)	2005	G 1.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	RIO(BC)	2005	G 1.5 DOHC	AIRBAG [Airbag Control (RHD)]		√	√	√		
Europe/General	RIO(BC)	2005	G 1.5 DOHC	AIRBAG [Airbag Control (LHD)]		√	√	√		
Europe/General	RIO(BC)	2005	G 1.6 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	RIO(BC)	2005	G 1.6 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	RIO(BC)	2005	G 1.6 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	RIO(BC)	2005	G 1.6 DOHC	AIRBAG [Airbag Control]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.3 SOHC	ENGINE [Unleaded (RHD) - MAP]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.3 SOHC	ENGINE [Unleaded (RHD) - MAF]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.3 SOHC	ENGINE [Unleaded - MAF]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.3 SOHC	ENGINE [Leaded All]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.3 SOHC	ENGINE [Unleaded - W / IMMO]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.3 SOHC	ENGINE [Unleaded - MAP]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.3 SOHC	AT [Automatic Transaxle (RHD)]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.3 SOHC	AT [Automatic Transaxle (LHD)]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.3 SOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	RIO(BC)	2004	G 1.3 SOHC	AIRBAG [Airbag Control (RHD)]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.3 SOHC	AIRBAG [Airbag Control (LHD)]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.5 DOHC	ENGINE [Unleaded (RHD) - MAP]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.5 DOHC	ENGINE [Unleaded (RHD) - MAF]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.5 DOHC	ENGINE [Unleaded - MAF]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.5 DOHC	ENGINE [Unleaded - W / IMMO]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.5 DOHC	ENGINE [Unleaded - MAP]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.5 DOHC	AT [Automatic Transaxle (RHD)]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.5 DOHC	AT [Automatic Transaxle (LHD)]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	RIO(BC)	2004	G 1.5 DOHC	AIRBAG [Airbag Control (RHD)]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.5 DOHC	AIRBAG [Airbag Control (LHD)]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.6 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.6 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	RIO(BC)	2004	G 1.6 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	RIO(BC)	2004	G 1.6 DOHC	AIRBAG [Airbag Control]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.3 SOHC	ENGINE [Unleaded (RHD) - MAP]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.3 SOHC	ENGINE [Unleaded (RHD) - MAF]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.3 SOHC	ENGINE [Unleaded - MAF]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.3 SOHC	ENGINE [Leaded All]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.3 SOHC	ENGINE [Unleaded - W / IMMO]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.3 SOHC	ENGINE [Unleaded - MAP]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.3 SOHC	AT [Automatic Transaxle (RHD)]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.3 SOHC	AT [Automatic Transaxle (LHD)]		√	√	√		

Europe/General	RIO(BC)	2003	G 1.3 SOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	RIO(BC)	2003	G 1.3 SOHC	AIRBAG [Airbag Control (RHD)]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.3 SOHC	AIRBAG [Airbag Control (LHD)]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.5 DOHC	ENGINE [Unleaded (RHD) - MAP]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.5 DOHC	ENGINE [Unleaded (RHD) - MAF]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.5 DOHC	ENGINE [Unleaded - MAF]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.5 DOHC	ENGINE [Leaded All]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.5 DOHC	ENGINE [Unleaded - W / IMMO]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.5 DOHC	ENGINE [Unleaded - MAP]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.5 DOHC	AT [Automatic Transaxle (RHD)]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.5 DOHC	AT [Automatic Transaxle (LHD)]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	RIO(BC)	2003	G 1.5 DOHC	AIRBAG [Airbag Control (RHD)]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.5 DOHC	AIRBAG [Airbag Control (LHD)]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.6 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.6 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	RIO(BC)	2003	G 1.6 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	RIO(BC)	2003	G 1.6 DOHC	AIRBAG [Airbag Control]		√	√	√		
Europe/General	RIO(BC)	2002	G 1.3 SOHC	ENGINE [Unleaded (RHD) - MAP]		√	√	√		
Europe/General	RIO(BC)	2002	G 1.3 SOHC	ENGINE [Unleaded (RHD) - MAF]		√	√	√		
Europe/General	RIO(BC)	2002	G 1.3 SOHC	ENGINE [Leaded All]		√	√	√		
Europe/General	RIO(BC)	2002	G 1.3 SOHC	ENGINE [Unleaded - W / IMMO]		√	√	√		
Europe/General	RIO(BC)	2002	G 1.3 SOHC	ENGINE [Unleaded - MAP]		√	√	√		
Europe/General	RIO(BC)	2002	G 1.3 SOHC	AT [Automatic Transaxle (RHD)]		√	√	√		
Europe/General	RIO(BC)	2002	G 1.3 SOHC	AT [Automatic Transaxle (LHD)]		√	√	√		
Europe/General	RIO(BC)	2002	G 1.3 SOHC	AIRBAG [Airbag Control (RHD)]		√	√	√		
Europe/General	RIO(BC)	2002	G 1.3 SOHC	AIRBAG [Airbag Control (LHD)]		√	√	√		
Europe/General	RIO(BC)	2002	G 1.5 DOHC	ENGINE [Unleaded (RHD) - MAP]		√	√	√		
Europe/General	RIO(BC)	2002	G 1.5 DOHC	ENGINE [Unleaded (RHD) - MAF]		√	√	√		
Europe/General	RIO(BC)	2002	G 1.5 DOHC	ENGINE [Unleaded - MAF]		√	√	√		
Europe/General	RIO(BC)	2002	G 1.5 DOHC	ENGINE [Leaded All]		√	√	√		
Europe/General	RIO(BC)	2002	G 1.5 DOHC	ENGINE [Unleaded - W / IMMO]		√	√	√		
Europe/General	RIO(BC)	2002	G 1.5 DOHC	ENGINE [Unleaded - MAP]		√	√	√		
Europe/General	RIO(BC)	2002	G 1.5 DOHC	AT [Automatic Transaxle (RHD)]		√	√	√		
Europe/General	RIO(BC)	2002	G 1.5 DOHC	AT [Automatic Transaxle (LHD)]		√	√	√		
Europe/General	RIO(BC)	2002	G 1.5 DOHC	AIRBAG [Airbag Control (RHD)]		√	√	√		
Europe/General	RIO(BC)	2002	G 1.5 DOHC	AIRBAG [Airbag Control (LHD)]		√	√	√		
Europe/General	RIO(BC)	2001	G 1.3 SOHC	ENGINE [Unleaded (RHD) - MAP]		√	√	√		
Europe/General	RIO(BC)	2001	G 1.3 SOHC	ENGINE [Unleaded (RHD) - MAF]		√	√	√		
Europe/General	RIO(BC)	2001	G 1.3 SOHC	ENGINE [Unleaded - MAF]		√	√	√		
Europe/General	RIO(BC)	2001	G 1.3 SOHC	ENGINE [Leaded All]		√	√	√		
Europe/General	RIO(BC)	2001	G 1.3 SOHC	ENGINE [Unleaded - W / IMMO]		√	√	√		
Europe/General	RIO(BC)	2001	G 1.3 SOHC	ENGINE [Unleaded - MAP]		√	√	√		
Europe/General	RIO(BC)	2001	G 1.3 SOHC	AT [Automatic Transaxle (RHD)]		√	√	√		
Europe/General	RIO(BC)	2001	G 1.3 SOHC	AT [Automatic Transaxle (LHD)]		√	√	√		

Europe/General	RIO(BC)	2001	G 1.3 SOHC	AIRBAG [Airbag Control (RHD)]		√	√	√		
Europe/General	RIO(BC)	2001	G 1.3 SOHC	AIRBAG [Airbag Control (LHD)]		√	√	√		
Europe/General	RIO(BC)	2001	G 1.5 DOHC	ENGINE [Unleaded (RHD) - MAP]		√	√	√		
Europe/General	RIO(BC)	2001	G 1.5 DOHC	ENGINE [Unleaded (RHD) - MAF]		√	√	√		
Europe/General	RIO(BC)	2001	G 1.5 DOHC	ENGINE [Unleaded - MAF]		√	√	√		
Europe/General	RIO(BC)	2001	G 1.5 DOHC	ENGINE [Leaded All]		√	√	√		
Europe/General	RIO(BC)	2001	G 1.5 DOHC	ENGINE [Unleaded - W / IMMO]		√	√	√		
Europe/General	RIO(BC)	2001	G 1.5 DOHC	ENGINE [Unleaded - MAP]		√	√	√		
Europe/General	RIO(BC)	2001	G 1.5 DOHC	AT [Automatic Transaxle (RHD)]		√	√	√		
Europe/General	RIO(BC)	2001	G 1.5 DOHC	AT [Automatic Transaxle (LHD)]		√	√	√		
Europe/General	RIO(BC)	2001	G 1.5 DOHC	AIRBAG [Airbag Control (RHD)]		√	√	√		
Europe/General	RIO(BC)	2001	G 1.5 DOHC	AIRBAG [Airbag Control (LHD)]		√	√	√		
Europe/General	RIO(BC)	2000	G 1.3 SOHC	ENGINE [Unleaded (RHD) - MAP]		√	√	√		
Europe/General	RIO(BC)	2000	G 1.3 SOHC	ENGINE [Unleaded (RHD) - MAF]		√	√	√		
Europe/General	RIO(BC)	2000	G 1.3 SOHC	ENGINE [Leaded All]		√	√	√		
Europe/General	RIO(BC)	2000	G 1.3 SOHC	ENGINE [Unleaded - W / IMMO]		√	√	√		
Europe/General	RIO(BC)	2000	G 1.3 SOHC	ENGINE [Unleaded - MAP]		√	√	√		
Europe/General	RIO(BC)	2000	G 1.3 SOHC	AT [Automatic Transaxle (RHD)]		√	√	√		
Europe/General	RIO(BC)	2000	G 1.3 SOHC	AT [Automatic Transaxle (LHD)]		√	√	√		
Europe/General	RIO(BC)	2000	G 1.5 DOHC	ENGINE [Unleaded (RHD) - MAP]		√	√	√		
Europe/General	RIO(BC)	2000	G 1.5 DOHC	ENGINE [Unleaded (RHD) - MAF]		√	√	√		
Europe/General	RIO(BC)	2000	G 1.5 DOHC	ENGINE [Unleaded - MAF]		√	√	√		
Europe/General	RIO(BC)	2000	G 1.5 DOHC	ENGINE [Leaded All]		√	√	√		
Europe/General	RIO(BC)	2000	G 1.5 DOHC	ENGINE [Unleaded - W / IMMO]		√	√	√		
Europe/General	RIO(BC)	2000	G 1.5 DOHC	ENGINE [Unleaded - MAP]		√	√	√		
Europe/General	RIO(BC)	2000	G 1.5 DOHC	AT [Automatic Transaxle (RHD)]		√	√	√		
Europe/General	RIO(BC)	2000	G 1.5 DOHC	AT [Automatic Transaxle (LHD)]		√	√	√		
Europe/General	RIO(JB)	2012	D 1.5 TCI-U	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	RIO(JB)	2012	D 1.5 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2012	D 1.5 TCI-U	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2012	D 1.5 TCI-U	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2012	D 1.5 TCI-U	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	RIO(JB)	2012	D 1.5 TCI-U	IMMO [Immobilizer]				√		0075, 0072, 0112, 0075, 0092, 0083, 0119
Europe/General	RIO(JB)	2012	G 1.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2012	G 1.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0098
Europe/General	RIO(JB)	2012	G 1.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2012	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2012	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2012	G 1.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2012	G 1.4 DOHC	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	RIO(JB)	2012	G 1.4 DOHC	IMMO [Immobilizer]				√		0075, 0112, 0072, 0075, 0083, 0092, 0119
Europe/General	RIO(JB)	2012	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2012	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0098

Europe/General	RIO(JB)	2012	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2012	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2012	G 1.6 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2012	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2012	G 1.6 DOHC	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	RIO(JB)	2012	G 1.6 DOHC	IMMO [Immobilizer]				√		0075, 0112, 0072, 0075, 0083, 0092, 0119
Europe/General	RIO(JB)	2011	D 1.5 TCI-U	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	RIO(JB)	2011	D 1.5 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2011	D 1.5 TCI-U	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2011	D 1.5 TCI-U	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	RIO(JB)	2011	D 1.5 TCI-U	IMMO [Immobilizer]				√		0075, 0072, 0112, 0075, 0092, 0083, 0119
Europe/General	RIO(JB)	2011	G 1.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2011	G 1.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0098
Europe/General	RIO(JB)	2011	G 1.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2011	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2011	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2011	G 1.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2011	G 1.4 DOHC	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	RIO(JB)	2011	G 1.4 DOHC	IMMO [Immobilizer]				√		0075, 0112, 0072, 0075, 0083, 0092, 0119
Europe/General	RIO(JB)	2011	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2011	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0098
Europe/General	RIO(JB)	2011	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2011	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2011	G 1.6 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2011	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2011	G 1.6 DOHC	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	RIO(JB)	2011	G 1.6 DOHC	IMMO [Immobilizer]				√		0075, 0112, 0072, 0075, 0083, 0092, 0119
Europe/General	RIO(JB)	2010	D 1.5 TCI-U	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	RIO(JB)	2010	D 1.5 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2010	D 1.5 TCI-U	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2010	D 1.5 TCI-U	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2010	D 1.5 TCI-U	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	RIO(JB)	2010	D 1.5 TCI-U	IMMO [Immobilizer]				√		0075, 0072, 0112, 0075, 0092, 0083, 0119
Europe/General	RIO(JB)	2010	G 1.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2010	G 1.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0098
Europe/General	RIO(JB)	2010	G 1.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2010	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2010	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2010	G 1.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2010	G 1.4 DOHC	EPS [Motor driven Power Steering]	√	√	√	√		

Europe/General	RIO(JB)	2010	G 1.4 DOHC	IMMO [Immobilizer]				√		0075, 0112, 0072, 0075, 0083, 0092, 0119
Europe/General	RIO(JB)	2010	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2010	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0098
Europe/General	RIO(JB)	2010	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2010	G 1.6 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2010	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2010	G 1.6 DOHC	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	RIO(JB)	2010	G 1.6 DOHC	IMMO [Immobilizer]				√		0075, 0112, 0072, 0075, 0083, 0092, 0119
Europe/General	RIO(JB)	2009	D 1.5 TCI-U	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	RIO(JB)	2009	D 1.5 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2009	D 1.5 TCI-U	ABS [ABS (MGH - 40)]	√	√	√	√	√	
Europe/General	RIO(JB)	2009	D 1.5 TCI-U	ABS [ABS (MGH - 25)]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2009	D 1.5 TCI-U	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2009	D 1.5 TCI-U	IMMO [Immobilizer]				√		0075, 0072, 0112, 0075, 0092, 0083, 0119
Europe/General	RIO(JB)	2009	G 1.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2009	G 1.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0098
Europe/General	RIO(JB)	2009	G 1.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2009	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2009	G 1.4 DOHC	ABS [ABS (MGH - 40)]	√	√	√	√	√	
Europe/General	RIO(JB)	2009	G 1.4 DOHC	ABS [ABS (MGH - 25)]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2009	G 1.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2009	G 1.4 DOHC	IMMO [Immobilizer]				√		0075, 0112, 0072, 0075, 0083, 0092, 0119
Europe/General	RIO(JB)	2009	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2009	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0098
Europe/General	RIO(JB)	2009	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2009	G 1.6 DOHC	ABS [ABS (MGH - 40)]	√	√	√	√	√	
Europe/General	RIO(JB)	2009	G 1.6 DOHC	ABS [ABS (MGH - 25)]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2009	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2009	G 1.6 DOHC	IMMO [Immobilizer]				√		0075, 0112, 0072, 0075, 0083, 0092, 0119
Europe/General	RIO(JB)	2008	D 1.5 TCI-U	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	RIO(JB)	2008	D 1.5 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2008	D 1.5 TCI-U	ABS [ABS (MGH - 40)]	√	√	√	√	√	
Europe/General	RIO(JB)	2008	D 1.5 TCI-U	ABS [ABS (MGH - 25)]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2008	D 1.5 TCI-U	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2008	D 1.5 TCI-U	IMMO [Immobilizer]				√		0075, 0072, 0112, 0075, 0092, 0083, 0119
Europe/General	RIO(JB)	2008	G 1.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2008	G 1.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0098
Europe/General	RIO(JB)	2008	G 1.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2008	G 1.4 DOHC	ABS [ABS (MGH - 40)]	√	√	√	√	√	
Europe/General	RIO(JB)	2008	G 1.4 DOHC	ABS [ABS (MGH - 25)]	√	√	√	√	√	0051

Europe/General	RIO(JB)	2008	G 1.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2008	G 1.4 DOHC	IMMO [Immobilizer]				√		0075, 0112, 0072, 0075, 0083, 0092, 0119
Europe/General	RIO(JB)	2008	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2008	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0098
Europe/General	RIO(JB)	2008	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2008	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2008	G 1.6 DOHC	ABS [ABS (MGH - 40)]	√	√	√	√	√	
Europe/General	RIO(JB)	2008	G 1.6 DOHC	ABS [ABS (MGH - 25)]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2008	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2008	G 1.6 DOHC	IMMO [Immobilizer]				√		0075, 0112, 0072, 0075, 0083, 0092, 0119
Europe/General	RIO(JB)	2007	D 1.5 TCI-U	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	RIO(JB)	2007	D 1.5 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2007	D 1.5 TCI-U	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2007	D 1.5 TCI-U	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2007	D 1.5 TCI-U	IMMO [Immobilizer]				√		0075, 0072, 0112, 0075, 0092, 0083, 0119
Europe/General	RIO(JB)	2007	G 1.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2007	G 1.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0098
Europe/General	RIO(JB)	2007	G 1.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2007	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2007	G 1.4 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2007	G 1.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2007	G 1.4 DOHC	IMMO [Immobilizer]				√		0075, 0112, 0072, 0075, 0083, 0092, 0119
Europe/General	RIO(JB)	2007	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2007	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0098
Europe/General	RIO(JB)	2007	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2007	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2007	G 1.6 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2007	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2007	G 1.6 DOHC	IMMO [Immobilizer]				√		0075, 0112, 0072, 0075, 0083, 0092, 0119
Europe/General	RIO(JB)	2006	D 1.5 TCI-U	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	RIO(JB)	2006	D 1.5 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2006	D 1.5 TCI-U	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2006	D 1.5 TCI-U	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2006	G 1.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2006	G 1.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0098
Europe/General	RIO(JB)	2006	G 1.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2006	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2006	G 1.4 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2006	G 1.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2006	G 1.4 DOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	RIO(JB)	2006	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0098

Europe/General	RIO(JB)	2006	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0098
Europe/General	RIO(JB)	2006	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2006	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2006	G 1.6 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2006	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2006	G 1.6 DOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	RIO(JB)	2005	D 1.5 TCI-U	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	RIO(JB)	2005	D 1.5 TCI-U	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2005	D 1.5 TCI-U	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2005	D 1.5 TCI-U	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2005	D 1.5 TCI-U	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	RIO(JB)	2005	G 1.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2005	G 1.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0098
Europe/General	RIO(JB)	2005	G 1.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0098
Europe/General	RIO(JB)	2005	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2005	G 1.4 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2005	G 1.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2005	G 1.4 DOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	RIO(JB)	2005	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	RIO(JB)	2005	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	RIO(JB)	2005	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	RIO(JB)	2005	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(JB)	2005	G 1.6 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	RIO(JB)	2005	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	RIO(JB)	2005	G 1.6 DOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	RIO(QBR)	2017	G 1.4 MPI GAMMA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(QBR)	2017	G 1.4 MPI GAMMA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(QBR)	2017	G 1.4 MPI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(QBR)	2017	G 1.4 MPI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(QBR)	2017	G 1.4 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(QBR)	2017	G 1.4 MPI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(QBR)	2017	G 1.4 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0075, 0072, 0112, 0092, 0083
Europe/General	RIO(QBR)	2017	G 1.4 MPI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(QBR)	2017	G 1.4 MPI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	RIO(QBR)	2017	G 1.4 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(QBR)	2017	G 1.6 MPI GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126

Europe/General	RIO(QBR)	2017	G 1.6 MPI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(QBR)	2017	G 1.6 MPI GAMMA	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(QBR)	2017	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(QBR)	2017	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(QBR)	2017	G 1.6 MPI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(QBR)	2017	G 1.6 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0075, 0072, 0112, 0092, 0083
Europe/General	RIO(QBR)	2017	G 1.6 MPI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(QBR)	2017	G 1.6 MPI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	RIO(QBR)	2017	G 1.6 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(QBR)	2016	G 1.4 MPI GAMMA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(QBR)	2016	G 1.4 MPI GAMMA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(QBR)	2016	G 1.4 MPI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(QBR)	2016	G 1.4 MPI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(QBR)	2016	G 1.4 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(QBR)	2016	G 1.4 MPI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(QBR)	2016	G 1.4 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0075, 0072, 0112, 0092, 0083
Europe/General	RIO(QBR)	2016	G 1.4 MPI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(QBR)	2016	G 1.4 MPI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	RIO(QBR)	2016	G 1.4 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(QBR)	2016	G 1.6 MPI GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(QBR)	2016	G 1.6 MPI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(QBR)	2016	G 1.6 MPI GAMMA	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(QBR)	2016	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(QBR)	2016	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			

Europe/General	RIO(QBR)	2016	G 1.6 MPI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(QBR)	2016	G 1.6 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0075, 0072, 0112, 0092, 0083
Europe/General	RIO(QBR)	2016	G 1.6 MPI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(QBR)	2016	G 1.6 MPI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	RIO(QBR)	2016	G 1.6 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(QBR)	2015	G 1.4 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(QBR)	2015	G 1.4 DOHC	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(QBR)	2015	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(QBR)	2015	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(QBR)	2015	G 1.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(QBR)	2015	G 1.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(QBR)	2015	G 1.4 DOHC	IMMO [Immobilizer]		√	√	√		0075, 0072, 0112, 0092, 0083
Europe/General	RIO(QBR)	2015	G 1.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(QBR)	2015	G 1.4 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	RIO(QBR)	2015	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(QBR)	2015	G 1.4 MPI GAMMA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(QBR)	2015	G 1.4 MPI GAMMA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(QBR)	2015	G 1.4 MPI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(QBR)	2015	G 1.4 MPI GAMMA	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(QBR)	2015	G 1.4 MPI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(QBR)	2015	G 1.4 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(QBR)	2015	G 1.4 MPI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(QBR)	2015	G 1.4 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0075, 0072, 0112, 0092, 0083
Europe/General	RIO(QBR)	2015	G 1.4 MPI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(QBR)	2015	G 1.4 MPI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	RIO(QBR)	2015	G 1.4 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(QBR)	2015	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(QBR)	2015	G 1.6 DOHC	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(QBR)	2015	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(QBR)	2015	G 1.6 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(QBR)	2015	G 1.6 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(QBR)	2015	G 1.6 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			

Europe/General	RIO(QBR)	2015	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(QBR)	2015	G 1.6 DOHC	IMMO [Immobilizer]		√	√	√		0075, 0072, 0112, 0092, 0083
Europe/General	RIO(QBR)	2015	G 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(QBR)	2015	G 1.6 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	RIO(QBR)	2015	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(QBR)	2015	G 1.6 MPI GAMMA	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(QBR)	2015	G 1.6 MPI GAMMA	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(QBR)	2015	G 1.6 MPI GAMMA	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(QBR)	2015	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(QBR)	2015	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(QBR)	2015	G 1.6 MPI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(QBR)	2015	G 1.6 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0075, 0072, 0112, 0092, 0083
Europe/General	RIO(QBR)	2015	G 1.6 MPI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(QBR)	2015	G 1.6 MPI GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	RIO(QBR)	2015	G 1.6 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(QBR)	2014	G 1.4 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(QBR)	2014	G 1.4 DOHC	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(QBR)	2014	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(QBR)	2014	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(QBR)	2014	G 1.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(QBR)	2014	G 1.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(QBR)	2014	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(QBR)	2014	G 1.4 DOHC	IMMO [Immobilizer]		√	√	√		0075, 0072, 0112, 0092, 0083
Europe/General	RIO(QBR)	2014	G 1.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(QBR)	2014	G 1.4 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	RIO(QBR)	2014	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(QBR)	2014	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(QBR)	2014	G 1.6 DOHC	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(QBR)	2014	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(QBR)	2014	G 1.6 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(QBR)	2014	G 1.6 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(QBR)	2014	G 1.6 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(QBR)	2014	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(QBR)	2014	G 1.6 DOHC	IMMO [Immobilizer]		√	√	√		0075, 0072, 0112, 0092, 0083
Europe/General	RIO(QBR)	2014	G 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(QBR)	2014	G 1.6 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	RIO(QBR)	2014	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022

Europe/General	RIO(QBR)	2013	G 1.4 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(QBR)	2013	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(QBR)	2013	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(QBR)	2013	G 1.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(QBR)	2013	G 1.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(QBR)	2013	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(QBR)	2013	G 1.4 DOHC	IMMO [Immobilizer]		√	√	√		0075, 0072, 0112, 0092, 0083
Europe/General	RIO(QBR)	2013	G 1.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(QBR)	2013	G 1.4 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	RIO(QBR)	2013	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(QBR)	2013	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(QBR)	2013	G 1.6 DOHC	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(QBR)	2013	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(QBR)	2013	G 1.6 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(QBR)	2013	G 1.6 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(QBR)	2013	G 1.6 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(QBR)	2013	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(QBR)	2013	G 1.6 DOHC	IMMO [Immobilizer]		√	√	√		0075, 0072, 0112, 0092, 0083
Europe/General	RIO(QBR)	2013	G 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(QBR)	2013	G 1.6 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	RIO(QBR)	2013	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(QBR)	2012	G 1.4 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(QBR)	2012	G 1.4 DOHC	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(QBR)	2012	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(QBR)	2012	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(QBR)	2012	G 1.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(QBR)	2012	G 1.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(QBR)	2012	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(QBR)	2012	G 1.4 DOHC	IMMO [Immobilizer]		√	√	√		0075, 0072, 0112, 0092, 0083
Europe/General	RIO(QBR)	2012	G 1.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(QBR)	2012	G 1.4 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	RIO(QBR)	2012	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(QBR)	2012	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(QBR)	2012	G 1.6 DOHC	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(QBR)	2012	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(QBR)	2012	G 1.6 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(QBR)	2012	G 1.6 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(QBR)	2012	G 1.6 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(QBR)	2012	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(QBR)	2012	G 1.6 DOHC	IMMO [Immobilizer]		√	√	√		0075, 0072, 0112, 0092, 0083
Europe/General	RIO(QBR)	2012	G 1.6 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	RIO(QBR)	2012	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2017	D 1.1 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0025, 0047, 0094, 0047
Europe/General	RIO(UB)	2017	D 1.1 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2017	D 1.1 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			

Europe/General	RIO(UB)	2017	D 1.1 TCI-U2	AIRBAG [Airbag Event #2 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2017	D 1.1 TCI-U2	AIRBAG [Airbag Event #1 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2017	D 1.1 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2017	D 1.1 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	D 1.1 TCI-U2	AIRCON [Air Conditioner (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	D 1.1 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	D 1.1 TCI-U2	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2017	D 1.1 TCI-U2	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	RIO(UB)	2017	D 1.1 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2017	D 1.1 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2017	D 1.1 TCI-U2	BCM [Body Control Module (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	D 1.1 TCI-U2	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	D 1.1 TCI-U2	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	D 1.1 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2017	D 1.4 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	RIO(UB)	2017	D 1.4 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2017	D 1.4 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2017	D 1.4 TCI-U2	AIRBAG [Airbag Event #2 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2017	D 1.4 TCI-U2	AIRBAG [Airbag Event #1 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2017	D 1.4 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2017	D 1.4 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	D 1.4 TCI-U2	AIRCON [Air Conditioner (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	D 1.4 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2017	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	RIO(UB)	2017	D 1.4 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2017	D 1.4 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2017	D 1.4 TCI-U2	BCM [Body Control Module (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	D 1.4 TCI-U2	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	D 1.4 TCI-U2	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	D 1.4 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2017	G 1.2 DOHC	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(UB)	2017	G 1.2 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2017	G 1.2 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2017	G 1.2 DOHC	AIRBAG [Airbag Event #2 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2017	G 1.2 DOHC	AIRBAG [Airbag Event #1 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2017	G 1.2 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2017	G 1.2 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	G 1.2 DOHC	AIRCON [Air Conditioner (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	G 1.2 DOHC	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	G 1.2 DOHC	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2017	G 1.2 DOHC	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	

Europe/General	RIO(UB)	2017	G 1.2 DOHC	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2017	G 1.2 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2017	G 1.2 DOHC	BCM [Body Control Module (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	G 1.2 DOHC	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	G 1.2 DOHC	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	G 1.2 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2017	G 1.4 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2017	G 1.4 DOHC	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(UB)	2017	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(UB)	2017	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2017	G 1.4 DOHC	AIRBAG [Airbag Event #1 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2017	G 1.4 DOHC	AIRBAG [Airbag Event #2 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2017	G 1.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2017	G 1.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2017	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	G 1.4 DOHC	AIRCON [Air Conditioner (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	G 1.4 DOHC	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	G 1.4 DOHC	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	RIO(UB)	2017	G 1.4 DOHC	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2017	G 1.4 DOHC	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2017	G 1.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2017	G 1.4 DOHC	BCM [Body Control Module (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	G 1.4 DOHC	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	G 1.4 DOHC	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2017	G 1.6 GDI	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2017	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(UB)	2017	G 1.6 GDI	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2017	G 1.6 GDI	AIRBAG [Airbag Event #1 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2017	G 1.6 GDI	AIRBAG [Airbag Event #2 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2017	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2017	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2017	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	G 1.6 GDI	AIRCON [Air Conditioner (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	G 1.6 GDI	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	G 1.6 GDI	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	RIO(UB)	2017	G 1.6 GDI	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2017	G 1.6 GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2017	G 1.6 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2017	G 1.6 GDI	BCM [Body Control Module (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	G 1.6 GDI	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	G 1.6 GDI	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2017	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022

Europe/General	RIO(UB)	2016	D 1.1 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0025, 0047, 0094, 0047
Europe/General	RIO(UB)	2016	D 1.1 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2016	D 1.1 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2016	D 1.1 TCI-U2	AIRBAG [Airbag Event #2 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2016	D 1.1 TCI-U2	AIRBAG [Airbag Event #1 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2016	D 1.1 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2016	D 1.1 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	D 1.1 TCI-U2	AIRCON [Air Conditioner (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	D 1.1 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	D 1.1 TCI-U2	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2016	D 1.1 TCI-U2	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	RIO(UB)	2016	D 1.1 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2016	D 1.1 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2016	D 1.1 TCI-U2	BCM [Body Control Module (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	D 1.1 TCI-U2	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	D 1.1 TCI-U2	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	D 1.1 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2016	D 1.4 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	RIO(UB)	2016	D 1.4 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2016	D 1.4 TCI-U2	AIRBAG [Airbag Event #2 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2016	D 1.4 TCI-U2	AIRBAG [Airbag Event #1 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2016	D 1.4 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2016	D 1.4 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	D 1.4 TCI-U2	AIRCON [Air Conditioner (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	D 1.4 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2016	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	RIO(UB)	2016	D 1.4 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2016	D 1.4 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2016	D 1.4 TCI-U2	BCM [Body Control Module (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	D 1.4 TCI-U2	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	D 1.4 TCI-U2	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	D 1.4 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2016	G 1.2 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2016	G 1.2 DOHC	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(UB)	2016	G 1.2 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2016	G 1.2 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2016	G 1.2 DOHC	AIRBAG [Airbag Event #2 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2016	G 1.2 DOHC	AIRBAG [Airbag Event #1 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2016	G 1.2 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2016	G 1.2 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	G 1.2 DOHC	AIRCON [Air Conditioner (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	G 1.2 DOHC	EPS [Motor driven Power Steering]	√	√	√	√	√	

Europe/General	RIO(UB)	2016	G 1.2 DOHC	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2016	G 1.2 DOHC	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	RIO(UB)	2016	G 1.2 DOHC	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2016	G 1.2 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2016	G 1.2 DOHC	BCM [Body Control Module (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	G 1.2 DOHC	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	G 1.2 DOHC	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	G 1.2 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2016	G 1.4 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2016	G 1.4 DOHC	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(UB)	2016	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(UB)	2016	G 1.4 DOHC	AIRBAG [Airbag Event #1 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2016	G 1.4 DOHC	AIRBAG [Airbag Event #2 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2016	G 1.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2016	G 1.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2016	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	G 1.4 DOHC	AIRCON [Air Conditioner (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	G 1.4 DOHC	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	G 1.4 DOHC	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	RIO(UB)	2016	G 1.4 DOHC	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2016	G 1.4 DOHC	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2016	G 1.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2016	G 1.4 DOHC	BCM [Body Control Module (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	G 1.4 DOHC	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	G 1.4 DOHC	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2016	G 1.6 GDI	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2016	G 1.6 GDI	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2016	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(UB)	2016	G 1.6 GDI	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2016	G 1.6 GDI	AIRBAG [Airbag Event #1 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2016	G 1.6 GDI	AIRBAG [Airbag Event #2 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2016	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2016	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2016	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	G 1.6 GDI	AIRCON [Air Conditioner (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	G 1.6 GDI	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	G 1.6 GDI	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	RIO(UB)	2016	G 1.6 GDI	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2016	G 1.6 GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2016	G 1.6 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2016	G 1.6 GDI	BCM [Body Control Module (UB PE)]	√	√	√	√	√	

Europe/General	RIO(UB)	2016	G 1.6 GDI	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	G 1.6 GDI	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2016	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2015	D 1.1 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0025, 0047, 0094, 0047
Europe/General	RIO(UB)	2015	D 1.1 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2015	D 1.1 TCI-U2	AIRBAG [Airbag Event #2 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2015	D 1.1 TCI-U2	AIRBAG [Airbag Event #1 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2015	D 1.1 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2015	D 1.1 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	D 1.1 TCI-U2	AIRCON [Air Conditioner (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	D 1.1 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	D 1.1 TCI-U2	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2015	D 1.1 TCI-U2	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	RIO(UB)	2015	D 1.1 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2015	D 1.1 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2015	D 1.1 TCI-U2	BCM [Body Control Module (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	D 1.1 TCI-U2	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	D 1.1 TCI-U2	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	D 1.1 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2015	D 1.4 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	RIO(UB)	2015	D 1.4 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2015	D 1.4 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2015	D 1.4 TCI-U2	AIRBAG [Airbag Event #2 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2015	D 1.4 TCI-U2	AIRBAG [Airbag Event #1 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2015	D 1.4 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2015	D 1.4 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	D 1.4 TCI-U2	AIRCON [Air Conditioner (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	D 1.4 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2015	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	RIO(UB)	2015	D 1.4 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2015	D 1.4 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2015	D 1.4 TCI-U2	BCM [Body Control Module (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	D 1.4 TCI-U2	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	D 1.4 TCI-U2	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	D 1.4 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2015	G 1.2 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2015	G 1.2 DOHC	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(UB)	2015	G 1.2 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2015	G 1.2 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2015	G 1.2 DOHC	AIRBAG [Airbag Event #2 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2015	G 1.2 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2015	G 1.2 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	RIO(UB)	2015	G 1.2 DOHC	AIRCON [Air Conditioner (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	G 1.2 DOHC	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	G 1.2 DOHC	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2015	G 1.2 DOHC	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	RIO(UB)	2015	G 1.2 DOHC	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2015	G 1.2 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2015	G 1.2 DOHC	BCM [Body Control Module (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	G 1.2 DOHC	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	G 1.2 DOHC	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	G 1.2 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2015	G 1.4 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2015	G 1.4 DOHC	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(UB)	2015	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(UB)	2015	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2015	G 1.4 DOHC	AIRBAG [Airbag Event #1 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2015	G 1.4 DOHC	AIRBAG [Airbag Event #2 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2015	G 1.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2015	G 1.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2015	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	G 1.4 DOHC	AIRCON [Air Conditioner (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	G 1.4 DOHC	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	G 1.4 DOHC	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	RIO(UB)	2015	G 1.4 DOHC	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2015	G 1.4 DOHC	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2015	G 1.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2015	G 1.4 DOHC	BCM [Body Control Module (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	G 1.4 DOHC	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	G 1.4 DOHC	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2015	G 1.6 GDI	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2015	G 1.6 GDI	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2015	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(UB)	2015	G 1.6 GDI	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2015	G 1.6 GDI	AIRBAG [Airbag Event #1 (UB PE)]	√	√	√			
Europe/General	RIO(UB)	2015	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2015	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2015	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	G 1.6 GDI	AIRCON [Air Conditioner (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	G 1.6 GDI	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	G 1.6 GDI	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	RIO(UB)	2015	G 1.6 GDI	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2015	G 1.6 GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092

Europe/General	RIO(UB)	2015	G 1.6 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2015	G 1.6 GDI	BCM [Body Control Module (UB PE)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	G 1.6 GDI	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	G 1.6 GDI	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2015	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2014	D 1.1 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	D 1.1 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2014	D 1.1 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2014	D 1.1 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2014	D 1.1 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	D 1.1 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	D 1.1 TCI-U2	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	RIO(UB)	2014	D 1.1 TCI-U2	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2014	D 1.1 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2014	D 1.1 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2014	D 1.1 TCI-U2	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	D 1.1 TCI-U2	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	D 1.1 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2014	D 1.4 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	D 1.4 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2014	D 1.4 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2014	D 1.4 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2014	D 1.4 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	D 1.4 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	RIO(UB)	2014	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2014	D 1.4 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2014	D 1.4 TCI-U2	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	D 1.4 TCI-U2	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	D 1.4 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2014	G 1.2 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2014	G 1.2 DOHC	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(UB)	2014	G 1.2 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2014	G 1.2 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2014	G 1.2 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2014	G 1.2 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	G 1.2 DOHC	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	G 1.2 DOHC	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	RIO(UB)	2014	G 1.2 DOHC	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2014	G 1.2 DOHC	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2014	G 1.2 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2014	G 1.2 DOHC	BCM [Body Control Module (GEN)]	√	√	√	√	√	

Europe/General	RIO(UB)	2014	G 1.2 DOHC	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	G 1.2 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2014	G 1.4 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2014	G 1.4 DOHC	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(UB)	2014	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(UB)	2014	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2014	G 1.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2014	G 1.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2014	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	G 1.4 DOHC	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	G 1.4 DOHC	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	RIO(UB)	2014	G 1.4 DOHC	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2014	G 1.4 DOHC	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2014	G 1.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2014	G 1.4 DOHC	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	G 1.4 DOHC	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2014	G 1.6 GDI	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2014	G 1.6 GDI	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2014	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(UB)	2014	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2014	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2014	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	G 1.6 GDI	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	G 1.6 GDI	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	RIO(UB)	2014	G 1.6 GDI	TPMS [Tire Pressure Monitoring (LOW)]	√	√	√		√	
Europe/General	RIO(UB)	2014	G 1.6 GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2014	G 1.6 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2014	G 1.6 GDI	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	G 1.6 GDI	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2014	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2013	D 1.1 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	D 1.1 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2013	D 1.1 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2013	D 1.1 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2013	D 1.1 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	D 1.1 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	D 1.1 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	RIO(UB)	2013	D 1.1 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2013	D 1.1 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2013	D 1.1 TCI-U2	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	D 1.1 TCI-U2	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	D 1.1 TCI-U2	CODE [Transmitter Code Saving]				√		0022

Europe/General	RIO(UB)	2013	D 1.4 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	D 1.4 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2013	D 1.4 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2013	D 1.4 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2013	D 1.4 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	D 1.4 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	RIO(UB)	2013	D 1.4 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2013	D 1.4 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2013	D 1.4 TCI-U2	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	D 1.4 TCI-U2	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	D 1.4 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2013	G 1.2 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2013	G 1.2 DOHC	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(UB)	2013	G 1.2 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2013	G 1.2 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2013	G 1.2 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	G 1.2 DOHC	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	G 1.2 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	RIO(UB)	2013	G 1.2 DOHC	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2013	G 1.2 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2013	G 1.2 DOHC	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	G 1.2 DOHC	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	G 1.2 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2013	G 1.4 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2013	G 1.4 DOHC	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(UB)	2013	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(UB)	2013	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2013	G 1.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2013	G 1.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2013	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	G 1.4 DOHC	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	G 1.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	RIO(UB)	2013	G 1.4 DOHC	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2013	G 1.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2013	G 1.4 DOHC	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	G 1.4 DOHC	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2013	G 1.6 GDI	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2013	G 1.6 GDI	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2013	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(UB)	2013	G 1.6 GDI	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2013	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2013	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2013	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	RIO(UB)	2013	G 1.6 GDI	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	G 1.6 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	RIO(UB)	2013	G 1.6 GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2013	G 1.6 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2013	G 1.6 GDI	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	G 1.6 GDI	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2013	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2012	D 1.1 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	D 1.1 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2012	D 1.1 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2012	D 1.1 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	D 1.1 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	D 1.1 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	RIO(UB)	2012	D 1.1 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2012	D 1.1 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2012	D 1.1 TCI-U2	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	D 1.1 TCI-U2	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	D 1.1 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2012	D 1.4 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	D 1.4 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2012	D 1.4 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2012	D 1.4 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2012	D 1.4 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	D 1.4 TCI-U2	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	RIO(UB)	2012	D 1.4 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2012	D 1.4 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2012	D 1.4 TCI-U2	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	D 1.4 TCI-U2	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	D 1.4 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2012	G 1.2 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2012	G 1.2 DOHC	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	RIO(UB)	2012	G 1.2 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2012	G 1.2 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2012	G 1.2 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2012	G 1.2 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	G 1.2 DOHC	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	G 1.2 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	RIO(UB)	2012	G 1.2 DOHC	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2012	G 1.2 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2012	G 1.2 DOHC	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	G 1.2 DOHC	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	G 1.2 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2012	G 1.4 DOHC	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2012	G 1.4 DOHC	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0094, 0126

Europe/General	RIO(UB)	2012	G 1.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(UB)	2012	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2012	G 1.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2012	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	G 1.4 DOHC	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	G 1.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	RIO(UB)	2012	G 1.4 DOHC	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2012	G 1.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2012	G 1.4 DOHC	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	G 1.4 DOHC	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	RIO(UB)	2012	G 1.6 GDI	ENGINE [Unleaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2012	G 1.6 GDI	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	RIO(UB)	2012	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	RIO(UB)	2012	G 1.6 GDI	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0078
Europe/General	RIO(UB)	2012	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	RIO(UB)	2012	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	RIO(UB)	2012	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	G 1.6 GDI	EPS [Motor driven Power Steering]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	G 1.6 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	RIO(UB)	2012	G 1.6 GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	RIO(UB)	2012	G 1.6 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	RIO(UB)	2012	G 1.6 GDI	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	G 1.6 GDI	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	RIO(UB)	2012	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SEPHIA II(FB22)	2000	G 1.5 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SEPHIA II(FB22)	2000	G 1.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	SEPHIA II(FB22)	2000	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	SEPHIA II(FB22)	2000	G 1.8 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SEPHIA II(FB22)	2000	G 1.8 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	SEPHIA II(FB22)	1999	G 1.5 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SEPHIA II(FB22)	1999	G 1.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	SEPHIA II(FB22)	1999	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	SEPHIA II(FB22)	1999	G 1.8 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SEPHIA II(FB22)	1999	G 1.8 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	SEPHIA II(FB22)	1998	G 1.5 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SEPHIA II(FB22)	1998	G 1.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	SEPHIA II(FB22)	1998	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	SEPHIA II(FB22)	1998	G 1.8 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SEPHIA II(FB22)	1998	G 1.8 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	SEPHIA(FB12)	1998	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	SEPHIA(FB12)	1997	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	SHUMA/SPECTRA(SD)	2004	G 1.6 DOHC	ENGINE [Unleaded (IMMO+)]		√	√	√		

Europe/General	SHUMA/SPECTRA(SD)	2004	G 1.6 DOHC	ENGINE [Unleaded (IMMO -)]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2004	G 1.6 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2004	G 1.6 DOHC	AIRBAG [Airbag Control (Autonet)]	√	√	√			0090
Europe/General	SHUMA/SPECTRA(SD)	2004	G 1.6 DOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	SHUMA/SPECTRA(SD)	2004	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2004	G 1.8 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2004	G 1.8 DOHC	AIRBAG [Airbag Control (Autonet)]	√	√	√			0090
Europe/General	SHUMA/SPECTRA(SD)	2003	G 1.6 DOHC	ENGINE [Leaded All]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2003	G 1.6 DOHC	ENGINE [Unleaded (IMMO+)]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2003	G 1.6 DOHC	ENGINE [Unleaded (IMMO -)]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2003	G 1.6 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2003	G 1.6 DOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	SHUMA/SPECTRA(SD)	2003	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2003	G 1.8 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2002	G 1.6 DOHC	ENGINE [Leaded All]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2002	G 1.6 DOHC	ENGINE [Unleaded (IMMO+)]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2002	G 1.6 DOHC	ENGINE [Unleaded (IMMO -)]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2002	G 1.6 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2002	G 1.6 DOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	SHUMA/SPECTRA(SD)	2002	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2002	G 1.8 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2001	G 1.5 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2001	G 1.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	SHUMA/SPECTRA(SD)	2001	G 1.6 DOHC	ENGINE [Leaded All]		√	√	√		

Europe/General	SHUMA/SPECTRA(SD)	2001	G 1.6 DOHC	ENGINE [Unleaded (IMMO+)]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2001	G 1.6 DOHC	ENGINE [Unleaded (IMMO -)]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2001	G 1.6 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2001	G 1.6 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	SHUMA/SPECTRA(SD)	2001	G 1.6 DOHC	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	SHUMA/SPECTRA(SD)	2001	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2001	G 1.8 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SHUMA/SPECTRA(SD)	2001	G 1.8 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	SORENTO(BL)	2009	D 2.5 VGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2009	D 2.5 VGT	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2009	D 2.5 VGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	SORENTO(BL)	2009	D 2.5 VGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2009	D 2.5 VGT	4WD [4WD Control]		√	√			
Europe/General	SORENTO(BL)	2009	D 2.5 VGT	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2009	D 2.5 VGT	BCM [Body Control Module]	√			√	√	
Europe/General	SORENTO(BL)	2009	D 2.5 VGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	SORENTO(BL)	2009	D 2.5 VGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(BL)	2009	D 2.5 WGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2009	D 2.5 WGT	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2009	D 2.5 WGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	SORENTO(BL)	2009	D 2.5 WGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2009	D 2.5 WGT	4WD [4WD Control]		√	√			
Europe/General	SORENTO(BL)	2009	D 2.5 WGT	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2009	D 2.5 WGT	IMMO [Immobilizer]				√		
Europe/General	SORENTO(BL)	2009	D 2.5 WGT	BCM [Body Control Module]	√			√	√	
Europe/General	SORENTO(BL)	2009	D 2.5 WGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	SORENTO(BL)	2009	D 2.5 WGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(BL)	2009	G 3.3 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062
Europe/General	SORENTO(BL)	2009	G 3.3 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011
Europe/General	SORENTO(BL)	2009	G 3.3 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011
Europe/General	SORENTO(BL)	2009	G 3.3 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0116
Europe/General	SORENTO(BL)	2009	G 3.3 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2009	G 3.3 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	SORENTO(BL)	2009	G 3.3 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2009	G 3.3 DOHC	4WD [4WD Control]		√	√			
Europe/General	SORENTO(BL)	2009	G 3.3 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2009	G 3.3 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(BL)	2009	G 3.3 DOHC	BCM [Body Control Module]	√			√	√	

Europe/General	SORENTO(BL)	2009	G 3.3 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(BL)	2009	G 3.8 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062
Europe/General	SORENTO(BL)	2009	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011
Europe/General	SORENTO(BL)	2009	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011
Europe/General	SORENTO(BL)	2009	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2009	G 3.8 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2009	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	SORENTO(BL)	2009	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2009	G 3.8 DOHC	4WD [4WD Control]		√	√			
Europe/General	SORENTO(BL)	2009	G 3.8 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2009	G 3.8 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(BL)	2009	G 3.8 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	SORENTO(BL)	2009	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(BL)	2008	D 2.5 VGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2008	D 2.5 VGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	SORENTO(BL)	2008	D 2.5 VGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2008	D 2.5 VGT	4WD [4WD Control]		√	√			
Europe/General	SORENTO(BL)	2008	D 2.5 VGT	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2008	D 2.5 VGT	IMMO [Immobilizer]				√		0075, 0112, 0072, 0075, 0083, 0092, 0119
Europe/General	SORENTO(BL)	2008	D 2.5 VGT	BCM [Body Control Module]	√			√	√	
Europe/General	SORENTO(BL)	2008	D 2.5 VGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	SORENTO(BL)	2008	D 2.5 VGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(BL)	2008	D 2.5 WGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2008	D 2.5 WGT	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2008	D 2.5 WGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	SORENTO(BL)	2008	D 2.5 WGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2008	D 2.5 WGT	4WD [4WD Control]		√	√			
Europe/General	SORENTO(BL)	2008	D 2.5 WGT	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2008	D 2.5 WGT	IMMO [Immobilizer]				√		
Europe/General	SORENTO(BL)	2008	D 2.5 WGT	BCM [Body Control Module]	√			√	√	
Europe/General	SORENTO(BL)	2008	D 2.5 WGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	SORENTO(BL)	2008	D 2.5 WGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(BL)	2008	G 3.3 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062
Europe/General	SORENTO(BL)	2008	G 3.3 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011
Europe/General	SORENTO(BL)	2008	G 3.3 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011
Europe/General	SORENTO(BL)	2008	G 3.3 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2008	G 3.3 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2008	G 3.3 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	SORENTO(BL)	2008	G 3.3 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2008	G 3.3 DOHC	4WD [4WD Control]		√	√			
Europe/General	SORENTO(BL)	2008	G 3.3 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2008	G 3.3 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(BL)	2008	G 3.3 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	SORENTO(BL)	2008	G 3.3 DOHC	CODE [Transmitter Code Saving]				√		0022

Europe/General	SORENTO(BL)	2008	G 3.8 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062
Europe/General	SORENTO(BL)	2008	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011
Europe/General	SORENTO(BL)	2008	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011
Europe/General	SORENTO(BL)	2008	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2008	G 3.8 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2008	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	SORENTO(BL)	2008	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2008	G 3.8 DOHC	4WD [4WD Control]		√	√			
Europe/General	SORENTO(BL)	2008	G 3.8 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(BL)	2008	G 3.8 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	SORENTO(BL)	2008	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(BL)	2007	D 2.5 VGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2007	D 2.5 VGT	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2007	D 2.5 VGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	SORENTO(BL)	2007	D 2.5 VGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2007	D 2.5 VGT	4WD [4WD Control]		√	√			
Europe/General	SORENTO(BL)	2007	D 2.5 VGT	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2007	D 2.5 VGT	IMMO [Immobilizer]				√		0075, 0112, 0072, 0075, 0083, 0092, 0119
Europe/General	SORENTO(BL)	2007	D 2.5 VGT	BCM [Body Control Module]	√			√	√	
Europe/General	SORENTO(BL)	2007	D 2.5 VGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	SORENTO(BL)	2007	D 2.5 VGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(BL)	2007	D 2.5 WGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2007	D 2.5 WGT	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2007	D 2.5 WGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	SORENTO(BL)	2007	D 2.5 WGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2007	D 2.5 WGT	4WD [4WD Control]		√	√			
Europe/General	SORENTO(BL)	2007	D 2.5 WGT	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2007	D 2.5 WGT	IMMO [Immobilizer]				√		
Europe/General	SORENTO(BL)	2007	D 2.5 WGT	BCM [Body Control Module]	√			√	√	
Europe/General	SORENTO(BL)	2007	D 2.5 WGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	SORENTO(BL)	2007	D 2.5 WGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(BL)	2007	G 3.3 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062
Europe/General	SORENTO(BL)	2007	G 3.3 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011
Europe/General	SORENTO(BL)	2007	G 3.3 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011
Europe/General	SORENTO(BL)	2007	G 3.3 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2007	G 3.3 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2007	G 3.3 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	SORENTO(BL)	2007	G 3.3 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2007	G 3.3 DOHC	4WD [4WD Control]		√	√			
Europe/General	SORENTO(BL)	2007	G 3.3 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2007	G 3.3 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(BL)	2007	G 3.3 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	SORENTO(BL)	2007	G 3.3 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(BL)	2007	G 3.8 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062

Europe/General	SORENTO(BL)	2007	G 3.8 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011
Europe/General	SORENTO(BL)	2007	G 3.8 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011
Europe/General	SORENTO(BL)	2007	G 3.8 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2007	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	SORENTO(BL)	2007	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2007	G 3.8 DOHC	4WD [4WD Control]		√	√			
Europe/General	SORENTO(BL)	2007	G 3.8 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2007	G 3.8 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(BL)	2007	G 3.8 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	SORENTO(BL)	2007	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(BL)	2006	D 2.5 VGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2006	D 2.5 VGT	ABSESP [ABS / ESP]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2006	D 2.5 VGT	AIRBAG [Airbag Control]	√	√	√			0090
Europe/General	SORENTO(BL)	2006	D 2.5 VGT	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2006	D 2.5 VGT	4WD [4WD Control]		√	√			
Europe/General	SORENTO(BL)	2006	D 2.5 VGT	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2006	D 2.5 VGT	IMMO [Immobilizer]				√		0075, 0112, 0072, 0075, 0083, 0092, 0119
Europe/General	SORENTO(BL)	2006	D 2.5 VGT	BCM [Body Control Module]	√			√	√	
Europe/General	SORENTO(BL)	2006	D 2.5 VGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	SORENTO(BL)	2006	D 2.5 VGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(BL)	2006	D 2.5 WGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2006	D 2.5 WGT	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2006	D 2.5 WGT	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SORENTO(BL)	2006	D 2.5 WGT	4WD [4WD (TOD - AUTO)]		√	√			
Europe/General	SORENTO(BL)	2006	D 2.5 WGT	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2006	D 2.5 WGT	IMMO [Immobilizer]				√		
Europe/General	SORENTO(BL)	2006	D 2.5 WGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	SORENTO(BL)	2006	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2006	G 2.4 DOHC	ENGINE [Unleaded All]	√	√	√	√	√	0063
Europe/General	SORENTO(BL)	2006	G 2.4 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2006	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SORENTO(BL)	2006	G 2.4 DOHC	4WD [4WD (TOD - AUTO)]		√	√			
Europe/General	SORENTO(BL)	2006	G 2.4 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2006	G 2.4 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	SORENTO(BL)	2006	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0063
Europe/General	SORENTO(BL)	2006	G 3.5 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2006	G 3.5 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SORENTO(BL)	2006	G 3.5 DOHC	4WD [4WD (TOD - AUTO)]		√	√			
Europe/General	SORENTO(BL)	2006	G 3.5 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2006	G 3.5 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	SORENTO(BL)	2005	D 2.5 WGT	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2005	D 2.5 WGT	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SORENTO(BL)	2005	D 2.5 WGT	4WD [4WD (TOD - AUTO)]		√	√			
Europe/General	SORENTO(BL)	2005	D 2.5 WGT	EPS [Electronic Power Steering]	√	√	√	√		

Europe/General	SORENTO(BL)	2005	D 2.5 WGT	IMMO [Immobilizer]				√		
Europe/General	SORENTO(BL)	2005	D 2.5 WGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	SORENTO(BL)	2005	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2005	G 2.4 DOHC	ENGINE [Unleaded All]	√	√	√	√	√	0063
Europe/General	SORENTO(BL)	2005	G 2.4 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2005	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SORENTO(BL)	2005	G 2.4 DOHC	4WD [4WD (TOD - AUTO)]		√	√			
Europe/General	SORENTO(BL)	2005	G 2.4 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2005	G 2.4 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	SORENTO(BL)	2005	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0063
Europe/General	SORENTO(BL)	2005	G 3.5 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2005	G 3.5 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SORENTO(BL)	2005	G 3.5 DOHC	4WD [4WD (TOD - AUTO)]		√	√			
Europe/General	SORENTO(BL)	2005	G 3.5 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2005	G 3.5 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	SORENTO(BL)	2004	D 2.5 WGT	ENGINE [Engine (WGT)]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2004	D 2.5 WGT	ENGINE [Engine (WGT F / L)]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2004	D 2.5 WGT	AT [4 - Speed]		√	√	√	√	
Europe/General	SORENTO(BL)	2004	D 2.5 WGT	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2004	D 2.5 WGT	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SORENTO(BL)	2004	D 2.5 WGT	4WD [4WD (TOD - AUTO)]		√	√			
Europe/General	SORENTO(BL)	2004	D 2.5 WGT	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2004	D 2.5 WGT	IMMO [Immobilizer]				√		
Europe/General	SORENTO(BL)	2004	D 2.5 WGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	SORENTO(BL)	2004	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2004	G 2.4 DOHC	ENGINE [Unleaded All]	√	√	√	√	√	0063
Europe/General	SORENTO(BL)	2004	G 2.4 DOHC	AT [4 - Speed]		√	√	√	√	
Europe/General	SORENTO(BL)	2004	G 2.4 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2004	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SORENTO(BL)	2004	G 2.4 DOHC	4WD [4WD (TOD - AUTO)]		√	√			
Europe/General	SORENTO(BL)	2004	G 2.4 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2004	G 2.4 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	SORENTO(BL)	2004	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0063
Europe/General	SORENTO(BL)	2004	G 3.5 DOHC	AT [4 - Speed]		√	√	√	√	
Europe/General	SORENTO(BL)	2004	G 3.5 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2004	G 3.5 DOHC	4WD [4WD (TOD - AUTO)]		√	√			
Europe/General	SORENTO(BL)	2004	G 3.5 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2004	G 3.5 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	SORENTO(BL)	2003	D 2.5 WGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2003	D 2.5 WGT	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	SORENTO(BL)	2003	D 2.5 WGT	ABSESP [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2003	D 2.5 WGT	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SORENTO(BL)	2003	D 2.5 WGT	4WD [4WD (TOD - AUTO)]		√	√			
Europe/General	SORENTO(BL)	2003	D 2.5 WGT	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2003	D 2.5 WGT	IMMO [Immobilizer]				√		

Europe/General	SORENTO(BL)	2003	D 2.5 WGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	SORENTO(BL)	2003	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2003	G 2.4 DOHC	ENGINE [Unleaded All]	√	√	√	√	√	0063
Europe/General	SORENTO(BL)	2003	G 2.4 DOHC	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	SORENTO(BL)	2003	G 2.4 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2003	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SORENTO(BL)	2003	G 2.4 DOHC	4WD [4WD (TOD - AUTO)]		√	√			
Europe/General	SORENTO(BL)	2003	G 2.4 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2003	G 2.4 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	SORENTO(BL)	2003	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0063
Europe/General	SORENTO(BL)	2003	G 3.5 DOHC	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	SORENTO(BL)	2003	G 3.5 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2003	G 3.5 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SORENTO(BL)	2003	G 3.5 DOHC	4WD [4WD (TOD - AUTO)]		√	√			
Europe/General	SORENTO(BL)	2003	G 3.5 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2003	G 3.5 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	SORENTO(BL)	2002	D 2.5 WGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SORENTO(BL)	2002	D 2.5 WGT	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	SORENTO(BL)	2002	D 2.5 WGT	ABSESP [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2002	D 2.5 WGT	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SORENTO(BL)	2002	D 2.5 WGT	4WD [4WD (TOD - AUTO)]		√	√			
Europe/General	SORENTO(BL)	2002	D 2.5 WGT	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(BL)	2002	D 2.5 WGT	IMMO [Immobilizer]				√		
Europe/General	SORENTO(BL)	2002	D 2.5 WGT	BHEATER [Fuel Fired Heater]		√	√	√	√	
Europe/General	SORENTO(BL)	2002	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0063
Europe/General	SORENTO(BL)	2002	G 3.5 DOHC	AT [Automatic Transaxle]		√	√	√	√	
Europe/General	SORENTO(BL)	2002	G 3.5 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SORENTO(BL)	2002	G 3.5 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SORENTO(BL)	2002	G 3.5 DOHC	4WD [4WD (TOD - AUTO)]		√	√			
Europe/General	SORENTO(BL)	2002	G 3.5 DOHC	IMMO [Immobilizer]		√	√	√		0064, 0079, 0080, 0083
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	ENGINE [Engine Control]	√	√	√	√		0029, 0048, 0060, 0094, 0126
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	AEB [Autonomous Emergency Braking System]	√	√	√	√		
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring (HIGH)]	√	√	√		√	
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	

Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	AMP [Amplifier]						0003
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	SWRC [Steering Wheel Remote Control]	√	√	√			
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	CGW [Central Gateway]	√	√	√			0041
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	PTG [Power Tailgate]	√	√	√	√		0093
Europe/General	SORENTO(UM)	2017	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	ENGINE [Engine Control]	√	√	√	√		0126, 0029, 0060, 0094, 0048
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	AEB [Autonomous Emergency Braking System]	√	√	√	√		
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	AMP [Amplifier]						0003
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	ADM [Assist Door Module]	√	√	√	√	√	

Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	SWRC [Steering Wheel Remote Control]	√	√	√			
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	CGW [Central Gateway]	√	√	√			0041
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	PTG [Power Tailgate]	√	√	√	√		0093
Europe/General	SORENTO(UM)	2017	D 2.2 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0100, 0126
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	AEB [Autonomous Emergency Braking System]	√	√	√	√		
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	AMP [Amplifier]						0003

Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA	SWRC [Steering Wheel Remote Control]	√	√	√			
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	CGW [Central Gateway]	√	√	√			0041
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	PTG [Power Tailgate]	√	√	√	√		0093
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	ECALL [e - Call]	√	√	√			
Europe/General	SORENTO(UM)	2017	G 2.4 GDI THETA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	AEB [Autonomous Emergency Braking System]	√	√	√	√		
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	MFC [Multi Function Camera]	√	√	√	√		

Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	AMP [Amplifier]						0003
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA	SWRC [Steering Wheel Remote Control]	√	√	√			
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	PTG [Power Tailgate]	√	√	√	√		0093
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	ECALL [e - Call]	√	√	√			
Europe/General	SORENTO(UM)	2017	G 2.4 MPI THETA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	ENGINE [Engine Control]		√	√			0011, 0043, 0094, 0126
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	AEB [Autonomous Emergency Braking System]	√	√	√	√		
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	AMP [Amplifier]						0003
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	SWRC [Steering Wheel Remote Control]	√	√	√			
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	CGW [Central Gateway]	√	√	√			0041
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	PTG [Power Tailgate]	√	√	√	√		0093
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	ECALL [e - Call]	√	√	√			
Europe/General	SORENTO(UM)	2017	G 3.3 MPI LAMBDA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	ENGINE [Engine Control]	√	√	√	√		0029, 0048, 0060, 0094, 0126

Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	AMP [Amplifier]						0003
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	SWRC [Steering Wheel Remote Control]	√	√	√			
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	CGW [Central Gateway]	√	√	√			0041
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	PTG [Power Tailgate]	√	√	√	√		0093
Europe/General	SORENTO(UM)	2016	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	ENGINE [Engine Control]	√	√	√	√		0029, 0126, 0029, 0060, 0126, 0094, 0048
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	

Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	AMP [Amplifier]						0003
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	SWRC [Steering Wheel Remote Control]	√	√	√			
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	CGW [Central Gateway]	√	√	√			0041
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	PTG [Power Tailgate]	√	√	√	√		0093
Europe/General	SORENTO(UM)	2016	D 2.2 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0100, 0126
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015

Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	AMP [Amplifier]						0003
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA	SWRC [Steering Wheel Remote Control]	√	√	√			
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	PTG [Power Tailgate]	√	√	√	√		0093
Europe/General	SORENTO(UM)	2016	G 2.4 GDI THETA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	SVMS [Surround View Monitor System]	√	√	√	√	√	

Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	AMP [Amplifier]						0003
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA	SWRC [Steering Wheel Remote Control]	√	√	√			
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	CGW [Central Gateway]	√	√	√			0041
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	PTG [Power Tailgate]	√	√	√	√		0093
Europe/General	SORENTO(UM)	2016	G 2.4 MPI THETA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	ENGINE [Engine Control]		√	√			0011, 0043, 0094, 0126
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	AMP [Amplifier]						0003
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	SORENTO(UM)	2016	G 3.3 MPI	SWRC [Steering Wheel Remote Control]	√	√	√			
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	CGW [Central Gateway]	√	√	√			0041
Europe/General	SORENTO(UM)	2016	G 3.3 MPI LAMBDA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	ENGINE [Engine Control]	√	√	√	√		0029, 0048, 0060, 0094, 0126
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			

Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	AMP [Amplifier]						0003
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	SWRC [Steering Wheel Remote Control]	√	√	√			
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	CGW [Central Gateway]	√	√	√			0041
Europe/General	SORENTO(UM)	2015	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	ENGINE [Engine Control]	√	√	√	√		0029, 0126, 0029, 0060, 0126, 0094, 0048
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092

Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	AMP [Amplifier]						0003
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	SWRC [Steering Wheel Remote Control]	√	√	√			
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	CGW [Central Gateway]	√	√	√			0041
Europe/General	SORENTO(UM)	2015	D 2.2 TCI-R	PTG [Power Tailgate]	√	√	√	√		0093
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0100, 0126
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	AHS [Active Hood System]	√	√	√		√	

Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	AMP [Amplifier]						0003
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA	SWRC [Steering Wheel Remote Control]	√	√	√			
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	CGW [Central Gateway]	√	√	√			0041
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	PTG [Power Tailgate]	√	√	√	√		0093
Europe/General	SORENTO(UM)	2015	G 2.4 GDI THETA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	BSD [Blind Spot Detection]	√	√	√	√	√	

Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	AMP [Amplifier]						0003
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA	SWRC [Steering Wheel Remote Control]	√	√	√			
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	CGW [Central Gateway]	√	√	√			0041
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	PTG [Power Tailgate]	√	√	√	√		0093
Europe/General	SORENTO(UM)	2015	G 2.4 MPI THETA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	ENGINE [Engine Control]		√	√			0011, 0043, 0094, 0126
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	ABSESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	EPS [Motor Driven Power Steering]	√	√	√	√		

Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	AMP [Amplifier]						0003
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	SORENTO(UM)	2015	G 3.3 MPI	SWRC [Steering Wheel Remote Control]	√	√	√			
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	CGW [Central Gateway]	√	√	√			0041
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	PTG [Power Tailgate]	√	√	√	√		0093
Europe/General	SORENTO(UM)	2015	G 3.3 MPI LAMBDA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0100, 0126
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	AEB [Autonomous Emergency Braking System]	√	√	√	√		

Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	ABSESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	ODS [Occupant Classification System]	√	√	√	√		
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0045, 0102
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	AMP [Amplifier]						0003

Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	SWRC [Steering Wheel Remote Control]	√	√	√			
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	CGW [Central Gateway]	√	√	√			0041
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	PTG [Power Tailgate]	√	√	√	√		0093
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	TMU [Telematics Unit]	√	√	√			
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 2.4 GDI THETA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	ENGINE [Engine Control]		√	√			0011, 0043, 0094, 0126
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	ABSESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	AEB [Autonomous Emergency Braking System]	√	√	√	√		
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	ODS [Occupant Classification System]	√	√	√	√		

Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	MFC [Multi Function Camera]	√	√	√	√		
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0045, 0102
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	AMP [Amplifier]						0003
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	ADM [Assist Door Module]	√	√	√	√	√	

Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	CGW [Central Gateway]	√	√	√			0041
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	PTG [Power Tailgate]	√	√	√	√		0093
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	TMU [Telematics Unit]	√	√	√			
Europe/General	SORENTO(UMA)-For Mexico only	2017	G 3.3 GDI LAMBDA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0100, 0126
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	AT [Automatic Transaxle]	√	√	√	√		0099
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	ABSESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	ODS [Occupant Classification System]	√	√	√	√		
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	4WD [4WD Control]	√	√	√	√	√	0019, 0020

Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0045, 0102
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	AMP [Amplifier]						0003
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	SWRC [Steering Wheel Remote Control]	√	√	√			
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	PSM [Power Seat Module]	√	√	√	√	√	0106
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	CGW [Central Gateway]	√	√	√			0041

Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	PTG [Power Tailgate]	√	√	√	√		0093
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	TMU [Telematics Unit]	√	√	√			
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 2.4 GDI THETA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	ENGINE [Engine Control]		√	√			0011, 0043, 0094, 0126
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	ABSESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	EPB [Electric Parking Brake]	√	√	√	√	√	0017
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	ODS [Occupant Classification System]	√	√	√	√		
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	SVMS [Surround View Monitor System]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015

Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0045, 0102
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	AMP [Amplifier]						0003
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	SWRC [Steering Wheel Remote Control]	√	√	√			
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	ADM [Assist Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	DDM [Driver Door Module]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	CGW [Central Gateway]	√	√	√			0041
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	PTG [Power Tailgate]	√	√	√	√		0093
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	TMU [Telematics Unit]	√	√	√			
Europe/General	SORENTO(UMA)-For Mexico only	2016	G 3.3 GDI LAMBDA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0073
Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	EPS [Motor driven Power Steering]	√	√	√	√		

Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	SERVICE [Service Reminder]	√					
Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2015	D 2.2 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2015	D 2.2 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SORENTO(XM)	2015	D 2.2 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2015	D 2.2 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2015	D 2.2 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	D 2.2 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(XM)	2015	D 2.2 TCI-R	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2015	D 2.2 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2015	D 2.2 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	D 2.2 TCI-R	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SORENTO(XM)	2015	D 2.2 TCI-R	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	D 2.2 TCI-R	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(XM)	2015	D 2.2 TCI-R	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	D 2.2 TCI-R	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(XM)	2015	D 2.2 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2015	D 2.2 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(XM)	2015	D 2.2 TCI-R	SERVICE [Service Reminder]	√					
Europe/General	SORENTO(XM)	2015	D 2.2 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	D 2.2 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2015	G 2.4 GDI	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SORENTO(XM)	2015	G 2.4 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2015	G 2.4 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SORENTO(XM)	2015	G 2.4 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2015	G 2.4 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2015	G 2.4 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	G 2.4 GDI	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(XM)	2015	G 2.4 GDI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2015	G 2.4 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2015	G 2.4 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	G 2.4 GDI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SORENTO(XM)	2015	G 2.4 GDI	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	G 2.4 GDI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(XM)	2015	G 2.4 GDI	AHS [Active Hood System]	√	√	√		√	

Europe/General	SORENTO(XM)	2015	G 2.4 GDI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2015	G 2.4 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(XM)	2015	G 2.4 GDI	SERVICE [Service Reminder]	√					
Europe/General	SORENTO(XM)	2015	G 2.4 GDI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	G 2.4 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	SERVICE [Service Reminder]	√					
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	G 2.4 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2015	G 3.5 MPI	ENGINE [Engine Control]		√	√			0011, 0043, 0094, 0126
Europe/General	SORENTO(XM)	2015	G 3.5 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2015	G 3.5 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SORENTO(XM)	2015	G 3.5 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2015	G 3.5 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2015	G 3.5 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	G 3.5 MPI	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(XM)	2015	G 3.5 MPI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2015	G 3.5 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2015	G 3.5 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SORENTO(XM)	2015	G 3.5 MPI	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	G 3.5 MPI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(XM)	2015	G 3.5 MPI	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	G 3.5 MPI	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(XM)	2015	G 3.5 MPI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2015	G 3.5 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(XM)	2015	G 3.5 MPI	SERVICE [Service Reminder]	√					
Europe/General	SORENTO(XM)	2015	G 3.5 MPI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2015	G 3.5 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0073

Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	SERVICE [Service Reminder]	√					
Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2014	D 2.2 TCI-R	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048
Europe/General	SORENTO(XM)	2014	D 2.2 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2014	D 2.2 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2014	D 2.2 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2014	D 2.2 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	D 2.2 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(XM)	2014	D 2.2 TCI-R	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2014	D 2.2 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2014	D 2.2 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	D 2.2 TCI-R	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SORENTO(XM)	2014	D 2.2 TCI-R	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	D 2.2 TCI-R	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(XM)	2014	D 2.2 TCI-R	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	D 2.2 TCI-R	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(XM)	2014	D 2.2 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2014	D 2.2 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(XM)	2014	D 2.2 TCI-R	SERVICE [Service Reminder]	√					
Europe/General	SORENTO(XM)	2014	D 2.2 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	D 2.2 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2014	G 2.4 GDI	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SORENTO(XM)	2014	G 2.4 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2014	G 2.4 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SORENTO(XM)	2014	G 2.4 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2014	G 2.4 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2014	G 2.4 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	G 2.4 GDI	4WD [4WD Control]	√	√	√	√	√	0019, 0020

Europe/General	SORENTO(XM)	2014	G 2.4 GDI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2014	G 2.4 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2014	G 2.4 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	G 2.4 GDI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SORENTO(XM)	2014	G 2.4 GDI	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	G 2.4 GDI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(XM)	2014	G 2.4 GDI	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	G 2.4 GDI	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(XM)	2014	G 2.4 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(XM)	2014	G 2.4 GDI	SERVICE [Service Reminder]	√					
Europe/General	SORENTO(XM)	2014	G 2.4 GDI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	G 2.4 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	SERVICE [Service Reminder]	√					
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	G 2.4 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2014	G 3.5 MPI	ENGINE [Engine Control]		√	√			0011, 0043, 0094, 0126
Europe/General	SORENTO(XM)	2014	G 3.5 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2014	G 3.5 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SORENTO(XM)	2014	G 3.5 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2014	G 3.5 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2014	G 3.5 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	G 3.5 MPI	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(XM)	2014	G 3.5 MPI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2014	G 3.5 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2014	G 3.5 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	G 3.5 MPI	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	G 3.5 MPI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(XM)	2014	G 3.5 MPI	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	

Europe/General	SORENTO(XM)	2014	G 3.5 MPI	AHS [Active Hood System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	G 3.5 MPI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2014	G 3.5 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(XM)	2014	G 3.5 MPI	SERVICE [Service Reminder]	√					
Europe/General	SORENTO(XM)	2014	G 3.5 MPI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2014	G 3.5 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0073
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	SERVICE [Service Reminder]	√					
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2013	D 2.2 TCI-R	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048
Europe/General	SORENTO(XM)	2013	D 2.2 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2013	D 2.2 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SORENTO(XM)	2013	D 2.2 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2013	D 2.2 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	D 2.2 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(XM)	2013	D 2.2 TCI-R	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2013	D 2.2 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2013	D 2.2 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	D 2.2 TCI-R	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SORENTO(XM)	2013	D 2.2 TCI-R	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	D 2.2 TCI-R	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(XM)	2013	D 2.2 TCI-R	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	D 2.2 TCI-R	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(XM)	2013	D 2.2 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2013	D 2.2 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(XM)	2013	D 2.2 TCI-R	SERVICE [Service Reminder]	√					
Europe/General	SORENTO(XM)	2013	D 2.2 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	D 2.2 TCI-R	CODE [Transmitter Code Saving]				√		0022

Europe/General	SORENTO(XM)	2013	G 2.4 GDI	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SORENTO(XM)	2013	G 2.4 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2013	G 2.4 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SORENTO(XM)	2013	G 2.4 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2013	G 2.4 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2013	G 2.4 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	G 2.4 GDI	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(XM)	2013	G 2.4 GDI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2013	G 2.4 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2013	G 2.4 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	G 2.4 GDI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SORENTO(XM)	2013	G 2.4 GDI	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	G 2.4 GDI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(XM)	2013	G 2.4 GDI	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	G 2.4 GDI	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(XM)	2013	G 2.4 GDI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2013	G 2.4 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(XM)	2013	G 2.4 GDI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	G 2.4 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	SERVICE [Service Reminder]	√					
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	G 2.4 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2013	G 3.5 MPI	ENGINE [Engine Control]		√	√			0011, 0043, 0094, 0126
Europe/General	SORENTO(XM)	2013	G 3.5 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2013	G 3.5 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SORENTO(XM)	2013	G 3.5 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2013	G 3.5 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2013	G 3.5 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	SORENTO(XM)	2013	G 3.5 MPI	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SORENTO(XM)	2013	G 3.5 MPI	EPS [Motor driven Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2013	G 3.5 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2013	G 3.5 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	G 3.5 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SORENTO(XM)	2013	G 3.5 MPI	BSD [Blind Spot Detection]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	G 3.5 MPI	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	G 3.5 MPI	AHS [Active Hood System]	√	√	√		√	
Europe/General	SORENTO(XM)	2013	G 3.5 MPI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2013	G 3.5 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SORENTO(XM)	2013	G 3.5 MPI	SERVICE [Service Reminder]	√					
Europe/General	SORENTO(XM)	2013	G 3.5 MPI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2013	G 3.5 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2012	D 2.0 TCI-R	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	0048, 0073
Europe/General	SORENTO(XM)	2012	D 2.0 TCI-R	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	0048, 0073
Europe/General	SORENTO(XM)	2012	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2012	D 2.0 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(XM)	2012	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2012	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2012	D 2.0 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√		0007, 0120
Europe/General	SORENTO(XM)	2012	D 2.0 TCI-R	EPS [Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2012	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2012	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	D 2.0 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2012	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2012	D 2.0 TCI-R	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2012	D 2.0 TCI-R	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SORENTO(XM)	2012	D 2.0 TCI-R	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2012	D 2.2 TCI-R	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	0048
Europe/General	SORENTO(XM)	2012	D 2.2 TCI-R	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	0048
Europe/General	SORENTO(XM)	2012	D 2.2 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2012	D 2.2 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(XM)	2012	D 2.2 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2012	D 2.2 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2012	D 2.2 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	D 2.2 TCI-R	4WD [4WD Control]	√	√	√	√		0007, 0120
Europe/General	SORENTO(XM)	2012	D 2.2 TCI-R	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2012	D 2.2 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2012	D 2.2 TCI-R	AHLS [AHLS]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	D 2.2 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2012	D 2.2 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2012	D 2.2 TCI-R	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2012	D 2.2 TCI-R	BCM [Instrument Panel Module]	√	√	√	√	√	

Europe/General	SORENTO(XM)	2012	D 2.2 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0011, 0126, 0094, 0098
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0011, 0126, 0094, 0098
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0011, 0126, 0094, 0098
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	4WD [4WD Control]	√	√	√	√		0007, 0120
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	TPMS [Tire Pressure Monitoring (North America)]	√	√	√		√	
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	PDM [Power Distribution Module (North America)]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	SMKCODE [Smart Key Code Saving (North America)]				√		
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	SMK [Smart Key Unit (North America)]	√	√	√	√	√	0045, 0088, 0102
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	BCM [Instrument Panel Module (North America)]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2012	G 2.4 GDI	ENGINE [Engine Control]	√	√	√	√		0126, 0011, 0094, 0098
Europe/General	SORENTO(XM)	2012	G 2.4 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2012	G 2.4 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(XM)	2012	G 2.4 GDI	ODS [Weight Classification]	√	√	√			
Europe/General	SORENTO(XM)	2012	G 2.4 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2012	G 2.4 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2012	G 2.4 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 2.4 GDI	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2012	G 2.4 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2012	G 2.4 GDI	TPMS [Tire Pressure Monitoring (North America)]	√	√	√		√	
Europe/General	SORENTO(XM)	2012	G 2.4 GDI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2012	G 2.4 GDI	PDM [Power Distribution Module (North America)]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 2.4 GDI	SMKCODE [Smart Key Code Saving]				√		

Europe/General	SORENTO(XM)	2012	G 2.4 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2012	G 2.4 GDI	SMKCODE [Smart Key Code Saving (North America)]				√		
Europe/General	SORENTO(XM)	2012	G 2.4 GDI	SMK [Smart Key Unit (North America)]	√	√	√	√	√	0045, 0088, 0102
Europe/General	SORENTO(XM)	2012	G 2.4 GDI	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SORENTO(XM)	2012	G 2.4 GDI	BCM [Instrument Panel Module (North America)]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 2.4 GDI	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 2.4 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0094, 0098
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0094, 0098
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0094, 0098
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	4WD [4WD Control]	√	√	√	√		0007, 0120
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	TPMS [Tire Pressure Monitoring (North America)]	√	√	√		√	
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	PDM [Power Distribution Module (North America)]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	SMKCODE [Smart Key Code Saving (North America)]				√		
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	BCM [Instrument Panel Module (North America)]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 2.4 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	4WD [4WD Control]	√	√	√	√		0007, 0120
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	EPS [Electronic Power Steering]	√	√	√	√		

Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	TPMS [Tire Pressure Monitoring (North America)]	√	√	√		√	
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	PDM [Power Distribution Module (North America)]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	SMKCODE [Smart Key Code Saving (North America)]				√		
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	SMK [Smart Key Unit (North America)]	√	√	√	√	√	0045, 0088, 0102
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	BCM [Instrument Panel Module (North America)]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	4WD [4WD Control]	√	√	√	√		0007, 0120
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	TPMS [Tire Pressure Monitoring (North America)]	√	√	√		√	
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	PDM [Power Distribution Module (North America)]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	SMKCODE [Smart Key Code Saving (North America)]				√		
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	SMK [Smart Key Unit (North America)]	√	√	√	√	√	0045, 0088, 0102
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	BCM [Instrument Panel Module (North America)]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2012	G 3.5 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2011	D 2.0 TCI-R	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	0048, 0073
Europe/General	SORENTO(XM)	2011	D 2.0 TCI-R	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	0048, 0073

Europe/General	SORENTO(XM)	2011	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2011	D 2.0 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(XM)	2011	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2011	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2011	D 2.0 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√		0007, 0120
Europe/General	SORENTO(XM)	2011	D 2.0 TCI-R	EPS [Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2011	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2011	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	D 2.0 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2011	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2011	D 2.0 TCI-R	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2011	D 2.0 TCI-R	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SORENTO(XM)	2011	D 2.0 TCI-R	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2011	D 2.2 TCI-R	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	0048
Europe/General	SORENTO(XM)	2011	D 2.2 TCI-R	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	0048
Europe/General	SORENTO(XM)	2011	D 2.2 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2011	D 2.2 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2011	D 2.2 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2011	D 2.2 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	D 2.2 TCI-R	4WD [4WD Control]	√	√	√	√		0007, 0120
Europe/General	SORENTO(XM)	2011	D 2.2 TCI-R	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2011	D 2.2 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2011	D 2.2 TCI-R	AHLS [AHLS]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	D 2.2 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2011	D 2.2 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2011	D 2.2 TCI-R	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2011	D 2.2 TCI-R	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SORENTO(XM)	2011	D 2.2 TCI-R	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	D 2.2 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2011	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	G 2.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	G 2.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2011	G 2.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(XM)	2011	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2011	G 2.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2011	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	G 2.4 DOHC	4WD [4WD Control]	√	√	√	√		0007, 0120
Europe/General	SORENTO(XM)	2011	G 2.4 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2011	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2011	G 2.4 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2011	G 2.4 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035

Europe/General	SORENTO(XM)	2011	G 2.4 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2011	G 2.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2011	G 2.4 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2011	G 2.4 MPI	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	G 2.4 MPI	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	G 2.4 MPI	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	G 2.4 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2011	G 2.4 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(XM)	2011	G 2.4 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2011	G 2.4 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2011	G 2.4 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	G 2.4 MPI	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2011	G 2.4 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2011	G 2.4 MPI	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	G 2.4 MPI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2011	G 2.4 MPI	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SORENTO(XM)	2011	G 2.4 MPI	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2011	G 2.4 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2011	G 2.4 MPI	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	G 2.4 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2011	G 3.5 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	SORENTO(XM)	2011	G 3.5 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	SORENTO(XM)	2011	G 3.5 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	SORENTO(XM)	2011	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2011	G 3.5 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(XM)	2011	G 3.5 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2011	G 3.5 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2011	G 3.5 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	G 3.5 DOHC	4WD [4WD Control]	√	√	√	√		0007, 0120
Europe/General	SORENTO(XM)	2011	G 3.5 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2011	G 3.5 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2011	G 3.5 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	G 3.5 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2011	G 3.5 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SORENTO(XM)	2011	G 3.5 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2011	G 3.5 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2011	G 3.5 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2011	G 3.5 MPI	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	SORENTO(XM)	2011	G 3.5 MPI	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	SORENTO(XM)	2011	G 3.5 MPI	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	SORENTO(XM)	2011	G 3.5 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2011	G 3.5 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(XM)	2011	G 3.5 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			

Europe/General	SORENTO(XM)	2011	G 3.5 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2011	G 3.5 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	G 3.5 MPI	4WD [4WD Control]	√	√	√	√		0007, 0120
Europe/General	SORENTO(XM)	2011	G 3.5 MPI	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2011	G 3.5 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2011	G 3.5 MPI	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	G 3.5 MPI	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SORENTO(XM)	2011	G 3.5 MPI	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2011	G 3.5 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2011	G 3.5 MPI	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2011	G 3.5 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2010	D 2.0 TCI-R	ENGINE [Low Power (CPF -)]	√	√	√	√	√	0048, 0073
Europe/General	SORENTO(XM)	2010	D 2.0 TCI-R	ENGINE [Low Power (CPF+)]	√	√	√	√	√	0048, 0073
Europe/General	SORENTO(XM)	2010	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2010	D 2.0 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(XM)	2010	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2010	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2010	D 2.0 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√		0007, 0120
Europe/General	SORENTO(XM)	2010	D 2.0 TCI-R	EPS [Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2010	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2010	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	D 2.0 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2010	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2010	D 2.0 TCI-R	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2010	D 2.0 TCI-R	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SORENTO(XM)	2010	D 2.0 TCI-R	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2010	D 2.2 TCI-R	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	0048
Europe/General	SORENTO(XM)	2010	D 2.2 TCI-R	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	0048
Europe/General	SORENTO(XM)	2010	D 2.2 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2010	D 2.2 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(XM)	2010	D 2.2 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2010	D 2.2 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2010	D 2.2 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	D 2.2 TCI-R	4WD [4WD Control]	√	√	√	√		0007, 0120
Europe/General	SORENTO(XM)	2010	D 2.2 TCI-R	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2010	D 2.2 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2010	D 2.2 TCI-R	AHLS [AHLS]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	D 2.2 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2010	D 2.2 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2010	D 2.2 TCI-R	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2010	D 2.2 TCI-R	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SORENTO(XM)	2010	D 2.2 TCI-R	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	D 2.2 TCI-R	CODE [Transmitter Code Saving]				√		0022

Europe/General	SORENTO(XM)	2010	G 2.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	G 2.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2010	G 2.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(XM)	2010	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2010	G 2.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2010	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	G 2.4 DOHC	4WD [4WD Control]	√	√	√	√		0007, 0120
Europe/General	SORENTO(XM)	2010	G 2.4 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2010	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2010	G 2.4 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2010	G 2.4 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SORENTO(XM)	2010	G 2.4 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2010	G 2.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2010	G 2.4 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2010	G 2.4 MPI	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	G 2.4 MPI	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	G 2.4 MPI	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	G 2.4 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2010	G 2.4 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(XM)	2010	G 2.4 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2010	G 2.4 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2010	G 2.4 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	G 2.4 MPI	4WD [4WD Control]	√	√	√	√		0007, 0120
Europe/General	SORENTO(XM)	2010	G 2.4 MPI	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2010	G 2.4 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2010	G 2.4 MPI	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	G 2.4 MPI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2010	G 2.4 MPI	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SORENTO(XM)	2010	G 2.4 MPI	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2010	G 2.4 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2010	G 2.4 MPI	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	G 2.4 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2010	G 3.5 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	SORENTO(XM)	2010	G 3.5 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	SORENTO(XM)	2010	G 3.5 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	SORENTO(XM)	2010	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2010	G 3.5 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2010	G 3.5 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2010	G 3.5 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	G 3.5 DOHC	4WD [4WD Control]	√	√	√	√		0007, 0120
Europe/General	SORENTO(XM)	2010	G 3.5 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2010	G 3.5 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	

Europe/General	SORENTO(XM)	2010	G 3.5 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	G 3.5 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2010	G 3.5 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SORENTO(XM)	2010	G 3.5 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2010	G 3.5 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2010	G 3.5 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2010	G 3.5 MPI	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0094, 0126
Europe/General	SORENTO(XM)	2010	G 3.5 MPI	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0094, 0126
Europe/General	SORENTO(XM)	2010	G 3.5 MPI	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0094, 0126
Europe/General	SORENTO(XM)	2010	G 3.5 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2010	G 3.5 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SORENTO(XM)	2010	G 3.5 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2010	G 3.5 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2010	G 3.5 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	G 3.5 MPI	4WD [4WD Control]	√	√	√	√		0007, 0120
Europe/General	SORENTO(XM)	2010	G 3.5 MPI	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2010	G 3.5 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2010	G 3.5 MPI	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	G 3.5 MPI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2010	G 3.5 MPI	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SORENTO(XM)	2010	G 3.5 MPI	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2010	G 3.5 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2010	G 3.5 MPI	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2010	G 3.5 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2009	D 2.2 TCI-R	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	0048
Europe/General	SORENTO(XM)	2009	D 2.2 TCI-R	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	0048
Europe/General	SORENTO(XM)	2009	D 2.2 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SORENTO(XM)	2009	D 2.2 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2009	D 2.2 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2009	D 2.2 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2009	D 2.2 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2009	D 2.2 TCI-R	4WD [4WD Control]	√	√	√	√		0007, 0120
Europe/General	SORENTO(XM)	2009	D 2.2 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2009	D 2.2 TCI-R	AHLS [AHLS]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2009	D 2.2 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2009	D 2.2 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2009	D 2.2 TCI-R	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2009	D 2.2 TCI-R	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SORENTO(XM)	2009	D 2.2 TCI-R	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2009	D 2.2 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SORENTO(XM)	2009	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2009	G 2.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2009	G 2.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2009	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099

Europe/General	SORENTO(XM)	2009	G 2.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2009	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SORENTO(XM)	2009	G 2.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SORENTO(XM)	2009	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2009	G 2.4 DOHC	4WD [4WD Control]	√	√	√	√		0007, 0120
Europe/General	SORENTO(XM)	2009	G 2.4 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
Europe/General	SORENTO(XM)	2009	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SORENTO(XM)	2009	G 2.4 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2009	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SORENTO(XM)	2009	G 2.4 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SORENTO(XM)	2009	G 2.4 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SORENTO(XM)	2009	G 2.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SORENTO(XM)	2009	G 2.4 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SORENTO(XM)	2009	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL EV(PS EV)	2017	80KW	VMCU [Vehicle Motor Control System]	√	√	√	√	√	0037, 0094
Europe/General	SOUL EV(PS EV)	2017	80KW	EPB [Electric Parking Brake]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2017	80KW	ABSVC [Electronic Stability Control]	√	√	√	√	√	0009, 0046, 0059, 0068, 0078
Europe/General	SOUL EV(PS EV)	2017	80KW	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL EV(PS EV)	2017	80KW	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL EV(PS EV)	2017	80KW	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2017	80KW	BMS [EV Battery System]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2017	80KW	LDC [Low DC / DC Converter]	√	√	√	√		
Europe/General	SOUL EV(PS EV)	2017	80KW	OBC [On Board Charger]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2017	80KW	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL EV(PS EV)	2017	80KW	TPMS [Tire Pressure Monitoring]	√	√	√			
Europe/General	SOUL EV(PS EV)	2017	80KW	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2017	80KW	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2017	80KW	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2016	80KW	VMCU [Vehicle Motor Control System]	√	√	√	√	√	0037, 0094
Europe/General	SOUL EV(PS EV)	2016	80KW	EPB [Electric Parking Brake]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2016	80KW	ABSVC [Electronic Stability Control]	√	√	√	√	√	0009, 0046, 0059, 0068, 0078
Europe/General	SOUL EV(PS EV)	2016	80KW	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL EV(PS EV)	2016	80KW	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL EV(PS EV)	2016	80KW	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2016	80KW	BMS [EV Battery System]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2016	80KW	LDC [Low DC / DC Converter]	√	√	√	√		
Europe/General	SOUL EV(PS EV)	2016	80KW	OBC [On Board Charger]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2016	80KW	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL EV(PS EV)	2016	80KW	TPMS [Tire Pressure Monitoring]	√	√	√			
Europe/General	SOUL EV(PS EV)	2016	80KW	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL EV(PS EV)	2016	80KW	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2016	80KW	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2016	80KW	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2015	80KW	VMCU [Vehicle Motor Control System]	√	√	√	√	√	0037, 0094

Europe/General	SOUL EV(PS EV)	2015	80KW	EPB [Electric Parking Brake]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2015	80KW	ABSVC [Electronic Stability Control]	√	√	√	√	√	0009, 0046, 0059, 0068, 0078
Europe/General	SOUL EV(PS EV)	2015	80KW	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL EV(PS EV)	2015	80KW	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL EV(PS EV)	2015	80KW	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2015	80KW	BMS [EV Battery System]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2015	80KW	LDC [Low DC / DC Converter]	√	√	√	√		
Europe/General	SOUL EV(PS EV)	2015	80KW	OBC [On Board Charger]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2015	80KW	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL EV(PS EV)	2015	80KW	TPMS [Tire Pressure Monitoring]	√	√	√			
Europe/General	SOUL EV(PS EV)	2015	80KW	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL EV(PS EV)	2015	80KW	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2015	80KW	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL EV(PS EV)	2015	80KW	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SOUL(AM)	2014	D 1.6 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2014	D 1.6 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SOUL(AM)	2014	D 1.6 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2014	D 1.6 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2014	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(AM)	2014	D 1.6 TCI-U2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(AM)	2014	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SOUL(AM)	2014	D 1.6 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2014	D 1.6 TCI-U2	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SOUL(AM)	2014	D 1.6 TCI-U2	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SOUL(AM)	2014	D 1.6 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SOUL(AM)	2014	D 1.6 TCI-U2	BCM [Body Control Module (GEN)]	√			√	√	
Europe/General	SOUL(AM)	2014	D 1.6 TCI-U2	BCM [Body Control Module (EURO)]	√			√	√	
Europe/General	SOUL(AM)	2014	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2014	F 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(AM)	2014	F 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2014	F 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SOUL(AM)	2014	F 1.6 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2014	F 1.6 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2014	F 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(AM)	2014	F 1.6 DOHC	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(AM)	2014	F 1.6 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SOUL(AM)	2014	F 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2014	F 1.6 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SOUL(AM)	2014	F 1.6 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SOUL(AM)	2014	F 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SOUL(AM)	2014	F 1.6 DOHC	BCM [Body Control Module (GEN)]	√			√	√	
Europe/General	SOUL(AM)	2014	F 1.6 DOHC	BCM [Body Control Module (EURO)]	√			√	√	
Europe/General	SOUL(AM)	2014	F 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2014	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126

Europe/General	SOUL(AM)	2014	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2014	G 1.6 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SOUL(AM)	2014	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2014	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2014	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(AM)	2014	G 1.6 GDI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(AM)	2014	G 1.6 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SOUL(AM)	2014	G 1.6 GDI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2014	G 1.6 GDI	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SOUL(AM)	2014	G 1.6 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SOUL(AM)	2014	G 1.6 GDI	BCM [Body Control Module (GEN)]	√			√	√	
Europe/General	SOUL(AM)	2014	G 1.6 GDI	BCM [Body Control Module (EURO)]	√			√	√	
Europe/General	SOUL(AM)	2014	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2014	G 1.6 MPI	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	SOUL(AM)	2014	G 1.6 MPI	ENGINE [Unleaded GEN]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(AM)	2014	G 1.6 MPI	ENGINE [Unleaded EOBD]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(AM)	2014	G 1.6 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2014	G 1.6 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SOUL(AM)	2014	G 1.6 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2014	G 1.6 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2014	G 1.6 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(AM)	2014	G 1.6 MPI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(AM)	2014	G 1.6 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SOUL(AM)	2014	G 1.6 MPI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2014	G 1.6 MPI	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SOUL(AM)	2014	G 1.6 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SOUL(AM)	2014	G 1.6 MPI	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SOUL(AM)	2014	G 1.6 MPI	BCM [Body Control Module (GEN)]	√			√	√	
Europe/General	SOUL(AM)	2014	G 1.6 MPI	BCM [Body Control Module (EURO)]	√			√	√	
Europe/General	SOUL(AM)	2014	G 1.6 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2014	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√		0126, 0062, 0011, 0094, 0098
Europe/General	SOUL(AM)	2014	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√		0126, 0011, 0094, 0098
Europe/General	SOUL(AM)	2014	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√		0126, 0011, 0094, 0098
Europe/General	SOUL(AM)	2014	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2014	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SOUL(AM)	2014	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2014	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2014	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(AM)	2014	G 2.0 DOHC	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(AM)	2014	G 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SOUL(AM)	2014	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2014	G 2.0 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SOUL(AM)	2014	G 2.0 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SOUL(AM)	2014	G 2.0 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SOUL(AM)	2014	G 2.0 DOHC	BCM [Body Control Module (GEN)]	√			√	√	

Europe/General	SOUL(AM)	2014	G 2.0 DOHC	BCM [Body Control Module (EURO)]	√			√	√	
Europe/General	SOUL(AM)	2014	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2013	D 1.6 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2013	D 1.6 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SOUL(AM)	2013	D 1.6 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2013	D 1.6 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2013	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(AM)	2013	D 1.6 TCI-U2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(AM)	2013	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SOUL(AM)	2013	D 1.6 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2013	D 1.6 TCI-U2	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SOUL(AM)	2013	D 1.6 TCI-U2	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SOUL(AM)	2013	D 1.6 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SOUL(AM)	2013	D 1.6 TCI-U2	BCM [Body Control Module (GEN)]	√			√	√	
Europe/General	SOUL(AM)	2013	D 1.6 TCI-U2	BCM [Body Control Module (EURO)]	√			√	√	
Europe/General	SOUL(AM)	2013	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2013	F 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(AM)	2013	F 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2013	F 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SOUL(AM)	2013	F 1.6 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2013	F 1.6 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2013	F 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(AM)	2013	F 1.6 DOHC	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(AM)	2013	F 1.6 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SOUL(AM)	2013	F 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2013	F 1.6 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SOUL(AM)	2013	F 1.6 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SOUL(AM)	2013	F 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SOUL(AM)	2013	F 1.6 DOHC	BCM [Body Control Module (GEN)]	√			√	√	
Europe/General	SOUL(AM)	2013	F 1.6 DOHC	BCM [Body Control Module (EURO)]	√			√	√	
Europe/General	SOUL(AM)	2013	F 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2013	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(AM)	2013	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2013	G 1.6 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SOUL(AM)	2013	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2013	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2013	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(AM)	2013	G 1.6 GDI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(AM)	2013	G 1.6 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SOUL(AM)	2013	G 1.6 GDI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2013	G 1.6 GDI	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SOUL(AM)	2013	G 1.6 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SOUL(AM)	2013	G 1.6 GDI	BCM [Body Control Module (GEN)]	√			√	√	
Europe/General	SOUL(AM)	2013	G 1.6 GDI	BCM [Body Control Module (EURO)]	√			√	√	
Europe/General	SOUL(AM)	2013	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022

Europe/General	SOUL(AM)	2013	G 1.6 MPI	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	SOUL(AM)	2013	G 1.6 MPI	ENGINE [Unleaded GEN]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(AM)	2013	G 1.6 MPI	ENGINE [Unleaded EOBD]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(AM)	2013	G 1.6 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2013	G 1.6 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SOUL(AM)	2013	G 1.6 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2013	G 1.6 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2013	G 1.6 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(AM)	2013	G 1.6 MPI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(AM)	2013	G 1.6 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SOUL(AM)	2013	G 1.6 MPI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2013	G 1.6 MPI	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SOUL(AM)	2013	G 1.6 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SOUL(AM)	2013	G 1.6 MPI	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SOUL(AM)	2013	G 1.6 MPI	BCM [Body Control Module (GEN)]	√			√	√	
Europe/General	SOUL(AM)	2013	G 1.6 MPI	BCM [Body Control Module (EURO)]	√			√	√	
Europe/General	SOUL(AM)	2013	G 1.6 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2013	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√		0126, 0062, 0011, 0094, 0098
Europe/General	SOUL(AM)	2013	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√		0126, 0011, 0094, 0098
Europe/General	SOUL(AM)	2013	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√		0126, 0011, 0094, 0098
Europe/General	SOUL(AM)	2013	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2013	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SOUL(AM)	2013	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2013	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2013	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(AM)	2013	G 2.0 DOHC	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(AM)	2013	G 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SOUL(AM)	2013	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2013	G 2.0 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SOUL(AM)	2013	G 2.0 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SOUL(AM)	2013	G 2.0 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SOUL(AM)	2013	G 2.0 DOHC	BCM [Body Control Module (GEN)]	√			√	√	
Europe/General	SOUL(AM)	2013	G 2.0 DOHC	BCM [Body Control Module (EURO)]	√			√	√	
Europe/General	SOUL(AM)	2013	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2012	D 1.6 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2012	D 1.6 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SOUL(AM)	2012	D 1.6 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2012	D 1.6 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2012	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(AM)	2012	D 1.6 TCI-U2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(AM)	2012	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SOUL(AM)	2012	D 1.6 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2012	D 1.6 TCI-U2	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SOUL(AM)	2012	D 1.6 TCI-U2	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SOUL(AM)	2012	D 1.6 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102

Europe/General	SOUL(AM)	2012	D 1.6 TCI-U2	BCM [Body Control Module (GEN)]	√			√	√	
Europe/General	SOUL(AM)	2012	D 1.6 TCI-U2	BCM [Body Control Module (EURO)]	√			√	√	
Europe/General	SOUL(AM)	2012	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2012	F 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(AM)	2012	F 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2012	F 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SOUL(AM)	2012	F 1.6 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2012	F 1.6 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2012	F 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(AM)	2012	F 1.6 DOHC	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(AM)	2012	F 1.6 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
Europe/General	SOUL(AM)	2012	F 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2012	F 1.6 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SOUL(AM)	2012	F 1.6 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SOUL(AM)	2012	F 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SOUL(AM)	2012	F 1.6 DOHC	BCM [Body Control Module (GEN)]	√			√	√	
Europe/General	SOUL(AM)	2012	F 1.6 DOHC	BCM [Body Control Module (EURO)]	√			√	√	
Europe/General	SOUL(AM)	2012	F 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2012	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(AM)	2012	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2012	G 1.6 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SOUL(AM)	2012	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2012	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2012	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(AM)	2012	G 1.6 GDI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(AM)	2012	G 1.6 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SOUL(AM)	2012	G 1.6 GDI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2012	G 1.6 GDI	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SOUL(AM)	2012	G 1.6 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SOUL(AM)	2012	G 1.6 GDI	BCM [Body Control Module (GEN)]	√			√	√	
Europe/General	SOUL(AM)	2012	G 1.6 GDI	BCM [Body Control Module (EURO)]	√			√	√	
Europe/General	SOUL(AM)	2012	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2012	G 1.6 MPI	ENGINE [Leaded All]	√	√	√	√		0033, 0061, 0062, 0094, 0126
Europe/General	SOUL(AM)	2012	G 1.6 MPI	ENGINE [Unleaded GEN]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(AM)	2012	G 1.6 MPI	ENGINE [Unleaded EOBD]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(AM)	2012	G 1.6 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2012	G 1.6 MPI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SOUL(AM)	2012	G 1.6 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2012	G 1.6 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2012	G 1.6 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(AM)	2012	G 1.6 MPI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(AM)	2012	G 1.6 MPI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SOUL(AM)	2012	G 1.6 MPI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2012	G 1.6 MPI	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SOUL(AM)	2012	G 1.6 MPI	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102

Europe/General	SOUL(AM)	2012	G 1.6 MPI	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SOUL(AM)	2012	G 1.6 MPI	BCM [Body Control Module (GEN)]	√			√	√	
Europe/General	SOUL(AM)	2012	G 1.6 MPI	BCM [Body Control Module (EURO)]	√			√	√	
Europe/General	SOUL(AM)	2012	G 1.6 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2012	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√		0126, 0062, 0011, 0094, 0098
Europe/General	SOUL(AM)	2012	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√		0126, 0011, 0094, 0098
Europe/General	SOUL(AM)	2012	G 2.0 DOHC	ENGINE [Unleaded EOBd]	√	√	√	√		0126, 0011, 0094, 0098
Europe/General	SOUL(AM)	2012	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2012	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SOUL(AM)	2012	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2012	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2012	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(AM)	2012	G 2.0 DOHC	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(AM)	2012	G 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SOUL(AM)	2012	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2012	G 2.0 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SOUL(AM)	2012	G 2.0 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SOUL(AM)	2012	G 2.0 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SOUL(AM)	2012	G 2.0 DOHC	BCM [Body Control Module (GEN)]	√			√	√	
Europe/General	SOUL(AM)	2012	G 2.0 DOHC	BCM [Body Control Module (EURO)]	√			√	√	
Europe/General	SOUL(AM)	2012	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2011	D 1.6 TCI-U2	ENGINE [Engine (CPF -)]	√	√	√	√	√	
Europe/General	SOUL(AM)	2011	D 1.6 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2011	D 1.6 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SOUL(AM)	2011	D 1.6 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2011	D 1.6 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2011	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(AM)	2011	D 1.6 TCI-U2	EPS [MDPS]	√	√	√	√		
Europe/General	SOUL(AM)	2011	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SOUL(AM)	2011	D 1.6 TCI-U2	IMMO [IMMO (Bosch)]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2011	D 1.6 TCI-U2	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SOUL(AM)	2011	D 1.6 TCI-U2	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SOUL(AM)	2011	D 1.6 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SOUL(AM)	2011	D 1.6 TCI-U2	BCM [Body Control Module]	√			√	√	
Europe/General	SOUL(AM)	2011	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2011	F 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(AM)	2011	F 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2011	F 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SOUL(AM)	2011	F 1.6 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2011	F 1.6 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2011	F 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(AM)	2011	F 1.6 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	SOUL(AM)	2011	F 1.6 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SOUL(AM)	2011	F 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2011	F 1.6 DOHC	SMKCODE [Smart Key Code Saving]				√		

Europe/General	SOUL(AM)	2011	F 1.6 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SOUL(AM)	2011	F 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SOUL(AM)	2011	F 1.6 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	SOUL(AM)	2011	F 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2011	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	SOUL(AM)	2011	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0094, 0098, 0126
Europe/General	SOUL(AM)	2011	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0094, 0098, 0126
Europe/General	SOUL(AM)	2011	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2011	G 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SOUL(AM)	2011	G 1.6 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2011	G 1.6 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2011	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(AM)	2011	G 1.6 DOHC	EPS [MDPS]	√	√	√	√		
Europe/General	SOUL(AM)	2011	G 1.6 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SOUL(AM)	2011	G 1.6 DOHC	IMMO [IMMO (Bosch)]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2011	G 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SOUL(AM)	2011	G 1.6 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SOUL(AM)	2011	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	SOUL(AM)	2011	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2011	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0094, 0098
Europe/General	SOUL(AM)	2011	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0094, 0098
Europe/General	SOUL(AM)	2011	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0094, 0098
Europe/General	SOUL(AM)	2011	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2011	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SOUL(AM)	2011	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2011	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2011	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(AM)	2011	G 2.0 DOHC	EPS [MDPS]	√	√	√	√		
Europe/General	SOUL(AM)	2011	G 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SOUL(AM)	2011	G 2.0 DOHC	IMMO [IMMO (Bosch)]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2011	G 2.0 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	SOUL(AM)	2011	G 2.0 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	SOUL(AM)	2011	G 2.0 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	SOUL(AM)	2011	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	SOUL(AM)	2011	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2010	D 1.6 TCI-U2	ENGINE [Engine (CPF+)]	√	√	√	√	√	
Europe/General	SOUL(AM)	2010	D 1.6 TCI-U2	ENGINE [Engine (CPF -)]	√	√	√	√	√	
Europe/General	SOUL(AM)	2010	D 1.6 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2010	D 1.6 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	SOUL(AM)	2010	D 1.6 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2010	D 1.6 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2010	D 1.6 TCI-U2	EPS [MDPS]	√	√	√	√		
Europe/General	SOUL(AM)	2010	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SOUL(AM)	2010	D 1.6 TCI-U2	IMMO [IMMO (Bosch)]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2010	D 1.6 TCI-U2	BCM [Body Control Module]	√			√	√	

Europe/General	SOUL(AM)	2010	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2010	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	SOUL(AM)	2010	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0094, 0098, 0126
Europe/General	SOUL(AM)	2010	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0094, 0098, 0126
Europe/General	SOUL(AM)	2010	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2010	G 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	SOUL(AM)	2010	G 1.6 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2010	G 1.6 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2010	G 1.6 DOHC	EPS [MDPS]	√	√	√	√		
Europe/General	SOUL(AM)	2010	G 1.6 DOHC	IMMO [IMMO (Bosch)]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2010	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	SOUL(AM)	2010	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2010	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0094, 0098
Europe/General	SOUL(AM)	2010	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0094, 0098
Europe/General	SOUL(AM)	2010	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0094, 0098
Europe/General	SOUL(AM)	2010	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2010	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	SOUL(AM)	2010	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2010	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2010	G 2.0 DOHC	EPS [MDPS]	√	√	√	√		
Europe/General	SOUL(AM)	2010	G 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SOUL(AM)	2010	G 2.0 DOHC	IMMO [IMMO (Bosch)]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2010	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	SOUL(AM)	2010	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2009	D 1.6 TCI-U2	ENGINE [Engine (CPF+)]	√	√	√	√	√	
Europe/General	SOUL(AM)	2009	D 1.6 TCI-U2	ENGINE [Engine (CPF -)]	√	√	√	√	√	
Europe/General	SOUL(AM)	2009	D 1.6 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2009	D 1.6 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	SOUL(AM)	2009	D 1.6 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2009	D 1.6 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2009	D 1.6 TCI-U2	EPS [MDPS]	√	√	√	√		
Europe/General	SOUL(AM)	2009	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SOUL(AM)	2009	D 1.6 TCI-U2	IMMO [IMMO (Bosch)]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2009	D 1.6 TCI-U2	BCM [Body Control Module]	√			√	√	
Europe/General	SOUL(AM)	2009	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2009	G 1.6 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0094, 0098, 0126
Europe/General	SOUL(AM)	2009	G 1.6 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0094, 0098, 0126
Europe/General	SOUL(AM)	2009	G 1.6 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0094, 0098, 0126
Europe/General	SOUL(AM)	2009	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2009	G 1.6 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	SOUL(AM)	2009	G 1.6 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2009	G 1.6 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2009	G 1.6 DOHC	EPS [MDPS]	√	√	√	√		
Europe/General	SOUL(AM)	2009	G 1.6 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SOUL(AM)	2009	G 1.6 DOHC	IMMO [IMMO (Bosch)]				√		0072, 0075, 0083, 0092, 0112

Europe/General	SOUL(AM)	2009	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	SOUL(AM)	2009	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(AM)	2009	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0062, 0062, 0126, 0094, 0098
Europe/General	SOUL(AM)	2009	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0098, 0126, 0094, 0098
Europe/General	SOUL(AM)	2009	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(AM)	2009	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	SOUL(AM)	2009	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(AM)	2009	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(AM)	2009	G 2.0 DOHC	EPS [MDPS]	√	√	√	√		
Europe/General	SOUL(AM)	2009	G 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SOUL(AM)	2009	G 2.0 DOHC	IMMO [IMMO (Bosch)]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SOUL(AM)	2009	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	SOUL(AM)	2009	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	AT [Double Clutch Transmission]	√	√	√	√		0018, 0021
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	AEB [Assist Emergency Braking System]	√	√	√	√		
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	BSD - R [Blind Spot Detection]	√	√	√	√	√	0012
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	BSD - L [Blind Spot Detection - Left]	√	√	√	√	√	0012
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	AMP [Amplifier]						0003
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	ECALL [e - Call]	√	√	√			
Europe/General	SOUL(PS)	2017	D 1.6 TCI U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	AT [Automatic Transaxle]	√	√	√	√		0005, 0099
Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2017	F 1.6 MPI	AEB [Assist Emergency Braking System]	√	√	√	√		
Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			

Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	BSD - R [Blind Spot Detection]	√	√	√	√	√	0012
Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	BSD - L [Blind Spot Detection - Left]	√	√	√	√	√	0012
Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	AMP [Amplifier]						0003
Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	F 1.6 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	ENGINE [Engine Control]	√	√	√	√		0011, 0061, 0094, 0126
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2017	G 1.6 GDI	AEB [Assist Emergency Braking System]	√	√	√	√		
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	SCC [Smart Cruise Control]	√	√	√	√		

Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	BSD - R [Blind Spot Detection]	√	√	√	√	√	0012
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	BSD - L [Blind Spot Detection - Left]	√	√	√	√	√	0012
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	AMP [Amplifier]						0003
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	ECALL [e - Call]	√	√	√			
Europe/General	SOUL(PS)	2017	G 1.6 GDI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	AT [Automatic Transaxle]	√	√	√	√		0005, 0099
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2017	G 1.6 MPI	AEB [Assist Emergency Braking System]	√	√	√	√		
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	BSD - R [Blind Spot Detection]	√	√	√	√	√	0012

Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	BSD - L [Blind Spot Detection - Left]	√	√	√	√	√	0012
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	ECALL [e - Call]	√	√	√			
Europe/General	SOUL(PS)	2017	G 1.6 MPI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	ENGINE [Engine Control]	√	√	√	√		0011, 0061, 0094, 0126
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	AT [Double Clutch Transmission]	√	√	√	√		0018, 0021
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI	AEB [Assist Emergency Braking System]	√	√	√	√		
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	BSD - R [Blind Spot Detection]	√	√	√	√	√	0012
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	BSD - L [Blind Spot Detection - Left]	√	√	√	√	√	0012
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102

Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	AMP [Amplifier]						0003
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	ECALL [e - Call]	√	√	√			
Europe/General	SOUL(PS)	2017	G 1.6 T-GDI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0126
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	AT [Automatic Transaxle]	√	√	√	√		0005, 0099
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	AEB [Assist Emergency Braking System]	√	√	√	√		
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	SCC [Smart Cruise Control]	√	√	√	√		
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	BSD - R [Blind Spot Detection]	√	√	√	√	√	0012
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	BSD - L [Blind Spot Detection - Left]	√	√	√	√	√	0012
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	AMP [Amplifier]						0003
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	ECALL [e - Call]	√	√	√			
Europe/General	SOUL(PS)	2017	G 2.0 NU MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2016	D 1.6 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	SOUL(PS)	2016	D 1.6 TCI-U2	AT [Automatic Transaxle]	√	√	√	√		
Europe/General	SOUL(PS)	2016	D 1.6 TCI-U2	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2016	D 1.6 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2016	D 1.6 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2016	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	D 1.6 TCI-U2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2016	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2016	D 1.6 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	D 1.6 TCI-U2	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2016	D 1.6 TCI-U2	AHLS [AHLS]	√	√	√	√	√	0055

Europe/General	SOUL(PS)	2016	D 1.6 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2016	D 1.6 TCI-U2	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2016	D 1.6 TCI-U2	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	D 1.6 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	D 1.6 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2016	F 1.6 MPI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(PS)	2016	F 1.6 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2016	F 1.6 MPI	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2016	F 1.6 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2016	F 1.6 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2016	F 1.6 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	F 1.6 MPI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2016	F 1.6 MPI	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2016	F 1.6 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	F 1.6 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2016	F 1.6 MPI	AHLS [AHLS]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2016	F 1.6 MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2016	F 1.6 MPI	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2016	F 1.6 MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	F 1.6 MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	F 1.6 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2016	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(PS)	2016	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2016	G 1.6 GDI	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2016	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2016	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2016	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	G 1.6 GDI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2016	G 1.6 GDI	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2016	G 1.6 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	G 1.6 GDI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2016	G 1.6 GDI	AHLS [AHLS]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2016	G 1.6 GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2016	G 1.6 GDI	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2016	G 1.6 GDI	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	G 1.6 GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	G 1.6 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2016	G 1.6 MPI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(PS)	2016	G 1.6 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2016	G 1.6 MPI	ESC [Electronic Stability Control]	√	√	√	√	√	0051

Europe/General	SOUL(PS)	2016	G 1.6 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2016	G 1.6 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2016	G 1.6 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	G 1.6 MPI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2016	G 1.6 MPI	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2016	G 1.6 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	G 1.6 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2016	G 1.6 MPI	AHLS [AHLS]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2016	G 1.6 MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2016	G 1.6 MPI	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	G 1.6 MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	G 1.6 MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	G 1.6 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2016	G 2.0 NU MPI	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SOUL(PS)	2016	G 2.0 NU MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2016	G 2.0 NU MPI	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2016	G 2.0 NU MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2016	G 2.0 NU MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2016	G 2.0 NU MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	G 2.0 NU MPI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2016	G 2.0 NU MPI	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2016	G 2.0 NU MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	G 2.0 NU MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2016	G 2.0 NU MPI	AHLS [AHLS]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2016	G 2.0 NU MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2016	G 2.0 NU MPI	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2016	G 2.0 NU MPI	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	G 2.0 NU MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	G 2.0 NU MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2016	G 2.0 NU MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2015	D 1.6 TCI-U2	ENGINE [Engine Control (ISG -)]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	D 1.6 TCI-U2	ENGINE [Engine Control (ISG+)]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	D 1.6 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2015	D 1.6 TCI-U2	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2015	D 1.6 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2015	D 1.6 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2015	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	D 1.6 TCI-U2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2015	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2015	D 1.6 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	D 1.6 TCI-U2	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2015	D 1.6 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2015	D 1.6 TCI-U2	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102

Europe/General	SOUL(PS)	2015	D 1.6 TCI-U2	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	D 1.6 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	D 1.6 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2015	F 1.6 MPI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(PS)	2015	F 1.6 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2015	F 1.6 MPI	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2015	F 1.6 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2015	F 1.6 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2015	F 1.6 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	F 1.6 MPI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2015	F 1.6 MPI	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2015	F 1.6 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	F 1.6 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2015	F 1.6 MPI	AHLS [AHLS]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2015	F 1.6 MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2015	F 1.6 MPI	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2015	F 1.6 MPI	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	F 1.6 MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	F 1.6 MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	F 1.6 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2015	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(PS)	2015	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2015	G 1.6 GDI	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2015	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2015	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2015	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	G 1.6 GDI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2015	G 1.6 GDI	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2015	G 1.6 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	G 1.6 GDI	AHLS [AHLS]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2015	G 1.6 GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2015	G 1.6 GDI	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2015	G 1.6 GDI	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	G 1.6 GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	G 1.6 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2015	G 1.6 MPI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(PS)	2015	G 1.6 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2015	G 1.6 MPI	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2015	G 1.6 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2015	G 1.6 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2015	G 1.6 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	SOUL(PS)	2015	G 1.6 MPI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2015	G 1.6 MPI	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2015	G 1.6 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	G 1.6 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2015	G 1.6 MPI	AHLS [AHLS]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2015	G 1.6 MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2015	G 1.6 MPI	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2015	G 1.6 MPI	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	G 1.6 MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	G 1.6 MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	G 1.6 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2015	G 2.0 NU MPI	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SOUL(PS)	2015	G 2.0 NU MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2015	G 2.0 NU MPI	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2015	G 2.0 NU MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2015	G 2.0 NU MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2015	G 2.0 NU MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	G 2.0 NU MPI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2015	G 2.0 NU MPI	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2015	G 2.0 NU MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2015	G 2.0 NU MPI	AHLS [AHLS]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2015	G 2.0 NU MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2015	G 2.0 NU MPI	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2015	G 2.0 NU MPI	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	G 2.0 NU MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	G 2.0 NU MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2015	G 2.0 NU MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2014	D 1.6 TCI-U2	ENGINE [Engine Control (ISG -)]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	D 1.6 TCI-U2	ENGINE [Engine Control (ISG+)]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	D 1.6 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2014	D 1.6 TCI-U2	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2014	D 1.6 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2014	D 1.6 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2014	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	D 1.6 TCI-U2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2014	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2014	D 1.6 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	D 1.6 TCI-U2	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2014	D 1.6 TCI-U2	AHLS [AHLS]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2014	D 1.6 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2014	D 1.6 TCI-U2	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2014	D 1.6 TCI-U2	IPM [Instrument Panel Module]	√	√	√	√	√	

Europe/General	SOUL(PS)	2014	D 1.6 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	D 1.6 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2014	F 1.6 MPI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(PS)	2014	F 1.6 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2014	F 1.6 MPI	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2014	F 1.6 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2014	F 1.6 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2014	F 1.6 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	F 1.6 MPI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2014	F 1.6 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	F 1.6 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2014	F 1.6 MPI	AHLS [AHLS]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2014	F 1.6 MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2014	F 1.6 MPI	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2014	F 1.6 MPI	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	F 1.6 MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	F 1.6 MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	F 1.6 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2014	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(PS)	2014	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2014	G 1.6 GDI	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2014	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2014	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2014	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	G 1.6 GDI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2014	G 1.6 GDI	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2014	G 1.6 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	G 1.6 GDI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2014	G 1.6 GDI	AHLS [AHLS]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2014	G 1.6 GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2014	G 1.6 GDI	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2014	G 1.6 GDI	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	G 1.6 GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	G 1.6 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2014	G 1.6 MPI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(PS)	2014	G 1.6 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2014	G 1.6 MPI	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2014	G 1.6 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2014	G 1.6 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2014	G 1.6 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	G 1.6 MPI	TPMS [Tire Pressure Monitoring System]	√	√	√			

Europe/General	SOUL(PS)	2014	G 1.6 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	G 1.6 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2014	G 1.6 MPI	AHLS [AHLS]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2014	G 1.6 MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2014	G 1.6 MPI	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2014	G 1.6 MPI	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	G 1.6 MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	G 1.6 MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	G 1.6 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2014	G 2.0 NU MPI	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SOUL(PS)	2014	G 2.0 NU MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2014	G 2.0 NU MPI	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2014	G 2.0 NU MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2014	G 2.0 NU MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2014	G 2.0 NU MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	G 2.0 NU MPI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2014	G 2.0 NU MPI	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2014	G 2.0 NU MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	G 2.0 NU MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2014	G 2.0 NU MPI	AHLS [AHLS]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2014	G 2.0 NU MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2014	G 2.0 NU MPI	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2014	G 2.0 NU MPI	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	G 2.0 NU MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	G 2.0 NU MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2014	G 2.0 NU MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2013	D 1.6 TCI-U2	ENGINE [Engine Control (ISG -)]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	D 1.6 TCI-U2	ENGINE [Engine Control (ISG+)]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	D 1.6 TCI-U2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2013	D 1.6 TCI-U2	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2013	D 1.6 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2013	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	D 1.6 TCI-U2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2013	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2013	D 1.6 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	D 1.6 TCI-U2	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2013	D 1.6 TCI-U2	AHLS [AHLS]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2013	D 1.6 TCI-U2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2013	D 1.6 TCI-U2	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2013	D 1.6 TCI-U2	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	D 1.6 TCI-U2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	D 1.6 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	

Europe/General	SOUL(PS)	2013	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2013	F 1.6 MPI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(PS)	2013	F 1.6 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2013	F 1.6 MPI	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2013	F 1.6 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2013	F 1.6 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2013	F 1.6 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	F 1.6 MPI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2013	F 1.6 MPI	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2013	F 1.6 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	F 1.6 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2013	F 1.6 MPI	AHLS [AHLS]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2013	F 1.6 MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2013	F 1.6 MPI	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2013	F 1.6 MPI	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	F 1.6 MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	F 1.6 MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	F 1.6 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2013	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(PS)	2013	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2013	G 1.6 GDI	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2013	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2013	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	G 1.6 GDI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2013	G 1.6 GDI	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2013	G 1.6 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	G 1.6 GDI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2013	G 1.6 GDI	AHLS [AHLS]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2013	G 1.6 GDI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2013	G 1.6 GDI	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2013	G 1.6 GDI	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	G 1.6 GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	G 1.6 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2013	G 1.6 MPI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SOUL(PS)	2013	G 1.6 MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2013	G 1.6 MPI	ESC [Electronic Stability Control]	√	√	√	√	√	0051
Europe/General	SOUL(PS)	2013	G 1.6 MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2013	G 1.6 MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2013	G 1.6 MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	G 1.6 MPI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2013	G 1.6 MPI	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2013	G 1.6 MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	

Europe/General	SOUL(PS)	2013	G 1.6 MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2013	G 1.6 MPI	AHLS [AHLS]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2013	G 1.6 MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2013	G 1.6 MPI	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2013	G 1.6 MPI	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	G 1.6 MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	G 1.6 MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	G 1.6 MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SOUL(PS)	2013	G 2.0 NU MPI	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SOUL(PS)	2013	G 2.0 NU MPI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SOUL(PS)	2013	G 2.0 NU MPI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SOUL(PS)	2013	G 2.0 NU MPI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SOUL(PS)	2013	G 2.0 NU MPI	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	G 2.0 NU MPI	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SOUL(PS)	2013	G 2.0 NU MPI	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SOUL(PS)	2013	G 2.0 NU MPI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	G 2.0 NU MPI	LDWS [Lane Departure Warning System]	√	√	√	√		0070
Europe/General	SOUL(PS)	2013	G 2.0 NU MPI	AHLS [AHLS]	√	√	√	√	√	0055
Europe/General	SOUL(PS)	2013	G 2.0 NU MPI	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SOUL(PS)	2013	G 2.0 NU MPI	SMK [Smart Key Unit (Button)]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SOUL(PS)	2013	G 2.0 NU MPI	IPM [Instrument Panel Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	G 2.0 NU MPI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	G 2.0 NU MPI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SOUL(PS)	2013	G 2.0 NU MPI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(AL)	2004	D 2.0 RF-TCI	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	2004	D 2.0 RF-TCI	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	SPORTAGE(AL)	2004	D 2.0 RF-TCI	AIRBAG [Airbag Control]		√	√			
Europe/General	SPORTAGE(AL)	2004	G 2.0 DOHC	ENGINE [Leaded]		√	√	√	√	
Europe/General	SPORTAGE(AL)	2004	G 2.0 DOHC	ENGINE [Unleaded]	√	√	√	√		
Europe/General	SPORTAGE(AL)	2004	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	2004	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	SPORTAGE(AL)	2004	G 2.0 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	SPORTAGE(AL)	2003	D 2.0 RF-TCI	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	2003	D 2.0 RF-TCI	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	SPORTAGE(AL)	2003	D 2.0 RF-TCI	AIRBAG [Airbag Control]		√	√			
Europe/General	SPORTAGE(AL)	2003	G 2.0 DOHC	ENGINE [Leaded]		√	√	√	√	
Europe/General	SPORTAGE(AL)	2003	G 2.0 DOHC	ENGINE [Unleaded]	√	√	√	√		
Europe/General	SPORTAGE(AL)	2003	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	2003	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	SPORTAGE(AL)	2003	G 2.0 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	SPORTAGE(AL)	2002	D 2.0 RE(RF-TCI)	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	2002	D 2.0 RE(RF-TCI)	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	SPORTAGE(AL)	2002	D 2.0 RE(RF-TCI)	AIRBAG [Airbag Control]		√	√			

Europe/General	SPORTAGE(AL)	2002	D 2.0 RT(RF-TCI)	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	2002	D 2.0 RT(RF-TCI)	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	SPORTAGE(AL)	2002	D 2.0 RT(RF-TCI)	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(AL)	2002	G 2.0 DOHC	ENGINE [Unleaded]	√	√	√	√		
Europe/General	SPORTAGE(AL)	2002	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	2002	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	SPORTAGE(AL)	2002	G 2.0 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	SPORTAGE(AL)	2001	D 2.0 RE(RF-TCI)	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	2001	D 2.0 RE(RF-TCI)	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	SPORTAGE(AL)	2001	D 2.0 RE(RF-TCI)	AIRBAG [Airbag Control]		√	√			
Europe/General	SPORTAGE(AL)	2001	D 2.0 RT(RF-TCI)	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	2001	D 2.0 RT(RF-TCI)	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	SPORTAGE(AL)	2001	D 2.0 RT(RF-TCI)	AIRBAG [Airbag Control]		√	√			
Europe/General	SPORTAGE(AL)	2001	G 2.0 DOHC	ENGINE [Leaded]		√	√	√	√	
Europe/General	SPORTAGE(AL)	2001	G 2.0 DOHC	ENGINE [Unleaded]	√	√	√	√		
Europe/General	SPORTAGE(AL)	2001	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	2001	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
Europe/General	SPORTAGE(AL)	2001	G 2.0 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	SPORTAGE(AL)	2000	D 2.0 RE(RF-TCI)	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	2000	D 2.0 RE(RF-TCI)	AIRBAG [Airbag Control]		√	√			
Europe/General	SPORTAGE(AL)	2000	D 2.0 RT(RF-TCI)	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	2000	D 2.0 RT(RF-TCI)	AIRBAG [Airbag Control]		√	√			
Europe/General	SPORTAGE(AL)	2000	G 2.0 DOHC	ENGINE [Engine Control (AUS)]		√	√	√		
Europe/General	SPORTAGE(AL)	2000	G 2.0 DOHC	ENGINE [Leaded]		√	√	√	√	
Europe/General	SPORTAGE(AL)	2000	G 2.0 DOHC	ENGINE [Unleaded]		√	√	√		
Europe/General	SPORTAGE(AL)	2000	G 2.0 DOHC	AT [Automatic Transaxle (AUS)]		√	√	√		
Europe/General	SPORTAGE(AL)	2000	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	2000	G 2.0 DOHC	AIRBAG [Airbag (AUS)]		√	√			
Europe/General	SPORTAGE(AL)	2000	G 2.0 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	SPORTAGE(AL)	1999	D 2.0 RE(RF-TCI)	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	1999	D 2.0 RE(RF-TCI)	AIRBAG [Airbag Control]		√	√			
Europe/General	SPORTAGE(AL)	1999	D 2.0 RT(RF-TCI)	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	1999	D 2.0 RT(RF-TCI)	AIRBAG [Airbag Control]		√	√			
Europe/General	SPORTAGE(AL)	1999	G 2.0 DOHC	ENGINE [Leaded]		√	√	√	√	
Europe/General	SPORTAGE(AL)	1999	G 2.0 DOHC	ENGINE [Unleaded]		√	√	√		
Europe/General	SPORTAGE(AL)	1999	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	1999	G 2.0 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	SPORTAGE(AL)	1998	D 2.0 RE(RF-TCI)	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	1998	D 2.0 RE(RF-TCI)	AIRBAG [Airbag Control]		√	√			
Europe/General	SPORTAGE(AL)	1998	D 2.0 RT(RF-TCI)	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	1998	D 2.0 RT(RF-TCI)	AIRBAG [Airbag Control]		√	√			
Europe/General	SPORTAGE(AL)	1998	G 2.0 DOHC	ENGINE [Unleaded]		√	√	√		
Europe/General	SPORTAGE(AL)	1998	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	1998	G 2.0 DOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	SPORTAGE(AL)	1998	G 2.0 SOHC	ENGINE [Engine Control]		√	√	√		

Europe/General	SPORTAGE(AL)	1998	G 2.0 SOHC	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	1998	G 2.0 SOHC	AIRBAG [Airbag Control]		√	√			
Europe/General	SPORTAGE(AL)	1998	HW	ENGINE [Engine Control]		√	√	√		
Europe/General	SPORTAGE(AL)	1998	HW	AT [Automatic Transaxle]		√	√	√		
Europe/General	SPORTAGE(AL)	1998	HW	AIRBAG [Airbag Control]		√	√			
Europe/General	SPORTAGE(AL)	1997	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	SPORTAGE(AL)	1997	G 2.0 SOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	SPORTAGE(AL)	1997	HW	ENGINE [Engine Control]		√	√	√	√	
Europe/General	SPORTAGE(AL)	1996	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	SPORTAGE(AL)	1996	G 2.0 SOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	SPORTAGE(AL)	1996	HW	ENGINE [Engine Control]		√	√	√	√	
Europe/General	SPORTAGE(AL)	1995	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	SPORTAGE(AL)	1995	G 2.0 SOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	SPORTAGE(AL)	1995	HW	ENGINE [Engine Control]		√	√	√	√	
Europe/General	SPORTAGE(AL)	1994	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	SPORTAGE(AL)	1994	G 2.0 SOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	SPORTAGE(AL)	1994	HW	ENGINE [Engine Control]		√	√	√	√	
Europe/General	SPORTAGE(AL)	1993	G 2.0 SOHC	ENGINE [Engine Control]		√	√	√	√	
Europe/General	SPORTAGE(KM)	2010	D 2.0 VGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2010	D 2.0 VGT	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(KM)	2010	D 2.0 VGT	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SPORTAGE(KM)	2010	D 2.0 VGT	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2010	D 2.0 VGT	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2010	D 2.0 VGT	4WD [4WD Control]		√	√	√		
Europe/General	SPORTAGE(KM)	2010	D 2.0 VGT	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	SPORTAGE(KM)	2010	D 2.0 VGT	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2010	D 2.0 VGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2010	D 2.0 WGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2010	D 2.0 WGT	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(KM)	2010	D 2.0 WGT	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SPORTAGE(KM)	2010	D 2.0 WGT	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2010	D 2.0 WGT	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2010	D 2.0 WGT	4WD [4WD Control]		√	√	√		
Europe/General	SPORTAGE(KM)	2010	D 2.0 WGT	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	SPORTAGE(KM)	2010	D 2.0 WGT	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2010	D 2.0 WGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2010	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0126, 0094, 0098
Europe/General	SPORTAGE(KM)	2010	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0126, 0094, 0098
Europe/General	SPORTAGE(KM)	2010	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(KM)	2010	G 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SPORTAGE(KM)	2010	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2010	G 2.0 DOHC	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2010	G 2.0 DOHC	4WD [4WD Control]		√	√	√		
Europe/General	SPORTAGE(KM)	2010	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(KM)	2010	G 2.0 DOHC	ETACS [ETACS]	√			√	√	

Europe/General	SPORTAGE(KM)	2010	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2010	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0098
Europe/General	SPORTAGE(KM)	2010	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0098
Europe/General	SPORTAGE(KM)	2010	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0098
Europe/General	SPORTAGE(KM)	2010	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2010	G 2.7 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051
Europe/General	SPORTAGE(KM)	2010	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2010	G 2.7 DOHC	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2010	G 2.7 DOHC	4WD [4WD Control]		√	√	√		
Europe/General	SPORTAGE(KM)	2010	G 2.7 DOHC	IMMO [Immobilizer]		√	√	√		0075, 0083, 0092, 0119
Europe/General	SPORTAGE(KM)	2010	G 2.7 DOHC	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2010	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2009	D 2.0 VGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2009	D 2.0 VGT	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(KM)	2009	D 2.0 VGT	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2009	D 2.0 VGT	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2009	D 2.0 VGT	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2009	D 2.0 VGT	4WD [4WD Control]		√	√	√		
Europe/General	SPORTAGE(KM)	2009	D 2.0 VGT	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	SPORTAGE(KM)	2009	D 2.0 VGT	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2009	D 2.0 VGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2009	D 2.0 WGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2009	D 2.0 WGT	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(KM)	2009	D 2.0 WGT	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2009	D 2.0 WGT	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2009	D 2.0 WGT	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2009	D 2.0 WGT	4WD [4WD Control]		√	√	√		
Europe/General	SPORTAGE(KM)	2009	D 2.0 WGT	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	SPORTAGE(KM)	2009	D 2.0 WGT	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2009	D 2.0 WGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2009	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0094, 0098
Europe/General	SPORTAGE(KM)	2009	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0126, 0094, 0098
Europe/General	SPORTAGE(KM)	2009	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(KM)	2009	G 2.0 DOHC	ABSESP [ABS / ESP (MGH - 40)]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2009	G 2.0 DOHC	ABSESP [ABS / ESP (MGH - 25)]	√	√	√	√	√	0051
Europe/General	SPORTAGE(KM)	2009	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2009	G 2.0 DOHC	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2009	G 2.0 DOHC	4WD [4WD Control]		√	√	√		
Europe/General	SPORTAGE(KM)	2009	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(KM)	2009	G 2.0 DOHC	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2009	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2009	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0098
Europe/General	SPORTAGE(KM)	2009	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0098
Europe/General	SPORTAGE(KM)	2009	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0098
Europe/General	SPORTAGE(KM)	2009	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	

Europe/General	SPORTAGE(KM)	2009	G 2.7 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2009	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2009	G 2.7 DOHC	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2009	G 2.7 DOHC	4WD [4WD Control]		√	√	√		
Europe/General	SPORTAGE(KM)	2009	G 2.7 DOHC	IMMO [Immobilizer]		√	√	√		0075, 0083, 0092, 0119
Europe/General	SPORTAGE(KM)	2009	G 2.7 DOHC	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2009	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2008	D 2.0 VGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2008	D 2.0 VGT	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(KM)	2008	D 2.0 VGT	ABSESP [ABS / ESP (MGH - 40)]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2008	D 2.0 VGT	ABSESP [ABS / ESP (MGH - 25)]	√	√	√	√	√	0051
Europe/General	SPORTAGE(KM)	2008	D 2.0 VGT	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2008	D 2.0 VGT	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2008	D 2.0 VGT	4WD [4WD Control]		√	√	√		
Europe/General	SPORTAGE(KM)	2008	D 2.0 VGT	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	SPORTAGE(KM)	2008	D 2.0 VGT	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2008	D 2.0 VGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2008	D 2.0 WGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2008	D 2.0 WGT	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(KM)	2008	D 2.0 WGT	ABSESP [ABS / ESP (MGH - 40)]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2008	D 2.0 WGT	ABSESP [ABS / ESP (MGH - 25)]	√	√	√	√	√	0051
Europe/General	SPORTAGE(KM)	2008	D 2.0 WGT	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2008	D 2.0 WGT	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2008	D 2.0 WGT	4WD [4WD Control]		√	√	√		
Europe/General	SPORTAGE(KM)	2008	D 2.0 WGT	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2008	D 2.0 WGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2008	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0094, 0098
Europe/General	SPORTAGE(KM)	2008	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0094, 0098
Europe/General	SPORTAGE(KM)	2008	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0126, 0094, 0098
Europe/General	SPORTAGE(KM)	2008	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(KM)	2008	G 2.0 DOHC	ABSESP [ABS / ESP (MGH - 40)]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2008	G 2.0 DOHC	ABSESP [ABS / ESP (MGH - 25)]	√	√	√	√	√	0051
Europe/General	SPORTAGE(KM)	2008	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2008	G 2.0 DOHC	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2008	G 2.0 DOHC	4WD [4WD Control]		√	√	√		
Europe/General	SPORTAGE(KM)	2008	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(KM)	2008	G 2.0 DOHC	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2008	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2008	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0098
Europe/General	SPORTAGE(KM)	2008	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0098
Europe/General	SPORTAGE(KM)	2008	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0098
Europe/General	SPORTAGE(KM)	2008	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2008	G 2.7 DOHC	ABSESP [ABS / ESP (MGH - 40)]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2008	G 2.7 DOHC	ABSESP [ABS / ESP (MGH - 25)]	√	√	√	√	√	0051
Europe/General	SPORTAGE(KM)	2008	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			

Europe/General	SPORTAGE(KM)	2008	G 2.7 DOHC	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2008	G 2.7 DOHC	4WD [4WD Control]		√	√	√		
Europe/General	SPORTAGE(KM)	2008	G 2.7 DOHC	IMMO [Immobilizer]		√	√	√		0075, 0083, 0092, 0119
Europe/General	SPORTAGE(KM)	2008	G 2.7 DOHC	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2008	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2007	D 2.0 VGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2007	D 2.0 VGT	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(KM)	2007	D 2.0 VGT	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SPORTAGE(KM)	2007	D 2.0 VGT	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2007	D 2.0 VGT	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2007	D 2.0 VGT	4WD [4WD Control]		√	√	√		
Europe/General	SPORTAGE(KM)	2007	D 2.0 VGT	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	SPORTAGE(KM)	2007	D 2.0 VGT	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2007	D 2.0 VGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2007	D 2.0 WGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2007	D 2.0 WGT	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(KM)	2007	D 2.0 WGT	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SPORTAGE(KM)	2007	D 2.0 WGT	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2007	D 2.0 WGT	4WD [4WD Control]		√	√	√		
Europe/General	SPORTAGE(KM)	2007	D 2.0 WGT	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	SPORTAGE(KM)	2007	D 2.0 WGT	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2007	D 2.0 WGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2007	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2007	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2007	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0098
Europe/General	SPORTAGE(KM)	2007	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(KM)	2007	G 2.0 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SPORTAGE(KM)	2007	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2007	G 2.0 DOHC	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2007	G 2.0 DOHC	4WD [4WD Control]		√	√	√		
Europe/General	SPORTAGE(KM)	2007	G 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(KM)	2007	G 2.0 DOHC	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2007	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2007	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0098
Europe/General	SPORTAGE(KM)	2007	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0098
Europe/General	SPORTAGE(KM)	2007	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0098
Europe/General	SPORTAGE(KM)	2007	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2007	G 2.7 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SPORTAGE(KM)	2007	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2007	G 2.7 DOHC	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2007	G 2.7 DOHC	4WD [4WD Control]		√	√	√		
Europe/General	SPORTAGE(KM)	2007	G 2.7 DOHC	IMMO [Immobilizer]		√	√	√		0075, 0083, 0092, 0119
Europe/General	SPORTAGE(KM)	2007	G 2.7 DOHC	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2007	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2006	D 2.0 VGT	ENGINE [Engine Control]	√	√	√	√	√	

Europe/General	SPORTAGE(KM)	2006	D 2.0 VGT	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(KM)	2006	D 2.0 VGT	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SPORTAGE(KM)	2006	D 2.0 VGT	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2006	D 2.0 VGT	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2006	D 2.0 VGT	4WD [4WD Control]		√	√	√		
Europe/General	SPORTAGE(KM)	2006	D 2.0 VGT	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	SPORTAGE(KM)	2006	D 2.0 VGT	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2006	D 2.0 VGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2006	D 2.0 WGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2006	D 2.0 WGT	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(KM)	2006	D 2.0 WGT	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SPORTAGE(KM)	2006	D 2.0 WGT	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2006	D 2.0 WGT	4WD [4WD Control]		√	√			
Europe/General	SPORTAGE(KM)	2006	D 2.0 WGT	IMMO [Immobilizer]				√		0075, 0083, 0092, 0119
Europe/General	SPORTAGE(KM)	2006	D 2.0 WGT	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2006	D 2.0 WGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2006	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2006	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2006	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0098
Europe/General	SPORTAGE(KM)	2006	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2006	G 2.0 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SPORTAGE(KM)	2006	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2006	G 2.0 DOHC	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2006	G 2.0 DOHC	4WD [4WD Control]		√	√			
Europe/General	SPORTAGE(KM)	2006	G 2.0 DOHC	IMMO [Immobilizer]				√		
Europe/General	SPORTAGE(KM)	2006	G 2.0 DOHC	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2006	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2006	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0098
Europe/General	SPORTAGE(KM)	2006	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0098
Europe/General	SPORTAGE(KM)	2006	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0098
Europe/General	SPORTAGE(KM)	2006	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2006	G 2.7 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SPORTAGE(KM)	2006	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2006	G 2.7 DOHC	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2006	G 2.7 DOHC	4WD [4WD Control]		√	√			
Europe/General	SPORTAGE(KM)	2006	G 2.7 DOHC	IMMO [Immobilizer]		√	√	√		0075, 0083, 0092, 0119
Europe/General	SPORTAGE(KM)	2006	G 2.7 DOHC	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2006	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2005	D 2.0 WGT	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2005	D 2.0 WGT	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2005	D 2.0 WGT	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SPORTAGE(KM)	2005	D 2.0 WGT	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2005	D 2.0 WGT	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2005	D 2.0 WGT	4WD [4WD Control]		√	√			
Europe/General	SPORTAGE(KM)	2005	D 2.0 WGT	IMMO [Immobilizer]				√		

Europe/General	SPORTAGE(KM)	2005	D 2.0 WGT	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2005	D 2.0 WGT	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2005	G 2.0 DOHC	ENGINE [Leaded All]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2005	G 2.0 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2005	G 2.0 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0098
Europe/General	SPORTAGE(KM)	2005	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2005	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2005	G 2.0 DOHC	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2005	G 2.0 DOHC	4WD [4WD Control]		√	√			
Europe/General	SPORTAGE(KM)	2005	G 2.0 DOHC	IMMO [Immobilizer]				√		
Europe/General	SPORTAGE(KM)	2005	G 2.0 DOHC	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2005	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(KM)	2005	G 2.7 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0011, 0062, 0098
Europe/General	SPORTAGE(KM)	2005	G 2.7 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0011, 0098
Europe/General	SPORTAGE(KM)	2005	G 2.7 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0011, 0098
Europe/General	SPORTAGE(KM)	2005	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
Europe/General	SPORTAGE(KM)	2005	G 2.7 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
Europe/General	SPORTAGE(KM)	2005	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			
Europe/General	SPORTAGE(KM)	2005	G 2.7 DOHC	AIRCON [Air Conditioner]	√			√	√	
Europe/General	SPORTAGE(KM)	2005	G 2.7 DOHC	4WD [4WD Control]		√	√			
Europe/General	SPORTAGE(KM)	2005	G 2.7 DOHC	IMMO [Immobilizer]		√	√	√		0075, 0083, 0092, 0119
Europe/General	SPORTAGE(KM)	2005	G 2.7 DOHC	ETACS [ETACS]	√			√	√	
Europe/General	SPORTAGE(KM)	2005	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	ENGINE [Engine Control]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	CLU [Cluster Module]	√	√	√	√	√	

Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	ECALL [e - Call]	√	√	√			
Europe/General	SPORTAGE(QL)	2017	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	PTG [Power Tail Gate]	√	√	√	√		0093

Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	ECALL [e - Call]	√	√	√			
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI FFV NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	ECALL [e - Call]	√	√	√			
Europe/General	SPORTAGE(QL)	2017	G 2.0 MPI NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	ECALL [e - Call]	√	√	√			

Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0100, 0126
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	AT [Automatic Transaxle]	√	√	√	√		0005, 0099
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	SPORTAGE(QL)	2017	G 2.4 GDI THETA2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	ENGINE [Engine Control]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012

Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	ECALL [e - Call]	√	√	√			
Europe/General	SPORTAGE(QL)	2016	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	SJB [Smart Junction Block]	√	√	√	√	√	

Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	ECALL [e - Call]	√	√	√			
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI FFV NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	ECALL [e - Call]	√	√	√			
Europe/General	SPORTAGE(QL)	2016	G 2.0 MPI NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0100, 0126
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	AT [Automatic Transaxle]	√	√	√	√		0005, 0099
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	AEB [Autonomous Emergency Braking]	√	√	√	√		

Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	EPS [Motor Driven Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	0055
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	ECALL [e - Call]	√	√	√			
Europe/General	SPORTAGE(QL)	2016	G 2.4 GDI THETA2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	AT [Double Clutch Transmission]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051

Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	AIRBAG [Advanced (Event #2)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	AIRBAG [Advanced (Event #1)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	EPS [Motor Driven Power Steering (Mando R - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	EPS [Motor Driven Power Steering (Mando C - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	BCM [Body Control Module]	√	√	√	√	√	0109, 0121
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	ECALL [e - Call]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	D 1.7 U-II (Low Power)	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	ENGINE [Engine Control]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	AEB [Autonomous Emergency Braking]	√	√	√	√		

Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	AIRBAG [Advanced (Event #2)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	AIRBAG [Advanced (Event #1)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	EPS [Motor Driven Power Steering (TRW R - Typeo)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	EPS [Motor Driven Power Steering (Mando R - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	EPS [Motor Driven Power Steering (Mando C - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	BCM [Body Control Module]	√	√	√	√	√	0109, 0121
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	ECALL [e - Call]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	D 2.0 TCI R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	AIRBAG [Advanced (Event #2)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	AIRBAG [Advanced (Event #1)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	EPS [Motor Driven Power Steering (TRW R - Typeo)]	√	√	√	√		

Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	EPS [Motor Driven Power Steering (Mando R - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	EPS [Motor Driven Power Steering (Mando C - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	BCM [Body Control Module]	√	√	√	√	√	0109, 0121
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	ECALL [e - Call]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	G 1.6 GDI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	AT [Double Clutch Transmission]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	AIRBAG [Advanced (Event #2)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	AIRBAG [Advanced (Event #1)]	√	√	√			

Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	EPS [Motor Driven Power Steering (TRW R - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	EPS [Motor Driven Power Steering (Mando R - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	EPS [Motor Driven Power Steering (Mando C - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	BCM [Body Control Module]	√	√	√	√	√	0109, 0121
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	ECALL [e - Call]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	G 1.6 T-GDI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	AIRBAG [Advanced (Event #2)]	√	√	√			

Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	AIRBAG [Advanced (Event #1)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	EPS [Motor Driven Power Steering (TRW R - Typeo)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	EPS [Motor Driven Power Steering (Mando C - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	BCM [Body Control Module]	√	√	√	√	√	0109, 0121
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	ECALL [e - Call]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	G 2.0 MPI NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0100, 0126
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	AT [Automatic Transaxle]	√	√	√	√		0005, 0099
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	AIRBAG [Advanced (Event #2)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	AIRBAG [Advanced (Event #1)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	EPS [Motor Driven Power Steering (TRW R - Typeo)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	EPS [Motor Driven Power Steering (Mando R - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	EPS [Motor Driven Power Steering (Mando C - Type)]	√	√	√	√		

Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	BCM [Body Control Module]	√	√	√	√	√	0109, 0121
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	SPORTAGE(QLE)	2017	G 2.4 GDI THETA2	ECALL [e - Call]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	AT [Double Clutch Transmission]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	AIRBAG [Advanced (Event #2)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	AIRBAG [Advanced (Event #1)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	4WD [4WD Control]	√	√	√	√	√	0019, 0020

Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	EPS [Motor Driven Power Steering (TRW R - Typeo)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	EPS [Motor Driven Power Steering (Mando R - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	EPS [Motor Driven Power Steering (Mando C - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	BCM [Body Control Module]	√	√	√	√	√	0109, 0121
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	ECALL [e - Call]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	D 1.7 U-II (Low Power)	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	ENGINE [Engine Control]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	AT [Automatic Transaxle]	√	√	√	√		0005, 0099
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	AIRBAG [Advanced (Event #2)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	AIRBAG [Advanced (Event #1)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	4WD [4WD Control]	√	√	√	√	√	0019, 0020

Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	EPS [Motor Driven Power Steering (TRW R - Typeo)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	EPS [Motor Driven Power Steering (Mando R - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	EPS [Motor Driven Power Steering (Mando C - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	BCM [Body Control Module]	√	√	√	√	√	0109, 0121
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	ECALL [e - Call]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	D 2.0 TCI R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	AT [Automatic Transaxle]	√	√	√	√		0005, 0099
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	AIRBAG [Advanced (Event #2)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	AIRBAG [Advanced (Event #1)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	EPS [Motor Driven Power Steering (TRW R - Typeo)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	EPS [Motor Driven Power Steering (Mando R - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	EPS [Motor Driven Power Steering (Mando C - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	TPMS [Tire Pressure Monitoring System]	√	√	√			

Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	BCM [Body Control Module]	√	√	√	√	√	0109, 0121
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	ECALL [e - Call]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	G 1.6 GDI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	AT [Double Clutch Transmission]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	AIRBAG [Advanced (Event #2)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	EPS [Motor Driven Power Steering (TRW R - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	EPS [Motor Driven Power Steering (Mando R - Type)]	√	√	√	√		

Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	EPS [Motor Driven Power Steering (Mando C - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	BCM [Body Control Module]	√	√	√	√	√	0109, 0121
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	ECALL [e - Call]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	G 1.6 T-GDI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	AIRBAG [Advanced (Event #2)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	AIRBAG [Advanced (Event #1)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	EPS [Motor Driven Power Steering (TRW R - Typeo)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	EPS [Motor Driven Power Steering (Mando R - Type)]	√	√	√	√		

Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	EPS [Motor Driven Power Steering (Mando C - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	SPAS [Smart Parking Assist System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	IMMO [Immobilizer]		√	√	√		0072, 0075, 0083, 0092
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	BCM [Body Control Module]	√	√	√	√	√	0109, 0121
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	ECALL [e - Call]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	G 2.0 MPI NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI THETA2	ENGINE [Engine Control]	√	√	√	√	√	0011, 0043, 0094, 0098, 0100, 0126
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI THETA2	AT [Automatic Transaxle]	√	√	√	√		0005, 0099
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI THETA2	AEB [Autonomous Emergency Braking]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI THETA2	ABSESP [Electronic Stability Program]	√	√	√	√	√	0010, 0013, 0051
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI THETA2	AIRBAG [Advanced (Event #2)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI THETA2	AIRBAG [Advanced (Event #1)]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI THETA2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI THETA2	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI THETA2	EPS [Motor Driven Power Steering (TRW R - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI THETA2	EPS [Motor Driven Power Steering (Mando R - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI THETA2	EPS [Motor Driven Power Steering (Mando C - Type)]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI THETA2	TPMS [Tire Pressure Monitoring System]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI THETA2	PGS [Parking Guide System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI THETA2	SPAS [Smart Parking Assist System]	√	√	√	√		

Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI	LDWS [Lane Departure Warning System]	√	√	√	√		
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI	BSD - R [Blind Spot Detection - RH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI	BSD - L [Blind Spot Detection - LH]	√	√	√	√	√	0012
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI	AFLS [Adaptive Front Lighting System]	√	√	√	√	√	0015
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0034, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI	AMP [Amplifier]						0003
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI	WPC [Wireless Power Charger]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI	CLU [Cluster Module]	√	√	√	√	√	
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI	BCM [Body Control Module]	√	√	√	√	√	0109, 0121
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI	PTG [Power Tail Gate]	√	√	√	√		0093
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI	ECALL [e - Call]	√	√	√			
Europe/General	SPORTAGE(QLE)	2016	G 2.4 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2016	D 2.0 TCI-R	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0073
Europe/General	SPORTAGE(SL)	2016	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2016	D 2.0 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2016	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2016	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2016	D 2.0 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2016	D 2.0 TCI-R	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2016	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2016	D 2.0 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2016	D 2.0 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2016	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2016	D 2.0 TCI-R	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	D 2.0 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	D 2.0 TCI-R	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2016	F 2.0 MPI-NU	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SPORTAGE(SL)	2016	F 2.0 MPI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2016	F 2.0 MPI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078

Europe/General	SPORTAGE(SL)	2016	F 2.0 MPI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2016	F 2.0 MPI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	F 2.0 MPI-NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2016	F 2.0 MPI-NU	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2016	F 2.0 MPI-NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2016	F 2.0 MPI-NU	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	F 2.0 MPI-NU	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2016	F 2.0 MPI-NU	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2016	F 2.0 MPI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2016	F 2.0 MPI-NU	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	F 2.0 MPI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	F 2.0 MPI-NU	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	F 2.0 MPI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2016	G 2.0 GDI-NU	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SPORTAGE(SL)	2016	G 2.0 GDI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2016	G 2.0 GDI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2016	G 2.0 GDI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2016	G 2.0 GDI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2016	G 2.0 GDI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	G 2.0 GDI-NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2016	G 2.0 GDI-NU	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2016	G 2.0 GDI-NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2016	G 2.0 GDI-NU	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	G 2.0 GDI-NU	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2016	G 2.0 GDI-NU	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2016	G 2.0 GDI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2016	G 2.0 GDI-NU	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	G 2.0 GDI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	G 2.0 GDI-NU	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	G 2.0 GDI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2016	G 2.0 MPI-NU	ENGINE [Leaded]	√	√	√	√		0011, 0062, 0094, 0098, 0126
Europe/General	SPORTAGE(SL)	2016	G 2.0 MPI-NU	ENGINE [Unleaded]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SPORTAGE(SL)	2016	G 2.0 MPI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2016	G 2.0 MPI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2016	G 2.0 MPI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2016	G 2.0 MPI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2016	G 2.0 MPI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	G 2.0 MPI-NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2016	G 2.0 MPI-NU	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2016	G 2.0 MPI-NU	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	G 2.0 MPI-NU	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2016	G 2.0 MPI-NU	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2016	G 2.0 MPI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2016	G 2.0 MPI-NU	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	G 2.0 MPI-NU	SJB [Smart Junction Block]	√	√	√	√	√	

Europe/General	SPORTAGE(SL)	2016	G 2.0 MPI-NU	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	G 2.0 MPI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2016	G 2.4 MPI-THETA II	ENGINE [Leaded]	√	√	√	√		0011, 0062, 0094, 0098, 0126
Europe/General	SPORTAGE(SL)	2016	G 2.4 MPI-THETA II	ENGINE [Unleaded]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SPORTAGE(SL)	2016	G 2.4 MPI-THETA II	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2016	G 2.4 MPI-THETA II	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2016	G 2.4 MPI-THETA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2016	G 2.4 MPI-THETA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2016	G 2.4 MPI-THETA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	G 2.4 MPI-THETA II	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2016	G 2.4 MPI-THETA II	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2016	G 2.4 MPI-THETA II	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2016	G 2.4 MPI-THETA II	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	G 2.4 MPI-THETA II	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2016	G 2.4 MPI-THETA II	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2016	G 2.4 MPI-THETA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2016	G 2.4 MPI-THETA II	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	G 2.4 MPI-THETA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2016	G 2.4 MPI-THETA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2015	D 2.0 TCI-R	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0073
Europe/General	SPORTAGE(SL)	2015	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2015	D 2.0 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2015	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2015	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2015	D 2.0 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2015	D 2.0 TCI-R	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2015	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2015	D 2.0 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2015	D 2.0 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112

Europe/General	SPORTAGE(SL)	2015	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2015	D 2.0 TCI-R	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	D 2.0 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	D 2.0 TCI-R	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2015	F 2.0 MPI-NU	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SPORTAGE(SL)	2015	F 2.0 MPI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2015	F 2.0 MPI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2015	F 2.0 MPI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2015	F 2.0 MPI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2015	F 2.0 MPI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	F 2.0 MPI-NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2015	F 2.0 MPI-NU	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2015	F 2.0 MPI-NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2015	F 2.0 MPI-NU	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	F 2.0 MPI-NU	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2015	F 2.0 MPI-NU	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2015	F 2.0 MPI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2015	F 2.0 MPI-NU	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	F 2.0 MPI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	F 2.0 MPI-NU	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	F 2.0 MPI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2015	G 2.0 GDI-NU	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SPORTAGE(SL)	2015	G 2.0 GDI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2015	G 2.0 GDI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2015	G 2.0 GDI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2015	G 2.0 GDI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	G 2.0 GDI-NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2015	G 2.0 GDI-NU	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2015	G 2.0 GDI-NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2015	G 2.0 GDI-NU	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	G 2.0 GDI-NU	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2015	G 2.0 GDI-NU	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2015	G 2.0 GDI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2015	G 2.0 GDI-NU	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	G 2.0 GDI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	G 2.0 GDI-NU	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	G 2.0 GDI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2015	G 2.0 MPI-NU	ENGINE [Leaded]	√	√	√	√		0011, 0062, 0094, 0098, 0126
Europe/General	SPORTAGE(SL)	2015	G 2.0 MPI-NU	ENGINE [Unleaded]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SPORTAGE(SL)	2015	G 2.0 MPI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2015	G 2.0 MPI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2015	G 2.0 MPI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2015	G 2.0 MPI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2015	G 2.0 MPI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	SPORTAGE(SL)	2015	G 2.0 MPI-NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2015	G 2.0 MPI-NU	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2015	G 2.0 MPI-NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2015	G 2.0 MPI-NU	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	G 2.0 MPI-NU	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2015	G 2.0 MPI-NU	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2015	G 2.0 MPI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2015	G 2.0 MPI-NU	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	G 2.0 MPI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	G 2.0 MPI-NU	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	G 2.0 MPI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2015	G 2.4 MPI-THETA II	ENGINE [Leaded]	√	√	√	√		0011, 0062, 0094, 0098, 0126
Europe/General	SPORTAGE(SL)	2015	G 2.4 MPI-THETA II	ENGINE [Unleaded]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SPORTAGE(SL)	2015	G 2.4 MPI-THETA II	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2015	G 2.4 MPI-THETA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2015	G 2.4 MPI-THETA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2015	G 2.4 MPI-THETA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	G 2.4 MPI-THETA II	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2015	G 2.4 MPI-THETA II	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2015	G 2.4 MPI-THETA II	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2015	G 2.4 MPI-THETA II	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	G 2.4 MPI-THETA II	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2015	G 2.4 MPI-THETA II	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2015	G 2.4 MPI-THETA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2015	G 2.4 MPI-THETA II	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	G 2.4 MPI-THETA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	G 2.4 MPI-THETA II	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2015	G 2.4 MPI-THETA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2014	D 2.0 TCI-R	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0073
Europe/General	SPORTAGE(SL)	2014	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2014	D 2.0 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078

Europe/General	SPORTAGE(SL)	2014	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2014	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2014	D 2.0 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2014	D 2.0 TCI-R	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2014	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2014	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2014	D 2.0 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2014	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2014	D 2.0 TCI-R	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	D 2.0 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	D 2.0 TCI-R	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2014	F 2.0 MPI-NU	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SPORTAGE(SL)	2014	F 2.0 MPI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2014	F 2.0 MPI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2014	F 2.0 MPI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2014	F 2.0 MPI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2014	F 2.0 MPI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	F 2.0 MPI-NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2014	F 2.0 MPI-NU	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2014	F 2.0 MPI-NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2014	F 2.0 MPI-NU	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	F 2.0 MPI-NU	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2014	F 2.0 MPI-NU	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2014	F 2.0 MPI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2014	F 2.0 MPI-NU	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	F 2.0 MPI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	F 2.0 MPI-NU	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	F 2.0 MPI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2014	G 2.0 GDI-NU	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SPORTAGE(SL)	2014	G 2.0 GDI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2014	G 2.0 GDI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2014	G 2.0 GDI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2014	G 2.0 GDI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2014	G 2.0 GDI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	G 2.0 GDI-NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2014	G 2.0 GDI-NU	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2014	G 2.0 GDI-NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2014	G 2.0 GDI-NU	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	G 2.0 GDI-NU	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2014	G 2.0 GDI-NU	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2014	G 2.0 GDI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2014	G 2.0 GDI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	G 2.0 GDI-NU	BCM [Body Control Module (EURO)]	√	√	√	√	√	

Europe/General	SPORTAGE(SL)	2014	G 2.0 GDI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI THETA II	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI THETA II	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0043, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI THETA II	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI THETA II	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI THETA II	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI THETA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI THETA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI THETA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI THETA II	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI THETA II	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI THETA II	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI THETA II	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI THETA II	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI THETA II	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI THETA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI THETA II	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI THETA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI THETA II	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI THETA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI-NU	ENGINE [Unleaded]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI-NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI-NU	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI-NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	

Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI-NU	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI-NU	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	0074
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI-NU	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI-NU	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI-NU	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	G 2.0 MPI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2014	G 2.4 MPI-THETA II	ENGINE [Unleaded]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SPORTAGE(SL)	2014	G 2.4 MPI-THETA II	ENGINE [Leaded]	√	√	√	√		0011, 0062, 0094, 0098, 0126
Europe/General	SPORTAGE(SL)	2014	G 2.4 MPI-THETA II	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2014	G 2.4 MPI-THETA II	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2014	G 2.4 MPI-THETA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2014	G 2.4 MPI-THETA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2014	G 2.4 MPI-THETA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	G 2.4 MPI-THETA II	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2014	G 2.4 MPI-THETA II	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2014	G 2.4 MPI-THETA II	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2014	G 2.4 MPI-THETA II	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	G 2.4 MPI-THETA II	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2014	G 2.4 MPI-THETA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2014	G 2.4 MPI-THETA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	G 2.4 MPI-THETA II	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2014	G 2.4 MPI-THETA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2013	D 1.7 TCI-U2	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	D 1.7 TCI-U2	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	D 1.7 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2013	D 1.7 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2013	D 1.7 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2013	D 1.7 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	D 1.7 TCI-U2	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2013	D 1.7 TCI-U2	EPS [Power Steering]	√	√	√	√		

Europe/General	SPORTAGE(SL)	2013	D 1.7 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	D 1.7 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2013	D 1.7 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2013	D 1.7 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2013	D 1.7 TCI-U2	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	D 1.7 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	D 1.7 TCI-U2	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	D 1.7 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2013	D 2.0 TCI-R	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	0048, 0073
Europe/General	SPORTAGE(SL)	2013	D 2.0 TCI-R	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	0048, 0073
Europe/General	SPORTAGE(SL)	2013	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2013	D 2.0 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2013	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2013	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2013	D 2.0 TCI-R	AIRCON [Air Conditioner (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	D 2.0 TCI-R	AIRCON [Air Conditioner (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2013	D 2.0 TCI-R	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2013	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2013	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2013	D 2.0 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2013	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2013	D 2.0 TCI-R	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	D 2.0 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	D 2.0 TCI-R	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2013	F 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√		0126, 0011, 0094, 0098
Europe/General	SPORTAGE(SL)	2013	F 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2013	F 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2013	F 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2013	F 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2013	F 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	F 2.0 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2013	F 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2013	F 2.0 DOHC	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	F 2.0 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2013	F 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2013	F 2.0 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2013	F 2.0 DOHC	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	F 2.0 DOHC	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	F 2.0 DOHC	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	F 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2013	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SPORTAGE(SL)	2013	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099

Europe/General	SPORTAGE(SL)	2013	G 1.6 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2013	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2013	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2013	G 1.6 GDI	AIRCON [Air Conditioner (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	G 1.6 GDI	AIRCON [Air Conditioner (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	G 1.6 GDI	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2013	G 1.6 GDI	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2013	G 1.6 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2013	G 1.6 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	G 1.6 GDI	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2013	G 1.6 GDI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2013	G 1.6 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2013	G 1.6 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	G 1.6 GDI	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2013	G 2.0 MPI THETA II	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2013	G 2.0 MPI THETA II	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0043, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2013	G 2.0 MPI THETA II	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2013	G 2.0 MPI THETA II	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2013	G 2.0 MPI THETA II	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2013	G 2.0 MPI THETA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2013	G 2.0 MPI THETA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2013	G 2.0 MPI THETA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	G 2.0 MPI THETA II	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2013	G 2.0 MPI THETA II	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2013	G 2.0 MPI THETA II	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2013	G 2.0 MPI THETA II	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	G 2.0 MPI THETA II	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2013	G 2.0 MPI THETA II	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2013	G 2.0 MPI THETA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2013	G 2.0 MPI THETA II	BCM [Body Control Module (GEN)]	√	√	√	√	√	

Europe/General	SPORTAGE(SL)	2013	G 2.0 MPI THETA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	G 2.0 MPI THETA II	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	G 2.0 MPI THETA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2013	G 2.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0043, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2013	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2013	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2013	G 2.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2013	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2013	G 2.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2013	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	G 2.4 DOHC	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2013	G 2.4 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2013	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2013	G 2.4 DOHC	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	G 2.4 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2013	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2013	G 2.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2013	G 2.4 DOHC	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	G 2.4 DOHC	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	G 2.4 DOHC	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2013	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2012	D 1.7 TCI-U2	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	D 1.7 TCI-U2	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	D 1.7 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2012	D 1.7 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2012	D 1.7 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2012	D 1.7 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	D 1.7 TCI-U2	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2012	D 1.7 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2012	D 1.7 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2012	D 1.7 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2012	D 1.7 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2012	D 1.7 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2012	D 1.7 TCI-U2	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	D 1.7 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	D 1.7 TCI-U2	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	D 1.7 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2012	D 2.0 TCI-R	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	0048, 0073
Europe/General	SPORTAGE(SL)	2012	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2012	D 2.0 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078

Europe/General	SPORTAGE(SL)	2012	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2012	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2012	D 2.0 TCI-R	AIRCON [Air Conditioner (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	D 2.0 TCI-R	AIRCON [Air Conditioner (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2012	D 2.0 TCI-R	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2012	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2012	D 2.0 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2012	D 2.0 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2012	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2012	D 2.0 TCI-R	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	D 2.0 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	D 2.0 TCI-R	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2012	F 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√		0126, 0011, 0094, 0098
Europe/General	SPORTAGE(SL)	2012	F 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2012	F 2.0 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2012	F 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2012	F 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2012	F 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	F 2.0 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2012	F 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2012	F 2.0 DOHC	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	F 2.0 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2012	F 2.0 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2012	F 2.0 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2012	F 2.0 DOHC	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	F 2.0 DOHC	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	F 2.0 DOHC	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	F 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2012	G 1.6 GDI GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SPORTAGE(SL)	2012	G 1.6 GDI GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2012	G 1.6 GDI GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2012	G 1.6 GDI GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2012	G 1.6 GDI GAMMA	AIRCON [Air Conditioner (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	G 1.6 GDI GAMMA	AIRCON [Air Conditioner (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	G 1.6 GDI GAMMA	4WD [4WD Control]	√	√	√	√	√	0019, 0020

Europe/General	SPORTAGE(SL)	2012	G 1.6 GDI GAMMA	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2012	G 1.6 GDI GAMMA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2012	G 1.6 GDI GAMMA	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	G 1.6 GDI GAMMA	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2012	G 1.6 GDI GAMMA	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2012	G 1.6 GDI GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2012	G 1.6 GDI GAMMA	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	G 1.6 GDI GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	G 1.6 GDI GAMMA	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	G 1.6 GDI GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2012	G 2.0 MPI THETA II	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2012	G 2.0 MPI THETA II	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0043, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2012	G 2.0 MPI THETA II	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2012	G 2.0 MPI THETA II	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2012	G 2.0 MPI THETA II	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2012	G 2.0 MPI THETA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2012	G 2.0 MPI THETA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	G 2.0 MPI THETA II	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2012	G 2.0 MPI THETA II	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2012	G 2.0 MPI THETA II	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2012	G 2.0 MPI THETA II	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	G 2.0 MPI THETA II	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2012	G 2.0 MPI THETA II	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2012	G 2.0 MPI THETA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102

Europe/General	SPORTAGE(SL)	2012	G 2.0 MPI THETA II	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	G 2.0 MPI THETA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	G 2.0 MPI THETA II	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	G 2.0 MPI THETA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2012	G 2.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2012	G 2.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0043, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2012	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2012	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2012	G 2.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2012	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2012	G 2.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2012	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	G 2.4 DOHC	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2012	G 2.4 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2012	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2012	G 2.4 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2012	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2012	G 2.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2012	G 2.4 DOHC	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	G 2.4 DOHC	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	G 2.4 DOHC	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2012	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2011	D 1.7 TCI-U2	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	D 1.7 TCI-U2	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	D 1.7 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2011	D 1.7 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2011	D 1.7 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2011	D 1.7 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	D 1.7 TCI-U2	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2011	D 1.7 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2011	D 1.7 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2011	D 1.7 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2011	D 1.7 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2011	D 1.7 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2011	D 1.7 TCI-U2	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	D 1.7 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	D 1.7 TCI-U2	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	D 1.7 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2011	D 2.0 TCI-R	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	0048, 0073

Europe/General	SPORTAGE(SL)	2011	D 2.0 TCI-R	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	0048, 0073
Europe/General	SPORTAGE(SL)	2011	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2011	D 2.0 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2011	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2011	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2011	D 2.0 TCI-R	AIRCON [Air Conditioner (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	D 2.0 TCI-R	AIRCON [Air Conditioner (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2011	D 2.0 TCI-R	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2011	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2011	D 2.0 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2011	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2011	D 2.0 TCI-R	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	D 2.0 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	D 2.0 TCI-R	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2011	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SPORTAGE(SL)	2011	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2011	G 1.6 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2011	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2011	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2011	G 1.6 GDI	AIRCON [Air Conditioner (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	G 1.6 GDI	AIRCON [Air Conditioner (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	G 1.6 GDI	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2011	G 1.6 GDI	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2011	G 1.6 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2011	G 1.6 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	G 1.6 GDI	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2011	G 1.6 GDI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2011	G 1.6 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2011	G 1.6 GDI	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	G 1.6 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	G 1.6 GDI	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2011	G 2.0 MPI THETA II	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2011	G 2.0 MPI THETA II	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0043, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2011	G 2.0 MPI THETA II	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2011	G 2.0 MPI THETA II	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2011	G 2.0 MPI THETA II	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078

Europe/General	SPORTAGE(SL)	2011	G 2.0 MPI THETA II	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2011	G 2.0 MPI THETA II	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2011	G 2.0 MPI THETA II	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	G 2.0 MPI THETA II	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2011	G 2.0 MPI THETA II	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2011	G 2.0 MPI THETA II	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	G 2.0 MPI THETA II	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2011	G 2.0 MPI THETA II	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2011	G 2.0 MPI THETA II	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2011	G 2.0 MPI THETA II	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	G 2.0 MPI THETA II	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	G 2.0 MPI THETA II	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	G 2.0 MPI THETA II	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SL)	2011	G 2.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2011	G 2.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0043, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2011	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SL)	2011	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SL)	2011	G 2.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SL)	2011	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SL)	2011	G 2.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SL)	2011	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	G 2.4 DOHC	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SL)	2011	G 2.4 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SL)	2011	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SL)	2011	G 2.4 DOHC	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	G 2.4 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SL)	2011	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SL)	2011	G 2.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SL)	2011	G 2.4 DOHC	BCM [Body Control Module (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	G 2.4 DOHC	BCM [Body Control Module (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SL)	2011	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2016	D 1.7 TCI-U2	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126

Europe/General	SPORTAGE(SLE)	2016	D 1.7 TCI-U2	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	SPORTAGE(SLE)	2016	D 1.7 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2016	D 1.7 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2016	D 1.7 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2016	D 1.7 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2016	D 1.7 TCI-U2	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2016	D 1.7 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2016	D 1.7 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2016	D 1.7 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2016	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2016	D 1.7 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2016	D 1.7 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2016	D 1.7 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2016	D 1.7 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2016	D 1.7 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2016	D 2.0 TCI-R	ENGINE [Engine Control (Low Power)]	√	√	√	√	√	0048, 0073
Europe/General	SPORTAGE(SLE)	2016	D 2.0 TCI-R	ENGINE [Engine Control (High Power)]	√	√	√	√	√	0029, 0048, 0073
Europe/General	SPORTAGE(SLE)	2016	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2016	D 2.0 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2016	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2016	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2016	D 2.0 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2016	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2016	D 2.0 TCI-R	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2016	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2016	D 2.0 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2016	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2016	D 2.0 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2016	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2016	D 2.0 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2016	D 2.0 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2016	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2016	G 1.6 GDI-GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2016	G 1.6 GDI-GAMMA	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2016	G 1.6 GDI-GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2016	G 1.6 GDI-GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2016	G 1.6 GDI-GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2016	G 1.6 GDI-GAMMA	4WD [4WD Control]	√	√	√	√	√	0019, 0020

Europe/General	SPORTAGE(SLE)	2016	G 1.6 GDI-GAMMA	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2016	G 1.6 GDI-GAMMA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2016	G 1.6 GDI-GAMMA	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2016	G 1.6 GDI-GAMMA	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2016	G 1.6 GDI-GAMMA	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2016	G 1.6 GDI-GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2016	G 1.6 GDI-GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2016	G 1.6 GDI-GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2016	G 1.6 GDI-GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2016	G 2.0 GDI-NU	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SPORTAGE(SLE)	2016	G 2.0 GDI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2016	G 2.0 GDI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2016	G 2.0 GDI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2016	G 2.0 GDI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2016	G 2.0 GDI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2016	G 2.0 GDI-NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2016	G 2.0 GDI-NU	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2016	G 2.0 GDI-NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2016	G 2.0 GDI-NU	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2016	G 2.0 GDI-NU	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2016	G 2.0 GDI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2016	G 2.0 GDI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2016	G 2.0 GDI-NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2016	G 2.0 GDI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2016	G 2.0 MPI-NU	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SPORTAGE(SLE)	2016	G 2.0 MPI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2016	G 2.0 MPI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2016	G 2.0 MPI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2016	G 2.0 MPI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2016	G 2.0 MPI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2016	G 2.0 MPI-NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2016	G 2.0 MPI-NU	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2016	G 2.0 MPI-NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2016	G 2.0 MPI-NU	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2016	G 2.0 MPI-NU	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2016	G 2.0 MPI-NU	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2016	G 2.0 MPI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102

Europe/General	SPORTAGE(SLE)	2016	G 2.0 MPI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2016	G 2.0 MPI-NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2016	G 2.0 MPI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2015	D 1.7 TCI-U2	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	SPORTAGE(SLE)	2015	D 1.7 TCI-U2	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	SPORTAGE(SLE)	2015	D 1.7 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2015	D 1.7 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2015	D 1.7 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2015	D 1.7 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	D 1.7 TCI-U2	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2015	D 1.7 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2015	D 1.7 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2015	D 1.7 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2015	D 1.7 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2015	D 1.7 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2015	D 1.7 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	D 1.7 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	D 2.0 TCI-R	ENGINE [Engine Control (Low Power)]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	D 2.0 TCI-R	ENGINE [Engine Control (High Power)]	√	√	√	√	√	0029, 0048, 0073
Europe/General	SPORTAGE(SLE)	2015	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2015	D 2.0 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2015	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2015	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2015	D 2.0 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2015	D 2.0 TCI-R	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2015	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2015	D 2.0 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2015	D 2.0 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2015	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2015	D 2.0 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	D 2.0 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2015	G 1.6 GDI-GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SPORTAGE(SLE)	2015	G 1.6 GDI-GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2015	G 1.6 GDI-GAMMA	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2015	G 1.6 GDI-GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			

Europe/General	SPORTAGE(SLE)	2015	G 1.6 GDI-GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2015	G 1.6 GDI-GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	G 1.6 GDI-GAMMA	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2015	G 1.6 GDI-GAMMA	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2015	G 1.6 GDI-GAMMA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2015	G 1.6 GDI-GAMMA	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	G 1.6 GDI-GAMMA	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2015	G 1.6 GDI-GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2015	G 1.6 GDI-GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	G 1.6 GDI-GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	G 1.6 GDI-GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2015	G 2.0 GDI-NU	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SPORTAGE(SLE)	2015	G 2.0 GDI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2015	G 2.0 GDI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2015	G 2.0 GDI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2015	G 2.0 GDI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2015	G 2.0 GDI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	G 2.0 GDI-NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2015	G 2.0 GDI-NU	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2015	G 2.0 GDI-NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2015	G 2.0 GDI-NU	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	G 2.0 GDI-NU	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2015	G 2.0 GDI-NU	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2015	G 2.0 GDI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2015	G 2.0 GDI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	G 2.0 GDI-NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	G 2.0 GDI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2015	G 2.0 MPI-NU	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SPORTAGE(SLE)	2015	G 2.0 MPI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2015	G 2.0 MPI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2015	G 2.0 MPI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2015	G 2.0 MPI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2015	G 2.0 MPI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	G 2.0 MPI-NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2015	G 2.0 MPI-NU	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2015	G 2.0 MPI-NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	

Europe/General	SPORTAGE(SLE)	2015	G 2.0 MPI-NU	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	G 2.0 MPI-NU	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2015	G 2.0 MPI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2015	G 2.0 MPI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	G 2.0 MPI-NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2015	G 2.0 MPI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2014	D 1.7 TCI-U2	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	D 1.7 TCI-U2	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	D 1.7 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2014	D 1.7 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2014	D 1.7 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2014	D 1.7 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	D 1.7 TCI-U2	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2014	D 1.7 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2014	D 1.7 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2014	D 1.7 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2014	D 1.7 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2014	D 1.7 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2014	D 1.7 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	D 1.7 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	D 1.7 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2014	D 2.0 TCI-R	ENGINE [Engine Control (Low Power)]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	D 2.0 TCI-R	ENGINE [Engine Control (High Power)]	√	√	√	√	√	0029, 0048, 0073
Europe/General	SPORTAGE(SLE)	2014	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2014	D 2.0 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2014	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2014	D 2.0 TCI-R	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2014	D 2.0 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	D 2.0 TCI-R	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2014	D 2.0 TCI-R	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2014	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2014	D 2.0 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2014	D 2.0 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2014	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2014	D 2.0 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	D 2.0 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	G 1.6 GDI-GAMMA	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SPORTAGE(SLE)	2014	G 1.6 GDI-GAMMA	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2014	G 1.6 GDI-GAMMA	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078

Europe/General	SPORTAGE(SLE)	2014	G 1.6 GDI-GAMMA	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2014	G 1.6 GDI-GAMMA	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2014	G 1.6 GDI-GAMMA	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	G 1.6 GDI-GAMMA	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2014	G 1.6 GDI-GAMMA	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2014	G 1.6 GDI-GAMMA	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2014	G 1.6 GDI-GAMMA	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	G 1.6 GDI-GAMMA	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2014	G 1.6 GDI-GAMMA	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2014	G 1.6 GDI-GAMMA	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2014	G 1.6 GDI-GAMMA	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	G 1.6 GDI-GAMMA	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	G 1.6 GDI-GAMMA	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2014	G 2.0 GDI-NU	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SPORTAGE(SLE)	2014	G 2.0 GDI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2014	G 2.0 GDI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2014	G 2.0 GDI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2014	G 2.0 GDI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2014	G 2.0 GDI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	G 2.0 GDI-NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2014	G 2.0 GDI-NU	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2014	G 2.0 GDI-NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2014	G 2.0 GDI-NU	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2014	G 2.0 GDI-NU	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2014	G 2.0 GDI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2014	G 2.0 GDI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	G 2.0 GDI-NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	G 2.0 GDI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI THETA 2	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI THETA 2	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0043, 0126, 0094, 0098
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI THETA 2	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0126, 0094, 0098

Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI THETA 2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI THETA 2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI THETA 2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI THETA 2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI THETA 2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI THETA 2	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI THETA 2	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI THETA 2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI THETA 2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI THETA 2	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI THETA 2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI THETA 2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI THETA 2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI THETA 2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI-NU	ENGINE [Engine Control]	√	√	√	√		0011, 0094, 0098, 0126
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI-NU	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI-NU	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI-NU	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI-NU	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI-NU	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI-NU	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI-NU	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI-NU	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI-NU	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI-NU	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI-NU	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI-NU	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI-NU	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI-NU	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2014	G 2.0 MPI-NU	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2013	D 1.7 TCI-U2	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	D 1.7 TCI-U2	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	D 1.7 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078

Europe/General	SPORTAGE(SLE)	2013	D 1.7 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2013	D 1.7 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2013	D 1.7 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	D 1.7 TCI-U2	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2013	D 1.7 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2013	D 1.7 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2013	D 1.7 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2013	D 1.7 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2013	D 1.7 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2013	D 1.7 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	D 1.7 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	D 1.7 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2013	D 2.0 TCI-R	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	0048, 0073
Europe/General	SPORTAGE(SLE)	2013	D 2.0 TCI-R	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	0048, 0073
Europe/General	SPORTAGE(SLE)	2013	D 2.0 TCI-R	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2013	D 2.0 TCI-R	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2013	D 2.0 TCI-R	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2013	D 2.0 TCI-R	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	D 2.0 TCI-R	4WD [4WD]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2013	D 2.0 TCI-R	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2013	D 2.0 TCI-R	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2013	D 2.0 TCI-R	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	D 2.0 TCI-R	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2013	D 2.0 TCI-R	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2013	D 2.0 TCI-R	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2013	D 2.0 TCI-R	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	D 2.0 TCI-R	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	D 2.0 TCI-R	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2013	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SPORTAGE(SLE)	2013	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2013	G 1.6 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2013	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2013	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2013	G 1.6 GDI	AIRCON [Air Conditioner (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	G 1.6 GDI	AIRCON [Air Conditioner (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	G 1.6 GDI	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2013	G 1.6 GDI	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2013	G 1.6 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2013	G 1.6 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	G 1.6 GDI	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2013	G 1.6 GDI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2013	G 1.6 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2013	G 1.6 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	G 1.6 GDI	BCM [Body Control Module]	√	√	√	√	√	

Europe/General	SPORTAGE(SLE)	2013	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2013	G 2.0 MPI THETA 2	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SLE)	2013	G 2.0 MPI THETA 2	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0043, 0126, 0094, 0098
Europe/General	SPORTAGE(SLE)	2013	G 2.0 MPI THETA 2	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SLE)	2013	G 2.0 MPI THETA 2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2013	G 2.0 MPI THETA 2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2013	G 2.0 MPI THETA 2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2013	G 2.0 MPI THETA 2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	G 2.0 MPI THETA 2	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2013	G 2.0 MPI THETA 2	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2013	G 2.0 MPI THETA 2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2013	G 2.0 MPI THETA 2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	G 2.0 MPI THETA 2	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2013	G 2.0 MPI THETA 2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2013	G 2.0 MPI THETA 2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2013	G 2.0 MPI THETA 2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	G 2.0 MPI THETA 2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	G 2.0 MPI THETA 2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2013	G 2.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SLE)	2013	G 2.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0043, 0126, 0094, 0098
Europe/General	SPORTAGE(SLE)	2013	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SLE)	2013	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2013	G 2.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2013	G 2.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2013	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2013	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	G 2.4 DOHC	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2013	G 2.4 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2013	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	

Europe/General	SPORTAGE(SLE)	2013	G 2.4 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2013	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2013	G 2.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2013	G 2.4 DOHC	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	G 2.4 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2013	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2012	D 1.7 TCI-U2	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	D 1.7 TCI-U2	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	D 1.7 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2012	D 1.7 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2012	D 1.7 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2012	D 1.7 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	D 1.7 TCI-U2	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2012	D 1.7 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2012	D 1.7 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2012	D 1.7 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2012	D 1.7 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2012	D 1.7 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2012	D 1.7 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	D 1.7 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	D 1.7 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2012	D 2.0 TCI-R(Low Power)	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	0048, 0073
Europe/General	SPORTAGE(SLE)	2012	D 2.0 TCI-R(Low Power)	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	0048, 0073
Europe/General	SPORTAGE(SLE)	2012	D 2.0 TCI-R(Low Power)	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2012	D 2.0 TCI-R(Low Power)	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2012	D 2.0 TCI-R(Low Power)	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2012	D 2.0 TCI-R(Low Power)	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2012	D 2.0 TCI-R(Low Power)	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	D 2.0 TCI-R(Low Power)	4WD [4WD]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2012	D 2.0 TCI-R(Low Power)	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2012	D 2.0 TCI-R(Low Power)	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	D 2.0 TCI-R(Low Power)	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2012	D 2.0 TCI-R(Low Power)	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112

Europe/General	SPORTAGE(SLE)	2012	D 2.0 TCI-R(Low Power)	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2012	D 2.0 TCI-R(Low Power)	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	D 2.0 TCI-R(Low Power)	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	D 2.0 TCI-R(Low Power)	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2012	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SPORTAGE(SLE)	2012	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2012	G 1.6 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2012	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2012	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2012	G 1.6 GDI	AIRCON [Air Conditioner (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	G 1.6 GDI	AIRCON [Air Conditioner (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	G 1.6 GDI	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2012	G 1.6 GDI	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2012	G 1.6 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2012	G 1.6 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	G 1.6 GDI	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2012	G 1.6 GDI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2012	G 1.6 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2012	G 1.6 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	G 1.6 GDI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2012	G 2.0 MPI THETA 2	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SLE)	2012	G 2.0 MPI THETA 2	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0043, 0126, 0094, 0098
Europe/General	SPORTAGE(SLE)	2012	G 2.0 MPI THETA 2	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SLE)	2012	G 2.0 MPI THETA 2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2012	G 2.0 MPI THETA 2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2012	G 2.0 MPI THETA 2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2012	G 2.0 MPI THETA 2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	G 2.0 MPI THETA 2	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2012	G 2.0 MPI THETA 2	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2012	G 2.0 MPI THETA 2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2012	G 2.0 MPI THETA 2	SPAS [Smart Parking Assist System]	√	√	√	√	√	

Europe/General	SPORTAGE(SLE)	2012	G 2.0 MPI THETA 2	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2012	G 2.0 MPI THETA 2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2012	G 2.0 MPI THETA 2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2012	G 2.0 MPI THETA 2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	G 2.0 MPI THETA 2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	G 2.0 MPI THETA 2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2012	G 2.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SLE)	2012	G 2.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0043, 0126, 0094, 0098
Europe/General	SPORTAGE(SLE)	2012	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SLE)	2012	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2012	G 2.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2012	G 2.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2012	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2012	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	G 2.4 DOHC	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2012	G 2.4 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2012	G 2.4 DOHC	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	G 2.4 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2012	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2012	G 2.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2012	G 2.4 DOHC	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	G 2.4 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2012	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2011	D 1.7 TCI-U2	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	D 1.7 TCI-U2	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	D 1.7 TCI-U2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2011	D 1.7 TCI-U2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2011	D 1.7 TCI-U2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2011	D 1.7 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	D 1.7 TCI-U2	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2011	D 1.7 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2011	D 1.7 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2011	D 1.7 TCI-U2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	D 1.7 TCI-U2	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2011	D 1.7 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2011	D 1.7 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2011	D 1.7 TCI-U2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	D 1.7 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	

Europe/General	SPORTAGE(SLE)	2011	D 1.7 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2011	D 2.0 TCI-R(Low Power)	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	0048, 0073
Europe/General	SPORTAGE(SLE)	2011	D 2.0 TCI-R(Low Power)	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	0048, 0073
Europe/General	SPORTAGE(SLE)	2011	D 2.0 TCI-R(Low Power)	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2011	D 2.0 TCI-R(Low Power)	ESP [ESP (Mando)]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2011	D 2.0 TCI-R(Low Power)	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2011	D 2.0 TCI-R(Low Power)	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2011	D 2.0 TCI-R(Low Power)	AIRCON [Air Conditioner (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	D 2.0 TCI-R(Low Power)	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2011	D 2.0 TCI-R(Low Power)	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2011	D 2.0 TCI-R(Low Power)	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2011	D 2.0 TCI-R(Low Power)	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	D 2.0 TCI-R(Low Power)	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2011	D 2.0 TCI-R(Low Power)	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2011	D 2.0 TCI-R(Low Power)	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2011	D 2.0 TCI-R(Low Power)	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	D 2.0 TCI-R(Low Power)	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	D 2.0 TCI-R(Low Power)	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2011	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	SPORTAGE(SLE)	2011	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2011	G 1.6 GDI	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2011	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2011	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2011	G 1.6 GDI	AIRCON [Air Conditioner (EURO)]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	G 1.6 GDI	AIRCON [Air Conditioner (GEN)]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	G 1.6 GDI	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2011	G 1.6 GDI	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2011	G 1.6 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2011	G 1.6 GDI	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	G 1.6 GDI	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2011	G 1.6 GDI	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112

Europe/General	SPORTAGE(SLE)	2011	G 1.6 GDI	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2011	G 1.6 GDI	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	G 1.6 GDI	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2011	G 2.0 MPI THETA 2	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SLE)	2011	G 2.0 MPI THETA 2	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SLE)	2011	G 2.0 MPI THETA 2	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2011	G 2.0 MPI THETA 2	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2011	G 2.0 MPI THETA 2	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2011	G 2.0 MPI THETA 2	AIRBAG [Airbag (Event #1)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2011	G 2.0 MPI THETA 2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	G 2.0 MPI THETA 2	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2011	G 2.0 MPI THETA 2	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2011	G 2.0 MPI THETA 2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2011	G 2.0 MPI THETA 2	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	G 2.0 MPI THETA 2	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2011	G 2.0 MPI THETA 2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2011	G 2.0 MPI THETA 2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2011	G 2.0 MPI THETA 2	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	G 2.0 MPI THETA 2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	G 2.0 MPI THETA 2	CODE [Transmitter Code Saving]				√		0022
Europe/General	SPORTAGE(SLE)	2011	G 2.4 DOHC	ENGINE [Unleaded EOBD]	√	√	√	√	√	0126, 0011, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SLE)	2011	G 2.4 DOHC	ENGINE [Unleaded GEN]	√	√	√	√	√	0126, 0011, 0043, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SLE)	2011	G 2.4 DOHC	ENGINE [Leaded All]	√	√	√	√	√	0126, 0062, 0011, 0011, 0126, 0094, 0098
Europe/General	SPORTAGE(SLE)	2011	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	SPORTAGE(SLE)	2011	G 2.4 DOHC	ESP [Electronic Stability Program]	√	√	√	√	√	0051, 0078
Europe/General	SPORTAGE(SLE)	2011	G 2.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
Europe/General	SPORTAGE(SLE)	2011	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	SPORTAGE(SLE)	2011	G 2.4 DOHC	4WD [4WD Control]	√	√	√	√	√	0019, 0020
Europe/General	SPORTAGE(SLE)	2011	G 2.4 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	SPORTAGE(SLE)	2011	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	SPORTAGE(SLE)	2011	G 2.4 DOHC	SPAS [Smart Parking Assist System]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	G 2.4 DOHC	AHLS [Auto Headlamp Leveling]	√	√	√	√		0074
Europe/General	SPORTAGE(SLE)	2011	G 2.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	SPORTAGE(SLE)	2011	G 2.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	SPORTAGE(SLE)	2011	G 2.4 DOHC	SJB [Smart Junction Block]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	G 2.4 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	SPORTAGE(SLE)	2011	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	TOWNER(HA)	2003	G 0.8 SOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	TOWNER(HA)	2002	G 0.8 SOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	TOWNER(HA)	2001	G 0.8 SOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	TOWNER(HA)	2000	G 0.8 SOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	TOWNER(HA)	1999	G 0.8 SOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	TOWNER(HA)	1998	G 0.8 SOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	TOWNER(HA)	1997	G 0.8 SOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	TOWNER(HA)	1996	G 0.8 SOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	TOWNER(HA)	1995	G 0.8 SOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	TOWNER(HA)	1994	G 0.8 SOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	TOWNER(HA)	1993	G 0.8 SOHC	ENGINE [Engine Control]		√	√	√		
Europe/General	VENGA(YN)	2017	D 1.4 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	VENGA(YN)	2017	D 1.4 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2017	D 1.4 TCI-U2	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2017	D 1.4 TCI-U2	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2017	D 1.4 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2017	D 1.4 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2017	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2017	D 1.4 TCI-U2	IMMO [Immobilizer]				√		
Europe/General	VENGA(YN)	2017	D 1.4 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2017	D 1.4 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2017	D 1.4 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2017	D 1.6 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	VENGA(YN)	2017	D 1.6 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2017	D 1.6 TCI-U2	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2017	D 1.6 TCI-U2	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2017	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2017	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2017	D 1.6 TCI-U2	IMMO [Immobilizer]				√		
Europe/General	VENGA(YN)	2017	D 1.6 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2017	D 1.6 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2017	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2017	G 1.4 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	VENGA(YN)	2017	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2017	G 1.4 DOHC	AIRBAG [Airbag Control (Event #2)]	√	√	√			

Europe/General	VENGA(YN)	2017	G 1.4 DOHC	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2017	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2017	G 1.4 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2017	G 1.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2017	G 1.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2017	G 1.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2017	G 1.4 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2017	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2017	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	VENGA(YN)	2017	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	VENGA(YN)	2017	G 1.6 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2017	G 1.6 DOHC	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2017	G 1.6 DOHC	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2017	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2017	G 1.6 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2017	G 1.6 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2017	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2017	G 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2017	G 1.6 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2017	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2016	D 1.4 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0029, 0048, 0060, 0094, 0126
Europe/General	VENGA(YN)	2016	D 1.4 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2016	D 1.4 TCI-U2	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2016	D 1.4 TCI-U2	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2016	D 1.4 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2016	D 1.4 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2016	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2016	D 1.4 TCI-U2	IMMO [Immobilizer]				√		
Europe/General	VENGA(YN)	2016	D 1.4 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2016	D 1.4 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2016	D 1.4 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2016	D 1.6 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2016	D 1.6 TCI-U2	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2016	D 1.6 TCI-U2	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2016	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2016	D 1.6 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2016	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2016	D 1.6 TCI-U2	IMMO [Immobilizer]				√		
Europe/General	VENGA(YN)	2016	D 1.6 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2016	D 1.6 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2016	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2016	G 1.4 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	VENGA(YN)	2016	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2016	G 1.4 DOHC	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2016	G 1.4 DOHC	AIRBAG [Airbag Control (Event #1)]	√	√	√			

Europe/General	VENGA(YN)	2016	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2016	G 1.4 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2016	G 1.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2016	G 1.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2016	G 1.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2016	G 1.4 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2016	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2016	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	VENGA(YN)	2016	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	VENGA(YN)	2016	G 1.6 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2016	G 1.6 DOHC	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2016	G 1.6 DOHC	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2016	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2016	G 1.6 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2016	G 1.6 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2016	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2016	G 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2016	G 1.6 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2016	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2015	D 1.4 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	VENGA(YN)	2015	D 1.4 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2015	D 1.4 TCI-U2	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2015	D 1.4 TCI-U2	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2015	D 1.4 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2015	D 1.4 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2015	D 1.4 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2015	D 1.4 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2015	D 1.4 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2015	D 1.4 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2015	D 1.6 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	VENGA(YN)	2015	D 1.6 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2015	D 1.6 TCI-U2	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2015	D 1.6 TCI-U2	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2015	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2015	D 1.6 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2015	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2015	D 1.6 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2015	D 1.6 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2015	D 1.6 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2015	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2015	G 1.4 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	VENGA(YN)	2015	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2015	G 1.4 DOHC	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2015	G 1.4 DOHC	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2015	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	VENGA(YN)	2015	G 1.4 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2015	G 1.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2015	G 1.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2015	G 1.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2015	G 1.4 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2015	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2015	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	VENGA(YN)	2015	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	VENGA(YN)	2015	G 1.6 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2015	G 1.6 DOHC	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2015	G 1.6 DOHC	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2015	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2015	G 1.6 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2015	G 1.6 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2015	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2015	G 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2015	G 1.6 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2015	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2014	D 1.4 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	VENGA(YN)	2014	D 1.4 TCI-U2	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2014	D 1.4 TCI-U2	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2014	D 1.4 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2014	D 1.4 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2014	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2014	D 1.4 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2014	D 1.4 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2014	D 1.4 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2014	D 1.4 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2014	D 1.6 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	VENGA(YN)	2014	D 1.6 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2014	D 1.6 TCI-U2	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2014	D 1.6 TCI-U2	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2014	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2014	D 1.6 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2014	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2014	D 1.6 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2014	D 1.6 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2014	D 1.6 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2014	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2014	G 1.4 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	VENGA(YN)	2014	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2014	G 1.4 DOHC	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2014	G 1.4 DOHC	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2014	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2014	G 1.4 DOHC	EPS [Power Steering]	√	√	√	√		

Europe/General	VENGA(YN)	2014	G 1.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√	√	√	
Europe/General	VENGA(YN)	2014	G 1.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2014	G 1.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2014	G 1.4 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2014	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2014	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	VENGA(YN)	2014	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	VENGA(YN)	2014	G 1.6 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2014	G 1.6 DOHC	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2014	G 1.6 DOHC	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2014	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2014	G 1.6 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2014	G 1.6 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2014	G 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2014	G 1.6 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2014	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2013	D 1.4 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	VENGA(YN)	2013	D 1.4 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2013	D 1.4 TCI-U2	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2013	D 1.4 TCI-U2	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2013	D 1.4 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2013	D 1.4 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2013	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2013	D 1.4 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2013	D 1.4 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2013	D 1.4 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2013	D 1.4 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2013	D 1.6 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	VENGA(YN)	2013	D 1.6 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2013	D 1.6 TCI-U2	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2013	D 1.6 TCI-U2	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2013	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2013	D 1.6 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2013	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2013	D 1.6 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2013	D 1.6 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2013	D 1.6 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2013	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2013	G 1.4 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	VENGA(YN)	2013	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2013	G 1.4 DOHC	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2013	G 1.4 DOHC	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2013	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2013	G 1.4 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2013	G 1.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	

Europe/General	VENGA(YN)	2013	G 1.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2013	G 1.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2013	G 1.4 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2013	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2013	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	VENGA(YN)	2013	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	VENGA(YN)	2013	G 1.6 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2013	G 1.6 DOHC	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2013	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2013	G 1.6 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2013	G 1.6 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2013	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2013	G 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2013	G 1.6 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2013	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2012	D 1.4 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	VENGA(YN)	2012	D 1.4 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2012	D 1.4 TCI-U2	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2012	D 1.4 TCI-U2	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2012	D 1.4 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2012	D 1.4 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2012	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2012	D 1.4 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2012	D 1.4 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2012	D 1.4 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2012	D 1.4 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2012	D 1.6 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	
Europe/General	VENGA(YN)	2012	D 1.6 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2012	D 1.6 TCI-U2	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2012	D 1.6 TCI-U2	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2012	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2012	D 1.6 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2012	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2012	D 1.6 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2012	D 1.6 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2012	D 1.6 TCI-U2	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2012	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2012	G 1.4 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	VENGA(YN)	2012	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2012	G 1.4 DOHC	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2012	G 1.4 DOHC	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2012	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2012	G 1.4 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2012	G 1.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2012	G 1.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112

Europe/General	VENGA(YN)	2012	G 1.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2012	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2012	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	VENGA(YN)	2012	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	VENGA(YN)	2012	G 1.6 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2012	G 1.6 DOHC	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2012	G 1.6 DOHC	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2012	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2012	G 1.6 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2012	G 1.6 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2012	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2012	G 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0023, 0035, 0036, 0045, 0102
Europe/General	VENGA(YN)	2012	G 1.6 DOHC	BCM [Body Control Module]	√	√	√	√	√	
Europe/General	VENGA(YN)	2012	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2011	D 1.4 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	VENGA(YN)	2011	D 1.4 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2011	D 1.4 TCI-U2	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2011	D 1.4 TCI-U2	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2011	D 1.4 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2011	D 1.4 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2011	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2011	D 1.4 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2011	D 1.4 TCI-U2	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	VENGA(YN)	2011	D 1.4 TCI-U2	SMKCODE [Smart Key Code Saving]				√		
Europe/General	VENGA(YN)	2011	D 1.4 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	VENGA(YN)	2011	D 1.4 TCI-U2	BCM [Body Control Module]	√			√	√	
Europe/General	VENGA(YN)	2011	D 1.4 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2011	D 1.6 TCI-U2	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	
Europe/General	VENGA(YN)	2011	D 1.6 TCI-U2	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	
Europe/General	VENGA(YN)	2011	D 1.6 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2011	D 1.6 TCI-U2	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2011	D 1.6 TCI-U2	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2011	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2011	D 1.6 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2011	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2011	D 1.6 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2011	D 1.6 TCI-U2	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	VENGA(YN)	2011	D 1.6 TCI-U2	SMKCODE [Smart Key Code Saving]				√		
Europe/General	VENGA(YN)	2011	D 1.6 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	VENGA(YN)	2011	D 1.6 TCI-U2	BCM [Body Control Module]	√			√	√	
Europe/General	VENGA(YN)	2011	G 1.4 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	VENGA(YN)	2011	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2011	G 1.4 DOHC	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2011	G 1.4 DOHC	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2011	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	

Europe/General	VENGA(YN)	2011	G 1.4 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2011	G 1.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2011	G 1.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2011	G 1.4 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	VENGA(YN)	2011	G 1.4 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	VENGA(YN)	2011	G 1.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	VENGA(YN)	2011	G 1.4 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	VENGA(YN)	2011	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2011	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	VENGA(YN)	2011	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	VENGA(YN)	2011	G 1.6 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2011	G 1.6 DOHC	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2011	G 1.6 DOHC	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2011	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2011	G 1.6 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2011	G 1.6 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2011	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2011	G 1.6 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	VENGA(YN)	2011	G 1.6 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	VENGA(YN)	2011	G 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	VENGA(YN)	2011	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	VENGA(YN)	2011	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2010	D 1.4 TCI-U2	ENGINE [Engine Control]	√	√	√	√	√	0047
Europe/General	VENGA(YN)	2010	D 1.4 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2010	D 1.4 TCI-U2	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2010	D 1.4 TCI-U2	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2010	D 1.4 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2010	D 1.4 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2010	D 1.4 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2010	D 1.4 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2010	D 1.4 TCI-U2	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	VENGA(YN)	2010	D 1.4 TCI-U2	SMKCODE [Smart Key Code Saving]				√		
Europe/General	VENGA(YN)	2010	D 1.4 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	VENGA(YN)	2010	D 1.4 TCI-U2	BCM [Body Control Module]	√			√	√	
Europe/General	VENGA(YN)	2010	D 1.6 TCI-U2	ENGINE [Engine Control (CPF -)]	√	√	√	√	√	
Europe/General	VENGA(YN)	2010	D 1.6 TCI-U2	ENGINE [Engine Control (CPF+)]	√	√	√	√	√	
Europe/General	VENGA(YN)	2010	D 1.6 TCI-U2	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2010	D 1.6 TCI-U2	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2010	D 1.6 TCI-U2	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2010	D 1.6 TCI-U2	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2010	D 1.6 TCI-U2	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2010	D 1.6 TCI-U2	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2010	D 1.6 TCI-U2	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2010	D 1.6 TCI-U2	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	VENGA(YN)	2010	D 1.6 TCI-U2	SMKCODE [Smart Key Code Saving]				√		

Europe/General	VENGA(YN)	2010	D 1.6 TCI-U2	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	VENGA(YN)	2010	D 1.6 TCI-U2	BCM [Body Control Module]	√			√	√	
Europe/General	VENGA(YN)	2010	D 1.6 TCI-U2	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2010	G 1.4 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	VENGA(YN)	2010	G 1.4 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2010	G 1.4 DOHC	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2010	G 1.4 DOHC	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2010	G 1.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2010	G 1.4 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2010	G 1.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2010	G 1.4 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2010	G 1.4 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	VENGA(YN)	2010	G 1.4 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	VENGA(YN)	2010	G 1.4 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	VENGA(YN)	2010	G 1.4 DOHC	BCM [Body Control Module]	√			√	√	
Europe/General	VENGA(YN)	2010	G 1.4 DOHC	CODE [Transmitter Code Saving]				√		0022
Europe/General	VENGA(YN)	2010	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√		0033, 0061, 0094, 0126
Europe/General	VENGA(YN)	2010	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
Europe/General	VENGA(YN)	2010	G 1.6 DOHC	ABSESP [ABS / ESP]	√	√	√	√	√	0051, 0008
Europe/General	VENGA(YN)	2010	G 1.6 DOHC	AIRBAG [Airbag Control (Event #2)]	√	√	√			
Europe/General	VENGA(YN)	2010	G 1.6 DOHC	AIRBAG [Airbag Control (Event #1)]	√	√	√			
Europe/General	VENGA(YN)	2010	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
Europe/General	VENGA(YN)	2010	G 1.6 DOHC	EPS [Power Steering]	√	√	√	√		
Europe/General	VENGA(YN)	2010	G 1.6 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
Europe/General	VENGA(YN)	2010	G 1.6 DOHC	IMMO [Immobilizer]				√		0072, 0075, 0083, 0092, 0112
Europe/General	VENGA(YN)	2010	G 1.6 DOHC	PDM [Power Distribution Module]	√	√	√	√	√	0035
Europe/General	VENGA(YN)	2010	G 1.6 DOHC	SMKCODE [Smart Key Code Saving]				√		
Europe/General	VENGA(YN)	2010	G 1.6 DOHC	SMK [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
Europe/General	VENGA(YN)	2010	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
US	AMANTI(GH)	2009	G 3.8 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0094, 0081, 0086, 0044
US	AMANTI(GH)	2009	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	AMANTI(GH)	2009	G 3.8 DOHC	ESC [Electronic Stability Control]		√	√	√	√	
US	AMANTI(GH)	2009	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			0090, 0105
US	AMANTI(GH)	2009	G 3.8 DOHC	AIRCON [Air Conditioner]		√	√	√	√	
US	AMANTI(GH)	2009	G 3.8 DOHC	EPS [Electronic Power Steering]		√	√	√		
US	AMANTI(GH)	2009	G 3.8 DOHC	BCM [Power Window Assistance]		√	√		√	
US	AMANTI(GH)	2009	G 3.8 DOHC	BCM [Power Window Main]		√	√		√	
US	AMANTI(GH)	2009	G 3.8 DOHC	BCM [Power Seat]		√	√	√	√	
US	AMANTI(GH)	2009	G 3.8 DOHC	BCM [Body Control Module]	√	√	√		√	
US	AMANTI(GH)	2009	G 3.8 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	AMANTI(GH)	2009	G 3.8 DOHC	PIC [Power Distribution Module]	√	√	√	√	√	0035
US	AMANTI(GH)	2009	G 3.8 DOHC	PIC [Smart Key Code Saving]				√		
US	AMANTI(GH)	2009	G 3.8 DOHC	PIC [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
US	AMANTI(GH)	2009	G 3.8 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	

US	AMANTI(GH)	2009	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0096
US	AMANTI(GH)	2008	G 3.8 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0094, 0081, 0086, 0044
US	AMANTI(GH)	2008	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	AMANTI(GH)	2008	G 3.8 DOHC	ESC [Electronic Stability Control]		√	√	√	√	
US	AMANTI(GH)	2008	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			0090, 0105
US	AMANTI(GH)	2008	G 3.8 DOHC	AIRCON [Air Conditioner]		√	√	√	√	
US	AMANTI(GH)	2008	G 3.8 DOHC	EPS [Electronic Power Steering]		√	√	√		
US	AMANTI(GH)	2008	G 3.8 DOHC	BCM [Power Seat]		√	√	√	√	
US	AMANTI(GH)	2008	G 3.8 DOHC	BCM [Power Window Assistance]		√	√		√	
US	AMANTI(GH)	2008	G 3.8 DOHC	BCM [Power Window Main]		√	√		√	
US	AMANTI(GH)	2008	G 3.8 DOHC	BCM [Body Control Module]	√	√	√		√	
US	AMANTI(GH)	2008	G 3.8 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	AMANTI(GH)	2008	G 3.8 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	AMANTI(GH)	2008	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0096
US	AMANTI(GH)	2007	G 3.8 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0094, 0081, 0086, 0044
US	AMANTI(GH)	2007	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	AMANTI(GH)	2007	G 3.8 DOHC	ESC [Electronic Stability Control]		√	√	√	√	
US	AMANTI(GH)	2007	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			0090, 0105
US	AMANTI(GH)	2007	G 3.8 DOHC	AIRCON [Air Conditioner]		√	√	√	√	
US	AMANTI(GH)	2007	G 3.8 DOHC	EPS [Electronic Power Steering]		√	√	√		
US	AMANTI(GH)	2007	G 3.8 DOHC	BCM [Power Window Assistance]		√	√		√	
US	AMANTI(GH)	2007	G 3.8 DOHC	BCM [Power Window Main]		√	√		√	
US	AMANTI(GH)	2007	G 3.8 DOHC	BCM [Body Control Module]	√	√	√		√	
US	AMANTI(GH)	2007	G 3.8 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	AMANTI(GH)	2007	G 3.8 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	AMANTI(GH)	2007	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0096
US	AMANTI(GH)	2006	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0094
US	AMANTI(GH)	2006	G 3.5 DOHC	AT [Automatic Transaxle]		√	√	√	√	0065
US	AMANTI(GH)	2006	G 3.5 DOHC	ESC [Electronic Stability Control]		√	√	√	√	
US	AMANTI(GH)	2006	G 3.5 DOHC	AIRBAG [Airbag Control]	√	√	√			0091
US	AMANTI(GH)	2006	G 3.5 DOHC	AIRCON [Air Conditioner]		√	√	√	√	
US	AMANTI(GH)	2006	G 3.5 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	AMANTI(GH)	2006	G 3.5 DOHC	BCM [Power Seat]		√	√	√	√	
US	AMANTI(GH)	2006	G 3.5 DOHC	BCM [Power Window Assistance]		√	√		√	
US	AMANTI(GH)	2006	G 3.5 DOHC	BCM [Power Window Main]		√	√		√	
US	AMANTI(GH)	2006	G 3.5 DOHC	BCM [Body Control Module]	√	√	√	√	√	
US	AMANTI(GH)	2006	G 3.5 DOHC	IMMO [Immobilizer]				√		0076, 0119
US	AMANTI(GH)	2006	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0096
US	AMANTI(GH)	2005	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0094
US	AMANTI(GH)	2005	G 3.5 DOHC	AT [Automatic Transaxle]		√	√	√	√	0065
US	AMANTI(GH)	2005	G 3.5 DOHC	ESC [Electronic Stability Control]		√	√	√	√	
US	AMANTI(GH)	2005	G 3.5 DOHC	AIRBAG [Airbag Control]	√	√	√			0091
US	AMANTI(GH)	2005	G 3.5 DOHC	AIRCON [Air Conditioner]		√	√	√	√	

US	AMANTI(GH)	2005	G 3.5 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	AMANTI(GH)	2005	G 3.5 DOHC	BCM [Power Seat]		√	√	√	√	
US	AMANTI(GH)	2005	G 3.5 DOHC	BCM [Power Window Assistance]		√	√		√	
US	AMANTI(GH)	2005	G 3.5 DOHC	BCM [Power Window Main]		√	√		√	
US	AMANTI(GH)	2005	G 3.5 DOHC	BCM [Body Control Module]	√	√	√	√	√	
US	AMANTI(GH)	2005	G 3.5 DOHC	IMMO [Immobilizer]				√		0076, 0119
US	AMANTI(GH)	2005	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0096
US	AMANTI(GH)	2004	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044
US	AMANTI(GH)	2004	G 3.5 DOHC	AT [Automatic Transaxle]		√	√	√	√	
US	AMANTI(GH)	2004	G 3.5 DOHC	ESC [Electronic Stability Control]		√	√	√	√	
US	AMANTI(GH)	2004	G 3.5 DOHC	AIRBAG [Airbag Control]	√	√	√			
US	AMANTI(GH)	2004	G 3.5 DOHC	AIRCON [Air Conditioner]		√	√	√	√	
US	AMANTI(GH)	2004	G 3.5 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	AMANTI(GH)	2004	G 3.5 DOHC	BCM [Power Seat]		√	√	√	√	
US	AMANTI(GH)	2004	G 3.5 DOHC	BCM [Power Window Assistance]		√	√		√	
US	AMANTI(GH)	2004	G 3.5 DOHC	BCM [Body Control Module]	√	√	√	√	√	
US	AMANTI(GH)	2004	G 3.5 DOHC	IMMO [Immobilizer]				√		0076, 0119
US	AMANTI(GH)	2004	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0096
US	BORREGO(HM)	2009	G 3.8 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0081, 0086, 0094, 0126
US	BORREGO(HM)	2009	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099, 0116
US	BORREGO(HM)	2009	G 3.8 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	BORREGO(HM)	2009	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			0089, 0090
US	BORREGO(HM)	2009	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	BORREGO(HM)	2009	G 3.8 DOHC	EPS [Power Steering]	√	√	√	√		
US	BORREGO(HM)	2009	G 3.8 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	0002, 0052, 0054, 0056, 0057
US	BORREGO(HM)	2009	G 3.8 DOHC	4WD [4WD Control (TOD)]	√	√	√	√	√	0120
US	BORREGO(HM)	2009	G 3.8 DOHC	4WD [4WD Control (EST)]	√	√	√	√		
US	BORREGO(HM)	2009	G 3.8 DOHC	BCM [Driver Door Module]	√	√	√	√	√	
US	BORREGO(HM)	2009	G 3.8 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
US	BORREGO(HM)	2009	G 3.8 DOHC	BCM [Rear Area Module]	√	√	√	√	√	
US	BORREGO(HM)	2009	G 3.8 DOHC	BCM [Assist Door Module]	√	√	√	√	√	
US	BORREGO(HM)	2009	G 3.8 DOHC	BCM [Integrated Memory System]		√	√	√	√	
US	BORREGO(HM)	2009	G 3.8 DOHC	BCM [Steering Column Module]		√	√	√	√	
US	BORREGO(HM)	2009	G 3.8 DOHC	BCM [User Option]				√		
US	BORREGO(HM)	2009	G 3.8 DOHC	BCM [Front Area Module]	√	√	√	√	√	
US	BORREGO(HM)	2009	G 3.8 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	BORREGO(HM)	2009	G 3.8 DOHC	PIC [Power Distribution Module]	√	√	√	√	√	0035
US	BORREGO(HM)	2009	G 3.8 DOHC	PIC [Smart Key Code Saving]				√		
US	BORREGO(HM)	2009	G 3.8 DOHC	PIC [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
US	BORREGO(HM)	2009	G 3.8 DOHC	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074, 0115
US	BORREGO(HM)	2009	G 3.8 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	BORREGO(HM)	2009	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
US	BORREGO(HM)	2009	G 4.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0081, 0094, 0098, 0126
US	BORREGO(HM)	2009	G 4.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0014, 0099

US	BORREGO(HM)	2009	G 4.6 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	BORREGO(HM)	2009	G 4.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0089, 0090
US	BORREGO(HM)	2009	G 4.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	BORREGO(HM)	2009	G 4.6 DOHC	EPS [Power Steering]	√	√	√	√		
US	BORREGO(HM)	2009	G 4.6 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	0002, 0052, 0054, 0056, 0057
US	BORREGO(HM)	2009	G 4.6 DOHC	4WD [4WD Control (TOD)]	√	√	√	√	√	0120
US	BORREGO(HM)	2009	G 4.6 DOHC	4WD [4WD Control (EST)]	√	√	√	√		
US	BORREGO(HM)	2009	G 4.6 DOHC	BCM [Driver Door Module]	√	√	√	√	√	
US	BORREGO(HM)	2009	G 4.6 DOHC	BCM [Rear Area Module]	√	√	√	√	√	
US	BORREGO(HM)	2009	G 4.6 DOHC	BCM [Assist Door Module]	√	√	√	√	√	
US	BORREGO(HM)	2009	G 4.6 DOHC	BCM [Integrated Memory System]		√	√	√	√	
US	BORREGO(HM)	2009	G 4.6 DOHC	BCM [Steering Column Module]		√	√	√	√	
US	BORREGO(HM)	2009	G 4.6 DOHC	BCM [User Option]				√		
US	BORREGO(HM)	2009	G 4.6 DOHC	BCM [Front Area Module]	√	√	√	√	√	
US	BORREGO(HM)	2009	G 4.6 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	BORREGO(HM)	2009	G 4.6 DOHC	PIC [Power Distribution Module]	√	√	√	√	√	0035
US	BORREGO(HM)	2009	G 4.6 DOHC	PIC [Smart Key Code Saving]				√		
US	BORREGO(HM)	2009	G 4.6 DOHC	PIC [Smart Key Unit]	√	√	√	√	√	0036, 0045, 0088, 0102
US	BORREGO(HM)	2009	G 4.6 DOHC	AHLS [Auto Headlamp Leveling System]	√	√	√	√		0074, 0115
US	BORREGO(HM)	2009	G 4.6 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	BORREGO(HM)	2009	G 4.6 DOHC	CODE [Transmitter Code Saving]				√		0022
US	FORTE/FORTE KOUPTD)	2012	G 2.0 DOHC	ENGINE [Engine Control (ULEV)]	√	√	√	√	√	0126, 0011, 0044, 0094, 0081, 0087, 0098
US	FORTE/FORTE KOUPTD)	2012	G 2.0 DOHC	ENGINE [Engine Control (SULEV)]	√	√	√	√	√	0126, 0011, 0011, 0126, 0044, 0081, 0094, 0087, 0098
US	FORTE/FORTE KOUPTD)	2012	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	FORTE/FORTE KOUPTD)	2012	G 2.0 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	FORTE/FORTE KOUPTD)	2012	G 2.0 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	FORTE/FORTE KOUPTD)	2012	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			0090
US	FORTE/FORTE KOUPTD)	2012	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			0090
US	FORTE/FORTE KOUPTD)	2012	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	FORTE/FORTE KOUPTD)	2012	G 2.0 DOHC	EPS [Power Steering]	√	√	√	√		
US	FORTE/FORTE KOUPTD)	2012	G 2.0 DOHC	BCM [Body Control Module (KOUPTD)]	√			√	√	
US	FORTE/FORTE KOUPTD)	2012	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
US	FORTE/FORTE KOUPTD)	2012	G 2.0 DOHC	BCM [Body Control Module (5DR)]	√			√	√	

US	FORTE/FORTE KOUP(TD)	2012	G 2.0 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	FORTE/FORTE KOUP(TD)	2012	G 2.0 DOHC	PIC [Smart Key Code Saving]				√		
US	FORTE/FORTE KOUP(TD)	2012	G 2.0 DOHC	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0088, 0102
US	FORTE/FORTE KOUP(TD)	2012	G 2.0 DOHC	PIC [Power Distribution Module]	√	√	√	√	√	
US	FORTE/FORTE KOUP(TD)	2012	G 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	FORTE/FORTE KOUP(TD)	2012	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
US	FORTE/FORTE KOUP(TD)	2012	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0011, 0044, 0094, 0081, 0087, 0098
US	FORTE/FORTE KOUP(TD)	2012	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	FORTE/FORTE KOUP(TD)	2012	G 2.4 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	FORTE/FORTE KOUP(TD)	2012	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			0090
US	FORTE/FORTE KOUP(TD)	2012	G 2.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			0090
US	FORTE/FORTE KOUP(TD)	2012	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	FORTE/FORTE KOUP(TD)	2012	G 2.4 DOHC	EPS [Power Steering]	√	√	√	√		
US	FORTE/FORTE KOUP(TD)	2012	G 2.4 DOHC	EPS [Power Steering (KOUP)]	√	√	√	√		
US	FORTE/FORTE KOUP(TD)	2012	G 2.4 DOHC	BCM [Body Control Module (KOUP)]	√			√	√	
US	FORTE/FORTE KOUP(TD)	2012	G 2.4 DOHC	BCM [Body Control Module]	√			√	√	
US	FORTE/FORTE KOUP(TD)	2012	G 2.4 DOHC	BCM [Body Control Module (5DR)]	√			√	√	
US	FORTE/FORTE KOUP(TD)	2012	G 2.4 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	FORTE/FORTE KOUP(TD)	2012	G 2.4 DOHC	PIC [Smart Key Code Saving]				√		
US	FORTE/FORTE KOUP(TD)	2012	G 2.4 DOHC	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0088, 0102
US	FORTE/FORTE KOUP(TD)	2012	G 2.4 DOHC	PIC [Power Distribution Module]	√	√	√	√	√	
US	FORTE/FORTE KOUP(TD)	2012	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	FORTE/FORTE KOUP(TD)	2012	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
US	FORTE/FORTE KOUP(TD)	2011	G 2.0 DOHC	ENGINE [Engine Control (ULEV)]	√	√	√	√	√	0126, 0011, 0044, 0094, 0081, 0087, 0098

US	FORTE/FORTE KOUPTD)	2011	G 2.0 DOHC	ENGINE [Engine Control (SULEV)]	√	√	√	√	√	0126, 0011, 0044, 0094, 0081, 0087, 0098
US	FORTE/FORTE KOUPTD)	2011	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	FORTE/FORTE KOUPTD)	2011	G 2.0 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	FORTE/FORTE KOUPTD)	2011	G 2.0 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	FORTE/FORTE KOUPTD)	2011	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			0090
US	FORTE/FORTE KOUPTD)	2011	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			0090
US	FORTE/FORTE KOUPTD)	2011	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	FORTE/FORTE KOUPTD)	2011	G 2.0 DOHC	EPS [Power Steering]	√	√	√	√		
US	FORTE/FORTE KOUPTD)	2011	G 2.0 DOHC	BCM [Body Control Module (KOUPTD)]	√			√	√	
US	FORTE/FORTE KOUPTD)	2011	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
US	FORTE/FORTE KOUPTD)	2011	G 2.0 DOHC	BCM [Body Control Module (5DR)]	√			√	√	
US	FORTE/FORTE KOUPTD)	2011	G 2.0 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	FORTE/FORTE KOUPTD)	2011	G 2.0 DOHC	PIC [Smart Key Code Saving]				√		
US	FORTE/FORTE KOUPTD)	2011	G 2.0 DOHC	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0088, 0102
US	FORTE/FORTE KOUPTD)	2011	G 2.0 DOHC	PIC [Power Distribution Module]	√	√	√	√	√	
US	FORTE/FORTE KOUPTD)	2011	G 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	FORTE/FORTE KOUPTD)	2011	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
US	FORTE/FORTE KOUPTD)	2011	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0011, 0044, 0094, 0081, 0087, 0098
US	FORTE/FORTE KOUPTD)	2011	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	FORTE/FORTE KOUPTD)	2011	G 2.4 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	FORTE/FORTE KOUPTD)	2011	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			0090
US	FORTE/FORTE KOUPTD)	2011	G 2.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			0090
US	FORTE/FORTE KOUPTD)	2011	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	FORTE/FORTE KOUPTD)	2011	G 2.4 DOHC	EPS [Power Steering]	√	√	√	√		

US	FORTE/FORTE KOUPTD)	2011	G 2.4 DOHC	EPS [Power Steering (KOUPTD)]	√	√	√	√		
US	FORTE/FORTE KOUPTD)	2011	G 2.4 DOHC	BCM [Body Control Module (KOUPTD)]	√			√	√	
US	FORTE/FORTE KOUPTD)	2011	G 2.4 DOHC	BCM [Body Control Module]	√			√	√	
US	FORTE/FORTE KOUPTD)	2011	G 2.4 DOHC	BCM [Body Control Module (5DR)]	√			√	√	
US	FORTE/FORTE KOUPTD)	2011	G 2.4 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	FORTE/FORTE KOUPTD)	2011	G 2.4 DOHC	PIC [Smart Key Code Saving]				√		
US	FORTE/FORTE KOUPTD)	2011	G 2.4 DOHC	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0088, 0102
US	FORTE/FORTE KOUPTD)	2011	G 2.4 DOHC	PIC [Power Distribution Module]	√	√	√	√	√	
US	FORTE/FORTE KOUPTD)	2011	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	FORTE/FORTE KOUPTD)	2011	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
US	FORTE/FORTE KOUPTD)	2010	G 2.0 DOHC	ENGINE [Engine Control (ULEV)]	√	√	√	√	√	0126, 0011, 0044, 0094, 0081, 0087, 0098
US	FORTE/FORTE KOUPTD)	2010	G 2.0 DOHC	ENGINE [Engine Control (SULEV)]	√	√	√	√	√	0126, 0011, 0044, 0094, 0081, 0087, 0098
US	FORTE/FORTE KOUPTD)	2010	G 2.0 DOHC	AT [5 - Speed]	√	√	√	√	√	0099
US	FORTE/FORTE KOUPTD)	2010	G 2.0 DOHC	AT [4 - Speed]	√	√	√	√	√	0099
US	FORTE/FORTE KOUPTD)	2010	G 2.0 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	FORTE/FORTE KOUPTD)	2010	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			0090
US	FORTE/FORTE KOUPTD)	2010	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			0090
US	FORTE/FORTE KOUPTD)	2010	G 2.0 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	FORTE/FORTE KOUPTD)	2010	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	FORTE/FORTE KOUPTD)	2010	G 2.0 DOHC	EPS [Power Steering]	√	√	√	√		
US	FORTE/FORTE KOUPTD)	2010	G 2.0 DOHC	EPS [Power Steering (KOUPTD)]	√	√	√	√		
US	FORTE/FORTE KOUPTD)	2010	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
US	FORTE/FORTE KOUPTD)	2010	G 2.0 DOHC	BCM [Body Control Module (KOUPTD)]	√			√	√	
US	FORTE/FORTE KOUPTD)	2010	G 2.0 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119

US	FORTE/FORTE KOUP(TD)	2010	G 2.0 DOHC	PIC [Power Distribution Module (W / ESCL)]	√	√	√	√	√	0035
US	FORTE/FORTE KOUP(TD)	2010	G 2.0 DOHC	PIC [Smart Key Code Saving (W / ESCL)]				√		
US	FORTE/FORTE KOUP(TD)	2010	G 2.0 DOHC	PIC [Multiselection]	√	√	√	√	√	0036, 0045, 0088, 0102
US	FORTE/FORTE KOUP(TD)	2010	G 2.0 DOHC	PIC [Smart Key Unit (W / ESCL)]	√	√	√	√	√	0036, 0045, 0088, 0102
US	FORTE/FORTE KOUP(TD)	2010	G 2.0 DOHC	PIC [Smart Key Unit (W / O ESCL)]	√	√	√	√	√	0045, 0088, 0102
US	FORTE/FORTE KOUP(TD)	2010	G 2.0 DOHC	PIC [Power Distribution Module (W / O ESCL)]	√	√	√	√	√	
US	FORTE/FORTE KOUP(TD)	2010	G 2.0 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	FORTE/FORTE KOUP(TD)	2010	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
US	FORTE/FORTE KOUP(TD)	2010	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0011, 0044, 0094, 0081, 0087, 0098
US	FORTE/FORTE KOUP(TD)	2010	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	FORTE/FORTE KOUP(TD)	2010	G 2.4 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	FORTE/FORTE KOUP(TD)	2010	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			0090
US	FORTE/FORTE KOUP(TD)	2010	G 2.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			0090
US	FORTE/FORTE KOUP(TD)	2010	G 2.4 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	FORTE/FORTE KOUP(TD)	2010	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	FORTE/FORTE KOUP(TD)	2010	G 2.4 DOHC	EPS [Power Steering]	√	√	√	√		
US	FORTE/FORTE KOUP(TD)	2010	G 2.4 DOHC	EPS [Power Steering (KOUP)]	√	√	√	√		
US	FORTE/FORTE KOUP(TD)	2010	G 2.4 DOHC	BCM [Body Control Module]	√			√	√	
US	FORTE/FORTE KOUP(TD)	2010	G 2.4 DOHC	BCM [Body Control Module (KOUP)]	√			√	√	
US	FORTE/FORTE KOUP(TD)	2010	G 2.4 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	FORTE/FORTE KOUP(TD)	2010	G 2.4 DOHC	PIC [Multiselection]	√	√	√	√	√	0036, 0045, 0088, 0102
US	FORTE/FORTE KOUP(TD)	2010	G 2.4 DOHC	PIC [Smart Key Code Saving (W / ESCL)]				√		
US	FORTE/FORTE KOUP(TD)	2010	G 2.4 DOHC	PIC [Power Distribution Module (W / ESCL)]	√	√	√	√	√	0035
US	FORTE/FORTE KOUP(TD)	2010	G 2.4 DOHC	PIC [Smart Key Unit (W / ESCL)]	√	√	√	√	√	0036, 0045, 0088, 0102

US	FORTE/FORTE KOUPTD)	2010	G 2.4 DOHC	PIC [Smart Key Code Saving (W / O ESCL)]				√		
US	FORTE/FORTE KOUPTD)	2010	G 2.4 DOHC	PIC [Smart Key Unit (W / O ESCL)]	√	√	√	√	√	0045, 0088, 0102
US	FORTE/FORTE KOUPTD)	2010	G 2.4 DOHC	PIC [Power Distribution Module (W / O ESCL)]	√	√	√	√	√	
US	FORTE/FORTE KOUPTD)	2010	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	FORTE/FORTE KOUPTD)	2010	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	ENGINE [Engine Control]	√	√	√	√	√	0011, 0042, 0094, 0098, 0126
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	ABSESC [ABS / ESC]	√	√	√	√	√	0051, 0077
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	AHB [Active Hydraulic Booster]	√	√	√	√	√	
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	AIRBAG [Airbag (Event #2)]	√	√	√			
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	AIRBAG [Airbag (Event #1)]	√	√	√			
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	AIRBAG [Weight Classification]	√	√	√	√		0124
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	HCU [HEV Control System]	√	√	√	√		0026, 0039, 0040, 0069
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	MCU [HEV Motor System]	√	√	√	√	√	0037, 0082
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	BMS [HEV Battery System]	√	√	√	√	√	
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	LDC [Low DC / DC Converter]	√	√	√	√		
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	AAF [Active Air Flap]	√	√	√	√	√	
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	EPS [Motor Driven Power Steering]	√	√	√	√		
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	BCM [Smart Junction Box]	√	√	√	√	√	
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	BCM [Power Seat Module]	√	√	√	√	√	0106
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	BCM [Cluster Module]	√	√	√	√	√	
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	BCM [Body Control Module]	√	√	√	√	√	
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0102

US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	OPTIMA HYBRID(TF HEV)	2012	G 2.4 HEV	CODE [Transmitter Code Saving]				√		0022
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	ENGINE [Engine Control]	√	√	√	√	√	0011, 0042, 0094, 0098, 0126
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	ABSESC [ABS / ESC]	√	√	√	√	√	0051, 0077
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	AHB [Active Hydraulic Booster]	√	√	√	√	√	
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	AIRBAG [Airbag (Event #2)]	√	√	√			
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	AIRBAG [Airbag (Event #1)]	√	√	√			
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	AIRBAG [Weight Classification]	√	√	√	√		0124
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	AIRCON [Air Conditioner]	√	√	√	√	√	
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	HCU [HEV Control System]	√	√	√	√		0026, 0039, 0040, 0069
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	MCU [HEV Motor System]	√	√	√	√	√	0037, 0082
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	BMS [HEV Battery System]	√	√	√	√	√	
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	LDC [Low DC / DC Converter]	√	√	√	√		
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	AAF [Active Air Flap]	√	√	√	√	√	
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	EPS [Motor Driven Power Steering]	√	√	√	√		
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	BCM [Smart Junction Box]	√	√	√	√	√	
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	BCM [Power Seat Module]	√	√	√	√	√	0106
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	BCM [Cluster Module]	√	√	√	√	√	
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	BCM [Body Control Module]	√	√	√	√	√	
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0102
US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	AHLS [Auto Headlamp Leveling System]	√	√	√	√	√	

US	OPTIMA HYBRID(TF HEV)	2011	G 2.4 HEV	CODE [Transmitter Code Saving]				√		0022
US	OPTIMA(MG)	2010	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0011, 0044, 0094, 0081, 0098
US	OPTIMA(MG)	2010	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	OPTIMA(MG)	2010	G 2.4 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	OPTIMA(MG)	2010	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	OPTIMA(MG)	2010	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	OPTIMA(MG)	2010	G 2.4 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	OPTIMA(MG)	2010	G 2.4 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
US	OPTIMA(MG)	2010	G 2.4 DOHC	BCM [Body Control Module]	√			√	√	
US	OPTIMA(MG)	2010	G 2.4 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	OPTIMA(MG)	2010	G 2.4 DOHC	PIC [Smart Key Code Saving (W / ESCL)]				√		
US	OPTIMA(MG)	2010	G 2.4 DOHC	PIC [Power Distribution Module (W / O ESCL)]	√	√	√	√	√	
US	OPTIMA(MG)	2010	G 2.4 DOHC	PIC [Smart Key Unit (W / ESCL)]	√	√	√	√	√	0036, 0045, 0088, 0102
US	OPTIMA(MG)	2010	G 2.4 DOHC	PIC [Smart Key Code Saving (W / O ESCL)]				√		
US	OPTIMA(MG)	2010	G 2.4 DOHC	PIC [Multiselection]	√	√	√	√	√	0045, 0088, 0102, 0117
US	OPTIMA(MG)	2010	G 2.4 DOHC	PIC [Smart Key Unit (W / O ESCL)]	√	√	√	√	√	0045, 0088, 0102, 0117
US	OPTIMA(MG)	2010	G 2.4 DOHC	PIC [Power Distribution Module (W / ESCL)]	√	√	√	√	√	0035
US	OPTIMA(MG)	2010	G 2.4 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	OPTIMA(MG)	2010	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
US	OPTIMA(MG)	2010	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0081, 0086, 0094, 0126
US	OPTIMA(MG)	2010	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	OPTIMA(MG)	2010	G 2.7 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	OPTIMA(MG)	2010	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	OPTIMA(MG)	2010	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	OPTIMA(MG)	2010	G 2.7 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	OPTIMA(MG)	2010	G 2.7 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
US	OPTIMA(MG)	2010	G 2.7 DOHC	BCM [Body Control Module]	√			√	√	
US	OPTIMA(MG)	2010	G 2.7 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	OPTIMA(MG)	2010	G 2.7 DOHC	PIC [Smart Key Code Saving (W / ESCL)]				√		
US	OPTIMA(MG)	2010	G 2.7 DOHC	PIC [Power Distribution Module (W / O ESCL)]	√	√	√	√	√	
US	OPTIMA(MG)	2010	G 2.7 DOHC	PIC [Smart Key Code Saving (W / O ESCL)]				√		
US	OPTIMA(MG)	2010	G 2.7 DOHC	PIC [Multiselection]	√	√	√	√	√	0045, 0088, 0102, 0117
US	OPTIMA(MG)	2010	G 2.7 DOHC	PIC [Smart Key Unit (W / O ESCL)]	√	√	√	√	√	0045, 0088, 0102, 0117
US	OPTIMA(MG)	2010	G 2.7 DOHC	PIC [Power Distribution Module (W / ESCL)]	√	√	√	√	√	0035
US	OPTIMA(MG)	2010	G 2.7 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	

US	OPTIMA(MG)	2010	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
US	OPTIMA(MG)	2009	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0011, 0044, 0094, 0081, 0098
US	OPTIMA(MG)	2009	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	OPTIMA(MG)	2009	G 2.4 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	
US	OPTIMA(MG)	2009	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	OPTIMA(MG)	2009	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	OPTIMA(MG)	2009	G 2.4 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	OPTIMA(MG)	2009	G 2.4 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
US	OPTIMA(MG)	2009	G 2.4 DOHC	BCM [Body Control Module]	√			√	√	
US	OPTIMA(MG)	2009	G 2.4 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	OPTIMA(MG)	2009	G 2.4 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	OPTIMA(MG)	2009	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
US	OPTIMA(MG)	2009	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0081, 0086, 0094, 0126
US	OPTIMA(MG)	2009	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	OPTIMA(MG)	2009	G 2.7 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	
US	OPTIMA(MG)	2009	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	OPTIMA(MG)	2009	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	OPTIMA(MG)	2009	G 2.7 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	OPTIMA(MG)	2009	G 2.7 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
US	OPTIMA(MG)	2009	G 2.7 DOHC	BCM [Body Control Module]	√			√	√	
US	OPTIMA(MG)	2009	G 2.7 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	OPTIMA(MG)	2009	G 2.7 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	OPTIMA(MG)	2009	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
US	OPTIMA(MG)	2008	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0011, 0044, 0094, 0081, 0044, 0098
US	OPTIMA(MG)	2008	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	OPTIMA(MG)	2008	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	OPTIMA(MG)	2008	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	OPTIMA(MG)	2008	G 2.4 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	OPTIMA(MG)	2008	G 2.4 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
US	OPTIMA(MG)	2008	G 2.4 DOHC	BCM [Body Control Module]	√			√	√	
US	OPTIMA(MG)	2008	G 2.4 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	OPTIMA(MG)	2008	G 2.4 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	OPTIMA(MG)	2008	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
US	OPTIMA(MG)	2008	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0094, 0081, 0086, 0044
US	OPTIMA(MG)	2008	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	OPTIMA(MG)	2008	G 2.7 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	OPTIMA(MG)	2008	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	OPTIMA(MG)	2008	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	OPTIMA(MG)	2008	G 2.7 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	OPTIMA(MG)	2008	G 2.7 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
US	OPTIMA(MG)	2008	G 2.7 DOHC	BCM [Body Control Module]	√			√	√	

US	OPTIMA(MG)	2008	G 2.7 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	OPTIMA(MG)	2008	G 2.7 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	OPTIMA(MG)	2008	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
US	OPTIMA(MG)	2007	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0011, 0044, 0094, 0081, 0044, 0098
US	OPTIMA(MG)	2007	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	OPTIMA(MG)	2007	G 2.4 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	OPTIMA(MG)	2007	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	OPTIMA(MG)	2007	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	OPTIMA(MG)	2007	G 2.4 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	OPTIMA(MG)	2007	G 2.4 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
US	OPTIMA(MG)	2007	G 2.4 DOHC	BCM [Body Control Module]	√			√	√	
US	OPTIMA(MG)	2007	G 2.4 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	OPTIMA(MG)	2007	G 2.4 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	OPTIMA(MG)	2007	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
US	OPTIMA(MG)	2007	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0081, 0086, 0094, 0126
US	OPTIMA(MG)	2007	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	OPTIMA(MG)	2007	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	OPTIMA(MG)	2007	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	OPTIMA(MG)	2007	G 2.7 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	OPTIMA(MG)	2007	G 2.7 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
US	OPTIMA(MG)	2007	G 2.7 DOHC	BCM [Body Control Module]	√			√	√	
US	OPTIMA(MG)	2007	G 2.7 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	OPTIMA(MG)	2007	G 2.7 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	OPTIMA(MG)	2007	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
US	OPTIMA(MG)	2006	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	
US	OPTIMA(MG)	2006	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
US	OPTIMA(MG)	2006	G 2.4 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	OPTIMA(MG)	2006	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	OPTIMA(MG)	2006	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	OPTIMA(MG)	2006	G 2.4 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	OPTIMA(MG)	2006	G 2.4 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	
US	OPTIMA(MG)	2006	G 2.4 DOHC	BCM [Body Control Module]	√			√	√	
US	OPTIMA(MG)	2006	G 2.4 DOHC	IMMO [Immobilizer]				√		
US	OPTIMA(MG)	2006	G 2.4 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	OPTIMA(MG)	2006	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
US	OPTIMA(MG)	2006	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	
US	OPTIMA(MG)	2006	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
US	OPTIMA(MG)	2006	G 2.7 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	OPTIMA(MG)	2006	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	OPTIMA(MG)	2006	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	OPTIMA(MG)	2006	G 2.7 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	OPTIMA(MG)	2006	G 2.7 DOHC	ECS [Electronic Control Suspension]	√	√	√	√	√	

US	OPTIMA(MG)	2006	G 2.7 DOHC	BCM [Body Control Module]	√			√	√	
US	OPTIMA(MG)	2006	G 2.7 DOHC	IMMO [Immobilizer]				√		
US	OPTIMA(MG)	2006	G 2.7 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	OPTIMA(MG)	2006	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
US	OPTIMA(MS)	2006	G 2.4 DOHC	ENGINE [Engine Control (M / T)]	√	√	√	√	√	0044, 0063, 0094
US	OPTIMA(MS)	2006	G 2.4 DOHC	ENGINE [Engine Control (A / T)]	√	√	√	√	√	0044, 0063, 0094
US	OPTIMA(MS)	2006	G 2.4 DOHC	AT [Automatic Transaxle]		√	√	√	√	0065
US	OPTIMA(MS)	2006	G 2.4 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
US	OPTIMA(MS)	2006	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			
US	OPTIMA(MS)	2006	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0094, 0098
US	OPTIMA(MS)	2006	G 2.7 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
US	OPTIMA(MS)	2006	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			
US	OPTIMA(MS)	2005	G 2.4 DOHC	ENGINE [Engine Control (M / T)]	√	√	√	√	√	0044, 0063, 0094
US	OPTIMA(MS)	2005	G 2.4 DOHC	ENGINE [Engine Control (A / T)]	√	√	√	√	√	0044, 0063, 0094
US	OPTIMA(MS)	2005	G 2.4 DOHC	AT [Automatic Transaxle]		√	√	√	√	0065
US	OPTIMA(MS)	2005	G 2.4 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
US	OPTIMA(MS)	2005	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			
US	OPTIMA(MS)	2005	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0094, 0098
US	OPTIMA(MS)	2005	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
US	OPTIMA(MS)	2005	G 2.7 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
US	OPTIMA(MS)	2005	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			
US	OPTIMA(MS)	2004	G 2.4 DOHC	ENGINE [Engine Control (M / T)]	√	√	√	√	√	0044
US	OPTIMA(MS)	2004	G 2.4 DOHC	ENGINE [Engine Control (A / T)]	√	√	√	√	√	0044
US	OPTIMA(MS)	2004	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
US	OPTIMA(MS)	2004	G 2.4 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
US	OPTIMA(MS)	2004	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			
US	OPTIMA(MS)	2004	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0098
US	OPTIMA(MS)	2004	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
US	OPTIMA(MS)	2004	G 2.7 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
US	OPTIMA(MS)	2004	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			
US	OPTIMA(MS)	2003	G 2.4 DOHC	ENGINE [Engine Control (M / T)]	√	√	√	√	√	0044
US	OPTIMA(MS)	2003	G 2.4 DOHC	ENGINE [Engine Control (A / T)]	√	√	√	√	√	0044
US	OPTIMA(MS)	2003	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
US	OPTIMA(MS)	2003	G 2.4 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
US	OPTIMA(MS)	2003	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			
US	OPTIMA(MS)	2003	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0098
US	OPTIMA(MS)	2003	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
US	OPTIMA(MS)	2003	G 2.7 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
US	OPTIMA(MS)	2003	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			
US	OPTIMA(MS)	2002	G 2.4 DOHC	ENGINE [Engine Control (M / T)]	√	√	√	√	√	0044
US	OPTIMA(MS)	2002	G 2.4 DOHC	ENGINE [Engine Control (A / T)]	√	√	√	√	√	0044
US	OPTIMA(MS)	2002	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
US	OPTIMA(MS)	2002	G 2.4 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0051
US	OPTIMA(MS)	2002	G 2.4 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051
US	OPTIMA(MS)	2002	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			

US	OPTIMA(MS)	2002	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0098
US	OPTIMA(MS)	2002	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
US	OPTIMA(MS)	2002	G 2.7 DOHC	ABS [Anti - Lock Brake (Bosch)]		√	√	√	√	0051
US	OPTIMA(MS)	2002	G 2.7 DOHC	ABS [Anti - Lock Brake (Mando)]		√	√	√	√	0051
US	OPTIMA(MS)	2001	G 2.4 DOHC	ENGINE [Engine Control (M / T)]	√	√	√	√	√	0044
US	OPTIMA(MS)	2001	G 2.4 DOHC	ENGINE [Engine Control (A / T)]	√	√	√	√	√	0044
US	OPTIMA(MS)	2001	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
US	OPTIMA(MS)	2001	G 2.4 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
US	OPTIMA(MS)	2001	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			
US	OPTIMA(MS)	2001	G 2.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0098
US	OPTIMA(MS)	2001	G 2.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
US	OPTIMA(MS)	2001	G 2.5 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
US	OPTIMA(MS)	2001	G 2.5 DOHC	AIRBAG [Airbag Control]	√	√	√			
US	OPTIMA(TF/QF)	2012	G 2.0 T-GDI	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0094, 0098, 0126
US	OPTIMA(TF/QF)	2012	G 2.0 T-GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	OPTIMA(TF/QF)	2012	G 2.0 T-GDI	ESC [Electronic Stability Control]	√	√	√	√	√	0051, 0077
US	OPTIMA(TF/QF)	2012	G 2.0 T-GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
US	OPTIMA(TF/QF)	2012	G 2.0 T-GDI	AIRBAG [Weight Classification]	√	√	√	√		0124
US	OPTIMA(TF/QF)	2012	G 2.0 T-GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
US	OPTIMA(TF/QF)	2012	G 2.0 T-GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2012	G 2.0 T-GDI	EPS [Power Steering]	√	√	√	√		
US	OPTIMA(TF/QF)	2012	G 2.0 T-GDI	BCM [Smart Junction Box]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2012	G 2.0 T-GDI	BCM [Body Control Module]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2012	G 2.0 T-GDI	BCM [Power Seat Module]	√	√	√	√	√	0106
US	OPTIMA(TF/QF)	2012	G 2.0 T-GDI	BCM [Cluster Module]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2012	G 2.0 T-GDI	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	OPTIMA(TF/QF)	2012	G 2.0 T-GDI	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0102
US	OPTIMA(TF/QF)	2012	G 2.0 T-GDI	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2012	G 2.0 T-GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	OPTIMA(TF/QF)	2012	G 2.0 T-GDI	CODE [Transmitter Code Saving]				√		0022
US	OPTIMA(TF/QF)	2012	G 2.4 GDI	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0087, 0094, 0098, 0126
US	OPTIMA(TF/QF)	2012	G 2.4 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	OPTIMA(TF/QF)	2012	G 2.4 GDI	ESC [Electronic Stability Control]	√	√	√	√	√	0051, 0077
US	OPTIMA(TF/QF)	2012	G 2.4 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
US	OPTIMA(TF/QF)	2012	G 2.4 GDI	AIRBAG [Weight Classification]	√	√	√	√		0124
US	OPTIMA(TF/QF)	2012	G 2.4 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
US	OPTIMA(TF/QF)	2012	G 2.4 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2012	G 2.4 GDI	EPS [Power Steering]	√	√	√	√		
US	OPTIMA(TF/QF)	2012	G 2.4 GDI	BCM [Smart Junction Box]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2012	G 2.4 GDI	BCM [Body Control Module]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2012	G 2.4 GDI	BCM [Power Seat Module]	√	√	√	√	√	0106
US	OPTIMA(TF/QF)	2012	G 2.4 GDI	BCM [Cluster Module]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2012	G 2.4 GDI	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0102

US	OPTIMA(TF/QF)	2012	G 2.4 GDI	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2012	G 2.4 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	OPTIMA(TF/QF)	2012	G 2.4 GDI	CODE [Transmitter Code Saving]				√		0022
US	OPTIMA(TF/QF)	2011	G 2.0 T-GDI	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0094, 0098, 0126
US	OPTIMA(TF/QF)	2011	G 2.0 T-GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	OPTIMA(TF/QF)	2011	G 2.0 T-GDI	ESC [Electronic Stability Control]	√	√	√	√	√	0051, 0077
US	OPTIMA(TF/QF)	2011	G 2.0 T-GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
US	OPTIMA(TF/QF)	2011	G 2.0 T-GDI	AIRBAG [Weight Classification]	√	√	√	√		0124
US	OPTIMA(TF/QF)	2011	G 2.0 T-GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
US	OPTIMA(TF/QF)	2011	G 2.0 T-GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2011	G 2.0 T-GDI	EPS [Power Steering]	√	√	√	√		
US	OPTIMA(TF/QF)	2011	G 2.0 T-GDI	BCM [Smart Junction Box]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2011	G 2.0 T-GDI	BCM [Body Control Module]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2011	G 2.0 T-GDI	BCM [Power Seat Module]	√	√	√	√	√	0106
US	OPTIMA(TF/QF)	2011	G 2.0 T-GDI	BCM [Cluster Module]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2011	G 2.0 T-GDI	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	OPTIMA(TF/QF)	2011	G 2.0 T-GDI	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0102
US	OPTIMA(TF/QF)	2011	G 2.0 T-GDI	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2011	G 2.0 T-GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	OPTIMA(TF/QF)	2011	G 2.0 T-GDI	CODE [Transmitter Code Saving]				√		0022
US	OPTIMA(TF/QF)	2011	G 2.4 GDI	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0087, 0094, 0098, 0126
US	OPTIMA(TF/QF)	2011	G 2.4 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	OPTIMA(TF/QF)	2011	G 2.4 GDI	ESC [Electronic Stability Control]	√	√	√	√	√	0051, 0077
US	OPTIMA(TF/QF)	2011	G 2.4 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
US	OPTIMA(TF/QF)	2011	G 2.4 GDI	AIRBAG [Weight Classification]	√	√	√	√		0124
US	OPTIMA(TF/QF)	2011	G 2.4 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
US	OPTIMA(TF/QF)	2011	G 2.4 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2011	G 2.4 GDI	EPS [Power Steering]	√	√	√	√		
US	OPTIMA(TF/QF)	2011	G 2.4 GDI	BCM [Smart Junction Box]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2011	G 2.4 GDI	BCM [Body Control Module]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2011	G 2.4 GDI	BCM [Power Seat Module]	√	√	√	√	√	0106
US	OPTIMA(TF/QF)	2011	G 2.4 GDI	BCM [Cluster Module]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2011	G 2.4 GDI	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	OPTIMA(TF/QF)	2011	G 2.4 GDI	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0102
US	OPTIMA(TF/QF)	2011	G 2.4 GDI	AHLS [Auto Headlamp Leveling]	√	√	√	√	√	
US	OPTIMA(TF/QF)	2011	G 2.4 GDI	CODE [Transmitter Code Saving]				√		0022
US	RIO(BC)	2005	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√		0044, 0094
US	RIO(BC)	2005	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	RIO(BC)	2005	G 1.6 DOHC	ABS [Anti - Lock Brake System]		√	√	√	√	0051
US	RIO(BC)	2004	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√		0044
US	RIO(BC)	2004	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	RIO(BC)	2004	G 1.6 DOHC	ABS [Anti - Lock Brake System]		√	√	√	√	0051

US	RIO(BC)	2003	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√		0044
US	RIO(BC)	2003	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	RIO(BC)	2003	G 1.6 DOHC	ABS [Anti - Lock Brake System]		√	√	√	√	0051
US	RIO(BC)	2002	G 1.5 DOHC	ENGINE [Engine Control]	√	√	√	√		0044
US	RIO(BC)	2002	G 1.5 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	RIO(BC)	2001	G 1.5 DOHC	ENGINE [Engine Control]	√	√	√	√		0044
US	RIO(BC)	2001	G 1.5 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	RIO(JB)	2011	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0094, 0081, 0044, 0098
US	RIO(JB)	2011	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	RIO(JB)	2011	G 1.6 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
US	RIO(JB)	2011	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	RIO(JB)	2011	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	RIO(JB)	2011	G 1.6 DOHC	EPS [Power Steering]	√	√	√	√		
US	RIO(JB)	2011	G 1.6 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	RIO(JB)	2010	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0094, 0081, 0044, 0098
US	RIO(JB)	2010	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	RIO(JB)	2010	G 1.6 DOHC	ABS [Anti - Lock Brake]	√	√	√	√	√	0051
US	RIO(JB)	2010	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	RIO(JB)	2010	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	RIO(JB)	2010	G 1.6 DOHC	EPS [Power Steering]	√	√	√	√		
US	RIO(JB)	2010	G 1.6 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	RIO(JB)	2009	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0094, 0081, 0044, 0098
US	RIO(JB)	2009	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	RIO(JB)	2009	G 1.6 DOHC	ABS [ABS (MGH - 40)]	√	√	√	√	√	
US	RIO(JB)	2009	G 1.6 DOHC	ABS [ABS (MGH - 25)]	√	√	√	√	√	0051
US	RIO(JB)	2009	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	RIO(JB)	2009	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	RIO(JB)	2009	G 1.6 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	RIO(JB)	2008	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0094, 0081, 0044, 0098
US	RIO(JB)	2008	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	RIO(JB)	2008	G 1.6 DOHC	ABS [ABS (MGH - 25)]	√	√	√	√	√	0051
US	RIO(JB)	2008	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	RIO(JB)	2008	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	RIO(JB)	2008	G 1.6 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	RIO(JB)	2007	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0094, 0081, 0044, 0098
US	RIO(JB)	2007	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	RIO(JB)	2007	G 1.6 DOHC	ABS [Anti - Lock Brake System]	√	√	√	√	√	0051
US	RIO(JB)	2007	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	RIO(JB)	2007	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	RIO(JB)	2007	G 1.6 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	RIO(JB)	2006	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0094, 0081, 0044, 0098
US	RIO(JB)	2006	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	RIO(JB)	2006	G 1.6 DOHC	ABS [Anti - Lock Brake System]	√	√	√	√	√	0051
US	RIO(JB)	2006	G 1.6 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	RIO(JB)	2006	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	

US	RIO(JB)	2006	G 1.6 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√	√	√	
US	RIO(UB)	2013	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√	√	0044, 0061, 0094, 0126
US	RIO(UB)	2013	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	RIO(UB)	2013	G 1.6 GDI	ABSESC [ABS / ESC]	√	√	√	√	√	0051, 0077
US	RIO(UB)	2013	G 1.6 GDI	AIRBAG [Weight Classification]	√	√	√	√		0124
US	RIO(UB)	2013	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
US	RIO(UB)	2013	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
US	RIO(UB)	2013	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
US	RIO(UB)	2013	G 1.6 GDI	EPS [Motor driven Power Steering]	√	√	√	√	√	
US	RIO(UB)	2013	G 1.6 GDI	BCM [Body Control Module]	√	√	√	√	√	
US	RIO(UB)	2013	G 1.6 GDI	IMMO [Immobilizer]		√	√	√		0075, 0083, 0092, 0119
US	RIO(UB)	2013	G 1.6 GDI	PIC [Smart Key Unit]	√	√	√	√	√	0023, 0045, 0102
US	RIO(UB)	2013	G 1.6 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	RIO(UB)	2013	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
US	RIO(UB)	2012	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√	√	0044, 0061, 0094, 0126
US	RIO(UB)	2012	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	RIO(UB)	2012	G 1.6 GDI	ABSESC [ABS / ESC]	√	√	√	√	√	0051, 0077
US	RIO(UB)	2012	G 1.6 GDI	AIRBAG [Weight Classification]	√	√	√	√		0124
US	RIO(UB)	2012	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
US	RIO(UB)	2012	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
US	RIO(UB)	2012	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
US	RIO(UB)	2012	G 1.6 GDI	EPS [Motor driven Power Steering]	√	√	√	√	√	
US	RIO(UB)	2012	G 1.6 GDI	IMMO [Immobilizer]		√	√	√		0075, 0083, 0092, 0119
US	RIO(UB)	2012	G 1.6 GDI	PIC [Smart Key Unit]	√	√	√	√	√	0023, 0045, 0102
US	RIO(UB)	2012	G 1.6 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	RIO(UB)	2012	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
US	RONDO(UN)	2010	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0011, 0011, 0126, 0044, 0081, 0094, 0098
US	RONDO(UN)	2010	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	RONDO(UN)	2010	G 2.4 DOHC	ABSESC [ABS / ESC]	√	√	√	√	√	0051
US	RONDO(UN)	2010	G 2.4 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	RONDO(UN)	2010	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	RONDO(UN)	2010	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	RONDO(UN)	2010	G 2.4 DOHC	BCM [Body Control Module]	√			√	√	
US	RONDO(UN)	2010	G 2.4 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	RONDO(UN)	2010	G 2.4 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	RONDO(UN)	2010	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
US	RONDO(UN)	2010	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0081, 0086, 0094, 0126
US	RONDO(UN)	2010	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	RONDO(UN)	2010	G 2.7 DOHC	ABSESC [ABS / ESC]	√	√	√	√	√	0051
US	RONDO(UN)	2010	G 2.7 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	RONDO(UN)	2010	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	RONDO(UN)	2010	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	RONDO(UN)	2010	G 2.7 DOHC	BCM [Body Control Module]	√			√	√	

US	RONDO(UN)	2010	G 2.7 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	RONDO(UN)	2010	G 2.7 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	RONDO(UN)	2010	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
US	RONDO(UN)	2009	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	
US	RONDO(UN)	2009	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	RONDO(UN)	2009	G 2.4 DOHC	ABSESC [ABS / ESC (MGH - 40)]	√	√	√	√	√	
US	RONDO(UN)	2009	G 2.4 DOHC	ABSESC [ABS / ESC (MGH - 25)]	√	√	√	√	√	0051
US	RONDO(UN)	2009	G 2.4 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	RONDO(UN)	2009	G 2.4 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	RONDO(UN)	2009	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	RONDO(UN)	2009	G 2.4 DOHC	BCM [Body Control Module]	√			√	√	
US	RONDO(UN)	2009	G 2.4 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	RONDO(UN)	2009	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
US	RONDO(UN)	2009	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0081, 0086, 0094, 0126
US	RONDO(UN)	2009	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	RONDO(UN)	2009	G 2.7 DOHC	ABSESC [ABS / ESC (MGH - 40)]	√	√	√	√	√	
US	RONDO(UN)	2009	G 2.7 DOHC	ABSESC [ABS / ESC (MGH - 25)]	√	√	√	√	√	0051
US	RONDO(UN)	2009	G 2.7 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	RONDO(UN)	2009	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	RONDO(UN)	2009	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	RONDO(UN)	2009	G 2.7 DOHC	BCM [Body Control Module]	√			√	√	
US	RONDO(UN)	2009	G 2.7 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	RONDO(UN)	2009	G 2.7 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	RONDO(UN)	2009	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
US	RONDO(UN)	2008	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0011, 0044, 0094, 0081, 0044, 0098
US	RONDO(UN)	2008	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	RONDO(UN)	2008	G 2.4 DOHC	ABS [ABS / ESC (MGH - 40)]	√	√	√	√	√	
US	RONDO(UN)	2008	G 2.4 DOHC	ABS [ABS / ESC (MGH - 25)]	√	√	√	√	√	0051
US	RONDO(UN)	2008	G 2.4 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	RONDO(UN)	2008	G 2.4 DOHC	AIRBAG [Airbag Control Unit]	√	√	√			0090
US	RONDO(UN)	2008	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	RONDO(UN)	2008	G 2.4 DOHC	BCM [Body Control Module]	√			√	√	
US	RONDO(UN)	2008	G 2.4 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	RONDO(UN)	2008	G 2.4 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	RONDO(UN)	2008	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
US	RONDO(UN)	2008	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0081, 0086, 0094, 0126
US	RONDO(UN)	2008	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	RONDO(UN)	2008	G 2.7 DOHC	ABS [ABS / ESC (MGH - 40)]	√	√	√	√	√	
US	RONDO(UN)	2008	G 2.7 DOHC	ABS [ABS / ESC (MGH - 25)]	√	√	√	√	√	0051
US	RONDO(UN)	2008	G 2.7 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	RONDO(UN)	2008	G 2.7 DOHC	AIRBAG [Airbag Control Unit]	√	√	√			0090

US	RONDO(UN)	2008	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	RONDO(UN)	2008	G 2.7 DOHC	BCM [Body Control Module]	√			√	√	
US	RONDO(UN)	2008	G 2.7 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	RONDO(UN)	2008	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
US	RONDO(UN)	2007	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0011, 0044, 0094, 0081, 0044, 0098
US	RONDO(UN)	2007	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	RONDO(UN)	2007	G 2.4 DOHC	ABS [Anti - Lock Brake System]	√	√	√	√	√	0051
US	RONDO(UN)	2007	G 2.4 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	RONDO(UN)	2007	G 2.4 DOHC	AIRBAG [Airbag Control Unit]	√	√	√			0090
US	RONDO(UN)	2007	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	RONDO(UN)	2007	G 2.4 DOHC	BCM [Body Control Module]	√			√	√	
US	RONDO(UN)	2007	G 2.4 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	RONDO(UN)	2007	G 2.4 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	RONDO(UN)	2007	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
US	RONDO(UN)	2007	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0081, 0086, 0094, 0126
US	RONDO(UN)	2007	G 2.7 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	RONDO(UN)	2007	G 2.7 DOHC	ABS [Anti - Lock Brake System]	√	√	√	√	√	0051
US	RONDO(UN)	2007	G 2.7 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	RONDO(UN)	2007	G 2.7 DOHC	AIRBAG [Airbag Control Unit]	√	√	√			0090
US	RONDO(UN)	2007	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	RONDO(UN)	2007	G 2.7 DOHC	BCM [Body Control Module]	√			√	√	
US	RONDO(UN)	2007	G 2.7 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	RONDO(UN)	2007	G 2.7 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	RONDO(UN)	2007	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SEDONA(GQ)	2005	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0063, 0094
US	SEDONA(GQ)	2005	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0065
US	SEDONA(GQ)	2005	G 3.5 DOHC	ABS [Anti - Lock Brake System]		√	√	√	√	0051
US	SEDONA(GQ)	2005	G 3.5 DOHC	AIRBAG [Airbag Control]		√	√			
US	SEDONA(GQ)	2004	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0063
US	SEDONA(GQ)	2004	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
US	SEDONA(GQ)	2004	G 3.5 DOHC	ABS [Anti - Lock Brake System]		√	√	√	√	0051
US	SEDONA(GQ)	2004	G 3.5 DOHC	AIRBAG [Airbag Control]		√	√			
US	SEDONA(GQ)	2003	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0063
US	SEDONA(GQ)	2003	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
US	SEDONA(GQ)	2003	G 3.5 DOHC	ABS [Anti - Lock Brake System]		√	√	√	√	0051
US	SEDONA(GQ)	2003	G 3.5 DOHC	AIRBAG [Airbag Control]		√	√			
US	SEDONA(GQ)	2002	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0063
US	SEDONA(GQ)	2002	G 3.5 DOHC	ABS [Anti - Lock Brake System]		√	√	√	√	0051
US	SEDONA(GQ)	2002	G 3.5 DOHC	AIRBAG [Airbag Control]		√	√			
US	SEDONA(VQ)	2012	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0086, 0094, 0123, 0126
US	SEDONA(VQ)	2012	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SEDONA(VQ)	2012	G 3.5 DOHC	ABSESC [ABS (MEB - 2)]	√	√	√	√	√	0051

US	SEDONA(VQ)	2012	G 3.5 DOHC	ABSESC [ESC (MEB - 2)]	√	√	√	√	√	0051
US	SEDONA(VQ)	2012	G 3.5 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			0090
US	SEDONA(VQ)	2012	G 3.5 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
US	SEDONA(VQ)	2012	G 3.5 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	SEDONA(VQ)	2012	G 3.5 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SEDONA(VQ)	2012	G 3.5 DOHC	BCM [Rear Area Module]	√	√	√	√	√	
US	SEDONA(VQ)	2012	G 3.5 DOHC	BCM [Front Area Module]	√	√	√	√	√	
US	SEDONA(VQ)	2012	G 3.5 DOHC	BCM [Driver Door Module]	√	√	√	√	√	
US	SEDONA(VQ)	2012	G 3.5 DOHC	BCM [Assist Door Module]	√	√	√	√	√	
US	SEDONA(VQ)	2012	G 3.5 DOHC	BCM [Integrated Memory System]	√	√	√	√	√	
US	SEDONA(VQ)	2012	G 3.5 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
US	SEDONA(VQ)	2012	G 3.5 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SEDONA(VQ)	2012	G 3.5 DOHC	PSD [Power Sliding Door - LH]	√	√	√	√		
US	SEDONA(VQ)	2012	G 3.5 DOHC	PSD [Power Sliding Door - RH]	√	√	√	√		
US	SEDONA(VQ)	2012	G 3.5 DOHC	PTG [Power Tail Gate]	√	√	√	√		
US	SEDONA(VQ)	2012	G 3.5 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SEDONA(VQ)	2012	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SEDONA(VQ)	2011	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0086, 0094, 0123, 0126
US	SEDONA(VQ)	2011	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SEDONA(VQ)	2011	G 3.5 DOHC	ABSESC [ABS (MEB - 2)]	√	√	√	√	√	0051
US	SEDONA(VQ)	2011	G 3.5 DOHC	ABSESC [ESC (MEB - 2)]	√	√	√	√	√	0051
US	SEDONA(VQ)	2011	G 3.5 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			0090
US	SEDONA(VQ)	2011	G 3.5 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
US	SEDONA(VQ)	2011	G 3.5 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	SEDONA(VQ)	2011	G 3.5 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SEDONA(VQ)	2011	G 3.5 DOHC	BCM [Rear Area Module]	√	√	√	√	√	
US	SEDONA(VQ)	2011	G 3.5 DOHC	BCM [Front Area Module]	√	√	√	√	√	
US	SEDONA(VQ)	2011	G 3.5 DOHC	BCM [Driver Door Module]	√	√	√	√	√	
US	SEDONA(VQ)	2011	G 3.5 DOHC	BCM [Assist Door Module]	√	√	√	√	√	
US	SEDONA(VQ)	2011	G 3.5 DOHC	BCM [Integrated Memory System]	√	√	√	√	√	
US	SEDONA(VQ)	2011	G 3.5 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
US	SEDONA(VQ)	2011	G 3.5 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SEDONA(VQ)	2011	G 3.5 DOHC	PSD [Power Sliding Door - RH]	√	√	√	√		
US	SEDONA(VQ)	2011	G 3.5 DOHC	PTG [Power Tail Gate]	√	√	√	√		
US	SEDONA(VQ)	2011	G 3.5 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SEDONA(VQ)	2011	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SEDONA(VQ)	2010	G 3.8 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0094, 0081, 0086, 0044
US	SEDONA(VQ)	2010	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SEDONA(VQ)	2010	G 3.8 DOHC	ABSESC [ABS (MEB - 2)]	√	√	√	√	√	0051
US	SEDONA(VQ)	2010	G 3.8 DOHC	ABSESC [ESC (MEB - 2)]	√	√	√	√	√	0051
US	SEDONA(VQ)	2010	G 3.8 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			0090
US	SEDONA(VQ)	2010	G 3.8 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
US	SEDONA(VQ)	2010	G 3.8 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124

US	SEDONA(VQ)	2010	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SEDONA(VQ)	2010	G 3.8 DOHC	BCM [Rear Area Module]	√	√	√	√	√	
US	SEDONA(VQ)	2010	G 3.8 DOHC	BCM [Front Area Module]	√	√	√	√	√	
US	SEDONA(VQ)	2010	G 3.8 DOHC	BCM [Driver Door Module]	√	√	√	√	√	
US	SEDONA(VQ)	2010	G 3.8 DOHC	BCM [Assist Door Module]	√	√	√	√	√	
US	SEDONA(VQ)	2010	G 3.8 DOHC	BCM [Integrated Memory System]	√	√	√	√	√	
US	SEDONA(VQ)	2010	G 3.8 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
US	SEDONA(VQ)	2010	G 3.8 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SEDONA(VQ)	2010	G 3.8 DOHC	PSD [Power Sliding Door - LH]	√	√	√	√		
US	SEDONA(VQ)	2010	G 3.8 DOHC	PSD [Power Sliding Door - RH]	√	√	√	√		
US	SEDONA(VQ)	2010	G 3.8 DOHC	PTG [Power Tail Gate]	√	√	√	√		
US	SEDONA(VQ)	2010	G 3.8 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SEDONA(VQ)	2010	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SEDONA(VQ)	2009	G 3.8 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0094, 0081, 0086, 0044
US	SEDONA(VQ)	2009	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SEDONA(VQ)	2009	G 3.8 DOHC	ABSESC [ABS / ESC]	√	√	√	√	√	0051
US	SEDONA(VQ)	2009	G 3.8 DOHC	AIRBAG [Airbag Control Unit]	√	√	√			
US	SEDONA(VQ)	2009	G 3.8 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	SEDONA(VQ)	2009	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SEDONA(VQ)	2009	G 3.8 DOHC	BCM [Assist Door Module]	√	√	√	√	√	
US	SEDONA(VQ)	2009	G 3.8 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
US	SEDONA(VQ)	2009	G 3.8 DOHC	BCM [Front Area Module]	√	√	√	√	√	
US	SEDONA(VQ)	2009	G 3.8 DOHC	BCM [Driver Door Module]	√	√	√	√	√	
US	SEDONA(VQ)	2009	G 3.8 DOHC	BCM [Integrated Memory System]	√	√	√	√	√	
US	SEDONA(VQ)	2009	G 3.8 DOHC	BCM [Rear Area Module]	√	√	√	√	√	
US	SEDONA(VQ)	2009	G 3.8 DOHC	PSD [Power Sliding Door - LH]	√	√	√	√		
US	SEDONA(VQ)	2009	G 3.8 DOHC	PSD [Power Sliding Door - RH]	√	√	√	√		
US	SEDONA(VQ)	2009	G 3.8 DOHC	PTG [Power Tail Gate]	√	√	√	√		
US	SEDONA(VQ)	2009	G 3.8 DOHC	TPMS [TPMS (LOW)]	√	√	√		√	
US	SEDONA(VQ)	2009	G 3.8 DOHC	TPMS [TPMS (HIGH)]	√	√	√		√	
US	SEDONA(VQ)	2009	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SEDONA(VQ)	2008	G 3.8 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0094, 0081, 0086, 0044
US	SEDONA(VQ)	2008	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SEDONA(VQ)	2008	G 3.8 DOHC	ABSESC [ABS / ESC]	√	√	√	√	√	0051
US	SEDONA(VQ)	2008	G 3.8 DOHC	AIRBAG [Airbag Control Unit]	√	√	√			
US	SEDONA(VQ)	2008	G 3.8 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	SEDONA(VQ)	2008	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SEDONA(VQ)	2008	G 3.8 DOHC	BCM [Driver Door Module]	√	√	√	√	√	
US	SEDONA(VQ)	2008	G 3.8 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
US	SEDONA(VQ)	2008	G 3.8 DOHC	BCM [Rear Area Module]	√	√	√	√	√	
US	SEDONA(VQ)	2008	G 3.8 DOHC	BCM [Assist Door Module]	√	√	√	√	√	
US	SEDONA(VQ)	2008	G 3.8 DOHC	BCM [Integrated Memory System]	√	√	√	√	√	
US	SEDONA(VQ)	2008	G 3.8 DOHC	BCM [Front Area Module]	√	√	√	√	√	

US	SEDONA(VQ)	2008	G 3.8 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SEDONA(VQ)	2008	G 3.8 DOHC	PSD [Power Sliding Door - LH]	√	√	√	√		
US	SEDONA(VQ)	2008	G 3.8 DOHC	PSD [Power Sliding Door - RH]	√	√	√	√		
US	SEDONA(VQ)	2008	G 3.8 DOHC	PTG [Power Tail Gate]	√	√	√	√		
US	SEDONA(VQ)	2008	G 3.8 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SEDONA(VQ)	2008	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SEDONA(VQ)	2007	G 3.8 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0094, 0081, 0086, 0044
US	SEDONA(VQ)	2007	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SEDONA(VQ)	2007	G 3.8 DOHC	ABSESC [ABS / ESC]	√	√	√	√	√	0051
US	SEDONA(VQ)	2007	G 3.8 DOHC	AIRBAG [Airbag Control Unit]	√	√	√			
US	SEDONA(VQ)	2007	G 3.8 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	SEDONA(VQ)	2007	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SEDONA(VQ)	2007	G 3.8 DOHC	BCM [Driver Door Module]	√	√	√	√	√	
US	SEDONA(VQ)	2007	G 3.8 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
US	SEDONA(VQ)	2007	G 3.8 DOHC	BCM [Rear Area Module]	√	√	√	√	√	
US	SEDONA(VQ)	2007	G 3.8 DOHC	BCM [Assist Door Module]	√	√	√	√	√	
US	SEDONA(VQ)	2007	G 3.8 DOHC	BCM [Integrated Memory System]	√	√	√	√	√	
US	SEDONA(VQ)	2007	G 3.8 DOHC	BCM [Front Area Module]	√	√	√	√	√	
US	SEDONA(VQ)	2007	G 3.8 DOHC	PSD [Power Sliding Door - LH]	√	√	√	√		
US	SEDONA(VQ)	2007	G 3.8 DOHC	PSD [Power Sliding Door - RH]	√	√	√	√		
US	SEDONA(VQ)	2007	G 3.8 DOHC	PTG [Power Tail Gate]	√	√	√	√		
US	SEDONA(VQ)	2007	G 3.8 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SEDONA(VQ)	2007	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SEDONA(VQ)	2006	G 3.8 DOHC	ENGINE [Engine Control]	√	√	√	√	√	
US	SEDONA(VQ)	2006	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
US	SEDONA(VQ)	2006	G 3.8 DOHC	ABSESC [Electronic Stability Control]	√	√	√	√	√	0051
US	SEDONA(VQ)	2006	G 3.8 DOHC	AIRBAG [Airbag Control Unit]	√	√	√			
US	SEDONA(VQ)	2006	G 3.8 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	SEDONA(VQ)	2006	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SEDONA(VQ)	2006	G 3.8 DOHC	BCM [Driver Door Module]	√	√	√	√	√	
US	SEDONA(VQ)	2006	G 3.8 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
US	SEDONA(VQ)	2006	G 3.8 DOHC	BCM [Rear Area Module]	√	√	√	√	√	
US	SEDONA(VQ)	2006	G 3.8 DOHC	BCM [Assist Door Module]	√	√	√	√	√	
US	SEDONA(VQ)	2006	G 3.8 DOHC	BCM [Integrated Memory System]	√	√	√	√	√	
US	SEDONA(VQ)	2006	G 3.8 DOHC	BCM [Front Area Module]	√	√	√	√	√	
US	SEDONA(VQ)	2006	G 3.8 DOHC	IMMO [Immobilizer]				√		
US	SEDONA(VQ)	2006	G 3.8 DOHC	PSD [Power Sliding Door - LH]	√	√	√	√		
US	SEDONA(VQ)	2006	G 3.8 DOHC	PSD [Power Sliding Door - RH]	√	√	√	√		
US	SEDONA(VQ)	2006	G 3.8 DOHC	PTG [Power Tail Gate]	√	√	√	√		
US	SEDONA(VQ)	2006	G 3.8 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SEDONA(VQ)	2006	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SEPHIA(FB)	2001	G 1.8 DOHC	ENGINE [Engine Control]	√	√	√	√		
US	SEPHIA(FB)	2001	G 1.8 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	SEPHIA(FB)	2000	G 1.8 DOHC	ENGINE [Engine Control]	√	√	√	√		

US	SEPHIA(FB)	2000	G 1.8 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	SEPHIA(FB)	1999	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√		
US	SEPHIA(FB)	1999	G 1.8 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	SEPHIA(FB)	1999	G 1.8 DOHC	ABS [Anti - Lock Brake System]		√	√	√	√	
US	SEPHIA(FB)	1998	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√		
US	SEPHIA(FB)	1998	G 1.8 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	SEPHIA(FB)	1998	G 1.8 DOHC	ABS [Anti - Lock Brake System]		√	√	√	√	
US	SEPHIA(FB)	1997	G 1.6 DOHC	ENGINE [Engine Control]		√	√	√		
US	SEPHIA(FB)	1997	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	SEPHIA(FB)	1997	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√		
US	SEPHIA(FB)	1996	G 1.6 DOHC	ENGINE [Engine Control]		√	√	√		
US	SEPHIA(FB)	1996	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	SEPHIA(FB)	1996	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√		
US	SEPHIA(FB)	1996	G 1.8 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	SEPHIA(FB)	1995	G 1.6 DOHC	ENGINE [Engine Control]		√	√	√		
US	SEPHIA(FB)	1995	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	SEPHIA(FB)	1995	G 1.6 SOHC	ENGINE [Engine Control]		√	√	√		
US	SEPHIA(FB)	1995	G 1.6 SOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	SEPHIA(FB)	1995	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√		
US	SEPHIA(FB)	1995	G 1.8 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	SEPHIA(FB)	1994	G 1.6 DOHC	ENGINE [Engine Control]		√	√	√		
US	SEPHIA(FB)	1994	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	SEPHIA(FB)	1994	G 1.6 SOHC	ENGINE [Engine Control]		√	√	√		
US	SEPHIA(FB)	1994	G 1.6 SOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	SEPHIA(FB)	1994	G 1.8 DOHC	ENGINE [Engine Control]		√	√	√		
US	SEPHIA(FB)	1994	G 1.8 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	SORENTO(BL)	2009	G 3.3 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0081, 0086, 0094, 0126
US	SORENTO(BL)	2009	G 3.3 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0116, 0099
US	SORENTO(BL)	2009	G 3.3 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	SORENTO(BL)	2009	G 3.3 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	SORENTO(BL)	2009	G 3.3 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SORENTO(BL)	2009	G 3.3 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	SORENTO(BL)	2009	G 3.3 DOHC	4WD [4WD Control]		√	√			
US	SORENTO(BL)	2009	G 3.3 DOHC	BCM [Body Control Module]	√			√	√	
US	SORENTO(BL)	2009	G 3.3 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SORENTO(BL)	2009	G 3.3 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SORENTO(BL)	2009	G 3.3 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SORENTO(BL)	2009	G 3.8 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0081, 0086, 0094, 0126
US	SORENTO(BL)	2009	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099, 0116
US	SORENTO(BL)	2009	G 3.8 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	SORENTO(BL)	2009	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	SORENTO(BL)	2009	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SORENTO(BL)	2009	G 3.8 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	SORENTO(BL)	2009	G 3.8 DOHC	4WD [4WD Control]		√	√			

US	SORENTO(BL)	2009	G 3.8 DOHC	BCM [Body Control Module]	√			√	√	
US	SORENTO(BL)	2009	G 3.8 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SORENTO(BL)	2009	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SORENTO(BL)	2008	G 3.3 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0081, 0086, 0094, 0126
US	SORENTO(BL)	2008	G 3.3 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099, 0116
US	SORENTO(BL)	2008	G 3.3 DOHC	ABSESC [ABS / ESC]	√	√	√	√	√	0051
US	SORENTO(BL)	2008	G 3.3 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	SORENTO(BL)	2008	G 3.3 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SORENTO(BL)	2008	G 3.3 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	SORENTO(BL)	2008	G 3.3 DOHC	4WD [4WD Control (TOD)]		√	√			
US	SORENTO(BL)	2008	G 3.3 DOHC	BCM [Body Control Module]	√			√	√	
US	SORENTO(BL)	2008	G 3.3 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SORENTO(BL)	2008	G 3.3 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SORENTO(BL)	2008	G 3.3 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SORENTO(BL)	2008	G 3.8 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0081, 0086, 0094, 0126
US	SORENTO(BL)	2008	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099, 0116
US	SORENTO(BL)	2008	G 3.8 DOHC	ABSESC [ABS / ESC]	√	√	√	√	√	0051
US	SORENTO(BL)	2008	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	SORENTO(BL)	2008	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SORENTO(BL)	2008	G 3.8 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	SORENTO(BL)	2008	G 3.8 DOHC	4WD [4WD Control (TOD)]		√	√			
US	SORENTO(BL)	2008	G 3.8 DOHC	BCM [Body Control Module]	√			√	√	
US	SORENTO(BL)	2008	G 3.8 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SORENTO(BL)	2008	G 3.8 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SORENTO(BL)	2008	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SORENTO(BL)	2007	G 3.3 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0081, 0086, 0094, 0126
US	SORENTO(BL)	2007	G 3.3 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099, 0116
US	SORENTO(BL)	2007	G 3.3 DOHC	ABSESC [ABS / ESC]	√	√	√	√	√	0051
US	SORENTO(BL)	2007	G 3.3 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	SORENTO(BL)	2007	G 3.3 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SORENTO(BL)	2007	G 3.3 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	SORENTO(BL)	2007	G 3.3 DOHC	4WD [4WD Control (TOD)]		√	√			
US	SORENTO(BL)	2007	G 3.3 DOHC	BCM [Body Control Module]	√			√	√	
US	SORENTO(BL)	2007	G 3.3 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SORENTO(BL)	2007	G 3.3 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SORENTO(BL)	2007	G 3.8 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0081, 0086, 0094, 0126
US	SORENTO(BL)	2007	G 3.8 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099, 0116
US	SORENTO(BL)	2007	G 3.8 DOHC	ABSESC [ABS / ESC]	√	√	√	√	√	0051
US	SORENTO(BL)	2007	G 3.8 DOHC	AIRBAG [Airbag Control]	√	√	√			0090
US	SORENTO(BL)	2007	G 3.8 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SORENTO(BL)	2007	G 3.8 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	SORENTO(BL)	2007	G 3.8 DOHC	4WD [4WD Control (TOD)]		√	√			

US	SORENTO(BL)	2007	G 3.8 DOHC	BCM [Body Control Module]	√			√	√	
US	SORENTO(BL)	2007	G 3.8 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SORENTO(BL)	2007	G 3.8 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SORENTO(BL)	2007	G 3.8 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SORENTO(BL)	2006	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0063, 0094
US	SORENTO(BL)	2006	G 3.5 DOHC	ABS [Anti - Lock Brake System]	√	√	√	√	√	0051
US	SORENTO(BL)	2006	G 3.5 DOHC	AIRBAG [Airbag Control]	√	√	√			0091
US	SORENTO(BL)	2006	G 3.5 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	SORENTO(BL)	2006	G 3.5 DOHC	4WD [4WD Control (TOD)]		√	√			
US	SORENTO(BL)	2005	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0063, 0094
US	SORENTO(BL)	2005	G 3.5 DOHC	ABS [Anti - Lock Brake System]	√	√	√	√	√	0051
US	SORENTO(BL)	2005	G 3.5 DOHC	AIRBAG [Airbag Control]	√	√	√			0091
US	SORENTO(BL)	2005	G 3.5 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	SORENTO(BL)	2005	G 3.5 DOHC	4WD [4WD Control (TOD)]		√	√			
US	SORENTO(BL)	2004	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0063
US	SORENTO(BL)	2004	G 3.5 DOHC	AT [Automatic Transaxle]		√	√	√	√	
US	SORENTO(BL)	2004	G 3.5 DOHC	ABS [Anti - Lock Brake System]	√	√	√	√	√	0051
US	SORENTO(BL)	2004	G 3.5 DOHC	AIRBAG [Airbag Control]	√	√	√			
US	SORENTO(BL)	2004	G 3.5 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	SORENTO(BL)	2004	G 3.5 DOHC	4WD [4WD Control (TOD)]		√	√			
US	SORENTO(BL)	2003	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0063
US	SORENTO(BL)	2003	G 3.5 DOHC	AT [Automatic Transaxle]		√	√	√	√	
US	SORENTO(BL)	2003	G 3.5 DOHC	ABS [Anti - Lock Brake System]	√	√	√	√	√	0051
US	SORENTO(BL)	2003	G 3.5 DOHC	AIRBAG [Airbag Control]	√	√	√			
US	SORENTO(BL)	2003	G 3.5 DOHC	EPS [Electronic Power Steering]	√	√	√	√		
US	SORENTO(BL)	2003	G 3.5 DOHC	4WD [4WD Control (TOD)]		√	√			
US	SORENTO(XM)	2013	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0011, 0044, 0094, 0081, 0087, 0098
US	SORENTO(XM)	2013	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SORENTO(XM)	2013	G 2.4 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	SORENTO(XM)	2013	G 2.4 DOHC	AIRBAG [Weight Classification]	√	√	√			
US	SORENTO(XM)	2013	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
US	SORENTO(XM)	2013	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SORENTO(XM)	2013	G 2.4 DOHC	4WD [4WD Control]	√	√	√	√		0007, 0120
US	SORENTO(XM)	2013	G 2.4 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
US	SORENTO(XM)	2013	G 2.4 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SORENTO(XM)	2013	G 2.4 DOHC	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0088, 0102
US	SORENTO(XM)	2013	G 2.4 DOHC	PIC [Smart Key Code Saving]				√		
US	SORENTO(XM)	2013	G 2.4 DOHC	PIC [Power Distribution Module]	√	√	√	√	√	
US	SORENTO(XM)	2013	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	SORENTO(XM)	2013	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SORENTO(XM)	2013	G 2.4 GDI	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0050, 0087, 0094, 0098, 0126
US	SORENTO(XM)	2013	G 2.4 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099

US	SORENTO(XM)	2013	G 2.4 GDI	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	SORENTO(XM)	2013	G 2.4 GDI	AIRBAG [Weight Classification]	√	√	√			
US	SORENTO(XM)	2013	G 2.4 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
US	SORENTO(XM)	2013	G 2.4 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
US	SORENTO(XM)	2013	G 2.4 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SORENTO(XM)	2013	G 2.4 GDI	4WD [4WD Control]	√	√	√	√		0007, 0120
US	SORENTO(XM)	2013	G 2.4 GDI	BCM [Instrument Panel Module]	√	√	√	√	√	
US	SORENTO(XM)	2013	G 2.4 GDI	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SORENTO(XM)	2013	G 2.4 GDI	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0088, 0102
US	SORENTO(XM)	2013	G 2.4 GDI	PIC [Smart Key Code Saving]				√		
US	SORENTO(XM)	2013	G 2.4 GDI	PIC [Power Distribution Module]	√	√	√	√	√	
US	SORENTO(XM)	2013	G 2.4 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	SORENTO(XM)	2013	G 2.4 GDI	CODE [Transmitter Code Saving]				√		0022
US	SORENTO(XM)	2013	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0086, 0094, 0123, 0126
US	SORENTO(XM)	2013	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SORENTO(XM)	2013	G 3.5 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	SORENTO(XM)	2013	G 3.5 DOHC	AIRBAG [Weight Classification]	√	√	√			
US	SORENTO(XM)	2013	G 3.5 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
US	SORENTO(XM)	2013	G 3.5 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
US	SORENTO(XM)	2013	G 3.5 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SORENTO(XM)	2013	G 3.5 DOHC	4WD [4WD Control]	√	√	√	√		0007, 0120
US	SORENTO(XM)	2013	G 3.5 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
US	SORENTO(XM)	2013	G 3.5 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SORENTO(XM)	2013	G 3.5 DOHC	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0088, 0102
US	SORENTO(XM)	2013	G 3.5 DOHC	PIC [Power Distribution Module]	√	√	√	√	√	
US	SORENTO(XM)	2013	G 3.5 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	SORENTO(XM)	2013	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SORENTO(XM)	2012	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0011, 0044, 0094, 0081, 0087, 0098
US	SORENTO(XM)	2012	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SORENTO(XM)	2012	G 2.4 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	SORENTO(XM)	2012	G 2.4 DOHC	AIRBAG [Weight Classification]	√	√	√			
US	SORENTO(XM)	2012	G 2.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
US	SORENTO(XM)	2012	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
US	SORENTO(XM)	2012	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SORENTO(XM)	2012	G 2.4 DOHC	4WD [4WD Control]	√	√	√	√		0007, 0120
US	SORENTO(XM)	2012	G 2.4 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
US	SORENTO(XM)	2012	G 2.4 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SORENTO(XM)	2012	G 2.4 DOHC	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0088, 0102
US	SORENTO(XM)	2012	G 2.4 DOHC	PIC [Smart Key Code Saving]				√		
US	SORENTO(XM)	2012	G 2.4 DOHC	PIC [Power Distribution Module]	√	√	√	√	√	
US	SORENTO(XM)	2012	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	SORENTO(XM)	2012	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022

US	SORENTO(XM)	2012	G 2.4 GDI	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0050, 0087, 0094, 0098, 0126
US	SORENTO(XM)	2012	G 2.4 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SORENTO(XM)	2012	G 2.4 GDI	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	SORENTO(XM)	2012	G 2.4 GDI	AIRBAG [Weight Classification]	√	√	√			
US	SORENTO(XM)	2012	G 2.4 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			
US	SORENTO(XM)	2012	G 2.4 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			
US	SORENTO(XM)	2012	G 2.4 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SORENTO(XM)	2012	G 2.4 GDI	4WD [4WD Control]	√	√	√	√		0007, 0120
US	SORENTO(XM)	2012	G 2.4 GDI	BCM [Instrument Panel Module]	√	√	√	√	√	
US	SORENTO(XM)	2012	G 2.4 GDI	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SORENTO(XM)	2012	G 2.4 GDI	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0088, 0102
US	SORENTO(XM)	2012	G 2.4 GDI	PIC [Smart Key Code Saving]				√		
US	SORENTO(XM)	2012	G 2.4 GDI	PIC [Power Distribution Module]	√	√	√	√	√	
US	SORENTO(XM)	2012	G 2.4 GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	SORENTO(XM)	2012	G 2.4 GDI	CODE [Transmitter Code Saving]				√		0022
US	SORENTO(XM)	2012	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0086, 0094, 0123, 0126
US	SORENTO(XM)	2012	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SORENTO(XM)	2012	G 3.5 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	SORENTO(XM)	2012	G 3.5 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
US	SORENTO(XM)	2012	G 3.5 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
US	SORENTO(XM)	2012	G 3.5 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SORENTO(XM)	2012	G 3.5 DOHC	4WD [4WD Control]	√	√	√	√		0007, 0120
US	SORENTO(XM)	2012	G 3.5 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
US	SORENTO(XM)	2012	G 3.5 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SORENTO(XM)	2012	G 3.5 DOHC	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0088, 0102
US	SORENTO(XM)	2012	G 3.5 DOHC	PIC [Smart Key Code Saving]				√		
US	SORENTO(XM)	2012	G 3.5 DOHC	PIC [Power Distribution Module]	√	√	√	√	√	
US	SORENTO(XM)	2012	G 3.5 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	SORENTO(XM)	2012	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SORENTO(XM)	2011	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0011, 0044, 0094, 0081, 0087, 0098
US	SORENTO(XM)	2011	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SORENTO(XM)	2011	G 2.4 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	SORENTO(XM)	2011	G 2.4 DOHC	AIRBAG [Airbag (ODS)]	√	√	√			
US	SORENTO(XM)	2011	G 2.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
US	SORENTO(XM)	2011	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
US	SORENTO(XM)	2011	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SORENTO(XM)	2011	G 2.4 DOHC	4WD [4WD Control]	√	√	√	√		0007, 0120
US	SORENTO(XM)	2011	G 2.4 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
US	SORENTO(XM)	2011	G 2.4 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SORENTO(XM)	2011	G 2.4 DOHC	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0088, 0102
US	SORENTO(XM)	2011	G 2.4 DOHC	PIC [Smart Key Code Saving]				√		

US	SORENTO(XM)	2011	G 2.4 DOHC	PIC [Power Distribution Module]	√	√	√	√	√	
US	SORENTO(XM)	2011	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	SORENTO(XM)	2011	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SORENTO(XM)	2011	G 3.5 DOHC	AIRBAG [Airbag (ODS)]	√	√	√			
US	SORENTO(XM)	2011	G 3.5 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
US	SORENTO(XM)	2011	G 3.5 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			
US	SORENTO(XM)	2011	G 3.5 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SORENTO(XM)	2011	G 3.5 DOHC	4WD [4WD Control]	√	√	√	√		0007, 0120
US	SORENTO(XM)	2011	G 3.5 DOHC	BCM [Instrument Panel Module]	√	√	√	√	√	
US	SORENTO(XM)	2011	G 3.5 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SORENTO(XM)	2011	G 3.5 DOHC	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0088, 0102
US	SORENTO(XM)	2011	G 3.5 DOHC	PIC [Smart Key Code Saving]				√		
US	SORENTO(XM)	2011	G 3.5 DOHC	PIC [Power Distribution Module]	√	√	√	√	√	
US	SORENTO(XM)	2011	G 3.5 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SORENTO(XM)	2011	G 3.5 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0086, 0094, 0123, 0126
US	SORENTO(XM)	2011	G 3.5 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SORENTO(XM)	2011	G 3.5 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	SOUL(AM)	2012	G 1.6 GDI	ENGINE [Engine Control]	√	√	√	√	√	0044, 0061, 0094, 0126
US	SOUL(AM)	2012	G 1.6 GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SOUL(AM)	2012	G 1.6 GDI	AT [Automatic Transaxle (W / ISG)]	√	√	√	√	√	0099
US	SOUL(AM)	2012	G 1.6 GDI	ESC [Electronic Stability Control]	√	√	√	√	√	0051, 0077
US	SOUL(AM)	2012	G 1.6 GDI	AIRBAG [Airbag (Event #2)]	√	√	√			0090
US	SOUL(AM)	2012	G 1.6 GDI	AIRBAG [Weight Classification]	√	√	√	√		0124
US	SOUL(AM)	2012	G 1.6 GDI	AIRBAG [Airbag (Event #1)]	√	√	√			0090
US	SOUL(AM)	2012	G 1.6 GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SOUL(AM)	2012	G 1.6 GDI	EPS [Motor Driven Power Steering]	√	√	√	√		
US	SOUL(AM)	2012	G 1.6 GDI	BCM [Body Control Module]	√			√	√	
US	SOUL(AM)	2012	G 1.6 GDI	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SOUL(AM)	2012	G 1.6 GDI	PIC [Smart Key Code Saving]				√		
US	SOUL(AM)	2012	G 1.6 GDI	PIC [Power Distribution Module]	√	√	√	√	√	
US	SOUL(AM)	2012	G 1.6 GDI	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0088, 0102, 0117
US	SOUL(AM)	2012	G 1.6 GDI	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SOUL(AM)	2012	G 1.6 GDI	CODE [Transmitter Code Saving]				√		0022
US	SOUL(AM)	2012	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0050, 0087, 0094, 0098, 0126
US	SOUL(AM)	2012	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SOUL(AM)	2012	G 2.0 DOHC	AT [Automatic Transaxle (W / ISG)]	√	√	√	√	√	0099
US	SOUL(AM)	2012	G 2.0 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051, 0077
US	SOUL(AM)	2012	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			0090
US	SOUL(AM)	2012	G 2.0 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	SOUL(AM)	2012	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			0090
US	SOUL(AM)	2012	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SOUL(AM)	2012	G 2.0 DOHC	EPS [Motor Driven Power Steering]	√	√	√	√		

US	SOUL(AM)	2012	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
US	SOUL(AM)	2012	G 2.0 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SOUL(AM)	2012	G 2.0 DOHC	PIC [Smart Key Code Saving]				√		
US	SOUL(AM)	2012	G 2.0 DOHC	PIC [Power Distribution Module]	√	√	√	√	√	
US	SOUL(AM)	2012	G 2.0 DOHC	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0088, 0102, 0117
US	SOUL(AM)	2012	G 2.0 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SOUL(AM)	2011	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0081, 0094, 0098, 0126
US	SOUL(AM)	2011	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SOUL(AM)	2011	G 1.6 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	SOUL(AM)	2011	G 1.6 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	SOUL(AM)	2011	G 1.6 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			0090
US	SOUL(AM)	2011	G 1.6 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			0090
US	SOUL(AM)	2011	G 1.6 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SOUL(AM)	2011	G 1.6 DOHC	EPS [Motor driven Power Steering]	√	√	√	√		
US	SOUL(AM)	2011	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
US	SOUL(AM)	2011	G 1.6 DOHC	PIC [Smart Key Code Saving]				√		
US	SOUL(AM)	2011	G 1.6 DOHC	PIC [Power Distribution Module]	√	√	√	√	√	
US	SOUL(AM)	2011	G 1.6 DOHC	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0088, 0102, 0117
US	SOUL(AM)	2011	G 1.6 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SOUL(AM)	2011	G 1.6 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SOUL(AM)	2011	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0094, 0098, 0126
US	SOUL(AM)	2011	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SOUL(AM)	2011	G 2.0 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	SOUL(AM)	2011	G 2.0 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	SOUL(AM)	2011	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			0090
US	SOUL(AM)	2011	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			0090
US	SOUL(AM)	2011	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SOUL(AM)	2011	G 2.0 DOHC	EPS [Motor driven Power Steering]	√	√	√	√		
US	SOUL(AM)	2011	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
US	SOUL(AM)	2011	G 2.0 DOHC	PIC [Smart Key Code Saving]				√		
US	SOUL(AM)	2011	G 2.0 DOHC	PIC [Power Distribution Module]	√	√	√	√	√	
US	SOUL(AM)	2011	G 2.0 DOHC	PIC [Smart Key Unit]	√	√	√	√	√	0045, 0088, 0102, 0117
US	SOUL(AM)	2011	G 2.0 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SOUL(AM)	2011	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SOUL(AM)	2010	G 1.6 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0081, 0094, 0098, 0126
US	SOUL(AM)	2010	G 1.6 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SOUL(AM)	2010	G 1.6 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	
US	SOUL(AM)	2010	G 1.6 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	SOUL(AM)	2010	G 1.6 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
US	SOUL(AM)	2010	G 1.6 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			0090
US	SOUL(AM)	2010	G 1.6 DOHC	EPS [Motor driven Power Steering]	√	√	√	√		
US	SOUL(AM)	2010	G 1.6 DOHC	BCM [Body Control Module]	√			√	√	
US	SOUL(AM)	2010	G 1.6 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SOUL(AM)	2010	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0094, 0098, 0126

US	SOUL(AM)	2010	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SOUL(AM)	2010	G 2.0 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	
US	SOUL(AM)	2010	G 2.0 DOHC	AIRBAG [Weight Classification]	√	√	√	√		0124
US	SOUL(AM)	2010	G 2.0 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			
US	SOUL(AM)	2010	G 2.0 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			0090
US	SOUL(AM)	2010	G 2.0 DOHC	EPS [Motor driven Power Steering]	√	√	√	√		
US	SOUL(AM)	2010	G 2.0 DOHC	BCM [Body Control Module]	√			√	√	
US	SOUL(AM)	2010	G 2.0 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SOUL(AM)	2010	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SPECTRA(LD)	2009	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0094, 0098, 0126
US	SPECTRA(LD)	2009	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SPECTRA(LD)	2009	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
US	SPECTRA(LD)	2009	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0091
US	SPECTRA(LD)	2009	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SPECTRA(LD)	2009	G 2.0 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SPECTRA(LD)	2008	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0094, 0098, 0126
US	SPECTRA(LD)	2008	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SPECTRA(LD)	2008	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
US	SPECTRA(LD)	2008	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0091
US	SPECTRA(LD)	2008	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SPECTRA(LD)	2008	G 2.0 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SPECTRA(LD)	2007	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0094, 0098, 0126
US	SPECTRA(LD)	2007	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SPECTRA(LD)	2007	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
US	SPECTRA(LD)	2007	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0091
US	SPECTRA(LD)	2007	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SPECTRA(LD)	2007	G 2.0 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SPECTRA(LD)	2006	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0094, 0098
US	SPECTRA(LD)	2006	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SPECTRA(LD)	2006	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
US	SPECTRA(LD)	2006	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0091
US	SPECTRA(LD)	2005	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0094, 0098
US	SPECTRA(LD)	2005	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SPECTRA(LD)	2005	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
US	SPECTRA(LD)	2005	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0091
US	SPECTRA(LD)	2004	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SPECTRA(LD)	2004	G 2.0 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	0051
US	SPECTRA(LD)	2004	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0091
US	SPECTRA(SD)	2004	G 1.8 DOHC	ENGINE [Engine Control]	√	√	√	√		
US	SPECTRA(SD)	2004	G 1.8 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	SPECTRA(SD)	2004	G 1.8 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	
US	SPECTRA(SD)	2003	G 1.8 DOHC	ENGINE [Engine Control]	√	√	√	√		
US	SPECTRA(SD)	2003	G 1.8 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	SPECTRA(SD)	2003	G 1.8 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	
US	SPECTRA(SD)	2002	G 1.8 DOHC	ENGINE [Engine Control]	√	√	√	√		

US	SPECTRA(SD)	2002	G 1.8 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	SPECTRA(SD)	2002	G 1.8 DOHC	ABS [Anti - Lock Brake]		√	√	√	√	
US	SPECTRA(SD)	2001	G 1.8 DOHC	ENGINE [Engine Control]	√	√	√	√		
US	SPECTRA(SD)	2001	G 1.8 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	SPECTRA(SD)	2000	G 1.8 DOHC	ENGINE [Engine Control]	√	√	√	√		
US	SPECTRA(SD)	2000	G 1.8 DOHC	AT [Automatic Transaxle]	√	√	√	√		0095
US	SPORTAGE(AL)	2002	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√		
US	SPORTAGE(AL)	2002	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		0095
US	SPORTAGE(AL)	2002	G 2.0 DOHC	ABS [Anti - Lock Brake System]		√	√	√	√	0051
US	SPORTAGE(AL)	2002	G 2.0 DOHC	AIRBAG [Airbag Control]		√	√			
US	SPORTAGE(AL)	2001	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√		
US	SPORTAGE(AL)	2001	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		0095
US	SPORTAGE(AL)	2001	G 2.0 DOHC	AIRBAG [Airbag Control]		√	√			
US	SPORTAGE(AL)	2000	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√		
US	SPORTAGE(AL)	2000	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		0095
US	SPORTAGE(AL)	2000	G 2.0 DOHC	AIRBAG [Airbag Control]		√	√			
US	SPORTAGE(AL)	1999	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√		
US	SPORTAGE(AL)	1999	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		0095
US	SPORTAGE(AL)	1999	G 2.0 DOHC	AIRBAG [Airbag Control]		√	√			
US	SPORTAGE(AL)	1998	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√		
US	SPORTAGE(AL)	1998	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		0095
US	SPORTAGE(AL)	1998	G 2.0 DOHC	AIRBAG [Airbag Control]		√	√			
US	SPORTAGE(AL)	1997	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√		
US	SPORTAGE(AL)	1997	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		0095
US	SPORTAGE(AL)	1997	G 2.0 DOHC	AIRBAG [Airbag Control]		√	√			
US	SPORTAGE(AL)	1996	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√		
US	SPORTAGE(AL)	1996	G 2.0 DOHC	AT [Automatic Transaxle]		√	√	√		0095
US	SPORTAGE(AL)	1996	G 2.0 DOHC	AIRBAG [Airbag Control]		√	√			
US	SPORTAGE(AL)	1995	G 2.0 DOHC	ENGINE [Engine Control]		√	√	√		
US	SPORTAGE(AL)	1995	G 2.0 DOHC	AIRBAG [Airbag Control]		√	√			
US	SPORTAGE(AL)	1995	G 2.0 SOHC	ENGINE [Engine Control]		√	√	√		
US	SPORTAGE(AL)	1995	G 2.0 SOHC	AT [Automatic Transaxle]		√	√	√		0095
US	SPORTAGE(AL)	1995	G 2.0 SOHC	AIRBAG [Airbag Control]		√	√			
US	SPORTAGE(KM)	2010	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0094, 0044, 0098
US	SPORTAGE(KM)	2010	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SPORTAGE(KM)	2010	G 2.0 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051
US	SPORTAGE(KM)	2010	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0089, 0090
US	SPORTAGE(KM)	2010	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SPORTAGE(KM)	2010	G 2.0 DOHC	4WD [4WD Control]		√	√	√		
US	SPORTAGE(KM)	2010	G 2.0 DOHC	ETACS [ETACS]	√			√	√	
US	SPORTAGE(KM)	2010	G 2.0 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SPORTAGE(KM)	2010	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SPORTAGE(KM)	2010	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0094, 0098
US	SPORTAGE(KM)	2010	G 2.7 DOHC	AT [Automatic Transaxle]		√	√	√	√	0065
US	SPORTAGE(KM)	2010	G 2.7 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	0051

US	SPORTAGE(KM)	2010	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0089, 0090
US	SPORTAGE(KM)	2010	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SPORTAGE(KM)	2010	G 2.7 DOHC	4WD [4WD Control]		√	√	√		
US	SPORTAGE(KM)	2010	G 2.7 DOHC	ETACS [ETACS]	√			√	√	
US	SPORTAGE(KM)	2010	G 2.7 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SPORTAGE(KM)	2010	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SPORTAGE(KM)	2009	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0126, 0044, 0094, 0044, 0098
US	SPORTAGE(KM)	2009	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SPORTAGE(KM)	2009	G 2.0 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	
US	SPORTAGE(KM)	2009	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0089, 0090
US	SPORTAGE(KM)	2009	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SPORTAGE(KM)	2009	G 2.0 DOHC	4WD [4WD Control]		√	√	√		
US	SPORTAGE(KM)	2009	G 2.0 DOHC	ETACS [ETACS]	√			√	√	
US	SPORTAGE(KM)	2009	G 2.0 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SPORTAGE(KM)	2009	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SPORTAGE(KM)	2009	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0094, 0098
US	SPORTAGE(KM)	2009	G 2.7 DOHC	AT [Automatic Transaxle]		√	√	√	√	0065
US	SPORTAGE(KM)	2009	G 2.7 DOHC	ESC [Electronic Stability Control]	√	√	√	√	√	
US	SPORTAGE(KM)	2009	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0089, 0090
US	SPORTAGE(KM)	2009	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SPORTAGE(KM)	2009	G 2.7 DOHC	ETACS [ETACS]	√			√	√	
US	SPORTAGE(KM)	2009	G 2.7 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SPORTAGE(KM)	2009	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SPORTAGE(KM)	2008	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0126, 0126, 0044, 0094, 0044, 0098
US	SPORTAGE(KM)	2008	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SPORTAGE(KM)	2008	G 2.0 DOHC	ABSESC [ABS / ESC (MGH - 40)]	√	√	√	√	√	
US	SPORTAGE(KM)	2008	G 2.0 DOHC	ABSESC [ABS / ESC (MGH - 25)]	√	√	√	√	√	0051
US	SPORTAGE(KM)	2008	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0089, 0090
US	SPORTAGE(KM)	2008	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SPORTAGE(KM)	2008	G 2.0 DOHC	4WD [4WD Control]		√	√	√		
US	SPORTAGE(KM)	2008	G 2.0 DOHC	ETACS [ETACS]	√			√	√	
US	SPORTAGE(KM)	2008	G 2.0 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SPORTAGE(KM)	2008	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SPORTAGE(KM)	2008	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0094, 0098
US	SPORTAGE(KM)	2008	G 2.7 DOHC	AT [Automatic Transaxle]		√	√	√	√	0065
US	SPORTAGE(KM)	2008	G 2.7 DOHC	ABSESC [ABS / ESC (MGH - 40)]	√	√	√	√	√	
US	SPORTAGE(KM)	2008	G 2.7 DOHC	ABSESC [ABS / ESC (MGH - 25)]	√	√	√	√	√	0051
US	SPORTAGE(KM)	2008	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0089, 0090
US	SPORTAGE(KM)	2008	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SPORTAGE(KM)	2008	G 2.7 DOHC	4WD [4WD Control]		√	√	√		
US	SPORTAGE(KM)	2008	G 2.7 DOHC	ETACS [ETACS]	√			√	√	
US	SPORTAGE(KM)	2008	G 2.7 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SPORTAGE(KM)	2008	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022

US	SPORTAGE(KM)	2007	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0044, 0094, 0098, 0126
US	SPORTAGE(KM)	2007	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SPORTAGE(KM)	2007	G 2.0 DOHC	ABS [Anti - Lock Brake System]	√	√	√	√	√	0051
US	SPORTAGE(KM)	2007	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0089, 0090
US	SPORTAGE(KM)	2007	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SPORTAGE(KM)	2007	G 2.0 DOHC	4WD [4WD Control]		√	√	√		
US	SPORTAGE(KM)	2007	G 2.0 DOHC	ETACS [ETACS]	√			√	√	
US	SPORTAGE(KM)	2007	G 2.0 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SPORTAGE(KM)	2007	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SPORTAGE(KM)	2007	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0094, 0098
US	SPORTAGE(KM)	2007	G 2.7 DOHC	AT [Automatic Transaxle]		√	√	√	√	0065
US	SPORTAGE(KM)	2007	G 2.7 DOHC	ABS [Anti - Lock Brake System]	√	√	√	√	√	0051
US	SPORTAGE(KM)	2007	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SPORTAGE(KM)	2007	G 2.7 DOHC	4WD [4WD Control]		√	√	√		
US	SPORTAGE(KM)	2007	G 2.7 DOHC	ETACS [ETACS]	√			√	√	
US	SPORTAGE(KM)	2007	G 2.7 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SPORTAGE(KM)	2007	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SPORTAGE(KM)	2006	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0094, 0098
US	SPORTAGE(KM)	2006	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
US	SPORTAGE(KM)	2006	G 2.0 DOHC	ABS [Anti - Lock Brake System]	√	√	√	√	√	0051
US	SPORTAGE(KM)	2006	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0089, 0090
US	SPORTAGE(KM)	2006	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SPORTAGE(KM)	2006	G 2.0 DOHC	4WD [4WD Control]		√	√			
US	SPORTAGE(KM)	2006	G 2.0 DOHC	ETACS [ETACS]	√			√	√	
US	SPORTAGE(KM)	2006	G 2.0 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SPORTAGE(KM)	2006	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SPORTAGE(KM)	2006	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0094, 0098
US	SPORTAGE(KM)	2006	G 2.7 DOHC	AT [Automatic Transaxle]		√	√	√	√	0065
US	SPORTAGE(KM)	2006	G 2.7 DOHC	ABS [Anti - Lock Brake System]	√	√	√	√	√	0051
US	SPORTAGE(KM)	2006	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0089, 0090
US	SPORTAGE(KM)	2006	G 2.7 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SPORTAGE(KM)	2006	G 2.7 DOHC	4WD [4WD Control]		√	√			
US	SPORTAGE(KM)	2006	G 2.7 DOHC	ETACS [ETACS]	√			√	√	
US	SPORTAGE(KM)	2006	G 2.7 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SPORTAGE(KM)	2006	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SPORTAGE(KM)	2005	G 2.0 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0094, 0098
US	SPORTAGE(KM)	2005	G 2.0 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	
US	SPORTAGE(KM)	2005	G 2.0 DOHC	ABS [Anti - Lock Brake System]	√	√	√	√	√	0051
US	SPORTAGE(KM)	2005	G 2.0 DOHC	AIRBAG [Airbag Control]	√	√	√			0089, 0090
US	SPORTAGE(KM)	2005	G 2.0 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SPORTAGE(KM)	2005	G 2.0 DOHC	4WD [4WD Control]		√	√			
US	SPORTAGE(KM)	2005	G 2.0 DOHC	ETACS [ETACS]	√			√	√	
US	SPORTAGE(KM)	2005	G 2.0 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SPORTAGE(KM)	2005	G 2.0 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SPORTAGE(KM)	2005	G 2.7 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0094, 0098

US	SPORTAGE(KM)	2005	G 2.7 DOHC	AT [Automatic Transaxle]		√	√	√	√	0065
US	SPORTAGE(KM)	2005	G 2.7 DOHC	ABS [Anti - Lock Brake System]	√	√	√	√	√	0051
US	SPORTAGE(KM)	2005	G 2.7 DOHC	AIRBAG [Airbag Control]	√	√	√			0089, 0090
US	SPORTAGE(KM)	2005	G 2.7 DOHC	4WD [4WD Control]		√	√			
US	SPORTAGE(KM)	2005	G 2.7 DOHC	ETACS [ETACS]	√			√	√	
US	SPORTAGE(KM)	2005	G 2.7 DOHC	TPMS [Tire Pressure Monitoring System]	√	√	√		√	
US	SPORTAGE(KM)	2005	G 2.7 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SPORTAGE(SL)	2012	G 2.0 T-GDI	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0094, 0098, 0126
US	SPORTAGE(SL)	2012	G 2.0 T-GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SPORTAGE(SL)	2012	G 2.0 T-GDI	ABSESC [Electronic Stability Control]	√	√	√	√	√	0051, 0077
US	SPORTAGE(SL)	2012	G 2.0 T-GDI	AIRBAG [Airbag (Event #2)]	√	√	√			0089
US	SPORTAGE(SL)	2012	G 2.0 T-GDI	AIRBAG [Airbag (Event #1)]	√	√	√			0089
US	SPORTAGE(SL)	2012	G 2.0 T-GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SPORTAGE(SL)	2012	G 2.0 T-GDI	EPS [Power Steering]	√	√	√	√		
US	SPORTAGE(SL)	2012	G 2.0 T-GDI	4WD [4WD Control]	√	√	√	√	√	0019, 0020
US	SPORTAGE(SL)	2012	G 2.0 T-GDI	BCM [Smart Junction Box]	√	√	√	√	√	
US	SPORTAGE(SL)	2012	G 2.0 T-GDI	BCM [Body Control Module]	√	√	√	√	√	
US	SPORTAGE(SL)	2012	G 2.0 T-GDI	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SPORTAGE(SL)	2012	G 2.0 T-GDI	PIC [Smart Key Unit]	√	√	√	√	√	0023, 0045, 0102
US	SPORTAGE(SL)	2012	G 2.0 T-GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	SPORTAGE(SL)	2012	G 2.0 T-GDI	CODE [Transmitter Code Saving]				√		0022
US	SPORTAGE(SL)	2012	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0087, 0094, 0098, 0126
US	SPORTAGE(SL)	2012	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SPORTAGE(SL)	2012	G 2.4 DOHC	ABSESC [Electronic Stability Control]	√	√	√	√	√	0051, 0077
US	SPORTAGE(SL)	2012	G 2.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			0089
US	SPORTAGE(SL)	2012	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			0089
US	SPORTAGE(SL)	2012	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SPORTAGE(SL)	2012	G 2.4 DOHC	EPS [Power Steering]	√	√	√	√		
US	SPORTAGE(SL)	2012	G 2.4 DOHC	4WD [4WD Control]	√	√	√	√	√	0019, 0020
US	SPORTAGE(SL)	2012	G 2.4 DOHC	BCM [Smart Junction Box]	√	√	√	√	√	
US	SPORTAGE(SL)	2012	G 2.4 DOHC	BCM [Body Control Module]	√	√	√	√	√	
US	SPORTAGE(SL)	2012	G 2.4 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SPORTAGE(SL)	2012	G 2.4 DOHC	PIC [Smart Key Unit]	√	√	√	√	√	0023, 0045, 0102
US	SPORTAGE(SL)	2012	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	SPORTAGE(SL)	2012	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022
US	SPORTAGE(SL)	2011	G 2.0 T-GDI	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0094, 0098, 0126
US	SPORTAGE(SL)	2011	G 2.0 T-GDI	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SPORTAGE(SL)	2011	G 2.0 T-GDI	AIRBAG [Airbag (Event #2)]	√	√	√			0089
US	SPORTAGE(SL)	2011	G 2.0 T-GDI	AIRBAG [Airbag (Event #1)]	√	√	√			0089
US	SPORTAGE(SL)	2011	G 2.0 T-GDI	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SPORTAGE(SL)	2011	G 2.0 T-GDI	EPS [Power Steering]	√	√	√	√		
US	SPORTAGE(SL)	2011	G 2.0 T-GDI	4WD [4WD Control]	√	√	√	√	√	0019, 0020

US	SPORTAGE(SL)	2011	G 2.0 T-GDI	BCM [Smart Junction Box]	√	√	√	√	√	
US	SPORTAGE(SL)	2011	G 2.0 T-GDI	BCM [Body Control Module]	√	√	√	√	√	
US	SPORTAGE(SL)	2011	G 2.0 T-GDI	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SPORTAGE(SL)	2011	G 2.0 T-GDI	PIC [Smart Key Unit]	√	√	√	√	√	0023, 0045, 0102
US	SPORTAGE(SL)	2011	G 2.0 T-GDI	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	SPORTAGE(SL)	2011	G 2.0 T-GDI	CODE [Transmitter Code Saving]				√		0022
US	SPORTAGE(SL)	2011	G 2.4 DOHC	ENGINE [Engine Control]	√	√	√	√	√	0011, 0044, 0087, 0094, 0098, 0126
US	SPORTAGE(SL)	2011	G 2.4 DOHC	AT [Automatic Transaxle]	√	√	√	√	√	0099
US	SPORTAGE(SL)	2011	G 2.4 DOHC	ABSESC [Electronic Stability Control]	√	√	√	√	√	0051, 0077
US	SPORTAGE(SL)	2011	G 2.4 DOHC	AIRBAG [Airbag (Event #2)]	√	√	√			0089
US	SPORTAGE(SL)	2011	G 2.4 DOHC	AIRBAG [Airbag (Event #1)]	√	√	√			0089
US	SPORTAGE(SL)	2011	G 2.4 DOHC	AIRCON [Air Conditioner]	√	√	√	√	√	
US	SPORTAGE(SL)	2011	G 2.4 DOHC	EPS [Power Steering]	√	√	√	√		
US	SPORTAGE(SL)	2011	G 2.4 DOHC	4WD [4WD Control]	√	√	√	√	√	0019, 0020
US	SPORTAGE(SL)	2011	G 2.4 DOHC	BCM [Smart Junction Box]	√	√	√	√	√	
US	SPORTAGE(SL)	2011	G 2.4 DOHC	BCM [Body Control Module]	√	√	√	√	√	
US	SPORTAGE(SL)	2011	G 2.4 DOHC	IMMO [Immobilizer]				√		0075, 0075, 0083, 0092, 0112, 0119
US	SPORTAGE(SL)	2011	G 2.4 DOHC	PIC [Smart Key Unit]	√	√	√	√	√	0023, 0045, 0102
US	SPORTAGE(SL)	2011	G 2.4 DOHC	TPMS [Tire Pressure Monitoring]	√	√	√		√	
US	SPORTAGE(SL)	2011	G 2.4 DOHC	CODE [Transmitter Code Saving]				√		0022

Special Function Table

0001	ABD / ASR Pressure Increase
0002	AIR FILLING SETUP
0003	AMP Operation Test
0004	ASP Calibration
0005	AT Adaptation Mode
0006	AVM Calibration
0008	Air Bleeding Mode
0009	Air Bleeding of Low Pressure Hose
0010	Assembly Check (ECU replacement)
0011	Auto Detected Configuration Reset
0012	BSD Radar Calibration
0013	Break Pad Change Mode
0014	CLEAR CAN Learnable Status
0015	Calibration
0016	Camera image correction function
0017	Cancel Factory Mode
0018	Checking the wear amount of clutch
0019	Clutch Learning Read

0020	Clutch Learning Reset
0021	Clutch compensation value setting
0022	Code Saving
0023	Current FOB Key Check
0024	DCT Learning Function
0025	DPF Service Regeneration
0026	E / C Fluid Pressure Cal.
0027	ECM Neutralization
0028	ECU Initialization
0029	ECU Tuning Data Confirm
0030	EOP (Electric Oil Pump) Test
0031	EPB Variant Coding
0032	EPS Type Recognition
0033	ERM (Engine RPM Monitoring)
0034	ESCL ENABLE OUTPUT CHECK
0035	ESCL OPEN STATUS CHECK
0036	ESCL STATUS INFORMATION
0037	Electric Water Pump Control
0038	Engine Clutch / Motor Resolver Adaptation
0039	Engine Test Off
0040	Engine Test On
0041	Erase Network Configuration
0042	Evap Leak Test [HEV]
0043	Evap. Leakage Test
0044	Evap. Leakage Test
0045	FOB KEY STATUS INFORMATION
0046	Fluid Circulation Mode
0048	Fuel line air removal
0049	G - Sensor Calibration
0050	GDI FUEL LEAK TEST
0051	HCU Air Bleeding Mode
0052	HEIGHT SENSOR CALIBRATION
0053	HPCU (MCU / GCU) self - diagnosis function
0054	Halt System Control
0055	Headlamp Levelling
0056	Height Sensor De - Calibration
0057	Height Sensor Mount Angle
0058	Height sensor Calibration (Reset)
0059	High Pressure Release Mode
0060	ISG (Idle Stop and Go) System Check
0061	ISG TEST (Option)
0062	Idle CO Adjustment
0063	Idle RPM Adjust Mode
0064	Immobilizer Reset
0065	Init Of TCU Learning

0066	Initialization of the engine clutch inspection line learning and diagnostic information
0067	Injector Specific Data
0068	Inline Bleeding
0069	LDC Activation Test
0070	LDWS Reference Point Calibration
0071	LDWS Region Code
0072	LEARNT KEYS
0073	Learning after replacing the turbocharger actuator
0074	Level Initialization
0075	Limp Home Mode
0076	Limp Home Mode
0077	Longitudinal G Sensor Calibration
0078	Longitudinal G Sensor Calibration (HAC / DBC Only)
0079	Master Key Delete
0080	Master Key Record / Change
0081	Monitoring Test Results
0082	Motor / HSG Resolver Calibration
0083	Neutral Mode
0084	PAD Change Mode (After Change)
0085	PAD Change Mode (Before Change)
0086	PCM Auto Detection Reset
0088	PDM STATUS INFORMATION
0089	PODS Reset
0090	Pass.Airbag Realtime Info.
0091	Passenger A / Bag Info.
0092	Password Teaching / Changing
0093	Power Tailgate Mode Configuration
0094	Read VIN
0095	Readiness Test
0096	Register Transmitter
0097	Removal of air from engine clutch hydraulic pressure line
0098	Resetting Adaptive Values
0099	Resetting Auto T / A Values
0100	Resetting E - CVVT Values
0101	Ring Break
0102	SMK STATUS INFORMATION
0103	SOC Calibration
0104	SPTAC Calibration
0105	STPS Status
0106	Seat Limit Position Setting
0107	Sensor Initialization
0108	Serial Communication Line Check
0109	Siren System Identification (Only EUROPE RHD)
0110	Siren System Identification (Only UK)
0111	Smart Key Code Saving

0112	Smatra Neutral Mode
0113	Stabilization of the engine clutch hardware transfer torque
0114	Steering Limit Position Setting
0115	System Initialization
0116	TCU Sub Rom Reset
0117	TP STATUS INFORMATION
0118	TPS Circuit Test
0119	Teaching
0120	Torque Coupling Control
0121	UIP System Identification (Only EUROPE RHD)
0122	UIP System Identification (Only UK)
0123	VCM Learning
0124	WCS Reset
0125	Wiper Setting Position Calibration Mode
0126	Write VIN

